

Troubleshooting Error Codes

Error 0: Power loss occurred. The units can be damaged if they lose power while running. Shutdown before turning off power when possible.

Error 100: User selected shutdown

Error 107: Power Source. Potentially a blown fuse.

Error 109: Circuit Board Failure

Error 111: CO₂ low pressure Alarm

Error 113: CO₂ holding tank High Level Alarm

Error 201: Preheat WPA before starting

Error 214: Potable H₂O holding tank High Level Alarm

Error 308: SRA requires N₂ purge before startup

Error 313: CO₂ holding tank Low Level Alarm

Error 414: Potable H₂O holding tank Low Level Alarm

Error 534: H₂ gas unavailable. Check that OGA is running.

Error 543: SRA not running. H₂ vent to atmosphere unavailable therefore SRA and OGA must both be running at the same rate in order for the H₂ gas to be safely consumed.

Error 900: Override from Mission Control system