

- 3 Press  to select **CONFIGURE DEVICE**.
- 4 Press  to highlight **RESETS**.
- 5 Press  to select **RESETS**.
- 6 Press  to highlight **RESET SUPPLIES**.
- 7 Press  to select **RESET SUPPLIES**.
- 8 Press  to highlight **NEW TRANSFER KIT**.
- 9 Press  to select **NEW TRANSFER KIT**.
- 10 Press  to highlight **YES**.
- 11 Press  to reset the transfer unit count.

Replacing the fuser

Replace the fuser when a **REPLACE FUSER KIT** message appears on the control-panel display.




NOTE If you replace the fuser when it is not at the end of life (for example, if it is defective) you will need to calibrate the printer and reset the fuser count through the control panel. See [Replacing the fuser when it is not at end of life](#).

- 1 Turn the printer off.
- 2 Use the side handles to open the top cover.




WARNING! The fuser might be hot. Wait 10 minutes before proceeding.

- 3 Completely loosen the blue thumb screws on each side of the fuser.




- 4 Grasp the ends and pull straight up to remove the fuser.




- 5 Remove the new fuser from the bag. Place the used fuser in the bag for recycling. See the enclosed recycling guide for recycling instructions.


- 6 Grasp the sides of the fuser and push down firmly into the printer.



- 7 Tighten the blue thumb screws.



- 8 Close the top cover, and turn the printer on. After a short while, a **NEW FUSER KIT=** message appears on the control-panel display.












- 9 Press  to highlight **YES**.

- 10 Press  to reset the fuser count.


Replacing the fuser when it is not at end of life

If you replace the fuser when it is not at the end of its life (for example, if it is defective) you will need to reset the fuser count through the control panel.


Use the following steps to reset the fuser count:

- 1 Press  (HP Color LaserJet 4600 models) or **MENU** (HP Color LaserJet 4610n and 4650 printer) to open the **MENUS**.
- 2 Press  to highlight **CONFIGURE DEVICE**.
- 3 Press  to select **CONFIGURE DEVICE**.
- 4 Press  to highlight **RESETS**.
- 5 Press  to select **RESETS**.
- 6 Press  to highlight **RESET SUPPLIES**.
- 7 Press  to select **RESET SUPPLIES**.
- 8 Press  to highlight **NEW FUSER KIT**.
- 9 Press  to select **NEW FUSER KIT**.
- 10 Press  to highlight **YES**.
- 11 Press  to reset the fuser count.

- 6 Remove the inside sealing tape by pulling the orange loop on the end and pulling the tape completely out. Discard the tape.



- 7 Grasp the blue handles on the sides of the print cartridge. Align the print cartridge with the tracks inside the printer and insert the cartridge until it is completely seated.



- 8 Installation is complete. Place the used print cartridge in the box in which the new cartridge arrived. See the enclosed recycling guide for recycling instructions.

Replacing the transfer unit


Replace the transfer unit when a **REPLACE TRANSFER KIT** message appears on the control-panel display.




NOTE If you replace the transfer unit when it is not at the end of life (for example, if it is defective) you will need to calibrate the printer and reset the transfer unit count through the control panel. See [Replacing the transfer unit when it is not at end of life](#).

- 1 Turn the printer off.
- 2 Use the side handles to open the top cover.


- 3** Grasp the green handle on the transfer unit and pull it down. The front cover opens as you pull down the transfer unit.



- 4** Locate the blue release buttons on each side of the transfer unit (near the bottom of the transfer unit).






- 5** Grasp the transfer unit with two hands. Simultaneously press both of the blue buttons and slide the transfer unit out of the printer.



- 6** Remove the new transfer unit from the bag. Place the used transfer unit in the bag for recycling. See the enclosed recycling guide for recycling instructions.

- 7 Hold the transfer unit on either side. Guide the feet into the cups and slide the transfer unit into the printer.










- 8 Close the transfer unit and front cover. Close the top cover and turn the printer on. After a short while a **NEW TRANSFER KIT=** message appears on the control-panel display.
- 9 Press  to highlight **YES**.
- 10 Press  to reset the transfer unit count.
- 11 Wait for the printer to calibrate.



Replacing the transfer unit when it is not at end of life

If you replace the transfer unit when it is not at the end of life (for example, if it is defective) you will need to calibrate the printer and reset the transfer unit count through the control panel.

Use the following steps to calibrate the printer:

- 1 Press  (HP Color LaserJet 4600 models) or **MENU** (HP Color LaserJet 4610n and 4650 models) to open the **MENUS**.
- 2 Press  to highlight **CONFIGURE DEVICE**.
- 3 Press  to select **CONFIGURE DEVICE**.
- 4 Press  to highlight **PRINT QUALITY**.
- 5 Press  to select **PRINT QUALITY**.
- 6 Press  to highlight **CALIBRATE NOW** (HP Color LaserJet 4600 models) or **FULL CALIBRATE NOW** (HP Color LaserJet 4610n and 4650 models).
- 7 Press  to select **CALIBRATE NOW** (HP Color LaserJet 4600 models) or **FULL CALIBRATE NOW** (HP Color LaserJet 4610n and 4650 models).
- 8 Wait for the printer to calibrate.

Use the following steps to reset the transfer unit count:

- 1 Press  (HP Color LaserJet 4600) or **MENU** (HP Color LaserJet 4610n and 4650 models) to open the **MENUS**.
- 2 Press  to highlight **CONFIGURE DEVICE**.

- 3 Press  to select **CONFIGURE DEVICE**.
- 4 Press  to highlight **RESETS**.
- 5 Press  to select **RESETS**.
- 6 Press  to highlight **RESET SUPPLIES**.
- 7 Press  to select **RESET SUPPLIES**.
- 8 Press  to highlight **NEW TRANSFER KIT**.
- 9 Press  to select **NEW TRANSFER KIT**.
- 10 Press  to highlight **YES**.
- 11 Press  to reset the transfer unit count.

Replacing the fuser

Replace the fuser when a **REPLACE FUSER KIT** message appears on the control-panel display.



NOTE If you replace the fuser when it is not at the end of life (for example, if it is defective) you will need to calibrate the printer and reset the fuser count through the control panel. See [Replacing the fuser when it is not at end of life](#).

- 1 Turn the printer off.
- 2 Use the side handles to open the top cover.



WARNING! The fuser might be hot. Wait 10 minutes before proceeding.

- 3 Completely loosen the blue thumb screws on each side of the fuser.

