



~ This assembly contains an electronic maintenance reset.

~ The printer MUST be powered OFF for the reset to work correctly.

~ Do not replace any two components at the same time containing electronic resets.  
(The printer may only reset one component)

~ If two or more components are to be replaced, be sure to cycle power (turn off/on) with each component being replaced.

*\*Warning\**

*Failure to install the new component using the above steps may prematurely trip the electronic maintenance reset, prevent the reset of the printer maintenance count, and may void the part warranty.*

<b>Model</b>	<b>Component</b>
CLJ 4700	RM1-3161/Q7504A
CP4005	RM1-3131/Q7502A
CLJ 4730MFP	" "
CM4730MFP	" "
CP4025	CE249A/RM1-5575
CP4525	CC493-67911/CE246A/RM1-5550
CM4540MFP	" "
M651	" "
M680MFP	" "
M806	CF367-67928
M830MFP	C2H67-67901
M855	C1N54-67901/RM2-5012
M880MFP	" "