

Instrument Cluster Multi-Pin Connector Assignments, from MY 2000




Note

Pin assignments dependent on available/optional equipment present and applicable engine versions.

Multi-Pin Connector, 32 Pin, Blue, T32

- 1 - Terminal 15, positive
- 2 - Indicator lamp for right turn signal
- 3 - Output signal 1 from electronic speedometer
- 4 - Indicator lamp for towing operation
- 5 - Fuel gauge
- 6 - Airbag (connected to ground in vehicles without airbag)
- 7 - Terminal 31, sensor ground
- 8 - Engine coolant temperature (ECT) gauge
- 9 - Terminal 31, ground
- 10 - Oil pressure switch
- 11 - not in use
- 12 - Generator indicator lamp, Terminal 61
- 13 - Indicator lamp for seat back release (only certain countries)
- 14 - Indicator lamp for fog lights
- 15 - not in use
- 16 - Indicator lamp for open tailgate (only certain countries)
- 17 - Indicator lamp for high-beam headlamp, terminal 56a
- 18 - Indicator lamp for left turn signal
- 19 - Anti-lock braking system (ABS)
- 20 - Lighting for instrument panel insert, terminal 58b
- 21 - Signal for open driver's door
- 22 - Low coolant indicator
- 23 - Terminal 30, positive
- 24 - Terminal 31, ground
- 25 - On-board diagnostics/ K line
- 26 - Right parking light, signal for light warning buzzer
- 27 - Left parking light, signal for light warning buzzer
- 28 - Input signal to electronic speedometer



- 29 - Indicator lamp for braking system
- 30 - S contact
- 31 - Safety belt warning system
- 32 - not in use

Multi-Pin Connector, 32 Pin, Green T32a

- 1 - not in use
- 2 - Induction coil for immobilizer 1
- 3 - Indicator lamp for parking light
- 4 - Data-BUS (CAN), Shielding for input signal
- 5 - W line
- 6 - Low washer fluid level
- 7 - Brake lining wear
- 8 - not in use
- 9 - not in use
- 10 - not in use
- 11 - Signal for vehicle service
- 12 - Climate control switched off
- 13 - Indicator lamp for parking brake
- 14 - Automatic traction control (ASR), vehicle stabilization
- 15 - not in use
- 16 - not in use
- 17 - Induction coil for immobilizer 2
- 18 - Signal for oil temperature and oil level warning
- 19 - Data-BUS (CAN), High input signal
- 20 - Data-BUS (CAN), Low input signal
- 21 - not in use
- 22 - Input signal for hood switch
- 23 - Recall button for MFA - top, (the display switches backward)
- 24 - Recall button for MFA - bottom, (the display switches forward)
- 25 - Memory switch for MFA - Reset
- 26 - Input signal for outside temperature
- 27 - Data-BUS (CAN), High output signal
- 28 - Data-BUS (CAN), Low output signal
- 29 - not in use
- 30 - clock
- 31 - Data
- 32 - enable

