


Multi-function steering wheel for cruise control and radio

from May 2000

Deviate relay location and fuse placements as well as the locations of multiple connectors see section "component locations".



97-14163

Relay location on the thirteenfold auxiliary relay panel, above relay panel:

- 5** Control module for multi-function steering wheel (450)
- 6**


Relay panel:

- 2** Load Reduction Relay (100)
- 4** Fuel Pump (FP) Relay (409)

Note: Number in parentheses indicates production control number stamped on relay housing.

Fuse colors


- 30 A - green
- 25 A - white
- 20 A - yellow
- 15 A - blue
- 10 A - red
- 7,5 A - brown
- 5 A - beige
- 3 A - violet



- D - Ignition/Starter Switch
E221 - Control unit in steering wheel
F138 - Airbag Spiral Spring/Return Spring with Slip Ring
H - Signal horn activation
J234 - Airbag Control Module
L45 - Operating Unit Light
N95 - Driver's Side Airbag Igniter
S5 - Fuse 5 in fuse holder
S240 - Fuse 40 in fuse holder
T5b - 5-Pin Connector, on airbag spiral spring
T5j - 5-Pin Connector, behind driver's airbag
T75 - 75-Pin Connector

- 42 - Ground connection, beside steering column

- 49 - Ground connection, on steering column
81 - Ground connection -1-, in instrument panel wiring harness
135 - Ground connection -2-, in instrument panel wiring harness
501 - Threaded connection -2- (30) on the relay plate
A2 - Plus connection (15), in instrument panel wiring harness
A20 - Wire connection (15a), in instrument panel wiring harness
A32 - Plus connection (30), in instrument panel wiring harness




- D - Ignition/Starter Switch
J4 - Horn Relay
J59 - Load Reduction Relay
J453 - Control module for multi-function steering wheel
J533 - Data Bus On Board Diagnostic Interface
R - Radio
T16 - Data Link Connector (DLC), below instrument panel, left
T18c - 18-Pin Connector
T20 - 20-Pin Connector, on Radio
T32a - 32-Pin Connector, green

- 81 - Ground connection -1-, in instrument panel wiring harness

- A32 - Plus connection (30), in instrument panel wiring harness
A76 - Connector (K-diagnosis wire) in instrument panel wiring harness
A80 - Connector -1- (X) in instrument panel wiring harness
A98 - Plus connector -4- (30), in instrument panel wiring harness
B229 - Connection (High-Bus) (interior wiring harness)
B230 - Connection (Low-Bus) (interior wiring harness)

** - Beginning August 2001

--- - Through July 2001



E20 - Instrument Panel Light Dimmer Switch

E45 - Cruise Control Switch

H1 - Dual tone horn

J453 - Control module for multi-function steering wheel

J... - Engine Control Module (ECM)

T3c - 3-Pin Connector

T10e - 10-Pin Connector, black, in protective housing for connectors, in plenum chamber, left*

T10s - 10-Pin Connector, near steering column

T18c - 18-Pin Connector

(12) - Ground connection, in engine compartment, left

(120) - Ground connection -2-, in headlight wiring harness

(A4) - Plus connection (58b), in instrument panel wiring harness

(A16) - Wire connection (cruise control), in instrument panel wiring harness

(A20) - Wire connection (15a), in instrument panel wiring harness

(A90) - Connector (two-tone horn), in instrument panel wiring harness

* - See also wiring diagram cruise control/ motor