



**Connector station in protective housing, in plenum chamber left (Model Year 2000 and later)**

Pos.	Color of Connector	Function
1	blue	Kick down switch, closed throttle position (CTP) switch, throttle position (TP) sensor, leak detection pump (LDP), angle sensors for throttle drive (power acceleration actuation)
2	brown	Starter, power supply for engine control module (ECM), fuel pump (FP) relay
3	orange	Instrument cluster, back-up lights, anti-theft immobilizer/data link connection, air conditioning
4	black	Cruise control
5	white	Generator (GEN), Data Link Connection (DLC) (low and high bus), Cruise control
6	grey	Automatic transmission