

[Support Package]

ID	TS-00110	Created	Mar. 23, 2006
		Updated	Aug. 14, 2007
Category	System Integration	Sub Category	ISV Software
Product			
Purpose	How to test RTP protocol with ACTi devices?		
Support URL	http://www.acti.com/support		
Tech Support	Customer.service@acti.com		
MSN Messenger ID	Customer.service@acti.com		

How to test RTP protocol with ACTi devices?

Table of Contents

How to test RTP protocol with ACTi devices?	2
Setup Firmware	5
Step 1: You need to have “TCP v2.0”-compliant devices	5
Step 2: Setup RTP Mode in firmware	6
How to configure RTP over TCP	8
How to setup Transcoder over RTP.....	9
Test with Apple QuickTime Player	10
Step 1: Download it from Apple web site	10
Step 2: Click on File -> Open URL	10
Step 3: Enter URL with rtsp://<IP Address>	11
Step 4: Apple QuickTime Player plays video from ACTi device.....	11
Test with VideoLan VLC Player	12
Step 1: Download it from VideoLan web site	12
Step 2: Click on File -> Open Network Stream	12
Step 3: Enter MRL with rtsp://<IP Address>:7070	13
Step 4: Minimize the video latency in VLC Player.....	13
Step 5: VLC Player plays video from ACTi device	14
ACTi MPEG-4 and RTP/RTSP Spec.	15
Step 1: Contact ACTi Sales representative.....	15

[Support Package]

RTP supported mapping table


Client Server	VLC 0.8.5	Quick Time	Media Player	NVR2.0	Activator 1.4 3.0	Trancoder SED-33xx ACD-3100
MPL	YES	YES	N/A	N/A	N/A	YES
EPL	YES	N/A	N/A	N/A	N/A	YES
NVR2.0	N/A					

	MPL	EPL	NVR2.0
RTP over UDP	YES	YES	N/A
RTP over TCP	YES	N/A	N/A

MPL includes SED-21xx, SED-231xQ, SED-24xx, SED-2610, CAM-52xx, CAM-53xx, CAM-65xx, CAM-66xx, CAM-72xx, CAM-73xx

EPL includes ACM-11xx, ACM-1311, ACM-143x, ACM-31xx, ACM-3211, ACM-3311, ACD-2100, ACD-2200,

[Support Package]



IMPORTANT: When receiving video stream with RTP via Router, you have to enable RTP over TCP in VLC. Currently, it only works with MPL cameras.




IMPORTANT: Currently, all ACTi cameras and video server only support one way audio with RTP; currently, two way audio is not supported over RTP.

[Support Package]

Setup Firmware

Step 1: You need to have “TCP v2.0”-compliant devices

1. Check firmware version, and see if your firmware is **v2.0** or **v3.0** series




IMPORTANT: Note that after firmware v2.04, RTSP will need account/password authentication

[Support Package]


Step 2: Setup RTP Mode in firmware

1. Check on Video Setting, select **Version 2.0**



[Support Package]


2. Choose RTP over UDP



[Support Package]

How to configure RTP over TCP

When you want to see video stream through firewall/router, generally, firewall/router block UDP packets by default, so in this case, RTP over TCP is the only way to see video stream through firewall/router. However, all EPL products do not support this function currently.



IMPORTANT: When using EPL cameras, please **don't** enable Use RTP over RTSP(TCP), otherwise, you would not be able to see video stream.

[Support Package]

How to setup Transcoder over RTP

Connection Setting

Source Type: Video Server

Connect Type: RTP

Variable FPS: Use Server's Setting

TCP Connect IP: 172.16.52.134

Multicast Connect IP: 228 . 5 . 6 . 1
(224.3.1.0 ~ 239.255.255.255)

Connect User Name: Admin

Connect Password:

Enable A/V STREAM: On

Enable Control Data: On

Dwell Time: 0

Stream Port: 6002

Control Port: 6001

Multicast Port: 5000

RTP Port: 7070

HTTP Port: 80

Apply Reset

Please select connect type as RTP

Please enable the control data function in Transcoder's Web Configurator then user can control PTZ with control panel over RTP


[Support Package]

Test with Apple QuickTime Player

Step 1: Download it from Apple web site



<http://www.apple.com/quicktime/download/win.html>

Step 2: Click on File -> Open URL




[Support Package]

Step 3: Enter URL with rtsp://<IP Address>



Step 4: Apple QuickTime Player plays video from ACTi device




[Support Package]

Test with VideoLan VLC Player

Step 1: Download it from VideoLan web site


<http://www.videolan.org/vlc/download-windows.html>

Step 2: Click on File -> Open Network Stream



[Support Package]

Step 3: Enter MRL with rtsp://<IP Address>:7070




IMPORTANT: Note that after firmware v2.04, RTSP will need account/password authentication. Please enter following command instead:
rtsp: //Admi n: 123456@192. 168. 1. 107: 7070

Step 4: Minimize the video latency in VLC Player

Please check “**Caching**” and set the value to **80**. The video latency via RTP/RTSP will be minimized without sacraficing video quality.

[Support Package]

Step 5: VLC Player plays video from ACTi device



[Support Package]

ACTi MPEG-4 and RTP/RTSP Spec.

Step 1: Contact ACTi Sales representative

1. To obtain the detailed specification of MPEG-4 and RTP/RTSP specification, you need to contact ACTi Sales representative first, sign the NDA, then you will receive the detailed specification.
2. If you do not know any ACTi Sales representative, please contact sales@acti.com