

[Support Package]

ID	TS-00110	Created	Mar. 23, 2006
		Updated	Jun. 7, 2006
Category	System Integration	Sub Category	ISV Software
Product			
Purpose	How to test RTP protocol with ACTi devices?		
Support URL	http://www.acti.com/support		
Tech Support	Customer.service@acti.com		
MSN Messenger ID	Customer.service@acti.com		

How to test RTP protocol with ACTi devices?

Table of Contents


How to test RTP protocol with ACTi devices?	2
Setup Firmware	3
Step 1: You need to have “TCP v2.0”-compliant devices	3
Step 2: Setup RTP Mode in firmware	4
Test with Apple QuickTime Player	6
Step 1: Download it from Apple web site	6
Step 2: Click on File -> Open URL	6
Step 3: Enter URL with rtsp://<IP Address>	7
Step 4: Apple QuickTime Player plays video from ACTi device.....	7
Test with VideoLan VLC Player	8
Step 1: Download it from VideoLan web site	8
Step 2: Click on File -> Open Network Stream	8
Step 3: Enter MRL with rtsp://<IP Address>:7070	9
Step 4: VLC Player plays video from ACTi device	10
ACTi MPEG-4 and RTP/RTSP Spec.	11
Step 1: Contact ACTi Sales representative.....	11

[Support Package]

Setup Firmware

Step 1: You need to have “TCP v2.0”-compliant devices

1. Check firmware version, and see if your firmware is **v2.0** series




IMPORTANT: Note that after firmware v2.04, RTSP will need account/password authentication

[Support Package]


Step 2: Setup RTP Mode in firmware

1. Check on Video Setting, select **Version 2.0**



[Support Package]

2. Choose RTP over UDP



[Support Package]

Test with Apple QuickTime Player

Step 1: Download it from Apple web site


<http://www.apple.com/quicktime/download/win.html>

Step 2: Click on File -> Open URL




[Support Package]

Step 3: Enter URL with rtsp://<IP Address>



IMPORTANT: Note that after firmware v2.04, RTSP will need account/password authentication. Please enter following command instead:
rtsp: //Admin: 123456@192. 168. 1. 107

Step 4: Apple QuickTime Player plays video from ACTi device




Test with VideoLan VLC Player

Step 1: Download it from VideoLan web site


<http://www.videolan.org/vlc/download-windows.html>

Step 2: Click on File -> Open Network Stream



[Support Package]

Step 3: Enter MRL with rtsp://<IP Address>:7070




IMPORTANT: Note that after firmware v2.04, RTSP will need account/password authentication. Please enter following command instead:
`rtsp: //Admi n: 123456@192. 168. 1. 107: 7070`

Step 3: Minimize the video latency in VLC Player

Please check “**Caching**” and set the value to **80**. The video latency via RTP/RTSP will be minimized without sacrificing video quality.

[Support Package]

Step 4: VLC Player plays video from ACTi device



[Support Package]

ACTi MPEG-4 and RTP/RTSP Spec.

Step 1: Contact ACTi Sales representative

1. To obtain the detailed specification of MPEG-4 and RTP/RTSP specification, you need to contact ACTi Sales representative first, sign the NDA, then you will receive the detailed specification.
2. If you do not know any ACTi Sales representative, please contact sales@acti.com