

WSM

WORKSHOP MANUAL
TRACTOR, FRONT LOADER,
BACKHOE, ROTARY MOWER

BX23S, LA340, BT603,
RCK54D, RCK60D,
RCK54, RCK60B

Kubota

TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of *BX23S*. It contains 4 parts: "Information", "General", "Mechanism", and "Servicing".

Information

This section primarily contains information below.

- Safety first
- Safety decal
- Specifications
- Dimensions

General

This section primarily contains information below.

- Engine identification
- Model identification
- General precautions
- Maintenance check list
- Check and maintenance
- Special tools

Mechanism

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Servicing

This section primarily contains information below.

- Troubleshooting
- Servicing specifications
- Tightening torques
- Checking, disassembling and servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

Kubota reserves the right to change all information at any time without notice.

Since this manual includes many models, information or illustrations and photographs can show more than one model.

March, 2017

© KUBOTA Corporation

CONTENTS

1. INFORMATION

SAFETY FIRST	1-1
1. Safety first.....	1-1
2. Before you start service	1-2
3. Start safely.....	1-2
4. Operate safely	1-2
5. Protect against high pressure spray	1-3
6. Avoid hot exhaust	1-3
7. Exhaust filter cleaning	1-3
8. Prevent a fire	1-4
9. Keep a good airflow in the work area	1-4
10. Discard fluids correctly	1-4
11. Prevent acid burns	1-4
12. Prepare for emergencies	1-5
SAFETY LABEL	1-7
1. Safety labels for BX tractor	1-7
2. Safety labels for mower	1-12
3. Safety labels for loader	1-13
4. Safety labels for backhoe	1-15
SPECIFICATIONS	1-17
1. BX tractor specifications	1-17
2. Mower specifications	1-19
3. Loader specifications	1-20
3.1 Loader specifications	1-20
3.2 Bucket specifications.....	1-21
3.3 Dimensional specifications of loader	1-22
3.4 Operational specifications of loader	1-23
4. Backhoe specifications	1-25
4.1 Backhoe specifications.....	1-25
4.2 Backhoe dimensions	1-26
4.3 Backhoe lift capacity	1-27
TRAVELING SPEEDS	1-29
DIMENSIONS	1-31

2. GENERAL

IDENTIFICATION.....	2-1
1. Tractor identification	2-1
1.1 Checking serial number and hour meter	2-1
1.2 Cylinder number	2-1
2. Checking mower identification	2-2
3. Checking loader identification.....	2-2
4. Checking backhoe identification	2-2
GENERAL PRECAUTIONS.....	2-3
HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING	2-5
LUBRICANTS, FUEL AND COOLANT	2-7
1. BX tractor.....	2-7
1.1 Lubricants, fuel, and coolant	2-7
1.1.1 Fuel.....	2-8
1.1.2 Engine oil	2-8
1.1.3 Transmission oil	2-8
1.2 Overview of biodiesel fuel (BDF).....	2-9
2. Mower	2-11
2.1 Lubricants.....	2-11
TIGHTENING TORQUES	2-13

1. General use screws, bolts and nuts	2-13
2. Stud bolts.....	2-13
3. Metric screws, bolts and nuts	2-14
4. American standard screws, bolts and nuts with UNC or UNF threads	2-14
5. Plugs.....	2-14
6. Adapters, elbows and others	2-15
MAINTENANCE CHECK LIST.....	2-17
1. BX tractor service intervals.....	2-17
2. Mower service intervals	2-19
CHECK AND MAINTENANCE.....	2-21
1. Periodic service	2-21
1.1 Opening bonnet.....	2-21
1.2 Daily check.....	2-21
1.2.1 Walk around inspection.....	2-21
1.2.2 Checking fuel gauge and refueling	2-21
1.2.3 Checking engine oil level	2-22
1.2.4 Checking transmission fluid level.....	2-22
1.2.5 Checking coolant level.....	2-23
1.2.6 Cleaning panel and radiator screen	2-23
1.2.7 Checking brake pedal	2-24
1.2.8 Checking gauges, meters, and Easy Checker™	2-24
1.2.9 Checking head light, hazard light, and tail light	2-24
1.2.10 Checking seat belt and ROPS	2-24
1.2.11 Checking and cleaning electrical wiring and battery cables.....	2-24
1.2.12 Checking movable parts	2-25
1.3 Check points of initial 50 hours	2-25
1.3.1 Changing engine oil	2-25
1.3.2 Replacing engine oil filter.....	2-25
1.3.3 Replacing transmission oil filter	2-26
1.3.4 Changing transmission fluid.....	2-26
1.3.5 Cleaning transmission strainer	2-27
1.4 Check points of every 50 hours.....	2-27
1.4.1 Greasing	2-27
1.4.2 Checking engine start system.....	2-29
1.4.3 Checking operator presence control (OPC) system	2-29
1.4.4 Checking wheel bolt torque	2-30
1.4.5 Cleaning lock lever shaft.....	2-30
1.5 Check points of every 100 hours.....	2-30
1.5.1 Checking battery condition	2-30
1.5.2 Cleaning air cleaner element	2-32
1.5.3 Checking fuel filter	2-32
1.5.4 Adjusting fan belt tension.....	2-33
1.5.5 Adjusting HST neutral spring	2-33
1.5.6 Adjusting brake pedal	2-34
1.6 Check point of every 200 hours	2-34
1.6.1 Replacing engine oil filter.....	2-34
1.6.2 Changing engine oil	2-35
1.6.3 Replacing transmission oil filter	2-35
1.6.4 Adjusting toe-in	2-36
1.7 Check points of every 400 hours.....	2-36
1.7.1 Adjusting front axle pivot.....	2-36
1.7.2 Changing transmission fluid.....	2-37
1.7.3 Cleaning transmission strainer	2-38
1.7.4 Changing front axle case oil	2-38
1.7.5 Replacing fuel filter element	2-38
1.8 Check points of every 800 hours.....	2-39
1.8.1 Adjusting engine valve clearance	2-39
1.9 Check points of every 1000 hours or 1 year	2-39

1.9.1 Replacing air cleaner element	2-39
1.10 Check points of every 1500 hours	2-39
1.10.1 Checking injection pressure of fuel injection nozzle	2-39
1.11 Check points of every 2000 hours or 2 years	2-39
1.11.1 Flushing cooling system and changing coolant.....	2-39
1.11.2 Antifreeze	2-40
1.12 Check points of every 3000 hours	2-41
1.12.1 Checking injection pump.....	2-41
1.13 Check points of every 1 year	2-41
1.13.1 Checking intake air line.....	2-41
1.13.2 Checking radiator hoses and hose clamps	2-41
1.13.3 Checking power steering line.....	2-41
1.13.4 Checking fuel lines.....	2-42
1.13.5 Checking engine breather hose	2-42
1.14 Check points of every 4 years	2-43
1.14.1 Replacing radiator hose	2-43
1.14.2 Replacing fuel hose	2-43
1.14.3 Replacing power steering hose	2-43
1.14.4 Replacing intake air line.....	2-43
1.14.5 Replacing engine breather hose	2-43
1.15 Service as required	2-43
1.15.1 Bleeding fuel system.....	2-43
1.15.2 Replacing fuse	2-43
1.15.3 Replacing light bulb	2-44
2. Mower	2-44
2.1 Check points of daily or each use	2-44
2.1.1 Retightening mower blade screw.....	2-44
2.1.2 Checking mower blade	2-45
2.1.3 Checking mower belt	2-45
2.1.4 Checking gear box oil level.....	2-45
2.1.5 Greasing spindle shafts, belt tension pivot and tension pulley	2-46
2.1.6 Greasing front and rear anti-scalp rollers	2-46
2.1.7 Greasing universal joint	2-46
2.2 Check points of initial 50 hours	2-47
2.2.1 Changing gear box oil.....	2-47
2.3 Check point of every 150 hours	2-47
2.3.1 Changing gear box oil.....	2-47
2.4 Check points of every 1 year.....	2-47
2.4.1 Checking gear box oil seal.....	2-47
2.5 Check point of every 4 years.....	2-48
2.5.1 Replacing gear box oil seal.....	2-48
3. Front loader	2-48
3.1 Check points of daily or each use	2-48
3.1.1 Checking transmission fluid level.....	2-48
3.1.2 Checking hydraulic hoses.....	2-48
3.2 Check points of every 10 hours.....	2-49
3.2.1 Greasing loader	2-49
3.3 Check points of every 50 hours.....	2-49
3.3.1 Checking torque of main frame bolt and nut.....	2-49
4. Backhoe.....	2-49
4.1 Check points of daily or each use	2-49
4.1.1 Checking transmission fluid level.....	2-49
4.1.2 Checking hydraulic hoses.....	2-49
4.1.3 Checking backhoe mounting pin.....	2-50
4.2 Check points of every 10 hours.....	2-50
4.2.1 Greasing backhoe.....	2-50
4.3 Check points of every 50 hours.....	2-51
4.3.1 Checking torque sub frame bolt and nut.....	2-51

TIRES, WHEELS, AND BALLAST	2-53
1. Tires	2-53
1.1 Inflation pressure of tires	2-53
1.2 Dual tires	2-53
2. Wheel tread	2-53
2.1 Front wheels	2-54
2.2 Rear wheels	2-54
3. Ballast	2-55
3.1 Front ballast	2-55
3.2 Rear ballast	2-55
IMPLEMENT LIMITATIONS	2-57
1. Implement limitation tables	2-57
SPECIAL TOOLS	2-61
1. Special tools for engine	2-61
1.1 Special use puller set	2-61
1.2 Diesel engine compression tester (for injection nozzle)	2-61
1.3 Nozzle tester	2-61
1.4 Injection pump pressure tester	2-61
1.5 Valve guide replacing tool	2-62
1.6 Bushing replacing tool	2-63
1.7 Flywheel stopper	2-64
1.8 Crankshaft bearing 1 replacing tool	2-64
2. Special tools for tractor	2-65
2.1 Tie-rod end lifter	2-65
2.2 Independent PTO clutch spring compression tool	2-65
2.3 Disassembling and assembling stand (1/2)	2-66
2.4 Disassembling and assembling stand (2/2)	2-68
2.5 Check and high pressure relief valve assembly tool	2-70

3. ENGINE

MECHANISM	3-1
1. Engine body	3-1
1.1 Function of cylinder block	3-1
1.2 Function of closed breather	3-1
1.3 Function of half-floating head cover	3-1
1.4 Function of piston	3-2
1.5 Function of piston ring	3-2
1.6 Function of connecting rod	3-2
1.7 Function of crankshaft	3-2
1.8 Function of camshaft	3-3
1.9 Function of rocker arm	3-3
1.10 Function of flywheel	3-3
1.11 Function of timing gears	3-4
2. Lubricating system	3-5
2.1 Overview of lubricating system	3-5
2.2 Function of oil strainer	3-7
2.3 Function of oil pump	3-7
2.4 Function of oil filter	3-7
2.5 Function of relief valve	3-8
2.6 Function of oil pressure switch	3-8
3. Cooling system	3-9
3.1 Overview of cooling system	3-9
3.2 Function of water pump	3-11
3.3 Function of radiator	3-11
3.4 Function of radiator cap	3-11
4. Fuel system	3-12
4.1 Overview of fuel system	3-12
4.2 Function of fuel filter	3-12

Click on the image link below for the full version of the service manual



4.3 Function of fuel feed pump.....	3-12
4.4 Function of injection nozzle.....	3-12
SERVICING	3-15
1. Troubleshooting for engine	3-15
2. Servicing specifications for engine	3-19
3. Tightening torques for engine	3-23
4. Checking and adjusting	3-24
4.1 Engine body	3-24
4.1.1 Checking compression pressure	3-24
4.1.2 Checking valve clearance	3-24
4.2 Lubricating system	3-25
4.2.1 Checking engine oil pressure	3-25
4.3 Cooling system.....	3-26
4.3.1 Checking fan belt tension	3-26
4.3.2 Checking fan belt damage and wear	3-26
4.3.3 Checking radiator cap air leakage	3-26
4.3.4 Checking radiator water leakage	3-27
4.3.5 Checking thermostat valve opening temperature	3-27
4.4 Fuel system	3-28
4.4.1 Checking injection timing	3-28
4.4.2 Checking fuel tightness of pump element.....	3-29
4.4.3 Checking fuel tightness of delivery valve	3-29
4.4.4 Checking nozzle spraying condition	3-29
4.4.5 Checking fuel injection pressure	3-30
4.4.6 Checking valve seat tightness	3-30
4.4.7 Checking nozzle holder	3-31
5. Disassembling and assembling	3-31
5.1 Separating engine	3-31
5.1.1 Draining engine oil	3-31
5.1.2 Removing battery.....	3-32
5.1.3 Removing bonnet.....	3-33
5.1.4 Disconnecting wiring harness and ground cables	3-33
5.1.5 Disconnecting fuel hoses.....	3-34
5.1.6 Disconnecting accelerator wire	3-34
5.1.7 Disconnecting propeller shaft assembly	3-35
5.1.8 Separating engine.....	3-35
5.1.9 Draining coolant and removing outer engine parts	3-36
5.2 Disassembling the engine	3-36
5.2.1 Cylinder head and valve	3-36
5.2.2 Gear case and timing gears.....	3-40
5.2.3 Piston and connecting rod	3-44
5.2.4 Flywheel and crankshaft	3-46
6. Servicing	3-48
6.1 Cylinder head and valve.....	3-48
6.1.1 Checking top clearance	3-48
6.1.2 Checking cylinder head surface flatness	3-48
6.1.3 Checking cylinder head flaw	3-49
6.1.4 Checking valve recessing	3-49
6.1.5 Checking clearance between valve stem and valve guide	3-49
6.1.6 Replacing valve guide.....	3-50
6.1.7 Checking valve seating.....	3-51
6.1.8 Correcting valve	3-51
6.1.9 Correcting valve seat	3-51
6.1.10 Lapping valve.....	3-52
6.1.11 Checking free length and tilt of valve spring	3-52
6.1.12 Checking valve spring setting load	3-52
6.1.13 Checking oil clearance between rocker arm and rocker arm shaft.....	3-53
6.1.14 Checking push rod alignment	3-53

6.1.15 Checking oil clearance between tappet and tappet guide bore	3-53
6.2 Timing gears, camshaft and governor gear.....	3-54
6.2.1 Checking timing gear backlash.....	3-54
6.2.2 Checking idle gear 1 side clearance.....	3-54
6.2.3 Checking camshaft side clearance	3-54
6.2.4 Checking camshaft alignment.....	3-55
6.2.5 Checking cam height	3-55
6.2.6 Checking oil clearance of camshaft journal	3-55
6.2.7 Checking oil clearance between idle gear 1 shaft and idle gear bushing	3-56
6.2.8 Replacing idle gear bushing	3-56
6.3 Piston and connecting rod.....	3-56
6.3.1 Checking piston pin bore I.D.....	3-56
6.3.2 Checking oil clearance between piston pin and small end bushing.....	3-56
6.3.3 Replacing small end bushing	3-57
6.3.4 Checking connecting rod alignment.....	3-57
6.3.5 Checking piston ring gap	3-57
6.3.6 Checking clearance between piston ring and piston ring groove	3-58
6.4 Crankshaft.....	3-58
6.4.1 Checking crankshaft side clearance	3-58
6.4.2 Checking crankshaft alignment.....	3-59
6.4.3 Checking oil clearance between crankpin and crankpin bearing	3-59
6.4.4 Checking oil clearance between crankshaft journal and crankshaft bearing 1	3-60
6.4.5 Replacing crankshaft bearing 1	3-61
6.4.6 Checking oil clearance between crankshaft journal and crankshaft bearing 2 and crankshaft bearing 3	3-62
6.5 Cylinder	3-63
6.5.1 Checking cylinder wear.....	3-63
6.5.2 Correcting cylinder (Oversize)	3-63
6.6 Oil pump	3-64
6.6.1 Checking rotor lobe clearance	3-64
6.6.2 Checking clearance between outer rotor and pump body	3-64
6.6.3 Checking clearance between rotor and cover	3-64
6.7 Relief valve spring	3-65
6.7.1 Checking relief valve.....	3-65

4. TRANSAXLE

MECHANISM	4-1
1. Structure of transaxle	4-1
2. Traveling system.....	4-2
2.1 Hydrostatic transmission	4-2
2.1.1 Structure of hydrostatic transmission.....	4-2
2.1.2 Oil flow of hydrostatic transmission	4-3
2.1.3 Structure of HST control linkage	4-8
2.1.4 Speed set linkage	4-9
2.2 Range gear shift section	4-12
2.2.1 Structure of range gear shift	4-12
2.3 Front wheel drive section	4-13
2.3.1 Structure of front wheel drive	4-13
2.4 Differential gear section.....	4-14
2.4.1 Structure of differential gears.....	4-14
2.4.2 Structure of differential lock	4-16
2.5 Brake section	4-17
2.5.1 Structure of brake system	4-17
3. PTO system	4-19
3.1 Structure of PTO system	4-19
3.1.1 Function of PTO clutch relief valve	4-20
3.1.2 Engaged function of PTO clutch	4-20
3.1.3 Disengaged function of PTO clutch	4-20

3.2 Structure of mid and rear PTO	4-21
4. Others	4-22
4.1 Hydraulic pump drive gear section	4-22
4.1.1 Structure of hydraulic pump drive gear	4-22
SERVICING	4-23
1. Troubleshooting for transaxle	4-23
2. Servicing specifications for transaxle	4-27
3. Tightening torques for transaxle	4-28
4. Checking and adjusting	4-29
4.1 Adjusting maximum speed	4-29
4.2 Adjusting HST neutral position	4-29
4.3 Checking and adjusting HST neutral spring (dynamic braking)	4-30
4.4 Checking charge relief pressure	4-31
4.5 Checking high relief pressure (Forward)	4-32
4.6 Checking high relief pressure (Reverse)	4-33
4.7 Readjusting relief valve (When HST does not work due to its loose hexagon socket head screw)	4-33
4.8 Checking PTO clutch operating pressure	4-34
4.9 Adjusting brake pedal free travel	4-35
5. Disassembling and assembling	4-35
5.1 Separating transaxle	4-35
5.1.1 Draining transmission fluid	4-35
5.1.2 Removing battery	4-36
5.1.3 Removing lift rod and lower link	4-36
5.1.4 Removing ROPS	4-37
5.1.5 Removing seat	4-37
5.1.6 Removing step	4-37
5.1.7 Removing fender	4-38
5.1.8 Removing fuel tank	4-38
5.1.9 Removing rear wheel	4-39
5.1.10 Removing fender center stay	4-39
5.1.11 Removing fender bracket and hitch plate	4-39
5.1.12 Removing transaxle assembly	4-40
5.1.13 Removing brake pedal	4-41
5.1.14 Removing propeller shaft	4-41
5.1.15 Removing differential lock pedal	4-41
5.1.16 Removing speed control pedal, HST damper, and cruise rod	4-42
5.2 Hydrostatic transmission	4-42
5.2.1 Removing levers and mower lift arm	4-42
5.2.2 Removing PTO clutch valve	4-43
5.2.3 Removing oil cooler cover	4-43
5.2.4 Removing center section and valve plates	4-43
5.2.5 Removing check and high pressure relief valve plug	4-44
5.2.6 Checking check and high pressure relief valve	4-44
5.2.7 Removing cylinder block	4-45
5.2.8 Removing cylinder block and piston	4-45
5.2.9 Removing swashplate and trust roller bearing	4-46
5.2.10 Removing 4WD detent ball	4-47
5.2.11 Removing neutral arm and trunnion arm	4-47
5.3 Hydraulic cylinder	4-47
5.3.1 Removing hydraulic cylinder	4-47
5.4 Transaxle shafts	4-48
5.4.1 Removing transaxle case front cover	4-48
5.4.2 Removing hydraulic pump assembly	4-49
5.4.3 Removing rear PTO cover assembly	4-50
5.4.4 Disassembling rear axle (L.H.)	4-50
5.4.5 Removing rear axle case (R.H.)	4-51
5.4.6 Removing 66T final gear	4-52
5.4.7 Removing rear axle case, R.H. and brake	4-53

5.4.8 Removing PTO clutch assembly.....	4-54
5.5 Assembling shafts	4-54
5.5.1 Assembling select arms and HST pump shaft (PTO clutch shaft)	4-54
5.5.2 Assembling front wheel drive shaft, shifter, spiral bevel pinion shaft and mid-PTO shaft.....	4-55
6. Servicing	4-56
6.1 Hydrostatic transmission	4-56
6.1.1 Checking center section	4-56
6.1.2 Checking charge relief valve.....	4-56
6.1.3 Checking check and high pressure relief valve	4-56
6.1.4 Checking cylinder block assembly	4-57
6.1.5 Checking thrust washer, thrust roller bearing, thrust plate and cradle bearing	4-57
6.1.6 Checking pump shaft (PTO clutch shaft)	4-57
6.1.7 Checking needle bearing	4-58
6.2 Transaxle case	4-58
6.2.1 Checking bearing	4-58
6.2.2 Checking PTO clutch disc wear	4-58
6.2.3 Checking separate plate and back plate wear	4-58
6.2.4 Checking flatness of clutch piston, pressure plate and steel plate	4-59
6.2.5 Checking clutch spring free length.....	4-59
6.2.6 Checking PTO brake disc wear	4-59
6.2.7 Checking PTO brake plate.....	4-59
6.2.8 Checking clearance between differential case and differential side gear	4-60
6.2.9 Checking clearance between differential pinion shaft and differential pinion.....	4-60
6.2.10 Checking backlash between differential pinion and differential side gear.....	4-60
6.2.11 Checking backlash between spiral bevel pinion gear and bevel gear.....	4-61
6.2.12 Checking brake cam lever movement	4-61
6.2.13 Checking flatness of actuator and bearing holder	4-61
6.2.14 Checking height of cam plate and ball	4-62
6.2.15 Checking brake disc and friction plate wear	4-62

5. FRONT AXLE

MECHANISM	5-1
1. Structure of front axle	5-1
2. Front wheel alignment	5-2
2.1 Camber of front axle.....	5-2
2.2 Kingpin angle of front axle.....	5-2
2.3 Caster of front axle	5-2
2.4 Toe-in of front axle	5-2
SERVICING	5-5
1. Troubleshooting for front axle	5-5
2. Servicing specifications for front axle	5-6
3. Tightening torques for front axle	5-7
4. Checking and adjusting	5-8
4.1 Adjusting toe-in	5-8
4.2 Adjusting front axle rocking force	5-8
4.3 Adjusting front wheel steering angle	5-9
5. Disassembling and assembling	5-9
5.1 Separating front axle assembly	5-9
5.1.1 Draining front axle case oil	5-9
5.1.2 Removing battery.....	5-9
5.1.3 Removing bonnet.....	5-10
5.1.4 Removing front wheel and propeller shaft cover	5-10
5.1.5 Disconnecting propeller shaft	5-10
5.1.6 Removing front axle assembly.....	5-11
5.2 Front axle assembly	5-11
5.2.1 Removing power steering cylinder.....	5-11
5.2.2 Removing bevel gear case and front gear case	5-12
5.2.3 Removing front gear case cover	5-12

5.2.4 Removing 36T bevel gear and front axle shaft	5-13
5.2.5 Removing front gear case and bevel gear case	5-13
5.2.6 Removing bevel pinion shaft and differential gear assembly	5-14
5.2.7 Removing differential gear	5-14
6. Servicing	5-15
6.1 Checking clearance between differential case and differential side gear	5-15
6.2 Checking clearance between differential pinion shaft and differential pinion	5-15
6.3 Checking backlash between differential pinion and differential side gear	5-16
6.4 Checking turning torque of bevel pinion shaft	5-16
6.5 Checking backlash between bevel pinion shaft and bevel gear	5-17
6.6 Checking backlash between 12T bevel gear and 15T bevel gear	5-17
6.7 Checking clearance between center pin and pin support bushing	5-18
6. STEERING	
MECHANISM	6-1
1. Structure of steering system	6-1
2. Hydraulic circuit of steering	6-2
3. Steering controller	6-3
3.1 Structure of steering controller	6-3
3.1.1 Control valve	6-3
3.1.2 Metering device	6-3
3.1.3 Relief valve	6-4
4. Steering cylinder	6-5
4.1 Structure of steering cylinder	6-5
SERVICING	6-7
1. Troubleshooting for steering	6-7
2. Servicing specifications for steering	6-9
3. Tightening torques for steering	6-10
4. Checking and adjusting	6-11
4.1 Checking relief valve operating pressure	6-11
5. Disassembling and assembling	6-11
5.1 Power steering cylinder	6-11
5.1.1 Removing adapter and tie-rod	6-11
5.1.2 Disassembling steering cylinder	6-12
5.2 Separating power steering controller	6-12
5.2.1 Removing battery	6-12
5.2.2 Removing steering wheel	6-13
5.2.3 Removing upper panel	6-13
5.2.4 Removing steering controller	6-13
5.3 Separating power steering cylinder	6-14
5.3.1 Removing bonnet	6-14
5.3.2 Removing front axle assembly	6-14
5.3.3 Removing power steering cylinder	6-15
6. Servicing	6-15
6.1 Checking steering cylinder I.D.	6-15
6.2 Checking clearance between rod and guide	6-15
7. HYDRAULIC SYSTEM	
MECHANISM	7-1
1. Structure of hydraulic system	7-1
2. Hydraulic circuit	7-2
3. Hydraulic pump	7-4
3.1 Outline of hydraulic pump	7-4
3.2 Structure of hydraulic pump	7-4
3.3 Specification of hydraulic pump	7-4
4. Control valve	7-4
4.1 Outline of control valve	7-4
4.2 Function of control valve	7-5

4.2.1 Control valve in neutral position	7-5
4.2.2 Control valve in lift position	7-6
4.2.3 Control valve in down position	7-7
5. Flow priority valve	7-8
5.1 Outline of flow priority valve	7-8
5.2 Structure of flow priority valve	7-9
5.3 Specification of flow priority valve	7-10
6. Relief valve	7-10
6.1 Outline of relief valve	7-10
6.2 Structure of relief valve	7-11
6.3 Function of relief valve	7-12
6.4 Specification of relief valve	7-13
7. Hydraulic cylinder	7-14
7.1 Structure of hydraulic cylinder	7-14
8. Hydraulic block type outlet	7-15
8.1 Structure of hydraulic block type outlet	7-15
9. Mower linkage	7-16
9.1 Structure of mower linkage	7-16
10. Front loader valve	7-17
10.1 Structure	7-17
10.1.1 Structure of front loader valve and pipe	7-17
10.1.2 Structure of front loader control valve	7-18
10.2 Front loader hydraulic circuit	7-19
10.3 Function of loader control valve	7-20
10.3.1 Loader control lever in neutral position	7-20
10.3.2 Loader control lever in up position	7-21
10.3.3 Loader control lever in down position	7-23
10.3.4 Loader control lever in floating position	7-25
10.3.5 Loader control lever in roll-back position	7-27
10.3.6 Loader control lever in dump position	7-30
SERVICING	7-33
1. Troubleshooting for hydraulic system	7-33
2. Servicing specifications for hydraulic system	7-34
3. Tightening torques for hydraulic system	7-35
4. Checking and adjusting	7-36
4.1 Relief valve	7-36
4.1.1 Checking relief valve setting pressure	7-36
4.2 Pump and priority valve	7-36
4.2.1 Checking hydraulic pump oil flow	7-36
4.2.2 Checking power steering oil flow	7-37
4.3 Mower lift linkage	7-38
4.3.1 Adjusting mower lift linkage	7-38
5. Disassembling and assembling	7-38
5.1 Hydraulic pump	7-38
5.1.1 Removing battery	7-38
5.1.2 Removing lift rod and lower link	7-39
5.1.3 Removing ROPS	7-39
5.1.4 Removing seat	7-40
5.1.5 Removing step	7-40
5.1.6 Removing fender	7-40
5.1.7 Removing fuel tank	7-41
5.1.8 Removing fender center stay	7-41
5.1.9 Removing hydraulic pump	7-41
5.2 Hydraulic cylinder block	7-42
5.2.1 Removing battery	7-42
5.2.2 Removing lift rod and lower link	7-43
5.2.3 Removing ROPS	7-43
5.2.4 Removing seat	7-43

5.2.5 Removing step	7-43
5.2.6 Removing fender	7-44
5.2.7 Removing fuel tank	7-44
5.2.8 Removing fender center stay	7-45
5.2.9 Removing mower linkage and wire harness	7-45
5.2.10 Removing hydraulic cylinder block	7-45
5.3 Hydraulic cylinder and control valve	7-46
5.3.1 Removing control valve	7-46
5.3.2 Removing control valve lever	7-46
5.3.3 Removing lift arm, hydraulic arm shaft and hydraulic arm	7-46
5.3.4 Removing hydraulic piston	7-47
5.3.5 Removing lowering speed adjusting valve	7-47
5.4 Mower lift linkage	7-48
5.4.1 Disassembling mower linkage	7-48
5.5 Control valve (Front loader)	7-49
5.5.1 Removing battery	7-49
5.5.2 Removing ROPS	7-49
5.5.3 Removing seat	7-49
5.5.4 Removing step	7-49
5.5.5 Removing fender	7-50
5.5.6 Removing control valve	7-50
5.5.7 Disassembling control valve	7-51
6. Servicing	7-52
6.1 Hydraulic pump	7-52
6.1.1 Checking clearance between tip of gear tooth and casing	7-52
6.1.2 Checking clearance between bushing and shaft	7-52
6.1.3 Checking side plate thickness	7-53
6.2 Hydraulic cylinder	7-53
6.2.1 Checking hydraulic cylinder bore	7-53
6.2.2 Checking hydraulic arm shaft bushing	7-53

8. ELECTRICAL SYSTEM

MECHANISM	8-1
1. Wiring diagram of BX tractor	8-1
2. Electrical connector chart	8-2
3. Reading electrical circuit diagrams	8-3
3.1 How to read wiring diagram	8-3
3.2 Layout of connector diagrams	8-6
3.3 Precautions on handling electrical connectors	8-7
4. Starting system	8-8
4.1 Electrical circuit of starting system	8-8
4.2 Function of relay	8-9
4.3 Function of starter	8-9
4.4 Function of glow plug	8-10
4.5 Function of safety switch	8-10
4.6 Function of fuel pump	8-10
5. OPC (Operator Presence Control) system	8-11
5.1 Electrical circuit of OPC timer	8-11
6. Charging system	8-12
6.1 Electrical circuit for charging system	8-12
6.2 Function of IC regulator (3P connector type)	8-13
7. Lighting system	8-14
7.1 Electrical circuit for lighting system	8-14
8. Gauges	8-15
8.1 Electrical circuit of gauge system	8-15
8.2 Meter panel	8-16
8.2.1 Function of hour meter	8-16
8.2.2 Function of tachometer	8-16

8.2.3 Function of fuel gauge	8-16
8.2.4 Function of coolant temperature gauge	8-16
8.3 Function of fuel level sensor	8-17
8.4 Function of coolant temperature sensor	8-17
8.5 Function of oil pressure switch	8-18
9. Others	8-19
9.1 Electrical circuit for accessory	8-19
9.2 Function of DC outlet	8-20
SERVICING	8-21
1. Troubleshooting for electrical system	8-21
2. Servicing specifications for electrical system	8-27
3. Tightening torques for electrical system	8-28
4. Checking and adjusting	8-29
4.1 Battery	8-29
4.1.1 Checking battery voltage	8-29
4.1.2 Checking battery terminal connection	8-29
4.1.3 Checking battery specific gravity	8-29
4.2 Main switch	8-30
4.2.1 Checking main switch connector voltage	8-30
4.2.2 Checking main switch continuity at off position	8-30
4.2.3 Checking main switch continuity at on position	8-31
4.2.4 Checking main switch continuity at preheat position	8-31
4.2.5 Checking main switch continuity at start position	8-31
4.3 Starter	8-31
4.3.1 Checking motor	8-31
4.3.2 Testing starter magnet switch (pull-in, holding coils)	8-32
4.4 Glow plug	8-32
4.4.1 Checking glow plug lead terminal voltage	8-32
4.4.2 Checking glow plug continuity	8-33
4.5 Safety switch	8-33
4.5.1 Checking PTO shift lever switch continuity	8-33
4.5.2 Checking HST neutral switch continuity	8-34
4.6 Operator presence control (OPC) system	8-34
4.6.1 Checking seat switch and seat turnover switch continuity	8-34
4.6.2 Checking OPC timer	8-35
4.7 Fuel pump	8-36
4.7.1 Checking fuel pump connector voltage	8-36
4.7.2 Checking fuel pump continuity	8-36
4.8 Engine stop solenoid	8-36
4.8.1 Testing engine stop solenoid	8-36
4.9 Timer relay	8-37
4.9.1 Checking timer relay connector voltage	8-37
4.9.2 Testing timer relay	8-37
4.10 Charging system	8-37
4.10.1 Checking battery charging current	8-37
4.11 Combination switch	8-38
4.11.1 Removing combination switch	8-38
4.11.2 Checking combination switch connector voltage	8-38
4.11.3 Checking head light switch continuity when setting switch at OFF position	8-38
4.11.4 Checking head light switch continuity when setting switch at ON position	8-39
4.11.5 Checking turn signal light switch continuity when setting switch knob at OFF position	8-39
4.11.6 Checking turn signal light switch continuity when setting switch knob at RIGHT position	8-40
4.11.7 Checking turn signal light switch continuity when setting switch knob at LEFT position	8-40
4.11.8 Checking hazard switch continuity when setting switch knob at OFF position	8-41
4.11.9 Checking hazard switch continuity when setting switch knob at ON position	8-41
4.11.10 Checking flasher unit connector voltage	8-41
4.11.11 Testing flasher unit actuation	8-42
4.12 Gauge	8-43

4.12.1 Checking charge lamp (charging circuit)	8-43
4.12.2 Checking engine oil pressure lamp.....	8-43
4.12.3 Checking engine oil pressure switch continuity	8-44
4.12.4 Checking fuel level sensor continuity.....	8-44
4.12.5 Checking coolant temperature sensor connector voltage.....	8-44
4.12.6 Checking coolant temperature sensor continuity	8-45
4.12.7 Checking hour meter and tachometer	8-45
4.13 Accessory.....	8-46
4.13.1 Checking DC outlet connector voltage	8-46
4.13.2 Checking DC outlet continuity.....	8-46
4.14 Meter panel	8-46
4.14.1 Checking connector voltage, sensor resistance and switch	8-46
5. Disassembling and assembling	8-47
5.1 Starter	8-47
5.1.1 Disassembling starter motor	8-47
5.1.2 Removing magnet switch.....	8-48
5.1.3 Removing plunger.....	8-48
5.2 Alternator.....	8-48
5.2.1 Removing pulley	8-48
5.2.2 Removing rear end cover	8-48
5.2.3 Removing brush holder.....	8-48
5.2.4 Removing IC regulator	8-49
5.2.5 Removing rectifier.....	8-49
5.2.6 Removing rear end frame	8-49
5.2.7 Removing rotor	8-49
5.2.8 Removing retainer plate.....	8-50
5.2.9 Removing bearing on drive end side	8-50
5.2.10 Removing bearing at slip ring side.....	8-50
6. Servicing	8-50
6.1 Starter	8-50
6.1.1 Checking overrunning clutch	8-50
6.1.2 Checking commutator and mica	8-51
6.1.3 Checking brush wear	8-51
6.1.4 Checking brush holder	8-52
6.1.5 Checking armature coil	8-52
6.1.6 Checking field coil.....	8-52
6.2 Alternator.....	8-52
6.2.1 Checking bearing	8-52
6.2.2 Checking stator	8-53
6.2.3 Checking rotor	8-53
6.2.4 Checking slip ring	8-53
6.2.5 Checking brush wear	8-53
6.2.6 Checking rectifier	8-54

9. MOWER

MECHANISM	9-1
1. Structure of power transmission of mower	9-1
2. Structure of lifting mechanism of mower	9-2
SERVICING	9-3
1. Troubleshooting for mower	9-3
2. Servicing specifications for mower	9-4
3. Tightening torques for mower	9-5
4. Setting up mower [RCK54D-26BX and RCK60D-26BX]	9-6
4.1 Assembling mower	9-6
4.2 Setting mower	9-6
4.3 Mounting front link	9-7
4.4 Mounting frame link	9-8
4.5 Setting tractor	9-8

4.6 Mounting mower.....	9-9
5. Checking and adjusting	9-10
5.1 Mower adjustment.....	9-10
5.1.1 Adjusting mower link.....	9-10
5.1.2 Adjusting front and rear cutting height.....	9-10
5.1.3 Adjusting left and right cutting height.....	9-11
5.1.4 Adjusting cutting height.....	9-12
5.2 Checking mower blade and belt.....	9-14
5.2.1 Checking mower blade	9-14
5.2.2 Checking mower belt	9-14
6. Disassembling and assembling	9-15
6.1 Removing ramps and belt covers.....	9-15
6.2 Removing mower blades.....	9-15
6.3 Removing blade boss.....	9-15
6.4 Removing gear box and mower belt	9-16
6.5 Disassembling gear box.....	9-16
6.6 Removing center pulley holder.....	9-17
6.7 Removing outer pulley and blade shaft.....	9-17
7. Servicing.....	9-18
7.1 Adjusting turning torque of pinion shaft.....	9-18
7.2 Adjusting backlash between bevel gears	9-18

10. FRONT LOADER

MECHANISM	10-1
1. Hydraulic circuit	10-1
2. Front remote hydraulic control system (if equipped)	10-3
2.1 Operating control lever	10-3
3. Boom cylinder and bucket cylinder.....	10-4
3.1 Structure of boom cylinder and bucket cylinder	10-4
4. One touch front loader	10-5
4.1 Outline of one touch front loader	10-5
5. One lever quick touch 4 lines coupler.....	10-5
5.1 Structure of one lever quick touch 4 lines coupler	10-5
6. Auto lock attachment and detachment	10-5
6.1 Outline of auto lock attachment and detachment.....	10-5
6.2 Function of auto lock attachment and detachment	10-6
7. Mechanical loader frame standing mechanism	10-6
7.1 Structure of mechanical loader frame standing mechanism	10-6
8. 3rd function valve (If equipped)	10-7
8.1 Structure of 3rd function valve	10-7
8.2 Function of 3rd function valve	10-8
8.2.1 Activation switch in off position	10-8
8.2.2 Activation switch in on position	10-9
SERVICING	10-11
1. Troubleshooting for front loader.....	10-11
2. Tightening torques for front loader.....	10-13
3. Checking and adjusting	10-14
3.1 Loader stand	10-14
3.1.1 Adjusting height of loader stand	10-14
3.2 Front hydraulic valve main switch and relay	10-17
3.2.1 Checking front hydraulic valve main switch continuity.....	10-17
3.2.2 Checking connector voltage of front hydraulic valve main switch.....	10-18
3.2.3 Checking relay	10-18
3.3 3rd function solenoid valve.....	10-19
3.3.1 Checking 3rd function solenoid valve continuity	10-19
3.3.2 Checking connector voltage of 3rd function solenoid valve	10-19
4. Disassembling and assembling	10-19
4.1 Removing and attaching front loader	10-19

4.1.1 Removing loader.....	10-19
4.1.2 Reinstalling loader	10-23
4.2 Bucket, boom and hydraulic cylinders.....	10-26
4.2.1 Attaching attachments	10-26
4.2.2 Removing attachments	10-28
4.2.3 Removing bucket cylinder.....	10-29
4.2.4 Removing boom cylinder and hydraulic tubes	10-29
4.2.5 Removing piston rod assembly.....	10-29
4.2.6 Removing cylinder head, piston and nut.....	10-30
4.2.7 Removing piston seal and O-ring	10-31
4.2.8 Installing O-ring and piston seal	10-31
4.3 Side frames, front guard and main frames.....	10-31
4.3.1 Removing side frames	10-31
4.3.2 Removing front guard	10-32
4.3.3 Removing main frames.....	10-32
4.4 3rd function valve (If equipped).....	10-32
4.4.1 Removing 3rd function valve	10-32
4.4.2 Removing hydraulic tubes of 3rd function.....	10-33
5. Servicing	10-33
5.1 Piston rod	10-33
5.1.1 Checking piston rod bend	10-33

11. BACKHOE

MECHANISM	11-1
1. Hydraulic circuit	11-1
2. Control valve.....	11-2
2.1 Structure of backhoe control valve	11-2
2.2 Function of backhoe control valve.....	11-4
2.2.1 Backhoe control valve in neutral position	11-4
2.2.2 Backhoe control valve in swing right position	11-5
2.2.3 Backhoe control valve in swing left position	11-6
2.2.4 Backhoe control valve in boom up position	11-7
2.2.5 Backhoe control valve in boom down position.....	11-8
2.2.6 Backhoe control valve in L.H. stabilizer shrink position	11-9
2.2.7 Backhoe control valve in L.H. stabilizer extend position	11-10
2.2.8 Backhoe control valve in R.H. stabilizer shrink position	11-11
2.2.9 Backhoe control valve in R.H. stabilizer extend position	11-12
2.2.10 Backhoe control valve in dipperstick crowd position.....	11-13
2.2.11 Backhoe control valve in dipperstick extend position.....	11-14
2.2.12 Backhoe control valve in bucket roll-back position	11-15
2.2.13 Backhoe control valve in bucket dump position	11-16
2.3 Structure of overload relief valve.....	11-17
2.3.1 Function of relief position.....	11-17
2.3.2 Function of anti-cavitation position	11-18
3. Structure of hydraulic cylinder	11-19
SERVICING	11-21
1. Troubleshooting for backhoe	11-21
2. Servicing specifications for backhoe	11-23
3. Tightening torques for backhoe	11-25
4. Checking and adjusting	11-26
4.1 Checking relief valve setting pressure	11-26
4.2 Checking control lever operation force.....	11-26
4.3 Checking stabilizer control lever operation force	11-26
5. Disassembling and assembling	11-26
5.1 Removing backhoe	11-26
5.1.1 Preparing to remove backhoe.....	11-26
5.1.2 Releasing mounting pins	11-27
5.1.3 Disconnecting hydraulic hoses	11-28

5.1.4 Removing backhoe	11-28
5.2 Installing backhoe	11-28
5.2.1 Preparing to install backhoe	11-28
5.2.2 Connecting hydraulic hoses.....	11-29
5.2.3 Setting mounting pins	11-29
5.2.4 Installing backhoe	11-29
5.3 Disassembling backhoe	11-30
5.3.1 Removing bucket	11-31
5.3.2 Removing dipperstick and bucket cylinder	11-31
5.3.3 Removing dipperstick cylinder, boom, boom cylinder, and hoses	11-32
5.3.4 Removing swing frame	11-33
5.3.5 Removing swing cylinder	11-33
5.3.6 Removing stabilizers and stabilizer cylinder	11-33
5.3.7 Removing lever support and control valve.....	11-34
5.3.8 Removing backhoe main frame	11-35
5.4 Disassembling control valve.....	11-35
5.5 Disassembling cylinder (Boom, dipperstick, bucket, swing, stabilizer)	11-35
5.5.1 Removing cylinder rod assembly	11-35
5.5.2 Removing cylinder head, piston, and nut.....	11-36
5.5.3 Checking cylinder adaptor angle	11-36
5.5.4 Removing piston seal and O-ring	11-37
5.5.5 Installing O-ring and piston seal	11-37
6. Servicing.....	11-38
6.1 Checking clearance between pin and bushing.....	11-38
6.2 Checking thrust washer wear	11-41
6.3 Checking piston rod bend	11-41

1. INFORMATION

SAFETY FIRST

1. Safety first

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you try to repair or use this unit.



DANGER

- Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

- Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

- Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



IMPORTANT


- Indicates that equipment or property damage could result if instructions are not followed.



NOTE


- Gives helpful information.

2. Before you start service






- Read all instructions and safety instructions in this manual and on your machine safety decals.
- Clean the work area and machine.
- Park the machine on a stable and level ground, and set the parking brake.
- Lower the implement to the ground.
- Stop the engine, then remove the key.
- Disconnect the battery negative cable.
- Hang a **"DO NOT OPERATE"** tag in the operator station.

3. Start safely



- Do not do the procedures below when you start the engine.
 1. Short across starter terminals.
 2. Bypass the safety start switch.
- Do not alter or remove any part of machine safety system.
- Before you start the engine, make sure that all shift levers are in neutral positions or in disengaged positions.
- Do not start the engine when you stay on the ground. Start the engine only from operator's seat.

4. Operate safely



- Do not use the machine after you consume alcohol or medication or when you are tired.
- Put on applicable clothing and safety equipment.
- Use applicable tools only. Do not use alternative tools or parts.
- When 2 or more persons do servicing, make sure that you do it safely.
- Do not touch the hot parts or parts that turn when the engine operates.
- Do not remove the radiator cap when the engine operates, or immediately after it stops. If not, hot water can spout out from the radiator. Only remove the radiator cap when it is at a sufficiently low temperature to touch with bare hands. Slowly

loosen the cap to release the pressure before you remove it fully.

- Released fluid (fuel or hydraulic oil) under pressure can cause damage to the skin and cause serious injury. Release the pressure before you disconnect hydraulic or fuel lines. Tighten all connections before you apply the pressure.
- Do not open a fuel system under high pressure. The fluid under high pressure that stays in fuel lines can cause serious injury. Do not disconnect or repair the fuel lines, sensors, or any other components between the fuel pump and injectors on engines with a common rail fuel system under high pressure.
- Put on an applicable ear protective device (earmuffs or earplugs) to prevent injury against loud noises.
- Be careful about electric shock. The engine generates a high voltage of more than DC100 V in the ECU and is applied to the injector.


5. Protect against high pressure spray



9Y1200165INI019A

- Spray from high pressure nozzles can penetrate the skin and cause serious injury. Keep spray from contacting hands or body.
- If an accident occurs, see a doctor immediately. Any high pressure spray injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source.


6. Avoid hot exhaust



9Y1200165INI020A

- Servicing machine or attachments with engine operating can result in serious personal injury. Avoid exposure and skin contact with hot exhaust gases and components.
- Exhaust parts and streams become very hot during operation. Exhaust gases and components reach temperatures hot enough to burn people, ignite, or melt common materials.


7. Exhaust filter cleaning



9Y1200165INI020A

- Servicing machine or attachments during exhaust filter cleaning can result in serious personal injury. Avoid exposure and skin contact with hot exhaust gases and components.
- During auto or manual/stationary exhaust filter cleaning operations, the engine will operate at elevated idle and hot temperatures for an extended period of time. Exhaust gases and exhaust filter components reach temperatures hot enough to burn people, or ignite, or melt common materials.


8. Prevent a fire



IBM006A

- Fuel is very flammable and explosive under some conditions. Do not smoke or let flames or sparks in your work area.
- To prevent sparks from an accidental short circuit, always disconnect the battery negative cable first and connect it last.
- The battery gas can cause an explosion. Keep the sparks and open flame away from the top of battery, especially when you charge the battery.
- Make sure that you do not spill fuel on the engine.

9. Keep a good airflow in the work area



IBM007A

- If the engine is in operation, make sure that the area has good airflow. Do not operate the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.


10. Discard fluids correctly



IBM009A

- Do not discard fluids on the ground, down the drain, into a stream, pond, or lake. Obey related environmental protection regulations when you discard oil, fuel, coolant, electrolyte and other dangerous waste.

11. Prevent acid burns



IBM008A

- Keep electrolyte away from your eyes, hands and clothing. Sulfuric acid in battery electrolyte is poisonous and it can burn your skin and clothing and cause blindness. If you spill electrolyte on yourself, clean yourself with water, and get medical aid immediately.

12. Prepare for emergencies



- Keep a first aid kit and fire extinguisher ready at all times.
- Keep the emergency contact telephone numbers near your telephone at all times.


SAFETY LABEL

1. Safety labels for BX tractor

The safety labels are installed on the machine. If a label becomes damaged, illegible or is not on the machine, replace it. The label part number is listed in the parts list.

1. INFORMATION

(1) Part No. K2871-6548-1



1AGAJBMAP0460



(2) Part No. K1272-6585-2
Diesel fuel No fire
only

1BDAHAQAP002A


(3) Part No. K2591-6557-2




1HNAAACAP0690



1PSQW00006A01



(1) Part No. K2581-6554-1



1AGAJBMAP0470

(2) Part No. K2581-6555-1




1AGAJBMAP0480

(3) Part No. K2871-6556-1



1AGAJBMAP0490

(4) Part No. K2871-6552-2



1AGAJBMAP0500

(5) Part No. K2651-6568-1





1AYACAAP1000

(6) Part No. K2871-6558-1




1AGAJBMAP0530



1. INFORMATION

(1) Part No. K2871-6541-1




1AGAJAXAP048E

(2) Part No. K2581-6547-1
Stay clear of engine fan and fanbelt.


1AGAJAXAP049E

(3) Part No. K2581-6543-1
Stay clear of engine fan and fanbelt.


1AGAJAXAP052E



1BXMCM00018A01



1BXMCM00019A01



1BXMCM00094A02

1PSQW00007A01

(1) Part No. K7591-6114-2



1A5AACQAP255A

(3) Part No. K2871-6542-1

Do not touch hot
surface like muffler, etc.






1AGAJBMAP0520

(2) Part No. K2871-6564-1



1AGAJBMAP0560




1PSQW00008A01


2. Safety labels for mower

The safety labels are installed on the mower. If a label becomes damaged, illegible or is not on the mower, replace it. The label part number is listed in the parts list.

[RCK60D-26BX]



[RCK54D-26BX]



(1) Part No. K5112-7311-2



(3) Part No. K5384-4715-1



(2) Part No. K5112-7312-2



(4) Part No. K5384-4171-1



2LEOP00023A01enUS

3. Safety labels for loader

The safety labels are installed on the loader. If a label becomes damaged, illegible or is not on the loader, replace it. The label part number is listed in the parts list.

<p>(1) Part No. 7J081-5645-1</p> <p>1A1ABAHAP019G</p>	<p>(2) Part No. 7J246-5641-1</p> <p>1A1ABAHAP017A</p>	<p>(3) Part No. 7J246-5643-1</p> <p>1A1ABAHAP016A</p>	<p>(4) Part No. 7J246-5642-1</p> <p>1A1ABAHAP018A</p>
<p>(5) Part No. 7J246-5644-2</p> <p>1A1ABAHAP020A</p>	<p>(6) Part No. 7J061-5649-1</p> <p>1A1ABACAP084A</p>	<p>1JJD00004A01</p>	
		<p>1JJD00005A01</p>	

1. INFORMATION

(1) Part No. 7J626-3648-1

⚠ DANGER

TO AVOID PERSONAL INJURY OR DEATH

1. Make sure both handles (LH,RH) (A) contact the ear plates (B) at the points and are all the way down.

2. Make sure both lock pins (LH,RH) (C) protrude through the pin slots (D).

(A) HANDLE (B) EAR PLATE (C) LOCK PIN (D) PIN SLOT

Kubota recommends the use of Kubota attachments on Kubota loaders. Non-Kubota attachments, if used, must comply with ISO 24410, first edition 2005-04-15.

Use of a non-Kubota attachment that does not comply with SAE J2513 or the improper positioning of handle(s) or non-protrusion of pin(s) may result in detachment of the attachment or deformation, causing loss of performance, personal injury or death.

For information, contact your Kubota Dealer.

1A1ABELAP0440

(2) Part No. 7J048-3923-4

⚠ DANGER

**PALLET FORK
RATED CAPACITY**

LA403, LA304, LA534	: 600 LBS.
LA434	: 390 LBS.
LA344, LA340	: 240 LBS.


TO AVOID PERSONAL INJURY OR DEATH CAUSED BY ROLLOVER

- Do not exceed rated load listed above.
- Use rear implement and tire ballast recommended in loader operator's manual.
- Operate tractor slowly taking special care when turning.

1A1ABELAP0380

(3) Part No. 7J246-5643-1


⚠ DANGER



TO AVOID SERIOUS INJURY OR DEATH CAUSED BY FALLING LOADS:


1. Load on raised bucket or fork can fall or roll back onto operator causing serious injury or death.
2. Use approved clamping and / or guard attachments for handling large, loose or shiftable loads such as bales, posts, sheets of plywood etc.
3. Carry loads as low as possible.

1A1ABAGAP075A



1JDJD00003A01

[BX2415 Pallet Fork]




4. Safety labels for backhoe

The safety labels are installed on the backhoe. If a label becomes damaged, illegible or is not on the backhoe, replace it. The label part number is listed in the parts list.

DANGER, WARNING AND CAUTION LABELS OF THE BACKHOE

(1) Part No. 75597-7528-1



1HNAAACAP008E

(2) Part No. 75595-7517-2




1HNAAACAP011E

(3) Part No. 75595-7524-2



1HNAAACAP012E

(4) Part No. 7K501-7529-1




1AJABAEAP028A


(5) Part No. 75597-7517-2



1HNAAACAP010E



1PSQW00010A01




1PSQW00011A01

1PSQW00009A01

1. INFORMATION

[BX6316 MECHANICAL THUMB] (Option for BT603)



(1) Part No, 7K523-8452-1 (Both sides)



1PSQW00013A01

SPECIFICATIONS

1. BX tractor specifications

Model			BX23S
PTO power*1			13.2 kW (17.7 HP)
Engine	Maker		KUBOTA
	Model		D902
	Type		Liquid-cooled, 4-cycle diesel
	Number of cylinders		3
	Bore and stroke		72.0 × 73.6 mm (2.83 × 2.90 in.)
	Total displacement		898 cm ³ (54.8 cu. in.)
	Engine gross power*2		17.1 kW (23.0 HP)
	Rated revolution		55.0 to 58.3 r/s (3300 to 3500 rpm)
	Low idling revolution		1350 to 1550 rpm
	Maximum torque		56.1 N · m (41.4 lbf · ft)
	Battery		12 V, CCA: 560 A, RC: 86 min.
	Fuel		Diesel fuel No.1 [below -10 °C (14 °F)] Diesel fuel No.2 [above -10 °C (14 °F)]
Capacities	Fuel tank		25 L (6.6 U.S.gals.)
	Engine crankcase (with filter)		3.3 L (3.5 U.S.qts.)
	Engine coolant		3.1 L (3.3 U.S.qts.)
	Recovery tank		0.4 L (0.4 U.S.qts.)
	Transmission case		11.3 L (2.99 U.S.gals.)
Dimensions	Overall length (without 3p)		2210 mm (87.01 in.)
	Overall length (with 3p)		2515 mm (99.02 in.)
	Overall width (Min. tread)		1145 mm (45.08 in.)
	Overall height	(with ROPS)	2190 mm (86.22 in.)
		(Top of seat)	1255 mm (49.41 in.)
	Wheel base		1400 mm (55.12 in.)
	Min. ground clearance		148 mm (5.83 in.)
	Tread	Front	930 mm (36.6 in.)
		Rear	820 mm (32.2 in.)
Weight (with ROPS)			725 kg (1600 lbs)
Clutch			N/A
Traveling system	Tire	Front: Turf/Bar/industrial	18 × 8.50-10
		Rear: Turf/Bar/industrial	26 × 12.00-12
	Steering		Hydrostatic type power steering
	Transmission		Main: Hydrostatic transmission, High-Low gear shift (2 forward, 2 reverse)

(Continued)

1. INFORMATION

Model			BX23S
Traveling system	Brake		Wet disk type
	Min. turning radius		2.3 m (7.5 ft)
Hydraulic unit	Hydraulic control system		Directional control, auto-return lever system
	Pump capacity		23.5 L/min. (6.21 gals/min)
	System pressure		12.3 to 12.8 MPa (126 to 130 kgf/cm ²) [1790 to 1850 psi]
	3-point hitch		SAE Category 1
	Max. lift force*3	At lift points	5390 N (1212 lbs)
		24 in. behind lift points	3040 N (680.4 lbs)
	Remote control valve coupler (Rear: Option)	System	2 valves
		Coupler	ISO 7241-1 series A
	Remote control valve coupler (Front: Option)	System	2 valves
		Coupler (Fitting)	ISO 7241-1 series B
PTO	Rear PTO	PTO shaft	SAE 1-3/8, 6 splines
		Revolution	STD (2500 rpm)
	Mid PTO	PTO shaft	USA No. 5 (KUBOTA 10-tooth) involute spline
		Revolution	STD (2500 rpm)

*1 Manufacturer's estimate

*2 SAE J1995

*3 See and check "Implement limitation tables".

2. Mower specifications

Model		RCK60D-26BX	RCK54D-26BX
Suitable tractor		BX23S	
Mounting method		Drive-over-quick-joint, parallel linkage	
		Drive-over-suspended-linkage	
Adjustment of cutting height		Dial gauge	
Cutting width		1524 mm (60 in.)	1372 mm (54 in.)
Cutting height		25 to 102 mm (1.0 to 4.0 in.)	
Weight	Mower	115 kg (250 lbs)	103 kg (227 lbs)
	Mower with frame link ^{*1}	134 kg (295 lbs)	122 kg (269 lbs)
Blade spindle speed		44.1 r/s (2647 rpm)	49.5 r/s (2969 rpm)
Blade tip velocity		72.5 m/s (14271 fpm)	73.8 m/s (14527 fpm)
Blade length		523 mm (20.6 in.)	475 mm (18.7 in.)
Number of blades		3	
Dimensions	Overall length	1000 mm (39.4 in.)	928 mm (36.5 in.)
	Overall width	1930 mm (76.0 in.)	1780 mm (66.5 in.)
	Overall height (Min.)	281 mm (11.0 in.)	
Tire		Industrial, turf ^{*2}	

*1 Remove the frame link when rear attachment is on. Remove the frame link when snow attachment is on.

*2 Bar tires are prohibited from driving over mower deck.

3. Loader specifications

3.1 Loader specifications

Loader model		LA340 and LA340S
Tractor model		BX23S
Boom cylinder	Bore	40 mm (1.6 in.)
	Stroke	326 mm (12.8 in.)
Bucket cylinder	Bore	65 mm (2.6 in.)
	Stroke	196 mm (7.72 in.)
Control valve		One detent float position, single bucket dump, power beyond circuit
Rated flow		14 L/m (3.7 GPM)
Maximum pressure		12.8 MPa (131 kg/cm ²) [1860 psi]
Net weight (approximate)		217 kg (478 lbs) ^{*1}


*1 Include the quick bucket 48 in.

3.2 Bucket specifications

Loader model		LA340	LA340S
Model		Square 48 in.	
Type		Rigid	Quick hitch
Width		1219 mm (47.99 in.)	
Depth		491 mm (19.3 in.)	470 mm (18.5 in.)
Height (M)		465 mm (18.3 in.)	523 mm (20.6 in.)
Length (N)		538 mm (21.2 in.)	586 mm (23.1 in.)
Capacity	Struck	0.14 m ³ (4.9 cu.ft.)	0.13 m ³ (4.6 cu.ft.)
	Heaped	0.17 m ³ (6.0 cu.ft.)	
Weight		60 kg (130 lbs.)	56 kg (120 lbs.)


3.3 Dimensional specifications of loader


Loader model		LA340	LA340S
Tractor model		BX23S	
A	Max. lift height (to bucket pivot pin)	1804 mm (71.02 in.)	
B	Max. lift height under level bucket	1662 mm (65.43 in.)	1664 mm (65.51 in.)
C	Clearance with bucket dumped	1323 mm (52.09 in.)	1288 mm (50.71 in.)
D	Reach at max. lift height (Dumping reach)	646 mm (25.4 in.)	677 mm (26.7 in.)
E	Max. dump angle	0.785 rad (45°)	
F	Reach with bucket on ground	1392 mm (54.80 in.)	1438 mm (56.61 in.)
G	Bucket roll-back angle	0.51 rad (29°)	
H	Digging depth	125 mm (4.92 in.)	122 mm (4.80 in.)
J	Overall height in carrying position	990 mm (39.0 in.)	





3.4 Operational specifications of loader

Loader model		LA340	LA340S
Tractor model		BX23S	
U	Lift capacity (Bucket pivot pin, max. height)	335 kg (739 lbs)	278 kg (613 lbs)
V	Lift capacity (500 mm forward, max. height)	231 kg (509 lbs)	192 kg (423 lbs)
W	Lift capacity (Bucket pivot pin, 1500 mm height)	372 kg (820 lbs)	317 kg (699 lbs)
X	Lift capacity (500 mm forward, 1500 mm height)	268 kg (591 lbs)	229 kg (505 lbs)
Y	Breakout force (Bucket pivot pin)	6258 N (1407 lbs)	5719 N (1286 lbs)
Z	Breakout force (500 mm forward)	4389 N (986.7 lbs)	4008 N (901.0 lbs)
VV	Bucket roll-back force at max. height	4731 N (1064 lbs)	4431 N (996.1 lbs)
XX	Bucket roll-back force at 1500 mm height	5557 N (1249 lbs)	5264 N (1183 lbs)
ZZ	Bucket rollback force at ground level	5456 N (1227 lbs)	5195 N (1168 lbs)
Raising time		3.3 s	
Lowering time		2.5 s	
Bucket dumping time		2.7 s	
Bucket rollback time		2.3 s	




LA340

1JDJD00010A01

**LA340S**

1JDJD00011A01



(A) Height (mm)
(B) Lift capacity (kg)

(C) At pivot pin
(D) 500 mm forward of pivot pin

(E) Rollback force (kN)

4. Backhoe specifications

4.1 Backhoe specifications

Digging force (Per SAE J49)

With bucket cylinder	8610 N (1936 lbs)
With dipperstick cylinder	5209 N (1171 lbs)

Cycle time (Seconds)

Boom cylinder, extend	4.5 s
Boom cylinder, retract	3.7 s
Swing cylinder, from 90 degrees to center	1.5 s
Dipperstick cylinder, extend	4.1 s
Dipperstick cylinder, retract	3.4 s
Bucket cylinder, extend	3.1 s
Bucket cylinder, retract	2.4 s
Stabilizer cylinder, max. height to ground	2.9 s
Stabilizer cylinder, ground to max. height	2.3 s

Hydraulic cylinders

	Boom	Dipperstick	Bucket	Stabilizer	Swing
Rod diameter	3.0 cm (1.2 in.)	2.5 cm (0.98 in.)	2.5 cm (0.98 in.)	2.5 cm (0.98 in.)	3.0 cm (1.2 in.)
Cylinder bore	6.5 cm (2.6 in.)	6.0 cm (2.4 in.)	5.0 cm (2.0 in.)	6.0 cm (2.4 in.)	6.0 cm (2.4 in.)

Bucket sizes


	Width	SAE truck capacity	SAE heaped capacity	Number of teeth	Weight
Trenching 8 in.	20.3 cm (7.99 in.)	0.009 m ³ (0.317 cu.ft.)	0.011 m ³ (0.388 cu.ft.)	2	10 kg (22 lbs)
Trenching 12 in.	30.5 cm (12.0 in.)	0.014 m ³ (0.494 cu.ft.)	0.020 m ³ (0.706 cu.ft.)	3	13 kg (29 lbs)
Trenching 16 in.	40.6 cm (16.0 in.)	0.020 m ³ (0.706 cu.ft.)	0.029 m ³ (1.024 cu.ft.)	3	16 kg (35 lbs)

4.2 Backhoe dimensions

Model		BT603
(A)	Transport height	1719 mm (67.68 in.)
(B)	Stabilizer spread-transport	1296 mm (51.02 in.)
(C)	Ground clearance	240 mm (9.45 in.)
(E)	Overall width	1128 mm (44.41 in.)
(F)	Maximum digging depth	1889 mm (74.37 in.)
(G)	Digging depth, 2 ft. flat bottom	1842 mm (72.52 in.)
(H)	Digging depth, 8 ft. flat bottom	1059 mm (41.69 in.)
(J)	Operating height, fully raised	2539 mm (99.96 in.)
(K)	Loading height	1533 mm (60.35 in.)
(L)	Loading reach	1016 mm (40.00 in.)
(M)	Reach from swing pivot	2612 mm (102.8 in.)
(N)	Swing pivot to rear axle center line	726 mm (28.6 in.)
(P)	Bucket rotation	3.14 rad (180°)
(R)	Stabilizer spread-operating	1862 mm (73.31 in.)
(A3)	Angle of departure per SAE J1234	0.351 rad (20.1°)
(U)	Leveling angle	0.19 rad (11°)
Swing arc		2.44 rad (140°)


NOTE

- The specifications are taken with KUBOTA BX23S tractor. (Tire size: Front 18×8.5-10, Rear 26×12.00-12)



4.3 Backhoe lift capacity

The lift capacities shown are 87% of maximum lift force, according to SAE definition.




[A] Rated lift capacity (over end)-kg (lbs)	(D) 209 kg (461 lbs)
(A) 192 kg (423 lbs)	(E) 203 kg (448 lbs)
(B) 212 kg (467 lbs)	(F) 201 kg (443 lbs)
(C) 215 kg (474 lbs)	(G) 214 kg (472 lbs)
	(H) 262 kg (578 lbs)

TRAVELING SPEEDS

Model		BX23S
Tire size (Rear)		26 × 12.00-12
Speed control pedal	Range gear shift lever	(At max. engine rpm)
Forward	Low	0 to 6.5 km/h 0 to 4.0 mph
	High	0 to 13.5 km/h 0 to 8.38 mph
Reverse	Low	0 to 5.0 km/h 0 to 3.1 mph
	High	0 to 10.5 km/h 0 to 6.52 mph

DIMENSIONS



2VTAL00032A01enUS