

いくつかのゲームは PSG カード用に修正が必要です。

以下のゲームは雑誌に掲載されたプログラムのままでは PSG から音が出ません。 以下のように修正してください。

「デストロイエイリアン」

雑誌掲載のダンプリストを入力する際

\$6003 を 1 にする。
\$614C,\$614D を \$FF30 にする。
\$6F1F,\$6F20 を \$FF30 にする。

すでにセーブしたプログラムがある場合

BASIC から以下のように入力してください。

- リスト中のファイル名"DESTROY"はすでにセーブしている名前に変更してください。

```
NEWON17
LOADM"DESTROY"
POKE &H6003,1
POKE &H614C,&HFF
POKE &H614D,&H30
POKE &H6F1F,&HFF
POKE &H6F20,&H30
SAVEM"DESTROY",&H6000,&H762F,&H6000
```

ゲームをロードする際は、PSG カードを PIA モードに設定してください。

「スキッパー」

雑誌掲載のダンプリストを入力する際

\$4B04 番地を 1 にする。

すでにセーブしたプログラムがある場合

BASIC から以下のように入力してください。

- リスト中のファイル名"SKIPPER"はすでにセーブしている名前に変更してください。

```
NEWON3
LOADM"SKIPPER"
POKE &H4B04,1
SAVEM"SKIPPER",&H4B00,&H902F,&H4B00
```

ゲームをロードする際は、PSG カードを VIA モードに設定してください。

Some games require patches for the PSG card.

In the following games, the PSG doesn't sound unless the patch is applied. Please correct it.

“Destroy Alien”

When you will input the dump list from the magazine:

Set 1 on \$6003.
Set \$FF30 on \$614C and \$614D.
Set \$FF30 on \$6F1F and \$6F20.

When you have the saved program:

Input following command on BASIC.

- Replace the file name "DESTROY" on the list to your saved name.

```
NEWON17
LOADM"DESTROY"
POKE &H6003,1
POKE &H614C,&HFF
POKE &H614D,&H30
POKE &H6F1F,&HFF
POKE &H6F20,&H30
SAVEM"DESTROY",&H6000,&H762F,&H6000
```

Set to PIA mode on the PSG card when loading the game.

“Skipper”

When you will input the dump list from the magazine:

Set 1 on \$4B04.

When you have the saved program:

Input following command on BASIC.

- Replace the file name "SKIPPER" on the list to your saved name.

```
NEWON3
LOADM"SKIPPER"
POKE &H4B04,1
SAVEM"SKIPPER",&H4B00,&H902F,&H4B00
```

Set to VIA mode on the PSG card when loading the game.