

Nascom Documentation Library



[1. Introduction to PolyDos](#)

[1.1 The manual](#)

[1.2 Notations](#)

[2. General System Information](#)

[2.1 PolyDos memory organisation](#)

[2.2 Disk formats](#)

[2.2.1 Single density format](#)

[2.2.2 Double density format](#)

[2.3 Replacing disks](#)

[2.4 TAB characters](#)

[2.5 The BREAK function](#)

[3. PolyDos disk drives](#)

[3.1 File specifiers](#)

[3.1.1 File names](#)

[3.1.2 File extensions](#)

[3.1.3 Drive numbers](#)

[3.2 File attributes](#)

[3.3 Family file specifiers](#)

[4. PolyDos operation](#)

[4.1 Power-up](#)

[4.2 Command lines](#)

[4.2.1 Command options](#)

[4.2.2 NAS-SYS commands](#)

[4.3 PolyDos commands](#)

- | | |
|--------------------------------------|--------------------------|
| <u>4.3.1 DIR</u> | – List directory |
| <u>4.3.2 COPY</u> | – Copy files |
| <u>4.3.3 REN</u> | – Rename files |
| <u>4.3.4 DEL</u> | – Delete files |
| <u>4.3.5 UNDEL</u> | – Undelete file |
| <u>4.3.6 LOCK</u> | – Lock files |
| <u>4.3.7 UNLOCK</u> | – Unlock files |
| <u>4.3.8 PACK</u> | – Pack disk |
| <u>4.3.9 SAVE</u> | – Save file |
| <u>4.3.10 LOAD</u> | – Load file |
| <u>4.3.11 ATTRIB</u> | – Change file attributes |
| <u>4.3.12 LIST</u> | – List file |
| <u>4.3.13 SKIP</u> | - Print blank lines |
| <u>4.3.14 BUFFER</u> | - Define RAM buffer |
| <u>4.3.15 NAME</u> | - Rename disk |
| <u>4.3.16 READ</u> | - Read sectors |
| <u>4.3.17 WRITE</u> | - Write sectors |
| <u>4.3.18 NEW</u> | - New disk(s) inserted |

<u>4.3.19 BOOT</u>	- Reboot PolyDos
<u>4.4 Special commands</u>	
<u>4.4.1 EDIT</u>	- Invoke PolyEdit
<u>4.4.2 BASIC</u>	- Invoke Disk Basic
<u>4.5 Executing files</u>	
<u>4.5.1 Standard file types</u>	
<u>4.5.1.1 Machine code program files</u>	
<u>4.5.1.2 Text files</u>	
<u>4.5.2 User defined file types</u>	
<u>5. The boot process</u>	
<u>5.1 Creating a turn-key system</u>	
<u>6. The system files</u>	
<u>7. Error messages</u>	