

# Nascom Documentation Library – Nas-Sys 3



- [1. Introduction](#)
- [2. Summary of Features](#)
- [3. List of Commands](#)
- [4. How to enter a command](#)
- [5. Errors when entering a command](#)
- [6. How to correct typing errors](#)
- [7. Screen editing](#)
- [8. The keyboard](#)
- [9. The reset button](#)
- [10. Scrolling display](#)
- [11. Detailed Description of Commands](#)
  - [A - Arithmetic command](#)
  - [B - Breakpoint command](#)
  - [C - Copy command](#)
  - [D - Start execution at D000 hex](#), cold start for Zeap or NasDos
  - [E - Execute command](#)
  - [G - Generate command](#)
  - [H - Half duplex terminal](#)
  - [I - Intelligent copy command](#)
  - [J - Jump command](#) – starts execution at FFFA hex, cold start for ROM BASIC
  - [K - Keyboard command](#)
  - [M - Modify command](#)
  - [N - Normal command](#)
  - [O - Output command](#)
  - [P - Display program registers](#)
  - [Q - Query command](#)
  - [R - Read command](#)
  - [S - Single step command](#)
  - [T - Tabulate command](#)
  - [U - User I/O command](#)
  - [V - Verify command](#)
  - [W - Write command](#)
  - [X - External command](#)
  - [Y - Y command](#) – start execution at B000 hex
  - [Z - Z command](#), start execution at FFFD hex – warm start for ROM BASIC
- [12. How to enter and test a program](#)
- [13. Display of program registers](#)
- [14. Simple instructions for input and output](#)
- [15. How to end a program](#)
- [16. Nas-Sys restarts and routines](#)
- [17. Nas-Sys Restart Instructions](#)
- [18. Nas-Sys routines](#)

- [19. Input and Output](#)
- [20. Nas-Sys Workspace](#)
- [21. Addressing of Video RAM](#)