

Nascom Documentation Library - CP/M



[CP/M 2.2 Rev 2.1 changes](#)

[1. Hardware Requirements](#)

[1.1 NASCOM 2](#)

[1.2 Minimum memory requirements](#)

[1.3 Boot loader](#)

[1.4 Memory decode PROM](#)

[1.5 Revised header](#)

[1.6 Disk drives](#)

[1.7 FDC card](#)

[1.8 CP/M 2.2 system disk](#)

[2. Starting CP/M](#)

[3. FORMAT](#)

[3.1 Description](#)

[3.2 Using FORMAT](#)

[3.3 Error messages from FORMAT](#)

[3.3.2 Retries](#)

[3.3.3 Miscellaneous errors](#)

[4. NASCOM CP/M error messages](#)

[4.1 Boot errors](#)

[4.1.1 Hardware errors](#)

[4.1.2 Bad disk reads](#)

[4.1.3 Non-system disk](#)

[4.2 BDOS errors](#)

[5. NASCOM CP/M 2.2 software user notes – Rev 2.1](#)

[5.0 Block size](#)

[5.1 Physical I/O devices](#)

[5.2 Special key functions](#)

[5.3 Screen Edit Mode](#)

[5.4 The Auto Load facility](#)

[6. Configuration Utility – Rev 2.1](#)

[6.0 Description](#)

[6.1 Configuration options](#)

[Appendix A CP/M with single drives](#)

[Appendix B NASCOM VDU control codes](#)

[Appendix C Useful BIOS patch locations](#)

[Appendix D I/O routine writers guide](#)

[Appendix E Double / Single sided drive compatibility](#)