

6165529 User Manual

1.How to install CubeCell Arduino Development Environment

Via Git: <https://github.com/HelTecAutomation/ASR650x-Arduino/blob/master/README.md>

Via Arduino Board Manager: https://docs.heltec.cn/#/en/user_manual/how_to_install_ASR650x_Arduino

2.CubeCell Series Source code

Heltec CubeCell series Arduino framework (the basic of CubeCell series products Arduino development environment): <https://github.com/HelTecAutomation/ASR650x-Arduino>

3.HTCC-AB01 Pin out Diagram

<https://github.com/HelTecAutomation/ASR650x-Arduino/blob/master/PinoutDiagram/HTCC-AB01.pdf>

4.Heltec Lora Node Product Difference Table(Product Selection Table)

https://docs.heltec.cn/#/zh_CN/products/lora/lora_node/heltec_lora_node_list_eu

5.Summary of Common Problems(F&Q Page)

https://docs.heltec.cn/#/en/faq/cubecell_series_common_problem_summary