

Set static IP for Raspberry Pi

1. Open config file

```
sudo nano /etc/dhcpd.conf
```

2. Add the following in the config file:

```
interface [NETWORK]
static ip_address=[STATIC_IP]/24
static routers=[ROUTER_IP]
static domain_name_servers=[DNS_IP]
```

3. Example:

```
interface wlan0
static ip_address=192.168.1.128/24
static routers=192.168.1.1
static domain_name_servers=192.168.1.5
```