

Edge Power Meter Faults During Unoccupied Periods

In OnyxxNetwork, link all ZonegCommand points to an And.

Link that And to a new And in each of the (used) Scout devices under ModbusAsyncNetwork.

Remove the link from NumberMeters (a GreaterThan) to a Numeric Switch and link it also to the And.

Link the And to the Numeric Switch.

Save the Edge.

Backup the Edge!