

## Programming a standalone FG controller

The router will need setup: the NAT rule to addresses for 21 and 8888 will change to the IP address.

From the twoprogramserver, run C:\CPT CATALYST Stand Alone\cpt.exe

Switch to the StandAlone tab.

Enter the port, UserName (admin), and clear out the password.

Open.

Press the toolbar button for the backup tool.

From the local tab, upload CATALYSTStandAloneMarch312016.

From the remote tab, restore the file (click restore). The connection will close when completed.

Reopen from the StandAlone tab with the username TWave.

Expand Graphics

Double-click Status

Tools | Full Deploy

Login to the controller from a browser.

IP address of the router:8888

Username: admin

### **Change Economizer to Auto**

Change Heat 1 fan speed to 90%

**SAVE settings**