

## FS VAVs with Heat – fix for heating minimum air flow

At H&M 075, Eric O. noticed that when VAV 08 was forced into heat its airflow setpoint inexplicably dropped from 630cfm to 400cfm.

This is a known issue, since corrected. The solution is to write the heating minimum also to the Auxillary Flow point.

The original VAV in the terminal gateway's Bacnet folder:

