

## ArduPlane Version 2.65

This code description is based partly on APM code outline  
<https://docs.google.com/document/d/1OCEMtCq7Njr-YeEroSsMPQCZNP0QvMxqYPPCJy2zZHI/edit?hl=en&pli=1>

Here only normal flight mode's functions with APM2.5 board are discussed. HIL modes and telemetry are out of the scope.

### ArduPlane.pde

-----

All the basic system and flight variables and structures are declared at the top of this file. User configurations are in APM\_config.h, g defined as Parameter class entity (Parameter.h)

```
static Parameters g;  
  // PID controllers  
  PID    pidNavRoll;  
  PID    pidServoRoll;  
  PID    pidServoPitch;  
  PID    pidNavPitchAirspeed;  
  PID    pidServoRudder;  
  PID    pidTeThrottle;  
  PID    pidNavPitchAltitude;
```

From parameters.h it's can be seen that plane's controllers are PID controllers including attitude angle controllers and servo controllers

```
// All GPS access should be through this pointer.  
static GPS    *g_gps;
```

### setup() Basic Initialization


Calls memcheck\_init() in libraries/memcheck/memcheck.cpp and calls init\_ardupilot() in system.pde to init serial ports, I2C, SPI, data flash, servos, RC and telemetry.

loop() Main system loop. Also know as the outside loop. This calls fast\_loop and medium\_loop.

fast\_loop() This loop should be executed at 50Hz if possible to ensure servos update frequency.

medium\_loop() - this loop is also called at 50Hz but with counter from 0 to 4 each branch is executed at 10 Hz, so the slow\_loop is called at 10 Hz. With counter 0, 1, 2, each branch is executed at  $3\frac{1}{3}$  Hz.

In the table below the main loop is shown



The control process with APM2.5 hardware can be imagined as follow:

ATMEGA 2560 radio input is PPM from ATMEGA 32-U2 with `_timer5_capt_cb()` for reading PPM signal, inputs/outputs are SERIAL0 to ATMEGA 32-U2 to USB (console) for loading software and running simulations, SERIAL1 (GPS data) for communicating with GPS, SERIAL2 or SERIAL0 according to SJ1/4 setting (Xbee telemetry) for telemetry, SPI\_mega bus for communicating with MPU6000 motion processing unit and baro MS5011, SPI\_DF for communicating with data flash chip, and I2C bus connects to magnetometer and I2C port, outputs are pwm outputs from timers to drive servos.

Outputs from RC receiver are connected to APM2.5 board inputs (max 8 channel, channel 8 for mode select). From there they are connected to ATMEGA 32-U2 . ATMEGA 32-U2 combines 8 PWM channels into 1 PPM output. Due to the fact that PPM channel frequency = servo update frequency = 50 Hz, so the PPM cycle is 20 ms and the maximum PWM pulse width is 1900us = 1.9 ms, so maximum 10 PWM channels can be combined into 1 PPM channel. This PPM channel from ATMEGA 32-U2 is used to interrupt ATMEGA 2560. Each time there's a PPM pulse, an interrupt is generated and `APM_RC_APM2.cpp _timer5_capt_cb()` interrupt service routine calculates time intervals between PPM pulses (the ppm pulse width) and saves in `_PPM_RAW[]`.

MPU6000 and pressure sensor MS5011 are connected to SPI\_mega bus, currently with Arduplane, ATMEGA 2560 only reads gyro and accelerator data from MPU6000 to calculate DCM based on the old DCM algorithm but in the future it may use DMP functions to calculate DCM for a beter performance. Besides, ATMEGA 2560 also reads magnetometer data on I2C interface and writes logs to data flash on SPI\_DF bus.

Pulse outputs from 2560 are generated by programmable timers in micro controller as programmed in `OutputCh(uint8_t ch, uint16_t pwm)` in `APM_RC_APM2.cpp` and this is called by `set_servos()` in `attitude.pde`. Maximum 10 pulse outputs can be generated.

Fast \_loop details

```
=====
read_radio() // radio.pde
```

`InputCh(ch)` in `APM_RC_APM2.cpp` reads `_PPM_RAW[ch]`. `read_radio()` then reads all 8 channels and sets pwm accordingly (`radio_in=pwm`).

```
g.channel_roll.set_pwm(APM_RC.InputCh(CH_ROLL));    // if not elevon mixing
g.channel_pitch.set_pwm(APM_RC.InputCh(CH_PITCH));
```

```
g.channel_throttle.set_pwm(APM_RC.InputCh(CH_3));
g.channel_rudder.set_pwm(APM_RC.InputCh(CH_4));
g.rc_5.set_pwm(APM_RC.InputCh(CH_5));
g.rc_6.set_pwm(APM_RC.InputCh(CH_6));
g.rc_7.set_pwm(APM_RC.InputCh(CH_7));
g.rc_8.set_pwm(APM_RC.InputCh(CH_8));
```

If there's a mode set on channel 8, it will be processed in medium\_loopCounter=1 case ( read\_control\_switch(); // control\_modes.pde).

=====

```
//full DCM update
ahrs.update();      // libraries/AP_AHRS/AP_AHRS_DCM.cpp.
```

( Look at DCMDraft2.pdf for more information

<http://code.google.com/p/gentlenav/downloads/detail?name=DCMDraft2.pdf&can=2&q>

also look at <http://gentlenav.googlecode.com/files/RollPitchDriftCompensation.pdf> about driftcorrection)

AP\_InertialSensor\_MPU6000::update() calculates gyro and accelerator vectors used in matrix\_update()

```
matrix_update(delta_t); // Integrate the DCM matrix using gyro inputs
normalize();           // Normalize the DCM matrix
drift_correction();   // Perform drift correction
check_matrix();       // paranoid check for bad values in the DCM matrix
euler_angles();       // Calculate pitch, roll, yaw for stabilization and navigation
```

(This is the most important algorithm of the software that calculates DCM matrix. In the future DMP functions may replace it. I think most of us don't need to understand this in details, it's necessary only in case you want to change the software basis)

=====

```
// uses the yaw from the DCM to give more accurate turns
calc_bearing_error();      // in Navigation.pde.
```

navigate() (navigation.pde) - called in medium\_loop as it needs GPS data, calculates nav\_bearing\_cd = target\_bearing\_cd = get\_bearing\_cd(&current\_loc, &next\_WP) (however for cases of LOITER, RTL, GUIDED nav\_bearing\_cd is changed in update\_loiter() as called in update\_navigation())

For calculating: bearing\_error\_cd = nav\_bearing\_cd – ahrs.yaw\_sensor; nav\_bearing\_cd doesn't change between navigate() calls in medium\_loop but ahrs.yaw\_sensor yes in fast\_loop, so the bearing\_error\_cd changes in fast\_loop that are used in calc\_nav\_yaw and calc\_nav\_roll.

=====

```
// custom code/exceptions for flight modes
// -----
update_current_flight_mode();      // (Arduplane.pde)
```

Most cases (except FBW, STABILIZE, CIRCLE and MANUAL) call calc\_nav\_roll, calc\_nav\_pitch, calc\_throttle (these are in attitude.pde) to calculate nav\_roll\_cd from bearing\_error\_cd, and also calculate throttle, nav\_pitch\_cd.

e.g. `nav_roll_cd = g.pidNavRoll.get_pid(bearing_error_cd, dTnav, nav_gain_scaler).`

In STABILIZE mode, `update_current_flight_mode()` sets `nav_roll_cd = nav_pitch_cd = 0`, so if you release stick that means `read_radio()` gives `radio_in = radio_trim`,

so in `stabilize()` in `attitude.pde`

`ch1_inf = ch2_inf = 1` (see `ch1_inf`, `ch2_inf` calculating in `stabilize()`),

`g.channel_roll.pwm_to_angle() = g.channel_pitch.pwm_to_angle() = 0`, and with

APM\_CONTROL disabled

`g.channel_roll.servo_out =`

`g.pidServoRoll.get_pid((nav_roll_cd - ahrs.roll_sensor), delta_ms_fast_loop, speed_scaler)`

`= g.pidServoRoll.get_pid((0 - ahrs.roll_sensor), delta_ms_fast_loop, speed_scaler)`

(similarly for `g.channel_pitch.servo_out`) so the plane will go back to `nav_roll_cd = nav_pitch_cd = 0` level state.

In CIRCLE mode it sets `nav_roll_cd = g.roll_limit_cd / 3`; `nav_pitch_cd = 0`; So when calling `stabilize()` the error in `get_pid()` `= g.roll_limit_cd / 3 - ahrs.roll_sensor` is coming to 0 i.e. `ahrs.roll_sensor` is coming to `g.roll_limit_cd / 3 = constant`, the plane circles.

In FBW modes, `nav_roll_cd = g.channel_roll.norm_input() * g.roll_limit_cd` and depends only on stick angle. The `nav_pitch_cd` depends on A or B modes.

In MANUAL mode (SOFTWARE MANUAL), `servo_out` values are calculated directly from stick inputs and then sent to servos without calling `stabilize()`.

`g.channel_roll.servo_out = g.channel_roll.pwm_to_angle();`

`g.channel_pitch.servo_out = g.channel_pitch.pwm_to_angle();`

`g.channel_rudder.servo_out = g.channel_rudder.pwm_to_angle();`

=====

`// apply desired roll, pitch and yaw to the plane`

`// -----`

`if (control_mode > MANUAL) stabilize();` `// in Attitude.pde.`

In `stabilize()` if there's an input from sticks in other modes (not FBW), it is mixed with

`servo_out` as `ch1_inf, ch2_inf < 1` `g.channel_roll.servo_out =`

`g.pidServoRoll.get_pid((nav_roll_cd - ahrs.roll_sensor), delta_ms_fast_loop, speed_scaler)`

`tempcalc = nav_pitch_cd +`

`fabs(ahrs.roll_sensor * g.kff_pitch_compensation) +`

`(g.channel_throttle.servo_out * g.kff_throttle_to_pitch) -`

`(ahrs.pitch_sensor - g.pitch_trim_cd);`

`g.channel_pitch.servo_out = g.pidServoPitch.get_pid(tempcalc, speed_scaler);`

`g.channel_roll.servo_out *= ch1_inf;`

`g.channel_pitch.servo_out *= ch2_inf;`

`g.channel_roll.servo_out += g.channel_roll.pwm_to_angle();`

`g.channel_pitch.servo_out += g.channel_pitch.pwm_to_angle();`

=====

```
// write out the servo PWM values
// -----
set_servos();                                // in Attitude.pde
```

Calculates channel\_roll.radio\_out, channel\_pitch.radio\_out, channel\_throttle.radio\_out and channel\_rudder.radio\_out from channel\_...servo\_out and mix\_mode then sends values to the PWM timers for output

```
-----
    APM_RC_APM2.OutputCh(CH_1, g.channel_roll.radio_out); // send to Servos
    APM_RC_APM2.OutputCh(CH_2, g.channel_pitch.radio_out); // send to Servos
    APM_RC_APM2.OutputCh(CH_3, g.channel_throttle.radio_out); // send to Servos
    APM_RC_APM2.OutputCh(CH_4, g.channel_rudder.radio_out); // send to Servos
    // Route configurable aux. functions to their respective servos
    g.rc_5.output_ch(CH_5);
    g.rc_6.output_ch(CH_6);
    g.rc_7.output_ch(CH_7);
    g.rc_8.output_ch(CH_8);
```

Medium\_loop details:

```
=====
update_GPS();
Updates GPS data and GPS light on board and clarifies ground start or air start at the beginning.
```

```
// Read 6-position switch on radio
// -----
read_control_switch();
Reads 6 control modes from channel 8 pulse width and sets flight control modes accordingly
```

```
// calculate the plane's desired bearing
// -----
navigate();
In auto mode calculates navigation bearing to the next waypoint and then verifies if waypoint is reached or missed so that the program can search for the next command (nav or non nav). In loiter relating flight modes (LOITER, RTL, GUIDED) it updates navigation bearing based on the distance to the waypoint.
```

```
// Read altitude from sensors
// -----
update_alt();
Calculates current location altitude based on GPS data and barometer data.
```

```
// altitude smoothing
// -----
```

```
if (control_mode != FLY_BY_WIRE_B)
    calc_altitude_error();
```

Calculates altitude error from the measured altitude and the target one.

```
// perform next command
```

```
// -----
```

```
    update_commands();
```

In auto mode it calls process\_next\_command(). The code of process\_next\_command() includes 2 parts, the first one searches for the next navigation command, the second one searches for the next non navigation command. In any case, if the current command is executed, then the next command is searched and if found then it is processed.

```
Log_Write_
```

Writes logs to flash on SPI\_DF bus based on log bitmask.

```
slow_loop();
```