

Mains & Power Schematic

File: PowerSchematic.kicad_sch

IO

File: IO.kicad_sch

E-Stop, Drive Error, External Error

File: EStop.kicad_sch

ULPanel

File: UL_Panel.kicad_sch

ESP32_DevelKICAD

File: ESP32_DevelKICAD.kicad_sch


CNC76010


File: CNC76010.kicad_sch

to do:

CNCconversion@yahoo.com
Only personal use - no commercial use
Do not distribute without approval
CNC conversion Netherlands


Sheet: /
File: ElectricalSchematic.kicad_sch
Title: **CNC refit imes GFY98**
Size: A3 | Date: 2025-05-10 | Rev: 1.0
KiCad E.D.A. 9.0.1 | Id: 1/7






E-Stop Circuit


In E-Stop Loop (when activated):
 -CNC760 :via Relay 17: provide +24V when activated
 -Spindle VFD :via Relay 18: break Enable Signal
 -Vacuum/Second VFD :via Relay 18: break Enable Signal
 -230VAC switched :via Relay 18: break Enable Signal
 -Servo Drives :via Relay 18: break Enable Signal



Drive Alarm Error (CNC760 AL+ pulled to gnd):



PowerContactor Control: If PC off: CNC760_ExtErr Active




CNC760_ExtErr direct to CNC760, also Input ESP32
 Prevent dependency on ESP32

External Error Circuit


In External Error Loop (when activated):

-Spindle VFD :
 -Vacuum/Second VFD :
 -Limit Switches :
 -ThermalAlarm HSD :
 -DryAirPress :

LimitSwitches NO (parallel)



LimitSwitches NC (series)



VFD Delta MS300 T000;
 APM + GND (manual 6-1 & table 6-3)
 Error Output: M01/M02: option 20; warning output of RY1
 STO: disconnect 24V from S1 & S2

CNCconversion@yahoo.com

Only personal use - no commercial use

Do not distribute without approval

CNC conversion Netherlands

Sheet: /E-Stop, Drive Error, External Error/

File: EStop.kicad_sch

Title: CNC refit lmes GFY98

Size: A4

Date: 2025-05-10

Rev: 1.0

KiCad E.D.A. 9.0.1

Id: 7/7

