


ZoneFlex Advanced

ZoneFlex Manager Configuration Guide

v 2.00

Publication No. 29383677

August 24, 2016



Legal Notices

Information in this document is subject to change without notice. No part of this document may be reproduced or transmitted to parties other than the customer and the customer's employees in any form or by any means, electronic or mechanical, for any purpose, without the express written consent of Intelligrated.

© 2013-2016 Intelligrated. All rights reserved

This document contains confidential proprietary information and trade secrets of Intelligrated. This document is distributed with the understanding that it will not be disclosed to any third party, in whole or part, without the prior written consent of Intelligrated.

Trademarks

Accuglide™, Casemat™, Dashboard™, E-Z-set™, IntelliFlow™, IntelliStar™, I-Watch™, Knowledgebase™, NetLok™, OnTimeParts™, Palmat™, Trak3™, Trak3 xD™, Trak3 xL™, Versa™, and ZoneFlex™ are trademarks of Intelligrated.

Accumat®, Accuzone®, Alvey®, BOSS®, Buschman®, EASYpick®, FKI Logistex®, IN-24x7®, InControlWare®, Intelligrated®, IntelliMerge®, IntelliQ®, IntelliSort®, Mathews®, SNE Systems®, Stearns®, Transitread®, and UniSort® are registered trademarks of Intelligrated.

Product and company names herein may be the trademarks of their respective owners.

ZoneFlex Manager Configurator v2.0.5063

Table of Contents

ABOUT THIS GUIDE	1
1.1 Introduction to ZoneFlex Advanced	1
System Architecture	2
1.2 The ZoneFlex Configurator.....	5
1.3 Documentation Conventions.....	6
1.3.1 Notes, Tips, and Important Information.....	7
GETTING STARTED	9
2.1 Connecting a PC to a ZoneFlex Manager.....	9
2.1.1 Manually Installing the Device Driver.....	15
2.2 Configuring a Secondary Network	16
2.2.1 Testing PC Communication with the ZFM	19
2.3 Installing the ZoneFlex Configurator	20
2.4 Testing the Software/ZFM Connection	23
2.5 Repairing the Configurator	24
2.6 Uninstalling the Configurator	26
ADVANCED ACCUMULATION MODES	29
3.1 Introduction	29
3.2 Accumulation Modes	29
3.2.1 0-Zone Accumulation	30
3.2.2 1-Zone Accumulation	30
3.2.3 2-Zone Accumulation	31
3.2.4 0&1-Zone Accumulation	32
3.2.5 1&2-Zone Accumulation	33
3.2.6 4-Zone Accumulation	34
3.2.7 4&5-Zone Accumulation	35
3.2.8 External Control (Smart Actuator).....	35
3.3 Accumulation and Release Commands.....	36

3.3.1	Discharge Zone Release Command.....	37
3.3.2	Stop Zone Accumulation Command.....	38
3.3.3	Slug and Drop to Gravity Groups.....	39
3.3.4	Manual Override Slug.....	41
3.4	Special Modes and Functions.....	41
3.4.1	Latching	41
3.4.2	Valve Output Inversion	42
3.4.3	Dynamic Auto Slug.....	43
3.4.4	Fixed Auto Slug.....	44
3.4.5	Sleep.....	45
3.4.6	Infeed Wake	46
3.4.7	Global Wake.....	48
3.4.8	Crowding	50
3.4.9	All Clear	50
3.4.10	Sensor Delay	51
3.4.11	Zone Eye Status	51
3.4.12	Jam and Stall.....	52
3.4.13	Speed Regulation	56
3.4.14	Neighborhood Mode	56
3.4.15	Disabled Zone Control	57
3.4.16	Commissioning Mode	57
3.4.17	Diagnostics	58
3.5	ZFM Default Settings.....	58
	GENERATING A CONFIGURATION	63
4.1	Introduction	63
4.2	Software Configuration Overview	63
4.2.1	Starting the Configurator	64
4.2.2	Exiting the Configurator.....	64
4.2.3	Starting a New Configuration.....	65
4.2.4	Entering Project Information	69

4.2.5	Viewing Lane Details	70
4.2.6	Configuring Lane Speeds	72
4.2.7	Configuring Lane Level Settings	72
4.2.8	Configuring Zones	81
4.3	Configuring Fieldbus	87
4.3.1	ZoneFlex Manager's Runtime Data	89
SAVING A CONFIGURATION		93
5.1	Saving an XML Configuration	93
5.2	Saving a ZFB Configuration	94
DOWNLOADING CONFIGURATION FILES		95
6.1	Downloading a Configuration from the ZFC	95
6.2	Deploying a Configuration	97
6.3	Downloading a Configuration from a PLC	97
WORKING WITH CONFIGURATION FILES		99
7.1	Opening an XML Configuration File	99
7.2	Importing a ZFB Configuration File	100
7.3	Reading a ZoneFlex Manager's Configuration	101
APPLICATION GUIDE		103
8.1	Approach and Fine Tuning	103
8.2	Initial ZoneFlex Manager Settings	105
8.3	Set Speed Regulator for Neighborhood Mode	108
TROUBLESHOOTING		109
9.1	Issues and Resolutions	109
9.2	ZFM and Module LEDs	111
9.3	Locating Bad ZFA Module(s) Process	115
9.4	Fieldbus Connections	117
9.4.1	PROFIBUS	117
9.4.2	EtherNetIP	118
9.4.3	DeviceNet	119
9.5	Troubleshooting Help	120

List of Figures

Figure 1-1 ZoneFlex Manager	2
Figure 1-2 ZoneFlex Advanced Module	3
Figure 1-3 ZoneFlex Advanced System Structure	4
Figure 1-4 ZoneFlex Configurator Overview	5
Figure 4-1 ZoneFlex Configurator Executable	64
Figure 4-2 Exit Prompt	65
Figure 4-3 Create New Configuration Screen	66
Figure 4-4 ZoneFlex Manager Configuration Summary	68
Figure 4-5 Project Information	69
Figure 4-6 Topology Summary	70
Figure 4-7 Lane Definition Summary Table	70
Figure 4-8 Lane Detail Screen.....	71
Figure 4-9 Zone Configuration Summary.....	71
Figure 4-10 Configure Lane Speeds.....	71
Figure 4-11 Configure Lane Speeds.....	72
Figure 4-12 Lane Level Delays Tab.....	73
Figure 4-13 Lane Level Signals Tab.....	74
Figure 4-14 Groups Tab	76
Figure 4-15 System Eyes Tab	78
Figure 4-16 Zone Details.....	81
Figure 4-17 Modes Tab	82
Figure 4-18 Zone Delays Tab.....	83
Figure 4-19 Actuator/Sensor Tab	83
Figure 4-20 Zone Speed Regulator Tab	84
Figure 4-21 Zone Signals Tab	85
Figure 4-22 Group Membership Tab	87
Figure 4-23 Fieldbus Configuration Button	87

Figure 8-1 Approach to Tuning ZFA	104
Figure 9-1 ZoneFlex Manager Layout	111
Figure 9-2 ZFA Module with LEDs.....	113
Figure 9-3 Standard LED positions and mounting	117

List of Tables

Table 1-1 Documentation Conventions.....	6
Table 3-1 0-Zone Accumulation States	30
Table 3-2 1-Zone Accumulation States	30
Table 3-3 2-Zone Accumulation States	31
Table 3-4 0&1-Zone Accumulation States	32
Table 3-5 1&2-Zone Accumulation States	33
Table 3-6 4-Zone Accumulation States.....	34
Table 3-7 4&5 Zone Accumulation States	35
Table 3-8 DAS Zone States.....	43
Table 3-9 Fixed Auto Slug States	44
Table 3-10 Sleep Zone States.....	45
Table 3-11 Zone Eye Statuses	51
Table 3-12 Clogged States.....	52
Table 3-13 Drained States.....	53
Table 3-14 Stall States	54
Table 3-15 Push-Thru Settings.....	55
Table 3-16 Jam Zones and Stall States	55
Table 3-17 ZFM Default Settings.....	58
Table 4-1 Configuration Modules and Lanes	67
Table 4-2 ZFM Configuration Summary Fields	69
Table 4-3 Configure Lane Speeds.....	72
Table 4-4 Configure Lane Level Delays.....	73
Table 4-5 Zone Configurations	81
Table 4-6 Zone Delays Tab Fields.....	83
Table 4-7 Actuator/Sensor Tab Selections	84
Table 8-1 Recommended Initial Configurable Settings	105
Table 8-2 Speed Regulator Settings.....	108

Table 9-1 LEDs	114
Table 9-2 Network Status/Operation Mode LED	117
Table 9-3 Module Status LED	118
Table 9-4 Network Status LED	118
Table 9-5 Module Status LED	118
Table 9-6 Link/Activity LED	119
Table 9-7 Network Status LED	119
Table 9-8 Module Status LED	119

About This Guide

1

1.1 Introduction to ZoneFlex Advanced

ZoneFlex™ Advanced provides a network approach to pneumatic zone control for accumulation conveyor. It consists of:

- A ZoneFlex Manager (ZFM)
- ZoneFlex Advanced (ZFA) Modules
- The ZoneFlex Configurator (ZFC) software

A ZoneFlex Manager is an intelligent controller that manages all of the connected ZFA modules. The ZFA modules report the status of inputs to the ZFM and update outputs per the ZFM's instructions.


The ZoneFlex Configurator software is used to generate configurations for the ZoneFlex Manager. The configurations can be saved in XML files or in ZoneFlex Binary (ZFB) files. They can then be downloaded to the ZoneFlex Manager using the USB or fieldbus interface, respectively.


This guide provides the information you will need to create ZoneFlex Manager configurations using the ZoneFlex Configurator. It also provides instructions for downloading the configurations to ZoneFlex Managers.

System Architecture

A ZoneFlex Advanced system consists of a ZoneFlex Manager and one or more ZoneFlex Advanced (ZFA) modules. The ZoneFlex Manager acts as a master that centrally controls and monitors all of the modules in the system. The modules report the status of inputs to the manager and update outputs per the manager's instruction. A single ZoneFlex Manager can support up to 100 modules.

Figure 1-1 ZoneFlex Manager



**Figure 1-2 ZoneFlex Advanced Module**

1. Female Micro Connector

2. Air Supply

3. Port A

4. Port B

5. Air Supply


6. Male Micro Connector

7. Photo-Eye B

8. Power/Communication

9. Power/Communication

10. Photo-Eye A

Figure 1-3 ZoneFlex Advanced System Structure

ZoneFlex Manager is connected at the physical beginning or end of the ZFA module chain. Each module controls two zones.


One NEC Class 2 power supply can operate 28 or 21 modules depending on where it is positioned and the Volts Direct Current (VDC) setting that is used, as follows:

- When connected to the center of a chain of modules, the power supply can power 28 modules. The output VDC should be set to 24.
- When connected to the end of the chain, the power supply can power 21 modules. The output VDC should be set to 27.6.
- Use a Power Isolating Cable to separate power supplies when the module count exceeds these numbers and you have multiple power supplies on the same network. This special cable allows data to traverse the total network, but separates the power.

1.2 The ZoneFlex Configurator

The ZoneFlex Configurator is a software application that is used to generate ZoneFlex Manager configurations. The configurations can be saved in XML or ZoneFlex Binary (ZFB) format. They can then be downloaded to the ZoneFlex Manager using the ZoneFlex Configurator, Machine Control Software (BOSS III, ICW, and MC4), or a PLC.

Figure 1-4 ZoneFlex Configurator Overview



The ZoneFlex Configurator can download both XML and ZFB configurations to a ZoneFlex Manager using the USB connection. Machine Control Software and PLCs can download ZFB configurations to a ZoneFlex Manager using a fieldbus connection.

1.3 Documentation Conventions

Many typographical conventions are used to distinguish between the different types of information presented in this document, as follows:

Table 1-1 Documentation Conventions

Convention	Description
Bold	Used to identify menu selections, toolbar selections, and section references.
<i>Italic</i>	In paragraph text, italics identify the titles of documents that are being referenced. When used in conjunction with the Code text described below, italics identify a variable that should be replaced by the user with an actual value.
<code>monospace text</code>	Used to identify code fragments.
<code><i>monospace italic text</i></code>	Used to identify variables in code fragments.
CTRL+X	A combination of keystrokes that are pressed simultaneously.
Function Function	A path to a function or dialog box within an interface. For example, “Select File Open ” indicates that you should select the Open function from the File menu.
() and	Parentheses enclose optional items in command syntax. The vertical bar separates syntax items in a list of choices. For example, any of the following four items can be entered in this syntax: persistPolicy (Never OnTimer OnUpdate NoMoreOftenThan)

1.3.1 Notes, Tips, and Important Information

The following callouts and icons are used to highlight information throughout this guide:



Note or Tip

A Note highlights related information or information that is tangential to the topic being discussed. A Tip highlights useful information that can be used to simplify the tasks that are being discussed.



Important

Important callouts highlight information of great significance or value that the reader should be certain to know before proceeding.

Getting Started

2

2.1 Connecting a PC to a ZoneFlex Manager

To connect a computer (PC) to a ZoneFlex Manager (ZFM), you will need:

- A Windows 7 PC running version 4.0 of the .NET Framework
- A USB cable
- And, potentially, internet access and an internet browser

When you have these items, complete the following steps.



Important

If this is that first time a ZFM is being connected to the PC, complete the steps below. If, however, a ZFM has been connected to the PC before, you should keep in mind the following:

- Use the same USB port that was used previously to connect the ZFM to the PC. If you do so, the driver will still be configured for the ZFM. If you use a different USB port, a driver will need to be configured for the new port.
- If you are connecting a different ZFM to the PC but using the same USB port, the driver will notice that the ZFM has a different ID. It will prompt use and ask if you want to continue. Select “Yes” to use the new ZFM.



Note



A PC communicates with a ZFM using a special Ethernet over USB driver, creating another network specifically for this link.

1. Plug the B side of the USB cable into the ZFM USB port.



2. Plug the A side of the USB cable into a USB port on the PC. Windows will automatically detect the device and attempt to install the USB EtherNET/RNDIS Gadget. This is the driver that is needed for the ZFM.




Installing device driver software  
[Click here for status.](#)




Note

You might receive an error message indicating that the device driver software was not successfully installed.




Windows displays this message because it does not yet have an IP address for the ZFM. However, it is possible that the driver was installed anyway. Proceed with the steps below to determine if it was properly installed.

3. Click on the Windows **Start** button and select the **Control Panel** option. The Control Panel window is displayed. Select **Device Manager**.






4. The Device Manager window is displayed. Expand the **Network Adapters** group.



5. Look for the **USB EtherNET/RNDIS Gadget**. If it appears in the list, the driver has been properly installed.



If the driver does not appear in the list, you will need to install it manually. (See Section 2.1.1.)

2.1.1 Manually Installing the Device Driver

If Windows does not automatically install a driver for the ZFM, manually install the USB Ethernet/RNDIS gadget by completing the following steps:


1. Download the driver here: <http://beagleboard.org/getting-started#step2>.




Important

If the PC has a 64bit operating system, use the 64bit version of the driver first.

2. Double-click the downloaded file. Follow the screen instructions to progress through the installation.
3. Plug the ZFM into the PC. Windows should detect the ZFM and apply the driver to it.




4. Confirm ZFM driver installation success by going into **Control Panel | Device Manager**. Open the **Network Adapters** list, and confirm that a device appears in that list that has **RNDIS Gadget** in its description. If so, proceed to the next Network Configuration section.



2.2 Configuring a Secondary Network


You will need to configure a secondary network for the ZFM. To do so, complete the following steps:

1. Click on the Windows **Start** button and select the **Control Panel** option. The Control Panel window is displayed.
2. Select **Network and Sharing Center**. The basic network information for the PC is displayed.







3. In the left navigation pane, select **Change Adapter Settings**. A list of networks is displayed. Notice that there are two Local Area Connections. The second (Local Area Connection 2) was created for the USB when the ZFM was detected.



4. Right click on the **Local Area Connection 2** and select **Properties**. A dialog box appears.



- Click on the **Internet Protocol Version 4 (TCP/IPv4)** option and select the **Properties** button. A dialog box appears.



- Select the **Use the following IP address** radio button.
- ZFMs use the following static IP address:

172.18.18.3

In the **IP address** field, enter 172.18.18.X where X is any number except for 3, which is already in use by the ZFM.

- Use the default **Subnet mask** and the **Default gateway**.
- Click **OK** to save your changes.
- Click **OK** to close the Local Area Network Properties dialog box.



2.2.1 Testing PC Communication with the ZFM

Now that the driver has been installed and the ZFM network has been configured, you can test communication with the ZFM. To do so, complete the following steps:

1. Click on the Windows **Start** button and select **Command Prompt**.
2. Type

```
ping 172.18.18.3
```

and press **Enter**. If the PC is communicating with the ZFM, you will receive the following message:

A screenshot of a Windows Command Prompt window titled "Administrator: Command Prompt". The window shows the output of a ping command to 172.18.18.3. The output indicates that the ping was successful with 0% loss and a round trip time of 1ms.

```
Administrator: Command Prompt
Microsoft Windows [Version 6.1.7600]
Copyright (c) 2009 Microsoft Corporation. All rights reserved.

U:\>ping 172.18.18.3

Pinging 172.18.18.3 with 32 bytes of data:
Reply from 172.18.18.3: bytes=32 time=1ms TTL=64
Reply from 172.18.18.3: bytes=32 time<1ms TTL=64
Reply from 172.18.18.3: bytes=32 time<1ms TTL=64
Reply from 172.18.18.3: bytes=32 time<1ms TTL=64

Ping statistics for 172.18.18.3:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 1ms, Average = 0ms

U:\>
```

2.3 Installing the ZoneFlex Configurator

To install the ZoneFlex Configurator (ZFC) software, complete the following steps:



Note


If an earlier version of the ZoneFlex Configurator is installed on the PC, it must be removed before the new version is installed.

1. Download ZoneFlex Configurator installation file from this website by searching the knowledgebase for the term “ZFC:”

<https://dashboard.intelligrated.com/>


You’ll need to create or use an Intelligrated Dashboard account and an email account.

2. Copy the Setup.msi file to the PC that is connected to the ZoneFlex Manager.
3. Double-click the Setup.msi file. The Setup Wizard is displayed.







- Click **Next**. The Installation Folder window is displayed.



- If you do not want to install the software at the default location, click the **Browse** button. A Browser window appears. You can use it to browse to the location where you would like to install the software.



If you are not sure where you would like to install the software or which hard drive has the space to accommodate it, click the **Disk Cost** button. A dialog box appears listing all of the hard drives attached to the computer and the amount of available disk space on each.



It also displays the amount of space that is required for the ZoneFlex Configurator software.

6. If you would like to make the Configurator available to all of the users on the computer, select the **Everyone** radio button. If you only want the Configurator to be visible to your user account, select the **Just Me** button.
7. Click **Next**. A confirmation window appears.
8. Click **Next** to begin the installation. A loading bar appears while the software is installed.


When the installation is complete, the Installation Complete window is displayed.

9. Click **Close** to exit the wizard. You can find the ZoneFlex Configurator at the location that you specified in Step 4.



2.4 Testing the Software/ZFM Connection

You can test that the software is communicating properly with the ZFM by starting the Configurator and selecting **ZFM | ZFM Information**. The software will read the information from the ZFM and display it on the screen.



Tip


If you receive a "GetADI() Exception" error, check the following:

- Make sure the ZFM is *powered up and connected* via USB.
- Be sure you are using the *same USB port* you used when first setting up the driver. Each port is independent.
- Check the driver installation again and be sure the RNDIS Gadget appears in Device Manager as shown in Section 2.1.
- Check the network installation again and be sure you can ping the ZFM as shown in Section 2.1.1.
- Be sure nothing is checked in Internet **Options | Connections** tab | **LAN Settings**.

2.5 Repairing the Configurator

If you need to repair the ZoneFlex Configurator, complete the following steps:


1. Locate the Setup.msi file on the computer.
2. Double-click the Setup.msi file. The Setup Wizard is displayed.




3. Make sure the **Repair ZoneFlexUI** option is selected.



- Click the **Finish** button. A loading bar briefly appears while the wizard repairs the Configurator's files.



When it is finished, an information screen is displayed.




- Click the **Close** button to exit the wizard.

2.6 Uninstalling the Configurator

If you would like to remove the ZoneFlex Configurator from a computer, complete the following steps:

1. Locate the Setup.msi file on the computer.
2. Double click the Setup.msi file. The Setup Wizard is displayed.




3. Make sure the **Remove ZoneFlexUI** option is selected.




4. Click the **Finish** button.

A loading bar appears while the wizard deletes the Configurator's files.



When the wizard is finished, an information screen is displayed.



5. Click the **Close** button to exit the wizard.

Advanced Accumulation Modes

3.1 Introduction

ZoneFlex Manager is configured using either the ZoneFlex Configurator software when DIP Switch 7 is OFF or through the other DIP switch settings when set to Local Mode (DIP Switch 7 ON). A ZoneFlex Manager can operate based on the downloaded configuration or based on the configuration defined by settings of the DIP switches located on the main circuit board. DIP Switch settings are detailed in Table 3-17. Downloadable configurations can be created with the ZoneFlex Configurator software. The configuration determines which accumulation mode is used throughout the system. This chapter describes the accumulation modes, signals, and other advanced features and settings that are available for ZoneFlex Advanced systems.

3.2 Accumulation Modes


Accumulation modes define the basic control logic for staging product on an accumulation conveyor. The logic behind the mode refers to the action of the local zone based on the state of its neighboring zones. For this reason, the logic contains local functions.

3.2.1 0-Zone Accumulation

With 0-Zone accumulation mode, the local zone uses the status of the local zone sensor to determine its operating state. This can be useful as a run-up eye or as a replacement for Gen 1.5 hardware where the valve is physically piped to the upstream eye.

Table 3-1 0-Zone Accumulation States

Zone Sensor State(s)			Operating State(s)	
Local	1 st Downstream	2 nd Downstream	Local Valve	Local Zone
Not Occupied	-	-	Energized	Active
Occupied	-	-	De-energized	Inactive




3.2.2 1-Zone Accumulation

With 1-Zone accumulation mode, the local zone uses the status of the first downstream zone sensor to determine its operating state. The discharge zone is inactive when a system is configured for 1-Zone because there is not an immediate (i.e., first) downstream zone sensor. An external release command is required for the discharge zone to become active.

Table 3-2 1-Zone Accumulation States

Zone Sensor State(s)			Operating State(s)	
Local	1 st Downstream	2 nd Downstream	Local Valve	Local Zone
-	Not Occupied	-	Energized	Active
-	Occupied	-	De-energized	Inactive




3.2.3 2-Zone Accumulation

With 2-Zone accumulation mode, the local zone uses the status of the second downstream zone sensor to determine its operating state. The discharge zone and its upstream zone are inactive when a system is configured for 2-Zone because there is not a second downstream zone sensor. An external release command is required for both zones to become active.

Table 3-3 2-Zone Accumulation States

Zone Sensor State(s)			Operating State(s)	
Local	1 st Downstream	2 nd Downstream	Local Valve	Local Zone
-	-	Not Occupied	Energized	Active
-	-	Occupied	De-energized	Inactive




3.2.4 0&1-Zone Accumulation

With 0&1-Zone accumulation mode, the local zone uses the status of the local zone sensor and the first downstream zone sensor to determine its operating state. The discharge zone functions as it would with 1-Zone accumulation because there is not an immediate (i.e., first) downstream zone sensor.

Table 3-4 0&1-Zone Accumulation States

Zone Sensor State(s)			Operating State(s)	
Local	1 st Downstream	2 nd Downstream	Local Valve	Local Zone
Not Occupied	Not Occupied	-	Energized	Active
Occupied	Not Occupied	-	Energized	Active
Not Occupied	Occupied	-	Energized	Active
Occupied	Occupied	-	De-energized	Inactive




The diagram illustrates the 0&1-Zone Accumulation configuration. It shows three zones: Z_{L-1} (green), Z_L (red), and Z_{L+1} (green). A large grey arrow labeled "Product Flow" points from left to right above the zones. Each zone has a blue sensor icon. Above the red zone Z_L and the green zone Z_{L+1} , there are brown rectangular blocks representing accumulation points. The red zone Z_L is the local zone, and the green zone Z_{L+1} is the first downstream zone.

3.2.5 1&2-Zone Accumulation

With 1&2-Zone accumulation, the local zone uses the status of the first downstream zone sensor and the second downstream zone sensor to determine its operating state. The discharge zone is inactive because there is not an immediate (i.e., first) or second downstream zone sensor. An external release command is required for the discharge zone to become active. The upstream zone of the discharge zone operates as a 1-Zone because there is not a second downstream zone sensor.

Table 3-5 1&2-Zone Accumulation States

Zone Sensor State(s)			Operating State(s)	
Local	1 st Downstream	2 nd Downstream	Local Valve	Local Zone
-	Not Occupied	Not Occupied	Energized	Active
-	Occupied	Not Occupied	Energized	Active
-	Not Occupied	Occupied	Energized	Active
-	Occupied	Occupied	De-energized	Inactive




The diagram illustrates the 1&2-Zone Accumulation configuration. It shows three zones: Z_L (red), Z_{L+1} (green), and Z_{L+2} (green). A large arrow labeled "Product Flow" points from left to right. Above Z_{L+1} and Z_{L+2} are brown rectangular blocks representing tanks. Each zone has a small blue square sensor icon. Z_L is the local zone, Z_{L+1} is the first downstream zone, and Z_{L+2} is the second downstream zone.

3.2.6 4-Zone Accumulation

With 4-Zone accumulation, the local zone uses the status of the fourth downstream zone sensor to determine its operating state. Typically, this mode is used for a non-accumulating curve.

Table 3-6 4-Zone Accumulation States

Zone Sensor State(s)			Operating State(s)	
Local	4 th Downstream*	5 th Downstream*	Local Valve**	Local Zone
-	Not Occupied	-	Energized	Active
-	Occupied	-	De-energized	Inactive
*Downstream of the of the curve			**Local immediately before the curve	





3.2.7 4&5-Zone Accumulation

With 4&5-Zone accumulation, the local zone will use the status of the fourth and the fifth downstream zone sensor to determine its operating state. Typically, this mode is used for a non-accumulating curve.

Table 3-7 4&5 Zone Accumulation States

Zone Sensor State(s)			Operating State(s)	
Local	4 th Downstream*	5 th Downstream*	Local Valve**	Local Zone
-	Not Occupied	Not Occupied	Energized	Active
-	Occupied	Not Occupied	Energized	Active
-	Not Occupied	Occupied	Energized	Active
-	Occupied	Occupied	De-energized	Inactive
*Downstream of the of the curve			**Local immediately before the curve	

3.2.8 External Control (Smart Actuator)

External control allows manual control of the zone valve. In this logical mode, a zone's operating state will follow the state of the configured command input. Zones that are in External Control mode are evaluated by the upstream zone's accumulation mode logic. For example, if the zone upstream of a zone in External Control mode is in 1-zone mode, that zone will follow the state of the eye in the zone that is in External Control mode. The smart actuators are configured using a user interface. The command input can be from a network level control, discrete input to the ZFM GPIO or a direct signal on the auxiliary input of a ZFA module.

3.3 Accumulation and Release Commands

Release commands are used to manually control product flow after accumulation has occurred. Using a release command will force a zone to become active. Accumulation commands are used to force a zone to become inactive so that product will accumulate. Both types of commands are applied externally using one of the following methods:

- Network level control using the fieldbus (i.e., PROFIBUS, DeviceNET, EtherNET/IP)
- Discrete input to the ZoneFlex Manager GPIO (Default)
- Auxiliary input on a ZFA module (for discharge zone only)




Important

For certain commands that are sent using the fieldbus (e.g., discharge zone release, external control), the user should make sure the active state is 1 (True). If the fieldbus connection is lost or if it errors out, the state of these commands will be set to 0 (False). This ensures that the command will only initiate when the fieldbus is active and not in an error state.

3.3.1 Discharge Zone Release Command

The Discharge Zone release command forces a discharge zone to become active for the duration of the command. Upstream product is then transported per the individual accumulation mode settings in each zone.



3.3.2 Stop Zone Accumulation Command

The Stop Zone accumulation command is used to manually force a zone to become inactive for the duration of the command. Zones included in a slug region that is upstream of a stopped zone are transported per the individual zone accumulation modes as long as the Stop Zone command is being asserted. A stopped zone is reported as accumulated to upstream zones.

The Stop Zone command is configured using a user interface. Zones will respond to a Stop Zone command from a network level control, discrete input to the ZFM GPIO, or a direct signal on the auxiliary input of a ZFA module.




Note

The auxiliary input/output serves a dual purpose; if the auxiliary output is enabled by a controller, the auxiliary input will go to an enabled or high state. If the zone is configured as a Stop Zone, it will stop. Therefore, the auxiliary output should not be controlled in a zone that is configured as a stopped zone.


3.3.3 Slug and Drop to Gravity Groups

Slug and Drop to Gravity groups are select group zones that are forced active (Slug) or inactive (Drop to Gravity) for the duration of an external command. The zones for each group are defined using a user interface. It is possible to define up to six independent Slug or Drop to Gravity groups for which any zone can be selected. All zones of a given group must be either Slug or Drop to Gravity. A given zone can be selected for both a Slug Group and a separate Drop to Gravity Group but will operate as Drop to Gravity when it receives both commands. The external command to trigger the Slug/Gravity group can be from a network level control, discrete input to the ZFM GPIO or a direct signal on the auxiliary input of a ZFA module.


The following example illustrates Slug Groups:




Or, a command for Slug Group #2 is applied instead. Slug Group #2 is configured so that the first and last zones become active.




All zones are active awaiting product.



A command for Drop to Gravity Group #1 is applied at the ZFM. Drop to Gravity Group #1 is configured for all zones in this example.



A command for Drop to Gravity Group #2 is applied at the ZFM. Drop to Gravity Group #2 is configured for the middle two zones in this example.





3.3.4 Manual Override Slug

A Manual Override Slug group can also be defined to provide a method for clearing jam conditions. By default, all zones are members of this group. This mode is only active while the signal is high. A Manual Override Slug can only be configured to be selected by GPIO.

3.4 Special Modes and Functions

3.4.1 Latching


The purpose of latching is to reflect that product was purposely released from a zone. For example, if a small carton causes a zone to be de-energized but stops past the zone sensor, the zone is actually still occupied and the latched Zone Sensor State would reflect that until the zone was energized.

Latching is a configurable by zone, Zone Sensor State conditioner. When the sensor detects product, the latch is set (blocked). In order for the latch to be reset (clear), the sensor has to be cleared and the valve output has to be energized. If latching is disabled for a zone the Zone sensor State will follow the value of the zone sensor, subject to the energized state.

3.4.2 Valve Output Inversion

The normal valve output state is Air-to-Drive. However, there are cases where the valve output state needs to be inverted to support Air-to-Brake. This can be configured at the zone level and has no effect on the local zone's logic mode. It should be noted that this inverted operating state may not be failsafe.

The zones in an accumulating curve require the valve to operate as Air-to-Brake (AtoB) instead of Air-to-Drive (AtoD).





3.4.3 Dynamic Auto Slug

If any zone configured for Dynamic Auto Slug (DAS) is clear and its immediate downstream zone is also clear then all contiguous upstream zones that are configured for DAS will become active. A Blocked state on either of the zones that triggered the DAS will stop the DAS operation and return the upstream zones to Local Accumulation Mode.

If local DIP switches 4 and 7 are ON, then all zones on a given zone control network are configured for DAS; otherwise, with local DIP switch 7 OFF, this is configured by zone through the user interface.

Table 3-8 DAS Zone States

Zone State(s)		Operating State(s)
Local	1 st Downstream	Upstream Zone(s)
Blocked	Blocked	Per Local Logic Mode
Blocked	Clear	
Clear	Blocked	
Clear	Clear	All Upstream Dynamic Auto Slug Zones Active
All zones are configured for Dynamic Auto Slug and 1-Zone Accumulation. The furthest downstream zone pictured is active.		
		
The furthest downstream two (2) consecutive zones pictured are clear which causes all upstream zones to become active.		
		

Dynamic Auto Slug Delay

DAS delay is a lane setting that extends the time until DAS is engaged with a time delay. The time delay is configurable between 0-30 seconds using a user interface.


3.4.4 Fixed Auto Slug

Fixed Auto Slug, previously known as Local Slug, links the local zone operating state to the first downstream zone. The local zone becomes active when the first downstream zone is active. It will become inactive as set by the accumulation mode if the first downstream zone is inactive.


Table 3-9 Fixed Auto Slug States

Zone State(s)		Operating State
Local	1 st Downstream	Local Zone
Inactive	Inactive	Per Local Logic Mode
Inactive	Active	Active
Active	Inactive	Per Local Logic Mode
Active	Active	Active

The local zone is configured for Fixed Auto Slug and all zones are configured for 1-Zone accumulation. The 2nd downstream zone is active.



The 1st downstream zone is active due to 1-Zone accumulation logic. The local zone is therefore also active due to Fixed Auto Slug. This occurs even though 1-Zone accumulation logic determines the local zone should be accumulated.



3.4.5 Sleep


Sleep is a temporary state that zones enter if the zone's sensor (photo eye) and the zone photo eye in the first and second upstream zones have been Clear for a configurable period of time. The time delay will reset if any of the pertinent zone sensors become Blocked. A zone in Sleep is considered inactive.

Sleep is used to cut down on noise and wear on rollers by not running the conveyor's rollers when product has not been detected.

The infeed zone will use only its local zone sensor to determine its Sleep operating state. The downstream zone of the infeed zone will use the status of its local zone sensor and the infeed zone sensor to determine its Sleep operating state.

Table 3-10 Sleep Zone States

Zone Sensor State(s)			Time Delay		Operating State
2 nd Upstream	1 st Upstream	Local	Start	Expire	Local Zone
Clear	Clear	Clear	X	-	Active
			X	X	Inactive
Clear	Clear	Blocked	-	-	Per Local Logic Mode
Clear	Blocked	Clear	-	-	
Blocked	Clear	Clear	-	-	
Clear	Blocked	Blocked	-	-	
Blocked	Clear	Blocked	-	-	
Blocked	Blocked	Clear	-	-	
Blocked	Blocked	Blocked	-	-	




Sleep Delay

The Sleep Delay is a configurable time in seconds that will cause a zone to enter the Sleep state as described above. A setting of 0 for delay will effectively turn off the sleep function. The setting is a lane level setting but applies to each zone as described in Sleep above. This can be set via a user interface.

3.4.6 Infeed Wake


Infeed wake forces an infeed zone to become active after sleeping for the duration of an external infeed wake command. Infeed wake will respond to a command from a network level control, discrete input to the ZFM GPIO or a direct signal on the auxiliary input of a ZFA module. Downstream zones exit sleep mode as instructed by the sleep logic. The infeed zone will not sleep as long as an infeed wake command is present; the sleep timer will resume running on removal of the wake command as if it were the upstream photo-eye. The normal behavior of the GPIO for wake is normally low, set high to signal wake, the normal behavior of the auxiliary input is high, set low to signal wake. This allows a photo-eye connected to the auxiliary input to be used to signal wake. When used as the infeed wake signal, both the GPIO and auxiliary input signal state can be inverted.



-continued-



Product is detected at the infeed zone which causes the first downstream zone and second downstream zone to exit Sleep due to the Sleep logic. Note that the Infeed Wake command is not necessarily applied.




Tip

Rather than install a separate photo-eye upstream of the conveyor to trigger *Infeed Wake*, select any unused signal (i.e., an unused GP Input) with the *Signal Picker* and set the *Active State* to "0." This will result in the 2 infeed zones ignoring "sleep" ensuring product travel from the supply conveyor makes it to the infeed zone photo eye which propagates the wake as the product advances through the zones.


3.4.7 Global Wake

Global wake forces all zones in a given zone control network to become active after having slept for the duration of an external global wake command. The command is configured using a user interface. Global wake will respond to a command from a network level control, discrete input to the ZFM GPIO, or a direct signal on the auxiliary input of a ZFA module. No zone will sleep as long as a global wake command is in force. The sleep timer will resume running on removal of the command, as if it were the upstream photo-eye. The normal behavior of the GPIO for Global wake is normally low, set high to signal wake, the normal behavior of the auxiliary input is high, set low to signal wake. This allows a photo-eye connected to the auxiliary input to be used to signal wake. When used as the infeed wake signal, both the GPIO and auxiliary input signal state can be inverted.





The Global Wake command is applied at the ZFM. All zones exit Sleep and become active



Tip

In applications where the accumulator is set to use Neighborhood and Sleep together, especially at high speeds, it is recommended to use global wake to wake the whole conveyor. Rather than install a separate photo eye, it is recommended to set the global wake signal to be the photo eye of the infeed zone. Be sure the active state is set to "0" for this signal since light operated photo-eyes turn off when product blocks them. This is best when used in conjunction with the tip for Infeed Wake.

3.4.8 Crowding

Crowding is a local control strategy that attempts to minimize product gap on an accumulated local zone by pulsing the local zone active and inactive. It begins when a local zone is accumulated for a set time delay and the first downstream zone is reporting as Crowded or is not set for Crowding. A local zone not configured for Crowding will always report as Crowded to the first upstream zone. A discharge zone cannot be configured for Crowding but will always report as Crowded.

When Crowding, the local zone will run for the configured Crowding Duration at a percentage of the Lane Max Speed as configured in Crowding Percentage and will then report as Crowded if the photo-eye does not clear.



Note

To start a new segment of Crowding, set Disable Crowding in a zone. This can often decrease the time required to crowd a line.

A zone is configured for Crowding using a user interface. The Crowding delay is configurable from 0-30 seconds and the Crowding Duration (run time) is configurable from 0-10 seconds.

3.4.9 All Clear

All Clear provides an indication that all zones on a lane have not been occupied for a set period of time. The state is reported as configured to a ZFA Module Aux Output or as a ZFM GPIO Output and is also available over a network level control. It is configurable from 0-30 seconds for each individual zone using a user interface. If any zone becomes occupied, the All Clear indication for the lane is canceled.

3.4.10 Sensor Delay


Sensor Delay is a time delay placed on a zone sensor signal. There are both accumulation and release sensor delays. Lane level Sensor Delays apply to all zones in a lane. Zone level Sensor Delays apply to an individual zone sensor. Both accumulation and release sensor delays are configured between 0-30 seconds using a user interface or network level control. When used in Local Mode, an accumulation delay of one second can be applied using a ZFM DIP switch. If the ZFC is used and a Local Sensor Delay is set to 255, the zone will use the lane level setting.

3.4.11 Zone Eye Status

Zone Eye Status provides the logical state with latching applied, if enabled, of a configured zone sensor. The state is reported as configured to a ZFA Module Aux Output or as a ZFM GPIO Output and is also available over a network level control. When the logical state of the eye is clear, the output is ON.

By default, the status of three Zone Eyes are provided. The zones reported are based on the number of zones in a given zone control network as shown in the algorithm in the following table. These can be modified by the user.

Table 3-11 Zone Eye Statuses

Zone Eye	Location	Example
infeed zone = n	$n =$ number of zones	
S1	$Z_{((n-3)/2)}$	
S2	$Z_{(3 \cdot (n-3)/4)}$	
S3	$Z_{(n-3)}$	

The intent of default Zone Eye Status is to provide a "50%," "75%," and "100%" lane full indication.



Note

The default values are minimized if the zone control network contains more than one lane.



Note

Users should verify that the location of the zone eye isn't impacted in an unintended manner by the configuration of the zones around it. For example, if a zone eye that was intended as a flow control eye was calculated to be interior to a section of zones configured as 4&5-Zone accumulation, it might not detect back-up conditions as intended.

3.4.12 Jam and Stall


Jam and Stall are control strategies for when product is not being transported in a zone as expected. They are local evaluations for each zone in a zone control network. Stall is the preamble to Jam. Both require definition of some additional zone states that are unique to their operation, as described in the following sections.

Clogged

The Clogged state indicates an apparent or potential obstruction in a zone. A local zone is labeled "Clogged" if the local zone sensor is blocked for a set period of time. This period of time is called the Clogged Delay. The Clogged Delay resets when the local zone sensor becomes clear. A default Clogged Delay of 12 seconds is applied to all zones. It is configurable from 0-30 seconds for each individual zone using a user interface.

Table 3-12 Clogged States

Sensor State	Clogged Delay		Jam and Stall State
Local Zone	Start	Expire	Local Zone
Clear	-	-	Not Clogged
Blocked	X	-	Not Clogged
	X	X	Clogged




Drained

The Drained state indicates a complete lack of product flow. A local zone is labeled as Drained if the local zone sensor is clear for a set period of time. This period of time is called the Drained Delay. The Drained Delay resets when the local zone sensor becomes blocked. A default Drained Delay of ten seconds is applied to all zones. It is configurable from 0-30 seconds for each individual zone using a user interface.

Table 3-13 Drained States

Sensor State	Drained Delay		Jam and Stall State
	Start	Expire	Local Zone
Blocked	-	-	Not Drained
Clear	X	-	Not Drained
	X	X	Drained




Stall

A Stall state indicates that product movement has been impaired or that a zone sensor is misaligned. A local zone is labeled “Stalled” when the zone has been labeled “Clogged” and its first downstream zone is labeled “Drained.” A Stall will clear if the local zone sensor is cleared. A zone Stall state is available over a network level control.

Table 3-14 Stall States

Zone Jam and Stall State(s)		Operating State
Local	1 st Downstream	Local
Drained	Drained	Per Local Logic Mode
Drained	Clogged	Per Local Logic Mode or Downstream Stall conditions
Clogged	Drained	Push-Thru per setting
Clogged	Clogged	Per Local Logic Mode or Downstream Stall conditions



Push-Thru

Push-Thru occurs when a Stall is declared by the local zone. It couples the local zone operating state (i.e., Active/Inactive) to the first upstream zone(s). This attempt to push product through the Stall will cease if the Stall is cleared. There are three Push-Thru settings, as follows:

Table 3-15 Push-Thru Settings

#	Setting	Description
1	No Push-Thru	Stall will result in no additional action in the upstream zones.
2	1-Zone Push-Thru	The first upstream zone operating state is coupled to the local zone operating state.
3	2-Zone Push-Thru	The first and second upstream zone operating states are coupled to the local zone operating state. In local mode, 2-Zone Accumulation will result in 2-Zone Push-Thru.

The setting can be selected using a user interface. 1-Zone Push-Thru is the default.

Jam

Jam indicates that product transport has essentially stopped due to a Stall that could not be successfully pushed through. A local zone is labeled Jammed when it has been labeled Stalled and the first upstream zone (if in 1 Zone Push-Thru) and the second upstream zone (if in 2 Zone Push-Thru) have been labeled Clogged. Jam disables Push-Thru from a Stall, allows all upstream zones to operate per their local logic mode, and cancels any upstream slug release.

Table 3-16 Jam Zones and Stall States

Mode	Zone Jam and Stall State(s)			Operating State
	2 nd Upstream	1 st Upstream	Local	Local Zone
Jam (Gray is 1 Zone Push Through only, entire table is for 2 Zone)	Drained	Drained	Stall	Per Local Logic Mode
	Drained	Clogged	Stall	
	Clogged	Drained	Stall	
	Clogged	Clogged	Jam	



Note

A Stalled state is only reported through a fieldbus interface. A Stalled state is not assignable to an output.

3.4.13 Speed Regulation

Speed Regulation is a control strategy that uses Pulse-Width Modulation (PWM) (US Patent 5,823,319) to change the effective speed of the product. The Speed Regulator function is called to control the valve, regardless of release or accumulation mode, and uses passed data to modulate the state of the valve to create the effective reduced speed. The current perceived speed and the current state of the valve will be taken into consideration whenever the requested effective speed is changed.

3.4.14 Neighborhood Mode

Neighborhood Mode is an algorithm that is used to ensure gentle handling of product at higher than typical conveyor speeds. It selects the appropriate effective speed for individual zones based on the states of multiple upstream and downstream zones (i.e., a neighborhood). The intent is to better control acceleration and deceleration of transported product on an accumulation conveyor. This in turn allows the accumulation conveyor to transport faster with a higher product density. Each zone monitors the accumulation state and the effective speed of the downstream zone to determine what effective speed it should be using.

Neighborhood Mode can be enabled on a zone-by-zone basis using the configuration software and can be applied to 3' or 6' zones that do not include a brake module. The mode uses configurable settings for acceleration, deceleration, and speed regulation for a zone by continually evaluating upstream, approaching product flow and downstream accumulation status. The default values can be modified by adjusting the Speed Regulator settings.

3.4.15 Disabled Zone Control

The actuator in zones that are configured as disabled zones follows the state of the Aux input in that zone. In this mode, the amber LED for that zone follows the state of the actuator. Since the zone is configured as disabled, it is not evaluated as a zone in the logic of the other zones in that lane. There is no additional configuration beyond disabling the zone required.



Note

This mode can be useful for controlling a brake module.



Important

During configuration, zones are configured as disabled as part of the topology configuration. Changes to the topology reset the entire topology and lane/zone configurations.

3.4.16 Commissioning Mode

The purpose of Commissioning Mode is to simplify commissioning and troubleshooting of the electrical and mechanical components of the conveyor line by placing all the ZFA modules in the network in a known, and simple, mode. Commissioning Mode is selected by pressing the Commissioning Button on the ZFM for more than 3 seconds. The green LED on the ZFM will flash and the Amber System Status LED on the ZFA modules will blink to indicate that the network is in Commissioning Mode. Commissioning Mode is cancelled by pressing the Commissioning Button for more than 3 seconds. Cycling the power of the ZFM will also clear Commissioning Mode. When the ZFM exits Commissioning Mode it will return to normal accumulation logic mode operation.

In Commissioning Mode, non-disabled ZFA Module valve outputs are active when the sensor input for a zone is high and are inactive when the sensor input is low.

3.4.17 Diagnostics

Jam and Stall states, if configured, are available over a network level control. The LEDs on both the ZFM and the ZFA modules indicate status and errors. Refer to the next section for definition of the LED states.

3.5 ZFM Default Settings

The following table contains the default values for the various configurable items in the ZoneFlex Manager. When you turn ON the ZFM for the first time, these settings will be in use.

Table 3-17 ZFM Default Settings

Item	Default Value or Assignment	Notes
GPIO	IN1 = Release IN2 = Group 1 Activate (Slug) IN3 = Global Wake IN4 = Infeed Wake IN5 = Manual Override Slug Group Active IN6 = Group 2 Activate (Drop to Gravity) OUT1 = Jam Detected OUT2 = Zone Eye Status 1 (S1) OUT3 = Zone Eye Status 2 (S2) OUT4 = Zone Eye Status 3 (S3)	Infeed Wake's Active State = 0, which causes the two infeed zones to ignore sleep. S1 Zone # = $(n-3)/2$ (50 %) S2 Zone # = $(3*(n-3)/4)$ (75%) S3 Zone # = $(n-3)$ (100%)
Discharge Zone (Zone 1)	Accum Mode = 1-Zone NOT a Member of Group 1 (Slug) Member of Group 2 (Drop to Gravity) Member of Manual Override Slug Group Latching = Disabled Valve Output Inversion = Disabled Accumulation Delay = 255 (sec) Release Delay = 255 (sec) External Control = Disabled Stop Zone = Disabled Crowding = Disabled Clogged = 12 sec Drained = 10 sec Push-Thru = 1-Zone	If = 255, use lane value If = 255, use lane value



Item	Default Value or Assignment	Notes
Discharge Zone (Zone 1) (-continued-)	Dynamic Auto Slug = Disabled Fixed Auto Slug (Local Slug) = Disabled Neighborhood = Disabled Accel = 200 (ft/min/sec) Decel = 35 (ft/min/sec) LengthOfZone = 36 (inches) MinRegulatorOnTime = 0.35 (sec) MinRegulatorOffTime = 0.35 (sec) ZoneSpeedMin = 0 (ft/min) ZoneSpeedMax = 200 (ft/min) Crowding = Disabled Crowding Delay = 0 (sec) Crowding Duration = 2 (sec) Crowding % = 15%	
Zone 2	Accum Mode = 1-Zone Member of Group 1 (Slug) Member of Group 2 (Drop to Gravity) Member of Manual Override Slug Group Latching = Disabled Valve Output Inversion = Disabled Accumulation Delay = 255 (sec) Release Delay = 255 (sec) External Control = Disabled Stop Zone = Disabled Crowding = Disabled Clogged = 12 sec (0 to disable) Drained = 10 sec (0 to disable) Push-Thru = 1-Zone Dynamic Auto Slug = Disabled Fixed Auto Slug (Local Slug) = Disabled Neighborhood = Disabled Accel = 200 (ft/min/sec) Decel = 35 (ft/min/sec) LengthOfZone = 36 (inches) MinRegulatorOnTime = 0.35 (sec) MinRegulatorOffTime = 0.35 (sec) ZoneSpeedMin = 0 (ft/min) ZoneSpeedMax = 200 (ft/min) Crowding = Disabled Crowding Delay = 0 (sec) Crowding Duration = 2 (sec) Crowding Percent = 15%	If =255, use lane value If =255, use lane value Jam is enabled.

[illegible]



Item	Default Value or Assignment			Notes
Neighborhood Mode	MaxReleaseSpeedPct = 100 LaneFullSpeed = 200 fpm OverrideRegulatorOnIdle = TRUE			Don't pulse when idle.
ZFM DIP 1	ON = A-B Product Flow OFF = B-A Product Flow			
ZFM DIP 2 & 3	OFF = 0 ON = 1			
	DIP 3	DIP 2	Mode	
	0	0	0 & 1 Zone	
	0	1	1 Zone	
	1	0	2 Zone	
	1	1	Future (1 Zone)	
ZFM DIP 4	ON = Dynamic Auto Slug Enabled OFF = Dynamic Auto Slug Disabled			
ZFM DIP 5	ON = Sensor Delay Enabled Globally OFF = Sensor Delay Disable Globally			
ZFM DIP 6	ON = Sleep Mode Enabled OFF = Sleep Mode Disabled			*When sleep is enabled in Local Mode, two infeed zones stay on
ZFM DIP 7	ZFM Active Settings: ON = based on DIP Switch settings OFF = based on downloaded Config			Changes to other DIP switches require power or DIP 7 to be cycled in order for the changes to be applied.
S1	Commissioning Button			Press and hold for > 3 seconds to enter commissioning mode. Press and hold for > 3 seconds to exit commissioning mode. With no slaves connected, press and hold for > 6 seconds to delete the current configuration (will need reconfigured after)
ZFA x (1 set of 3 LEDs for each zone)	Green ON = sensor Clear Green OFF = sensor Blocked Green Slow Blink = Zone is asleep Red ON = Zone Disabled Red Fast Flash (120 Hz) = Jam Red Med Flash (60 Hz) = Stall Red Slow Flash (30 Hz) = Clogged Amber ON = Valve Energized Amber OFF = Valve De-energized			Accounts for dark activated eyes

Item	Default Value or Assignment	Notes
ZFA System Status LED	Green ON = Communicating with ZFM Yellow Blink = Commissioning Mode Red Fast Flash – Network Topology error, doesn't match configuration.	EtherCAT network All available and expected modules will fast flash.

Generating a Configuration

4.1 Introduction

You'll use the ZoneFlex Configurator to specify configuration settings for a ZoneFlex Manager. You will then save the configuration and download it to the ZoneFlex Manager.

This chapter describes how to specify configuration settings.

4.2 Software Configuration Overview

These are the general steps you'll use to generate a ZoneFlex Manager configuration. Each step is described in more detail in the sections and chapters that follow.

In the ZoneFlex Configurator:

1. Start a new configuration. (See Section 4.2.3.)
2. Enter project information. (See Section 4.2.4.)
3. Configure lane speeds. (See Section 4.2.6.)
4. Configure lane level settings. (See Section 4.2.7.)
5. Configure zones. (See Section 4.2.8.)
6. Configure a fieldbus, when applicable. (See Section 4.3.)

7. Save the configuration. (See Chapter 5.)
8. Download the configuration to a ZoneFlex Manager or transfer it to a Machine Control Software controller or PLC. (See Chapter 6.)

4.2.1 Starting the Configurator

To start the ZoneFlex Configurator:

1. Locate the application on the PC. This is the same location that you specified in Step 4 of the installation process.
2. When you locate the executable file, double-click on it to start the application.

Figure 4-1 ZoneFlex Configurator Executable




4.2.2 Exiting the Configurator

To close the Configurator:

1. Go to the **File** menu and select **Exit**.
2. If you have an open configuration and you have made changes to the file, a prompt will appear.

Figure 4-2 Exit Prompt




3. If you would like to save the configuration, select **Yes**. If you would like to discard the file, select **No**. Select **Cancel** to keep the Configurator running.
4. If you select **Yes**, a Browser window will appear allowing you to select a location for storing the file. The Configurator will save the configuration and close once you have selected a location.

4.2.3 Starting a New Configuration

When the ZFC is started, the window is empty. To start creating a configuration:

1. Go to the **File** menu and select **New Configuration**. The first configuration screen is displayed.

Figure 4-3 Create New Configuration Screen



ZoneFlex Configurator
File ZFM Help

Create New Configuration

Number of Modules 10 Initial Module Side ☒ A ☐ B

Module Definitions

Module No.	Has Crossover	IO Slot A Disabled	IO Slot B Disabled
1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
8	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Lane Definitions

Select No. of Lanes ☐ 1 ☒ 2 ☐ 3 ☐ 4 ☐ 5

Lane No.	Lowest Module	Highest Module	Highest Module Role	Adjustments
1	Low: 1-A	High: 5-B	Infeed	<input type="text"/>
2	Low: 6-A	High: 10-B	Infeed	<input type="text"/>

Generate Topology



Note

If you want to work with an existing configuration, **Open**, **Import**, and **Read** functions are available. For more information, refer to Section 7, “Working with Configuration Files.”



This screen allows you to define the number of modules and lanes in the network. Complete the fields on this screen as follows:

Table 4-1 Configuration Modules and Lanes

Group	Field	Description
	Number of Modules	Complete this field with the number of ZoneFlex Advanced modules that are connected to the ZoneFlex Manager. When you do, the Module Definitions table will be populated with one row of information for each module. The range of this field is 1 - 100.
	Initial Module Side	The side of the first ZFA module (i.e., A or B) to which the ZFM is attached.
Module Definitions	Has Crossover	If the B side of the first ZFA is the side to which the ZFM is attached, a crossover is required. A-to-A and B-to-B connections also require crossovers. Crossovers are always placed before the ZFA modules.
Module Definitions	IO Slot A Disabled/ IO Slot B Disabled	Conveyor sections are sometimes made up of an odd number of zones. Enabling these checkboxes disables any unused module's I/O slot.
Lane Definitions	Select No. of Lanes	Select the radio button that represents the number of conveyor lanes that are present in the network. The number of rows in the Lane Definitions table will increase to represent the number of lanes you selected.
Lane Definitions	Highest Module Role	Select the role of the highest module number in the lane: infeed or discharge.
Lane Definitions	Adjustments	Use the Adjustments slider to adjust the range of modules in each lane. Moving the bar to the left reduces the number of modules in the lane while moving it to the right increases the number. Be sure that the resulting range identically matches the physical installation of the modules.




Tip

If this project utilized Intelligrated's ICAD-E plugin to AutoCAD Electrical to develop stick drawings for the accumulating conveyors, you can save a *.zfe extract file. This file saves time since it contains all of the above information. Use the **File | New Configuration (AutoCAD)** menu option to open this file.

- When you have finished defining the lanes and modules in the network, the Configurator has enough general information to create a schematic description of the arrangement of the network, which is known as the topology.

To create the description, click the **Generate Topology** button. The Configuration Summary is displayed.

Figure 4-4 ZoneFlex Manager Configuration Summary





4.2.4 Entering Project Information

The Configuration Summary screen contains an overview of the ZoneFlex Advanced network that you are configuring. The fields at the top of the screen contain general information about the network and about the configuration file you are creating.

Figure 4-5 Project Information

ZoneFlex Manager - Configuration Summary	
Project Name	ZFM Project
ZFM Name	ZFMDefault
IPAddress	172.18.18.3
Description	Project Description
Topo Mark	01/23/2014 15:56:28 UTC
Params Mark	01/23/2014 15:56:28 UTC
Fieldbus Mark	01/23/2014 15:56:28 UTC
CFGIdent = 20140123155628 0102020 20140123155628 20140123155628	

Table 4-2 ZFM Configuration Summary Fields

Field	Description												
Project Name	The name of the customer for which the system is being installed. You can also include a location to distinguish between the installation sites for that customer.												
ZFM Name	The name that has been assigned to this ZoneFlex Manager. One customer site can have any number of ZoneFlex Manager networks. This name helps to distinguish between them.												
IP Address	The IP address of the ZoneFlex Manager, which is the IP address for communication across the USB port. This should remain 172.18.18.3.												
Description	A description of the network and/or project.												
Topo Mark	The UTC time when the topology was generated.												
Params Mark	The UTC time when the last parameter was changed.												
Fieldbus Mark	The UTC time when the fieldbus configuration was changed.												
CFGIdent	<p>A unique identification number for the configuration. It is comprised of the Topo Mark, information about the modules and zones, and the Params Mark, as follows: TTTTTTTTTTTT MMMLZZZ PPPPPPPPPPPP FFFFFFFFFFFFFF</p> <p>Where:</p> <table> <tr> <th>Variable</th><th>Description</th></tr> <tr> <td>$T_1 - T_{14}$</td><td>The Topo Mark value, which can be found immediately below the CFGIdent field.</td></tr> <tr> <td>MMM</td><td>The number of modules in the configuration.</td></tr> <tr> <td>L</td><td>The number of lanes.</td></tr> <tr> <td>ZZZ</td><td>The number of active zones in the configuration.</td></tr> <tr> <td>$P_1 - P_{14}$</td><td>The Params Mark value, which can be found below the Topo Mark field.</td></tr> </table>	Variable	Description	$T_1 - T_{14}$	The Topo Mark value, which can be found immediately below the CFGIdent field.	MMM	The number of modules in the configuration.	L	The number of lanes.	ZZZ	The number of active zones in the configuration.	$P_1 - P_{14}$	The Params Mark value, which can be found below the Topo Mark field.
Variable	Description												
$T_1 - T_{14}$	The Topo Mark value, which can be found immediately below the CFGIdent field.												
MMM	The number of modules in the configuration.												
L	The number of lanes.												
ZZZ	The number of active zones in the configuration.												
$P_1 - P_{14}$	The Params Mark value, which can be found below the Topo Mark field.												

Field	Description	
	F_1-F_{14}	The Fieldbus Mark value, which can be found below the Params Mark.

Below the general information is a Topology Summary.

Figure 4-6 Topology Summary

Topology Summary	
Total Modules	10
Total IOSlots	20
Active IOSlots	20
Disabled IOSlots	0
Total Crossovers	0

4.2.5 Viewing Lane Details

The Lane Definition Summary table on the Configuration Summary screen displays the lane information that you entered on the Create New Configuration screen. It also contains a button that allows you to view detailed information about each lane.


Figure 4-7 Lane Definition Summary Table

Lane Definition Summary						
Lane No.	# Zones	Infeed Zone	Discharge Zone	Infeed Boundary	Discharge Boundary	To Detail
1	11	11 (6-A)	1 (1-A)	6-A	1-A	Lane Detail
2	1	1 (6-B)	1 (6-B)	6-B	6-B	

To configure the details for a lane, click on the lane in the summary table. A **Lane Detail** button appears in the **To Detail** column. Click on the button to display the Lane Detail screen for the selected lane.



Figure 4-8 Lane Detail Screen



The Lane Detail screen provides the information and settings you need to configure lane settings, zones, accumulation modes, and special modes/functions. The information at the top left of the screen is a summary of the information that you entered on the previous screens.

Figure 4-9 Zone Configuration Summary

Total Zones	Zone Boundary Control ECNode				
10	Infeed	10	5-B	5-B	6-B
	Discharge	1	1-A	1-A	10-A

The fields and checkbox at the top right of the screen are used to enter a maximum lane speed, maximum release speed percent, and the regulator override on Idle function.

Figure 4-10 Configure Lane Speeds

Lane Max Speed (ft/min)

200

Max. Release Speed (%)

100

☒ Override Regulator on Idle

The tabs in the center of the Lane Detail screen are used to configure lane level settings. The tabs at the bottom of the screen are used to configure individual zones.

Use the **Back** button to return to the Configuration Summary screen.

4.2.6 Configuring Lane Speeds

Figure 4-11 Configure Lane Speeds

Lane Max Speed (ft/min)	Max. Release Speed (%)
200	100
<input checked="" type="checkbox"/> Override Regulator on Idle	

Complete the fields and checkbox as follows:

Table 4-3 Configure Lane Speeds

Element	Description
Lane Max. Speed	The maximum allowable speed for this lane in feet/minute. The range for this field is 1 – 650. This speed is typically dictated by the equipment that is in use.
Max. Release Speed	The maximum allowable release speed for this lane given as a percentage. The range for this field is 0 – 100. This is also known as the Speed Regulator.
Override Regulator on Idle	Indicate whether, when the zone is idle, it should follow the regulated speed or remain at full speed (recommended). Remaining at full speed saves air and is less noisy.

4.2.7 Configuring Lane Level Settings

The Delays, Signals, Groups, and System Eyes tabs are used to configure settings that are on the lane level in scope. Whenever a zone makes use of a mode or function that requires a lane level setting, the value that you enter in this group of tabs will be used.

Configuring Lane Level Delays

The Delays tab contains fields that allow you to enter time delay lane level values. Accumulation and Release delay settings here will only affect zones whose corresponding delay is set to 255. A zone's corresponding Accumulation and Release Delay set at 255 will direct the logic to use the lane level setting. Any value other than 255 in a zone's Accumulation and Release Delay setting will override the lane level setting for that zone.



Figure 4-12 Lane Level Delays Tab

Lane Details

Delays | **Signals** | Groups | System Eyes

Delay Name	Time (secs)
Dynamic Auto-Slug	<input type="text" value="0"/>
Accumulation	<input type="text" value="1"/>
Release	<input type="text" value="0"/>
Sleep	<input type="text" value="1"/>
All Clear	<input type="text" value="1"/>

The time delays are described as follows:

Table 4-4 Configure Lane Level Delays

Time Delay	Description
Dynamic Auto Slug	The Dynamic Auto Slug (DAS) time delay is in seconds. For additional information about DAS, refer to Section 3.4.3.
Accumulation	The amount of time that the photo-eye is blocked before the zone is considered accumulated (depending on the accumulation mode in use). The range for this field is in seconds.
Release	The delay between when the photo-eye becomes clear and the release occurs. The range for this field is in seconds.
Sleep	The Sleep time delay is the amount of time a zone's photo-eye must remain Clear prior to entering Sleep. The value is in seconds. For additional information about Sleep mode, refer to Section 3.4.5.
All Clear	All Clear indicates that all zones on a lane have not been occupied for a set period of time. The time delay is the period of time that must transpire before All Clear is activated. The range for this field is in seconds. For additional information about All Clear mode, refer to Section 3.4.9.

Configuring Lane Level Signals


Signals can be used to trigger ZoneFlex Manager special functions and to report status. For inputs, an Active State selection of "1" will trigger the function when the input is ON. Conversely, an Active State selection of "0" will trigger the function when the input is OFF. For outputs (status) an active state selection of "1" will turn the output ON when the status condition is true while an active state selection of "0" will turn the output ON when the status condition is false.

Figure 4-13 Lane Level Signals Tab

Lane Details				
Delays	Signals	Groups	System Eyes	
Function	Signal Name	Active State	M	Command
Global Wake Input	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
Infeed Wake Input	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
Release Input	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
Jam Output	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
All Clear Output	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker

To configure a signal, complete the following steps:

1. Locate the function or status for which you want to configure a signal. For information about the different functions, refer to Sections 3.3 and 3.4.
2. Select the desired active state for the function or signal. Active State is described in detail in section above.
3. Click the **Signal Picker** button in the **Command** column. The signal picker dialog box appears.



The Signal Picker Dialog box is titled "Signal Picker Dialog" and shows "Global Wake Input" as the selected function. It has two radio buttons at the top: "ZoneFlex Manager Signals" (selected) and "ZoneFlex Module Signals". Below these are several radio buttons for signal selection: "None" (selected), "ZM1GPI - General Purpose Input 1", "ZM2GPI - General Purpose Input 2", "ZM3GPI - General Purpose Input 3", "ZM4GPI - General Purpose Input 4", "ZM5GPI - General Purpose Input 5", and "ZM6GPI - General Purpose Input 6". At the bottom, it says "Selected Signal None" and has "OK" and "Cancel" buttons.

4. Select the **ZoneFlex Manager Signals** radio button to display the inputs and outputs that are available on the ZoneFlex Manager. Select the **ZoneFlex Module Signals** radio button to display the inputs and outputs that are available on the ZoneFlex Advanced modules.
5. Make a selection from the list of signals.



6. Click **OK** to save your selection and close the dialog box. Notice that the name of the signal you selected now appears in the **Name** column and it is shaded orange to indicate that it is not the current default.

Lane Details				
Delays	Signals	Groups	System Eyes	
Function	Signal Name	Active State	M	Command
Global Wake Input	1001AXI	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
Infeed Wake Input	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
Release Input	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
Jam Output	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
All Clear Output	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker



Note

The **M** identifies signals that have been referenced more than once. It is a visual cue to alert you to that fact, even if the signal has been referenced more than once intentionally.

7. At this point, decide if you would like to restore the previous default or make the new signal the default for this function. If you make the new signal the default, you will not be able to revert back to the previous default.

If you would like to make the signal you selected the default for that function, right click on the name of the signal in the **Name** column and select **Set as New Default** from the context menu. The orange shading will be removed to indicate that the signal is now the default.

If you would like to revert back to the previous default, select **Restore Previous Default** from the context menu. This option is not available once you have set a new default.


8. Repeat Steps 1 through 7 for each of the functions that you will be using in your ZoneFlex Advanced network.

Configuring Groups

Zones can be assigned to groups which can then be forced to Slug mode or Drop to Gravity mode. A zone can be a member of more than one group.

In the **Groups** tab you can specify up to six groups and determine whether each is a Slug or Drop to Gravity group type.

Figure 4-14 Groups Tab




Group	Type	Signal Name	Active State	Command
Group1	<input checked="" type="radio"/> Slug <input type="radio"/> Gravity	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1	Signal Picker
Group2	<input type="radio"/> Slug <input checked="" type="radio"/> Gravity	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1	Signal Picker
Group3	<input type="radio"/> Slug <input checked="" type="radio"/> Gravity	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1	Signal Picker
Group4	<input type="radio"/> Slug <input checked="" type="radio"/> Gravity	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1	Signal Picker
Group5	<input type="radio"/> Slug <input checked="" type="radio"/> Gravity	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1	Signal Picker
Group6	<input type="radio"/> Slug <input checked="" type="radio"/> Gravity	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1	Signal Picker
Override Slug Group	<input checked="" type="radio"/> Slug <input type="radio"/> Gravity	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1	Signal Picker

To configure a group, complete the following steps:

1. Locate the group that you want to configure in the **Group** column.
2. Enable the **Slug** radio button if you would like it to be a Slug group. Enable the **Gravity** radio button if you would like it to be a Drop to Gravity group. For information about Slug and Drop to Gravity groups, refer to Section 3.3.3.
3. Select the **0** or **1** Active State radio button to indicate when the group should be activated. If 1 is selected (recommended), the group will be activated when the signal is ON. If 0 is selected, the group will be activated when the signal is OFF.



- Click the **Signal Picker** button in the **Command** column. The signal picker dialog box appears.



- Select the **ZoneFlex Manager Signals** radio button to display the inputs and outputs that are available on the ZoneFlex Manager. Select the **ZoneFlex Module Signals** radio button to display the inputs and outputs that are available on the ZoneFlex Advanced modules.
- Make a selection from the list of signals.
- Click **OK** to save your selection and close the dialog box. Notice that the name of the signal you selected now appears in the **Name** column and it is shaded orange to indicate that it is not the current default.

Lane Details					
Delays	Signals	Groups	System Eyes		
Group	Type	Signal Name	Active State	M	Command
Group1	<input checked="" type="radio"/> Slug <input type="radio"/> Gravity	ZM2GPI	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
Group2	<input type="radio"/> Slug <input checked="" type="radio"/> Gravity	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
Group3	<input type="radio"/> Slug <input checked="" type="radio"/> Gravity	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1		Signal Picker
Group4	<input type="radio"/> Slug <input checked="" type="radio"/> Gravity	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1		Signal Picker
Group5	<input type="radio"/> Slug <input checked="" type="radio"/> Gravity	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1		Signal Picker
Group6	<input type="radio"/> Slug <input checked="" type="radio"/> Gravity	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1		Signal Picker
Override Slug Group	<input checked="" type="radio"/> Slug <input type="radio"/> Gravity	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker



Note

The **M** identifies signals that have been referenced more than once. It is a visual cue to alert you to that fact, even if the signal has been referenced more than once intentionally.

8. At this point, decide if you would like to restore the previous default or make the new signal the default for this function. If you make the new signal the default, you will not be able to revert back to the previous default.

If you would like to make the signal you selected the default for that function, right click on the name of the signal in the **Name** column and select **Set as New Default** from the context menu. The orange shading will be removed to indicate that the signal is now the default.

If you would like to revert back to the previous default, select **Restore Previous Default** from the context menu. This option is not available once you have made a signal the default.

9. Repeat Steps 1 through 8 for each of the groups in your ZoneFlex Advanced network.

Configuring System Eyes

The System Eyes tab allows you to configure the status monitoring of three zone photo-eyes. Generically labeled as S1/S2/S3, these are by default (and typically) used to report Full Level of the Lane as 50%, 75%, and 100% full respectively. When the topology is created from a configuration containing only a single lane, an algorithm within the ZFC is used to populate these three fields to the zone numbers that would typically be used for reporting 50%, 75%, and 100% full.


Figure 4-15 System Eyes Tab

Lane Details					
Delays	Signals	Groups	System Eyes		
System Eye	Zone	Signal Name	Active State	M	Command
S1	0	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
S2	0	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
S3	0	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker



To configure a signal for a photo-eye, complete the following steps:

1. Locate the photo-eye that you want to configure in the **System Eye** column.
2. Enter the number of the zone to which the photo-eye is attached in the **Zone** field.
3. Select the 0 or 1 radio button to configure the active state of the signal. Active State 0 will turn the output signal ON when the photo-eye is blocked. Active State 1 will turn the output on when the photo-eye is clear.
4. Click the **Signal Picker** button in the **Command** column. The signal picker dialog box appears.



5. Select the **ZoneFlex Manager Signals** radio button to display the inputs and outputs that are available on the ZoneFlex Manager. Select the **ZoneFlex Module Signals** radio button to display the inputs and outputs that are available on the ZoneFlex Advanced modules.
6. Make a selection from the list of signals.

7. Click **OK** to save your selection and close the dialog box. Notice that the name of the signal you selected now appears in the **Name** column and it is shaded orange to indicate that it is not the default.

Lane Details					
Delays	Signals	Groups	System Eyes		
System Eye	Zone	Signal Name	Active State	M	Command
S1	0	ZM2GPO	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
S2	0	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker
S3	0	None	<input type="radio"/> 0 <input checked="" type="radio"/> 1		Signal Picker



Note

The **M** identifies signals that have been referenced more than once. It is a visual cue to alert you to that fact, even if the signal has been referenced more than once intentionally.

8. At this point, decide if you would like to restore the previous default or make the new signal the default for this function. If you make the new signal the default, you will not be able to revert back to the previous default.

If you would like to make the signal you selected the default for that function, right click on the name of the signal in the **Name** column and select **Set as New Default** from the context menu. The orange shading will be removed to indicate that the signal is now the default.


If you would like to revert back to the previous default, select **Restore Previous Default** from the context menu. This option is not available once you have made a signal the default.

9. Repeat Steps 1 through 8 for each photo-eye that you want to configure.

4.2.8 Configuring Zones

The Zone Details portion of the screen consists of two groups of settings. The upper grouping is used to select the zone that will be configured. The lower grouping of tabs is used to configure the zone.

Figure 4-16 Zone Details



Use the slider to select the zone that you want to configure. To increment/decrement the zone number by one, click above/below the slider. Notice that as you change the zone number, the Module, ECN Node, and ECN Offset values change to reflect the correct information for each zone.

The default configuration on the Modes, Delays, Actuator/Sensor, Signals, and Group Membership tabs will also change depending on the zone that is selected, as follows:


Table 4-5 Zone Configurations

Zone	Configuration
Zone 1	Zone 1 has a unique default configuration.
Zone 2	Zone 2 has a unique default configuration.
Zones 3- <i>N</i>	Zones 3 through <i>N</i> share a common default configuration. It is easy to propagate a change in any zone (from 3- <i>N</i>) to all other zones (from 3- <i>N</i>). To do so, change a configuration option, right click on it, and select Set as New Default for Zones 3-N . The new option will be set and be the default for zones 3 through <i>N</i> .

Configuring Accumulation Modes

The Modes tab allows you to choose the accumulation characteristics for the selected zone.

Figure 4-17 Modes Tab



The screenshot shows the 'Modes' tab in a configuration window. The window has several tabs: 'Modes', 'Delays', 'Actuator/Sensor', 'Speed Regulator', 'Signals', and 'Group Membership'. The 'Modes' tab is active and contains the following sections:

- Accumulation:** A list of radio buttons for selecting accumulation modes: '0 Zone' (selected), '1 Zone', '2 Zone', '0 & 1 Zone', '1 & 2 Zone', '4 Zone', '4 & 5 Zone', and 'External Override Input'. Below this is a table with columns 'Signal Name', 'Active State', and 'Command'. The 'Signal Name' column has a 'None' entry. The 'Active State' column has radio buttons for '0' and '1'. The 'Command' column has a 'Signal Picker' button.
- Push-Thru:** A list of radio buttons: 'None', '1 Zone' (selected), and '2 Zone'.
- Crowding:** A checkbox for 'Enabled' (checked), a 'Delay (secs)' input field with '0', a 'Duration (secs)' input field with '0', and a 'Percent (%)' input field with '50'.
- Neighborhood:** A checkbox for 'Enabled' (checked) and a 'Zone Length (in)' input field with '36'.
- AutoSlug:** Two checkboxes: 'Fixed' and 'Dynamic' (checked).

For information about the various modes, functions, and settings that are available, refer to **Chapter 3, Selecting an Advanced Accumulation Mode**.



Note

Configuring Crowding and Neighborhood Mode is reasonably easy when using **Chapter 8, Application Guide**. The recommended initial settings provided in this chapter offer a best practice starting point for these features.



Configuring Zone Delays

The Delays tab is used to configure delays that are unique to each zone.

Figure 4-18 Zone Delays Tab

Complete the fields on the Delays tab as follows:

Table 4-6 Zone Delays Tab Fields

Field	Description
Accumulation Delay	The amount of time that the photo-eye is blocked before the zone is considered accumulated (depending on the accumulation mode in use). The range for this field is in seconds. Use the number 255 to indicate that the lane level setting should be used.
Drained Delay	A default Drained Delay of 10 seconds is applied to all zones. It can be modified to between 0 and 30 seconds for each individual zone.
Clogged Delay	A default Clogged Delay of 12 seconds is applied to all zones. It can be modified to between 0 and 30 seconds for each individual zone.
Release Delay	The amount of time between when the photo-eye becomes clear and the release occurs. The range for this field is 0 – 30 seconds. Enter 255 to indicate that the lane level setting should be used.

Configuring Actuators and Sensors

The Actuator/Sensor tab is used to specify the behavior of the actuator and the interpretation of the photo-eye state for each zone.

Figure 4-19 Actuator/Sensor Tab

The selections on this tab are described as follows:


Table 4-7 Actuator/Sensor Tab Selections

Group	Selection	Description
Actuator	Normal	Solenoid valve is energized for motion.
Actuator	Inverted	Solenoid valve is de-energized for motion.
Sensor	Light Operated	Sensor is ON when clear. This is dictated by the type of sensor that is in use.
Sensor	Dark Operated	Sensor is ON when blocked. This is dictated by the type of sensor that is in use.
Sensor	Latching	The logical state of the sensor remains blocked until motion is commanded, regardless of the photo-eye state.

Configuring the Speed Regulator

The Speed Regulator tab allows you to configure the neighborhood characteristics for the selected zone.

Figure 4-20 Zone Speed Regulator Tab



Mode	Value	Unit
Acceleration	200	ft/min/sec
Deceleration	35	ft/min/sec
Zone Speed Min	0	ft/min
Zone Speed Max	200	ft/min
Min Reg On Time	35	msec
Min Reg Off Time	35	msec

For information about the various settings that are available, refer to **Chapter 3, Selecting an Advanced Accumulation Mode**.



Note

Configuring Neighborhood Mode and the associated Speed Regulator is reasonably easy when using **Chapter 8, Application Guide**. The recommended initial settings provided in this chapter offer a best practice starting point for these features.

Configuring Zone Signals


Signals can be used to trigger ZoneFlex Manager special functions and to report status. For inputs, an Active State selection of 1 will trigger the function when the input is ON. Conversely, an Active State selection of 0 will trigger the function when the input is OFF. For outputs (status) an Active State selection of 1 will turn the output ON when the status condition is true while an Active State selection of 0 will turn the output ON when the status condition is false.

Figure 4-21 Zone Signals Tab

Signal	Signal Name	Active State M	Command
Stop Input	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1	Signal Picker
Logical PE Output	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1	Signal Picker
Auxilliary Output	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1	Signal Picker

To configure a signal, complete the following steps:

1. Locate the function that you want to configure in the **Signal** column.
2. Select the desired active state for the function or signal. Active state is described in detail in section above (Configuring Zone Signals).
3. Click the **Signal Picker** button in the **Command** column. The signal picker dialog box appears.



The Signal Picker Dialog box is titled "Signal Picker Dialog" and has a subtitle "Global Wake Input". It contains two radio buttons: "ZoneFlex Manager Signals" (selected) and "ZoneFlex Module Signals". Below these are six radio buttons for "None", "ZM1GPI - General Purpose Input 1", "ZM2GPI - General Purpose Input 2", "ZM3GPI - General Purpose Input 3", "ZM4GPI - General Purpose Input 4", "ZM5GPI - General Purpose Input 5", and "ZM6GPI - General Purpose Input 6". At the bottom, it says "Selected Signal None" and has "OK" and "Cancel" buttons.

4. Select the **ZoneFlex Manager Signals** radio button to display the inputs and outputs that are available on the ZoneFlex Manager. Select the **ZoneFlex Module Signals** radio button to display the inputs and outputs that are available on the ZoneFlex Advanced modules.
5. Make a selection from the list of signals.
6. Click **OK** to save your selection and close the dialog box. Notice that the name of the signal you selected now appears in the **Name** column and it is shaded orange to indicate that it is not the current default.

Signal	Signal Name	Active State	M	Command
Stop Input	ZM3GPI	<input type="radio"/> 0 <input checked="" type="radio"/> 1	M	Signal Picker
Logical PE Output	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1		Signal Picker
Auxilliary Output	None	<input checked="" type="radio"/> 0 <input type="radio"/> 1		Signal Picker



Note

The **M** identifies signals that have been referenced more than once. It is a visual cue to alert you to that fact, even if the signal has been referenced more than once intentionally.

7. At this point, decide if you would like to restore the previous default or make the new signal the default for this function. If you make the new signal the default, you will not be able to revert back to the previous default.

If you would like to make the signal you selected the default for that function, right click on the name of the signal in the **Name** column and select **Set as New Default** from the context menu. The orange shading will be removed to indicate that the signal is now the default.


If you would like to revert back to the previous default, select **Restore Previous Default** from the context menu. This option is not available once you have made a signal the default.

8. Repeat Steps 1 through 7 for each of the signals in your ZoneFlex Advanced network.

Configuring Group Membership

A zone can be a member of one or more groups. The Group Membership tab is used to identify the group(s) to which a zone belongs.

Figure 4-22 Group Membership Tab



The screenshot shows a software window with several tabs: Modes, Delays, Actuator/Sensor, Speed Regulator, Signals, and Group Membership. The Group Membership tab is active. It contains a list of checkboxes for group membership:

<input type="checkbox"/> In Group 1	<input type="checkbox"/> In Group 4
<input checked="" type="checkbox"/> In Group 2	<input type="checkbox"/> In Group 5
<input type="checkbox"/> In Group 3	<input type="checkbox"/> In Group 6


Below the checkboxes, there is a note: ** Always a member of Override Slug Group*

To configure group membership, enable the checkboxes next to the group(s) you want the current zone to be part of.

4.3 Configuring Fieldbus

The ZFM often contains a fieldbus adapter that can be used to connect it to a Machine Control Software controller or PLC using PROFIBUS, DeviceNet (PLC only), or EthernetIP. The Configure button on the Configuration Summary screen is used to display the Fieldbus Configuration screen. From this screen, you can select the I/O points that you would like to cyclically monitor and/or set.


Figure 4-23 Fieldbus Configuration Button




The screenshot shows a window titled "Fieldbus Configuration". It contains a label "Type: None" and a button labeled "Configure".

To configure fieldbus, complete the following steps:

1. Click the **Configure** button on the Configuration Summary screen. The Fieldbus Configuration screen is displayed.



2. Select a network type at the top of the screen. Configuration settings will appear below the selection and Fieldbus Cyclic Data Categories will be displayed.





3. Complete the configuration settings with information about the network. The settings will vary depending on the type of network you are using.
4. Use the tabs in the Fieldbus Cyclic Data Categories to select the types of data and I/O that you would like to monitor/set. Mouse over the checkboxes to view the ADI number. Refer to the next section for information about each type of data and I/O.
5. Review the information in the Fieldbus Cyclic Data Map. The header contains a summary of the bytes you elected to use listed by input/output, the total bytes available, and the total bytes used. The columns in the lower portion of the map identify the Application Data Instances (ADIs) and bytes used. Mouse over the graphic to see which data or I/O point a row is describing.

4.3.1 ZoneFlex Manager's Runtime Data

The ZFM's runtime data is live data representing either raw I/O or internal states and variables. You can configure fieldbus to monitor this data using the tabs in the Fieldbus Cyclic Data Categories.

The following sections describe each data type in greater detail.

ZFM I/O Data

4 bytes	Input (UINT32)
A 32-bit value that represents the current state of LEDs, switches, and general purpose inputs/outputs on the ZFM. The data is returned as illustrated in the Data Template on the ZFM I/O Data tab.	

ZFA I/O Slot Data

1 byte	Input (UINT8)
Each ZFA module has an 8-bit value that represents the current state of the LEDs, valve, auxiliary output, and photo-eye. The data is returned as illustrated in the Data Template on the ZFA I/O Slot Data tab.	

ZFA Node Data

1 byte	Input (UINT8)
Each ZFA module has an 8-bit value that represents the current state of module level LEDs, test output, and test input. The data is returned as illustrated in the Data Template on the ZFA Node Data tab.	

ZFM GPIO Inputs

1 byte	Input (UINT8)
An 8-bit value that represents the ZFM's six general purpose, read only inputs. The values are also available in the ZFM I/O Data value. This selection allows only the inputs to be read. The data is returned as illustrated in the Data Template on the ZFM GPIO Inputs tab.	

ZFM GPIO Outputs

2 bytes	Input (UINT8)/Output (UINT8)
An 8-bit value that represents the ZFM's four general purpose outputs. The values are also available in the ZFM I/O Data value. This selection allows the values to be set. It also allows only the outputs to be monitored. The data is returned as illustrated in the Data Template on the ZFM GPIO Output tab.	

Lane Status

1 byte	Input (UINT8)
An 8-bit value that represents the status for lanes 1-5. Status can be obtained for any configured lane. This data is read only. The data is returned as illustrated in the Data Template on the Lane Status tab.	

Lane Commands

2 bytes	Input (UINT16)
A 16-bit value that provides real time control of a specific lane. Commands are triggered at the bit level	



Zone Status

1 byte	Input (UINT8)
An 8-bit value that represents the status of configured zones. The status of two zones is available in a single byte. This data is read only. The data is returned as illustrated in the Data Template on the Zone Status tab.	

Zone Commands

1 byte	Input (UINT8)
An 8-bit value that provides real time control of a specified zone pair in a configured lane. Commands are triggered at the bit level.	

Saving a Configuration

5

After you have generated a configuration, you can save it in an XML or ZFB file. The format you elect to use will be determined by how you plan to download the configuration to the ZoneFlex Manager.

If you plan to download the configuration using the ZoneFlex Configurator, you can save the file in either XML or ZFB format. The configurator can open/import either type of file and download it using the USB connection.

If you plan to download the configuration using a Machine Control Software controller or a PLC, you should save the file in ZFB format. The controller or PLC can then download the file using a fieldbus connection (if one exists).

5.1 Saving an XML Configuration

To save a configuration in an XML file, complete the following steps:

1. Select the **Save Configuration** option from the **File** menu. A browser window is displayed.
2. Enter a name for the configuration file in the **File Name** field. Be sure to use the .XML extension.
3. Browse to the location where you would like to save the file.
4. Select **Save** to save the file and close the browser window.

5.2 Saving a ZFB Configuration

To save a configuration in a ZFB file, complete the following steps:

1. Select **Export Binary File** from the **File** menu. A browser window is displayed.
2. Enter a name for the configuration file in the **File Name** field. Be sure to use the .ZFB extension.



Tip

The filename should include a reference to the network and the ZFM station address.

3. Browse to the location where you would like to save the file.
4. Select **Save** to save the file and close the browser window.

Downloading Configuration Files

6

If a configuration is saved in an XML file, it can be downloaded to the ZoneFlex Manager using the ZoneFlex Configurator and the USB connection.


If a configuration is saved in a ZFB file, it can be downloaded using the ZoneFlex Configurator, a Machine Control Software controller, or a PLC. If you will be using a BOSS III controller or PLC to perform the download, the ZFB file will need to be copied to the controller. From there, it can be downloaded to the ZoneFlex Manager using a fieldbus connection.

6.1 Downloading a Configuration from the ZFC

To download a configuration from the ZoneFlex Configurator, complete the following steps:


1. Open or import the configuration file in the ZoneFlex Configurator. For information about opening and importing files, refer to **Chapter 7, Working with Configuration Files**.

2. Go to the **ZFM** menu and select **Write ZFM Configuration** or select the **Send to ZFM** button at the bottom of the screen. A prompt similar to the one below is displayed.



The prompt will identify which part(s) of the configuration, if any, are newer or older than the existing configuration. It will also indicate whether a full or partial download is required.

3. Select **Yes** to download the configuration. A prompt appears showing the status of the download.



When the download is finished, the prompt indicates that it is complete.

4. Select **Close** to close the prompt.



6.2 Deploying a Configuration

To deploy a ZFB configuration to a ZFM over fieldbus from Machine Control Software (BOSS III, ICW, or MC4), you need to transfer the ZFB file to the Machine Control Software controller.

To transfer a ZFB file from a PC to a Machine Control Software controller, copy the file from the PC to a portable storage device, connect to the controller using Remote Desktop or FTP into the controller. You can then copy the file to the controller. The Machine Control Software application can then be used to deploy (i.e., write) the configuration to the ZoneFlex Manager. For additional information, refer to your Machine Control Software documentation.

6.3 Downloading a Configuration from a PLC

To download a configuration from a PLC to a ZoneFlex Manager, the ZFB configuration files must be resident on the PLC's memory card. An Index file that lists the resident configuration file names is also required. For information about naming configuration files and creating Index files, refer to the *ZoneFlex Advanced PLC Implementation Guide*.

Working with Configuration Files


7

7.1 Opening an XML Configuration File


After you have created and saved configurations, you can open them in the ZoneFlex Configurator:

To open a configuration file:

1. Go to the **File** menu and select **Open Configuration File**. A browser window opens.



If a configuration file is currently open and changes have been made to it, but not saved, a prompt is displayed.




Select **Yes** to save the configuration. Select **No** to discard the changes to the configuration or **Cancel** to return to the ZoneFlex Configurator.

2. Browse to the location of the configuration file that you want to open.
3. Double-click on the file name to open it in the ZoneFlex Configurator.


7.2 Importing a ZFB Configuration File

1. Go to the **File** menu and select **Import Binary File**. A browser window is opened.





If a configuration file is currently open and changes have been made to it, but not saved, a prompt is displayed.




Select **Yes** to save the configuration. Select **No** to discard the changes to the configuration or **Cancel** to return to the ZoneFlex Configurator.

2. Browse to the location of the configuration file that you want to import.
3. Double click on the file name to import it into the ZoneFlex Configurator.

7.3 Reading a ZoneFlex Manager's Configuration


To read the configuration from a ZFM, complete the following steps:

1. Select **Read Configuration** from the **ZFM** menu. A prompt appears.



The prompt contains the name of the configuration, the date and time that the topology was created, and the date and time that the last parameter was changed.

2. Select **Yes** to start reading the configuration. A prompt appears that displays the IP address of the ZFM and the progress of the upload.



3. When the upload is complete, click **Close**. The Configuration Summary is displayed.

Application Guide

8

8.1 Approach and Fine Tuning

Use the following processes and charts to initially configure and fine tune the conveyor's accumulation performance.



Tip

Print out this chapter to use while configuring or tuning a ZoneFlex Advanced conveyor.


The basic process always starts by:

1. Selecting the Accumulation Mode, with default settings found in Section 8.2.
2. Enable Neighborhood Mode (if applicable) with settings found in Section 8.3.
3. Test and tune settings (Accumulation, Autoslug, Accel/Decel, etc.).
4. *Fine Tuning*: If gaps between product continue to result during accumulation, or if need to further maximize product density:

Enable Crowding

and/or

Enable Accumulation Delay

Figure 8-1 Approach to Tuning ZFA



8.2 Initial ZoneFlex Manager Settings

See Table 8-1 for initial recommended ZoneFlex Manager settings. Depending on product mix, some fine tuning may be necessary.



Note

Apply the special settings to curves on Accuglide (AG) conveyors in Notes.

Table 8-1 Recommended Initial Configurable Settings

Configurable Setting	Conveyor Speed	Discharge Idler Length	ROC Zone Length	Discharge Zone	2nd Zone	Zones 3-n	Notes
Accumulation Mode	<180 fpm	3'	3'	1-zone	1-zone	1-zone	<ul style="list-style-type: none"> - 0-zone for the 6' zone discharge idlers - AG Curves always 0&1 zone
			6'	1-zone	1-zone	1-zone	
		6'	3'	0-zone	1-zone	1-zone	
			6'	0-zone	1-zone	1-zone	
	>=180 and <=270	3'	3'	1-zone	1-zone	1-zone	
			6'	1-zone	1-zone	1-zone	
		6'	3'	0-zone	1-zone	1-zone	
			6'	0-zone	1-zone	1-zone	
	>270 fpm	3'	3'	1-zone	1-zone	1-zone	
			6'	1-zone	1-zone	1-zone	
		6'	3'	0-zone	1-zone	1-zone	
			6'	0-zone	1-zone	1-zone	
Crowding				Tune as necessary depending on product mix after testing, if needed. Default setting is OFF.			<ul style="list-style-type: none"> - Settings at "0" delay, "2 sec" duration, 15% - AG Curves always "OFF"
Neighborhood Mode	<180 fpm	3'	3'	OFF	OFF	OFF	<ul style="list-style-type: none"> - Be sure each Zone Length is correct - AG Curves always "OFF" - OFF for discharge zones except for above 270 fpm - OFF when there is a brake in the zone
			6'	OFF	OFF	OFF	
		6'	3'	OFF	OFF	OFF	
			6'	OFF	OFF	OFF	
	>=180 and <=270	3'	3'	OFF	ON	ON	
			6'	OFF	ON	ON	
		6'	3'	OFF	ON	ON	
			6'	OFF	ON	ON	
	>270 fpm	3'	3'	ON	ON	ON	
			6'	ON	ON	ON	
		6'	3'	ON	ON	ON	
			6'	ON	ON	ON	
Dynamic Auto	<180 fpm	3'	3'	OFF	OFF	ON	- AG Curves always "OFF"

Configurable Setting	Conveyor Speed	Discharge Idler Length	ROC Zone Length	Discharge Zone	2nd Zone	Zones 3-n	Notes		
Slug		6'	6'	OFF	OFF	ON	- ON for zones 3-n		
			3'	OFF	OFF	ON			
			6'	OFF	OFF	ON			
	>=180 and <=270	3'	3'	OFF	OFF	ON			
			6'	OFF	OFF	ON			
			6'	OFF	OFF	ON			
	>270 fpm	3'	3'	OFF	OFF	ON			
			6'	OFF	OFF	ON			
		6'	3'	OFF	OFF	ON			
			6'	OFF	OFF	ON			
	Accumulation Delay	<180 fpm	3'	3'	None	None		None	- AG Curves always No Delay - 1 sec for slower speeds and 6' zones
				6'	None	1 sec		1 sec	
6'			3'	None	None	None			
			6'	1 sec	1 sec	1 sec			
>=180 and <=270		3'	3'	None	None	None			
			6'	None	1 sec	1 sec			
		6'	3'	None	None	None			
			6'	1 sec	1 sec	1 sec			
>270 fpm		3'	3'	None	None	None			
			6'	None	None	None			
		6'	3'	None	None	None			
			6'	None	None	None			
Latching	<180 fpm	3'	3'	OFF	OFF	OFF	ON for the 6' discharge zones for higher speeds		
			6'	OFF	OFF	OFF			
		6'	3'	OFF	OFF	OFF			
			6'	OFF	OFF	OFF			
	>=180 and <=270	3'	3'	OFF	OFF	OFF			
			6'	OFF	OFF	OFF			
		6'	3'	OFF	OFF	OFF			
			6'	OFF	OFF	OFF			
	>270 fpm	3'	3'	OFF	OFF	OFF			
			6'	OFF	OFF	OFF			
		6'	3'	ON	OFF	OFF			
			6'	ON	OFF	OFF			
Slug groups	Can set up two or more separate slug release groups. Release based on how full the conveyor is.								
Drop to Gravity	Set up all zones in one "Drop to Gravity" group for use at startup if no VFD/soft start is used at speeds <300 fpm. Speeds >=300 fpm always requires a VFD/soft start.								



Note

This table of settings is already specifically tailored to the application type (Sawtooth Merge, IntelliMerge, Aftersort, Standalone, Recirc, etc.) by the accumulating conveyor's very construction. When the conveyor was being conceived, the speed, discharge idler length, and rest of conveyor (ROC) zone length were built in such a way that this table can give you the best possible starting foot forward. The chart is based on testing and results at various locations and product mixes.

8.3 Set Speed Regulator for Neighborhood Mode

Neighborhood Mode is the patented gentle handling accumulation feature that allows product to accumulate under high speed. The Neighborhood Mode feature uses ZoneFlex Advanced's Speed Regulator that requires three pieces of information to handle product correctly: Zone Length, Acceleration and Deceleration. The Zone Length is set in each Zone in the ZoneFlex Configurator. Likewise, the Acceleration and Deceleration values are set in each zone, and are based on average live load, speed and container type (cartons or totes).

To correctly configure Neighborhood Mode, set the Zone Length, Acceleration and Deceleration values for each zone using the ZoneFlex Configurator. Use the table below to find the proper Acceleration and Deceleration values for the conveyor and product. In situations where mixed product weight is being used, start with finding the average and adjust if needed during commissioning with testing.

Table 8-2 Speed Regulator Settings

Live Load	Cartons			Totes	
	Speed	Acceleration	Deceleration	Acceleration	Deceleration
Light (≤15 lb/ft)	150	414	48	373	42
	180	414	51	373	45
	240	414	59	373	53
	270	414	63	373	57
	300	414	66	373	60
	400	414	79	373	73
Average (>15 and < 50 lb/ft)	150	344	43	310	37
	180	344	46	310	41
	240	344	54	310	48
	270	344	58	310	52
	300	344	61	310	56
	400	344	74	310	68
Heavy (≥50 lb/ft)	150	292	39	263	34
	180	292	43	263	38
	240	292	50	263	45
	270	292	54	263	49
	300	292	58	263	53
	400	292	70	263	65

Troubleshooting

9

9.1 Issues and Resolutions


Condition	Resolution
The ZoneFlex Configurator cannot connect to the ZFM and/or gives "GetADI() Exception" time out error.	<ol style="list-style-type: none">1. Verify that the ZFM is powered.2. Verify that the USB cable is correctly connected.3. Verify that the secondary network is configured correctly and ensure you can ping the ZFM as shown in Section 2.2.1.4. Be sure you are using the same USB port you used when first setting up the driver. Each USB port is independent.5. Check the driver installation again and ensure the RNDIS Gadget appears in Device Manager as shown in Section 2.1.6. Ensure there is nothing checked in Internet Options Connections tab LAN Settings.
Driver cannot find the ZFM at the configured IP address.	<p>Complete the device driver configuration described in Chapter 2.</p> <p>If this has already been completed, make sure the ZFM is connected to the same USB port that was used when the configuration was performed. If it is connected to a different USB port, the configuration described in Chapter 2 will need to be completed again for the new port.</p>
The ZoneFlex Configurator software cannot be installed on a PC.	Confirm that you have the appropriate rights on the PC.
The ZoneFlex Configurator software will not run on a PC.	Confirm that you have the appropriate rights on the PC and that it is available to your user account.
I cannot select a tab or the "Back" button.	Check to see if a Yellow Error message is displayed. If one is displayed, resolve the issue before attempting to navigate to a different screen or tab.

Condition	Resolution
<p>I get the following message when I try to open a configuration file: <i>File (<filename>.xml) is corrupt and cannot be used.</i></p>	<p>The file may have been saved using a different version of the ZoneFlex Configurator. To resolve this issue, complete one of the following tasks:</p> <ul style="list-style-type: none"> • Re-read the configuration from the ZFM, save it to a new file, and delete the corrupt file. • Use the same version of the ZFC that was used to save the original configuration file. • Open the file with a browser, for reference, and re-enter the configuration using the ZFC.
<p>Conveyor does not work. There is no heartbeat on the ZFM and the modules only have one green LED ON.</p>	<p>Cycle power to the ZFM. Give the ZFM about 2 minutes to power up completely. If the heartbeat returns, continue to use. If the heartbeat is still missing, turn the ZFM off and replace the SD card with one from another ZFM. If heartbeat returns, hardware is fine, SD card needs to be replaced by ordering one from Intelligrated (very specific). If heartbeat does not return, replace the ZFM.</p>

9.2 ZFM and Module LEDs

Health and status is given through LED indication on both the ZFM and ZFA Modules. After bootup, a properly running ZoneFlex Manager emits a heartbeat signal with its red Status LED, indicating the program is running.

Figure 9-1 ZoneFlex Manager Layout



(1) USB Port

ZoneFlex Manager contains a standard USB Type B vertical connector that provides access to configuration information and event logs and also provides access to the UI-API configuration file. The USB port is located inside of the ZoneFlex Manager's enclosure.

(2) DIP Switches

ZoneFlex Manager contains seven DIP switches that are located inside the ZoneFlex Manager's enclosure. These DIP switches are used for local configuration of simple or standalone systems.

(3) General Purpose I/O Interface (GPIO)

ZoneFlex Manager contains ten General Purpose Input/Output (GPIO) points.

All inputs must be AC or DC:

- ON > 10V AC/DC
- OFF < 6V AC/DC

All outputs must be AC or DC

- Voltage = 0 - 250V AC/DC
- Maximum Current = 50mA

A separate connection point for the inputs and outputs is provided for electrical common (ground). A Mini 8-pin cable is provided for inputs and a Mini 6-pin cable is provided for outputs.

Single color LEDs are located by each input and output to indicate that a signal is applied. The LED color for inputs is amber and the LED color for outputs is green. LEDs illuminate when the input/output is ON and do not illuminate when the input/output is OFF.

(4) Commissioning Mode

The Commissioning Mode:

- Simplifies commissioning and troubleshooting
- Places all modules in 0-zone mode
- Each zone photo-eye controls the valve in the same zone
- LED on the ZoneFlex Manager and the ZoneFlex Advanced Modules blinks to indicate commissioning mode active.
- Enter the commissioning mode by pressing the Commissioning Button and holding for 3 seconds. To cancel, press and hold the Commissioning Button for 3 seconds.
- The commissioning button can also be used to delete the factory configuration. If no slaves are plugged in and the commissioning button is held down for 6 seconds, the ZoneFlex Manager will delete any saved settings (database files).

(5) System Manager and Status LED

Note: LED #1 is closest to the DIP switches. (LED 1 to 6 are the status of the General Purpose Inputs.)

The System Manager has the following LEDs:

- Release Signal
- Slug Release Signal (optional)
- Global Wake Up Signal (optional)
- Infeed Wake Up Signal (optional)
- Manual Override Slug Group Active Signal (optional)
- Drop to Gravity Signal (optional)
- Commissioning Mode
- Program Running, red blinking is a heartbeat that indicates the program is running.

(6) microSD Card

ZoneFlex Manager includes a microSD card that stores:

- The operating system
- The base software
- An event log



The ZFA modules, likewise, indicate a wealth of information through the following LEDs.

Figure 9-2 ZFA Module with LEDs




Table 9-1 LEDs

Problem/Status	LED Color/State	Cause	Solution
Zone Status LEDs			
Red Zone LED	Solid	Zone is disabled.	No action needed.
	Fast Flash	Jam is detected.	Clear the jam photo-eye.
	Med Flash	Product is stalled.	Wait for zones to try to push product through the stall condition.
			Remove the cause of the stall.
			Align the zone sensor if needed.
	Slow Flash	Clog is detected.	Wait for zones to try to push product through the clog condition.
			Remove the cause of the clog.
	OFF	No alarms are detected.	No action needed.
Amber Zone LED	Solid ON	Valve is energized.	No action needed.
	OFF	Valve is de-energized.	
Green Zone LED	Solid ON	Sensor is clear.	No action needed.
	OFF	Sensor is blocked.	
	Slow Flash	Zone is asleep.	Wake up the zone by temporarily blocking the sensor. When the sensor clears, the zone will wake up.
System Status LEDs			
Red System Status LED	Fast Flash	Network topology error (configuration/zone count mismatch) is detected.	Check for faulty or disconnected module in the line.
Amber System Status LED	Flashing	Commissioning mode is active. Mode is used for commissioning and for troubleshooting mech./elec. components	Press the Commission switch for more than 3 seconds.
			Deactivate mode through the UI or Fieldbus.
			Cycle the power of the ZoneFlex Manager.
	OFF	System is operating per defined configuration.	No action needed.




Problem/Status	LED Color/State	Cause	Solution
Green System Status LED	Solid ON	Network is online and the ZoneFlex Module is communicating with the ZoneFlex Manager.	No action needed.
	Flashing	Line Fault detected somewhere in the system. Upstream or downstream modules flash green lights trending in the direction of the line fault.	Follow the lights towards the faulty module. Reconnect or replace the module.
	OFF	Network is offline and the ZoneFlex Module is not communicating with the ZoneFlex Manager.	Check the connection between the ZoneFlex Module and the ZoneFlex Manager. Make sure the ZoneFlex Manager is turned ON.
Indicators for Commissioning Mode			
System Status			When all of the LEDs are, at the same time, in the state described in the LED Color/State column, the system is in the Commissioning Mode.
Red Status LED	OFF	(Not applicable)	
Amber Status LED	Flashing		
Green Status LED	Solid ON		
Zone Status			
Red Zone LED	OFF	(Not applicable)	
Amber Zone LED	Solid ON	Valve is energized.	
	OFF	Valve is de-energized.	
Green Zone LED	Solid ON	Sensor is clear.	
	OFF	Sensor is blocked.	

9.3 Locating Bad ZFA Module(s) Process

Have the following equipment on hand: a network extension cable (male-to-female) and gender changer cables of both types (male-to-male and female-to-female).

With laptop connected to the ZoneFlex Manager, use the ZoneFlex Configurator's *ZFM Information* screen and note the number of *Detected Modules*.



1. Starting at the ZFM, follow the physical connection path of the ZFA network.
2. Count the ZFA Modules and stop at the Module matching the *Detected Count*.
3. Disconnect the module's cables from both ports.
4. Using the extension/gender changer, connect the outgoing port to the cable supplying the incoming port.
5. Allow up to 15 seconds for the ZFM to detect the Module.
6. If the network light comes on, then that Module is good and the next Module is bad.
7. If the network light does not come on, then that Module is bad.
8. After the bad Module is replaced, remove the gender changer and connect the new one.
9. Repeat the above process until any/all bad Modules have been replaced.



Note


Using this process, check the last module in the daisy chain to ensure its exit port is functioning.

9.4 Fieldbus Connections

Troubleshooting the fieldbus network connection can be achieved through looking inside of the box for two to four blinking LEDs on the Anybus fieldbus communication card.

The following charts for each fieldbus type show what the different LED states mean, assuming the fieldbus connections are oriented toward the left.

Figure 9-3 Standard LED positions and mounting



9.4.1 PROFIBUS

Table 9-2 Network Status/Operation Mode LED

LED State	Description
Off	Not online/No power
Green	Data exchange
Green, flashing	Clear
Flashing Red (1 flash)	Parametrization error
Flashing Red, (2 flashes)	PROFIBUS Configuration Error

Table 9-3 Module Status LED

LED State	Description
Off	Not initialized. Anybus state = "SETUP" or "NW_INIT"
Green	Initialized. Anybus module has left the "NW_INIT" state
Green, flashing	Initialized, diagnostic event(s) present. Extended diagnostic bit is set
Red	Exception error. Anybus state = "EXCEPTION"

PROFIBUS does not have the Link/Activity LEDs.

9.4.2 EtherNet/IP

Table 9-4 Network Status LED

LED State	Description
Off	No power or no IP address
Green	Online, one or more connections established (CIP class 1 or 3)
Green, flashing	Online, no connections established
Red	Duplicate IP address, FATAL error
Red, flashing	One or more connections timed out (CIP Class 1 or 3)

Note: A test sequence is performed on this LED during startup

Table 9-5 Module Status LED

LED State	Description
Off	No power
Green	Controlled by a Scanner in Run state
Green, flashing	Not configured, or Scanner in Idle state
Red	Major fault (EXCEPTION-state, FATAL error, etc.)
Red, flashing	Recoverable fault(s)

Note: A test sequence is performed on this LED during startup



Table 9-6 Link/Activity LED

LED State	Description
Off	No link, no activity
Green	Link (100 Mbit/s) established
Green, flickering	Activity (100 Mbit/s)
Yellow	Link (10 Mbit/s) established
Yellow, flickering	Activity (10 Mbit/s)

9.4.3 DeviceNet

Table 9-7 Network Status LED

LED State	Description
Off	Not online/No power
Green	Online, one or more connections are established
Green, flashing	Online, no connections established
Red	Critical link failure
Red, flashing	One or more connections timed out
Alternating Red/Green	Self test

Table 9-8 Module Status LED

LED State	Description
Off	No power
Green	Operating in normal condition
Green, flashing	Missing or incomplete configuration, device needs commissioning
Red	Unrecoverable fault(s)
Red, flashing	Recoverable fault(s)
Alternating Red/Green	Self test

DeviceNet does not have the Link/Activity LEDs.

9.5 Troubleshooting Help

If you need further assistance, please visit our website at www.intelligrated.com or call our Technical Support Department at 1-877-315-3400.

Index

- 0&1-Zone accumulation, 32
- 0-Zone accumulation, 30
- 1&2-Zone accumulation, 33
- 1-Zone accumulation mode, 30
- 2-Zone accumulation, 31
- 4&5-Zone accumulation, 35
- 4-Zone accumulation, 34
- A side, 67
- accumulation commands, 36
- accumulation delay, 73, 83
- accumulation mode control, 35
- accumulation modes, 29
 - 0&1-Zone, 32
 - 0-Zone, 30
 - 1&2-Zone, 33
 - 1-Zone, 30
 - 2-Zone, 31
 - 4&5-Zone, 35
 - 4-Zone, 34
 - configuring, 82
- actuators, 83
 - inverted, 84
 - normal, 84
- Adjustments slider, 67
- air-to-brake, 42
- air-to-drive, 42
- all clear, 50
 - default, 60
- all clear delay, 73
 - default, 60
- B side, 67
- bad ZFA Modules, 115
- binary file format, 5
- CFGIdent, 69
- clear jam conditions, 41
- clogged, 52
- clogged delay, 83
- command input, 35
- commissioning mode, 57
- commissioning switch, 61
- communication
 - testing, 19
- configuration
 - opening, 99
 - reading, 101
 - saving, 93
- Configuration Summary, 68
- configurations
 - downloading, 95
- configure
 - accumulation modes, 82
 - actuators and sensors, 83
 - fieldbus, 87
 - global delays, 72
 - global settings, 72
 - global signals, 73
 - group membership, 87
 - groups, 76
 - lane details, 70
 - lane speeds, 72
 - lanes, 67
 - modules, 67
 - secondary network, 16
 - speed regulation, 84
 - system eyes, 78
 - zone delays, 83
 - zone signals, 85
 - ZoneFlex Manager, 29
 - zones, 81
- connecting a PC to a ZFM, 9
- control logic, 29
- create a configuration, 65
- Create New Configuration screen, 70
- crossovers, 67
- crowding, 50
- dark-operated sensors, 84
- data types, 89
- defaults, 58
- deploy configuration, 97
- device driver
 - install manually, 15
- diagnostics, 58
- DIP switch 1 settings, 61
- DIP switch 2 settings, 61
- DIP switch 3 settings, 61
- DIP switch 4 settings, 61

- DIP switch 5 settings, 61
- DIP switch 6 settings, 61
- DIP switch 7 settings, 61
- disabled zone control, 57
- discharge zone
 - default, 58
- discharge zone release command, 37
- Disk Cost, 22
- documentation conventions, 6
- download configuration, 97
- download configurations, 95
- drained, 53
- drained delay, 83
- drop to gravity groups, 39
- dynamic auto slug, 43
- dynamic auto slug delay, 43, 73
 - default, 60
- exit the software, 64
- fieldbus
 - configuring, 87
- fieldbus connections, 117
- Fieldbus Mark, 69
- fixed auto slug, 44
- general purpose input/output
 - default, 58
- General Purpose Input/Output (GPIO), 35
- generate a topology, 68
- global delays, 72
- global sensor accumulation delay, 51
- global settings, 72
- global signals, 73
- global wake, 48
- GPIO inputs, 90
- GPIO output, 90
- group defaults, 60
- group membership, 87
- groups, 76
- I/O data, 89
- I/O slot data, 89
- idle zones, 72
- import a ZFB configuration file, 100
- infeed wake, 46
- Initial Module Side, 67
- install device driver manually, 15
- install the ZoneFlex Configurator, 20
- Internet Protocol Version 4 (TCP/IPv4), 18
- inverted actuators, 84
- IOSlotA, 67
- IOSlotB, 67
- IP address, 11, 18, 69
- jam, 55
 - jam and stall, 52
 - jam conditions
 - clearing, 41
 - lane commands, 90
 - Lane Definitions table, 67
 - lane details
 - configuring, 70
 - Lane Max. Speed, 72
 - lane speed
 - maximum, 72
 - lane speeds
 - configuring, 72
 - lane status, 90
 - lanes, 67
 - configuring, 67
 - modules on a, 67
 - latching, 41
 - latching sensors, 84
 - light-operated sensors, 84
 - local slug, 44
 - manual override slug group, 41
 - default, 60
 - manually install device driver, 15
 - Max. Release Speed, 72
 - Module Definitions table, 67
 - Module LEDs, 111
 - modules
 - configuring, 67
 - leading side, 67
 - specifying the number of, 67
 - modules on a lane, 67
 - neighborhood mode, 56
 - Neighborhood Mode, 108
 - network
 - description of, 69
 - node data, 90
 - normal actuators, 84
 - notes, 7
 - Number of Modules, 67
 - open a configuration, 99
 - Override Regulator on Idle, 72
 - Params Mark, 69
 - PC controller
 - connecting to a ZFM, 9
 - photo-eyes, 78
 - power supply
 - positioning and voltage, 4
 - Project Description, 69
 - project information, 69
 - Project Name, 69
 - pulse-width modulation, 56

- push-thru, 55
- read a configuration, 101
- release commands, 36
- release delay, 73, 83
- release speed
 - maximum, 72
- remove the ZoneFlex Configurator, 26
- repair the ZoneFlex Configurator, 24
- runtime data, 89
- run-up eye, 30
- save a configuration, 93
- save ZFB configuration, 94
- secondary network
 - configure, 16
- Select No. of Lanes, 67
- sensor delay, 51
- sensors, 83
 - dark-operated, 84
 - latching, 84
 - light-operated, 84
- set speed regulator, 108
- Setup.msi, 24
- Setup.msi file, 20
- sleep delay, 73
 - default, 60
- sleep mode, 45
- sleep timer, 45
- slug groups, 39
- software configuration, 63
- speed regulation, 56
- speed regulator, 84
 - setting, 108
- stall, 54
- starting the Configurator, 64
- stop zone accumulation command, 38
- system architecture, 2
- system eyes, 78
- test communication, 19
- test the ZFM connection, 23
- time delay values, 72
- tips, 7
- Topo Mark, 69
- topology
 - generating, 68
- Topology Summary, 70
- troubleshooting, 109
- typographical conventions, 6
- uninstall the ZoneFlex Configurator, 26
- USB EtherNET/RNDIS gadget, 14
- USB port, 9
- valve output inversion, 42
- volts direct current, 4
- XML files, 5, 93
 - saving, 93
- ZFA. *See* ZoneFlex Advanced
- ZFA node I/O defaults, 60
- ZFB configuration file
 - importing, 100
- ZFB files, 5, 93
 - saving, 94
- ZFC. *See* ZoneFlex Configurator
- ZFM. *See* ZoneFlex Manager
 - connecting to a PC, 9
 - runtime data, 89
 - testing communication with, 23
- ZFM configuration
 - creating, 65
- ZFM LEDs, 111
- ZFM Name, 69
- zone 2 default, 59
- zone commands, 91
- zone defaults, 60
- zone delays, 83
- zone eye status, 51
- zone signals, 85
- zone status, 91
- zone valve
 - controlling, 35
- ZoneFlex Advanced, 1
- ZoneFlex Advanced modules, 1
 - specifying the number of, 67
- ZoneFlex Configurator, 1, 5
 - exiting, 64
 - installing, 20
 - repairing, 24
 - starting, 64
 - uninstalling, 26
- ZoneFlex Manager, 1, 2
 - configuring, 29
 - connection, 4
 - IP address, 11, 18, 69
 - test communication with, 19
- zones, 81