

## 3.3

## Fault messages on the keypad or in the parameter setting program Global Drive Control

Keypad	PC 1)	Fault	Cause	Remedy
<b>nDEr</b>	0	No fault	-	-
<b>CCr</b> <b>Trip</b>	71	System failure	Strong interference injections on the control cables Earth loops in the wiring	Shield control cable
<b>CE0</b> <b>Trip</b>	61	Communication error on AIF (configurable in C0126)	Faulty transmission of control commands via AIF	Insert the communication module properly into the diagnosis terminal
<b>CE1</b> <b>Trip</b>	62	Communication error on CAN-IN1 with sync control	CAN-IN1 object receives faulty data or communication is interrupted	<ul style="list-style-type: none"> <li>Check plug connection of bus module ⇔ FIF</li> <li>Check sender</li> <li>Increase monitoring time in C0357/1, if necessary</li> </ul>
<b>CE2</b> <b>Trip</b>	63	Communication error on CAN-IN2	CAN-IN2 object receives faulty data or communication is interrupted	<ul style="list-style-type: none"> <li>Check plug connection of bus module ⇔ FIF</li> <li>Check sender</li> <li>Increase monitoring time in C0357/2, if necessary</li> </ul>
<b>CE3</b> <b>Trip</b>	64	Communication error on CAN-IN1 with event or time control	CAN-IN1 object receives faulty data or communication is interrupted	<ul style="list-style-type: none"> <li>Check plug connection of bus module ⇔ FIF</li> <li>Check sender</li> <li>Increase monitoring time in C0357/3, if necessary</li> </ul>
<b>CE4</b> <b>Trip</b>	65	BUS-OFF (many communication errors occurred)	Controller has received too many faulty telegrams via the system bus and has been disconnected from the bus	<ul style="list-style-type: none"> <li>Check whether bus termination is available</li> <li>Check shield connection of the cables</li> <li>Check PE connection</li> <li>Check bus load, reduce the baud rate, if necessary</li> </ul>
<b>CE5</b> <b>Trip</b>	66	CAN time-out (configurable in C0126)	In case of remote parameterisation via the system bus (C0370): Slave does not respond. Communication monitoring time has been exceeded	<ul style="list-style-type: none"> <li>Check wiring of the system bus</li> <li>Check system bus configuration</li> </ul>
			When operating with Application I/O: Parameter set change-over has been parameterised incorrectly	In all parameter sets, the "change parameter set" signal (C0410/13, C0410/14) must be connected with the same source
			When operating with module on FIF: Internal error	Contact Lenze
<b>CE6</b> <b>Trip</b>	67	System bus (CAN) function module on FIF has the "Warning" or "BUS-OFF" status (configurable in C0126)	CAN controller signals "Warning" or "BUS-OFF" status	<ul style="list-style-type: none"> <li>Check whether bus termination is available</li> <li>Check shield connection of the cables</li> <li>Check PE connection</li> <li>Check bus load, reduce the baud rate, if necessary</li> </ul>
<b>CE7</b> <b>Trip</b>	68	Communication error in case of remote parameterisation via the system bus (C0370) (configurable in C0126)	Node does not respond or is not available	<ul style="list-style-type: none"> <li>Check whether bus termination is available</li> <li>Check shield connection of the cables</li> <li>Check PE connection</li> <li>Check bus load, reduce the baud rate, if necessary</li> </ul>
			When operating with Application I/O: Parameter set change-over has been parameterised incorrectly	In all parameter sets, the "change parameter set" signal (C0410/13, C0410/14) must be connected with the same source
<b>EEr</b> <b>Trip</b>	91	External fault (TRIP-SET)	A digital signal assigned to the TRIP-SET function is activated	Check external encoder

Keypad	PC <sup>1)</sup>	Fault	Cause	Remedy
<i>Er-P0</i> ... <i>Er-P19</i> <b>Trip</b>	-	Communication interruption between keypad and standard device	Various	Contact Lenze
<i>FRnI</i> <b>Trip</b>	95	Fan failure (only 8200 motec 3 ... 7.5 kW)	Fan is defective	Replace fan
<i>FRnI</i>	-	TRIP or warning configurable in C0608	Fan is not connected	Connect fan Check wiring
<i>H05</i> <b>Trip</b>	105	Internal fault		Contact Lenze
<i>IdI</i> <b>Trip</b>	140	Faulty parameter identification	Motor is not connected	Connect motor
<i>LPI</i> <b>Trip</b>	32	Error in motor phase (Display when C0597 = 1)	<ul style="list-style-type: none"> <li>Failure of one/several motor phase(s)</li> <li>Motor current too low</li> </ul>	<ul style="list-style-type: none"> <li>Check motor supply cables</li> <li>Check <math>V_{min}</math> boost,</li> <li>Connect motor with a corresponding power or adapt motor with C0599</li> </ul>
<i>LPI</i>	182	Error in motor phase (Display when C0597 = 2)		
<i>LU</i> <b>IMP</b>	-	DC bus undervoltage	Mains voltage too low Voltage in DC-bus connection too low 400 V controller is connected to 240 V mains	Check mains voltage Check power supply module Connect controller to correct mains voltage
<i>OC1</i> <b>Trip</b>	11	Short circuit	Short circuit  Capacitive charging current of the motor cable too high	<ul style="list-style-type: none"> <li>Search for cause of short circuit; check motor cable</li> <li>Check brake resistor and cable to brake resistor</li> </ul> Use shorter/low-capacitance motor cable
<i>OC2</i> <b>Trip</b>	12	Earth fault	Earthed motor phase Capacitive charging current of the motor cable too high	Check motor; check motor cable Use shorter/low-capacitance motor cable  Deactivate earth-fault detection for test purposes
<i>OC3</i> <b>Trip</b>	13	Controller overload during acceleration or short circuit	Acceleration time set is too short (C0012) Defective motor cable Interturn fault in the motor	<ul style="list-style-type: none"> <li>Increase acceleration time</li> <li>Check drive dimensioning</li> </ul> Check wiring Check motor
<i>OC4</i> <b>Trip</b>	14	Controller overload during deceleration	Deceleration time set is too short (C0013)	<ul style="list-style-type: none"> <li>Increase deceleration time</li> <li>Check dimensioning of the external brake resistor</li> </ul>
<i>OC5</i> <b>Trip</b>	15	Controller overload during steady-state operation	Frequent and too long overload	Check drive dimensioning
<i>OC6</i> <b>Trip</b>	16	Motor overload ( $I^2 \times t$ overload)	Motor is thermally overloaded by e.g. <ul style="list-style-type: none"> <li>impermissible continuous current</li> <li>frequent or too long acceleration processes</li> </ul>	<ul style="list-style-type: none"> <li>Check drive dimensioning</li> <li>Check setting of C0120</li> </ul>
<i>OH</i> <b>Trip</b>	50	Heatsink temperature > +85 °C	Ambient temperature is too high	Allow controller to cool and provide better ventilation
<i>OH</i> <b>Warn</b>	-	Heatsink temperature > +80 °C	Heatsink is very dirty Impermissibly high currents or frequent and too long acceleration processes	Clean heatsink  <ul style="list-style-type: none"> <li>Check drive dimensioning</li> <li>Check load, exchange tight, defective bearings if necessary</li> </ul>

Keypad	PC <sup>1)</sup>	Fault	Cause	Remedy
<b>OH3</b> Trip	53	PTC monitoring (TRIP) (Display when C0119 = 1 or 4)	Motor too hot due to impermissibly high currents or frequent and too long acceleration processes	Check drive dimensioning
			No PTC connected	Connect PTC or switch off monitoring
<b>OH4</b> Trip	54	Controller overtemperature	Controller too hot inside	<ul style="list-style-type: none"> <li>• Reduce controller load</li> <li>• Improve cooling</li> <li>• Check fan in the controller</li> </ul>
<b>OH5I</b>	203	PTC monitoring (Display when C0119 = 2 or 5)	Motor too hot due to impermissibly high currents or frequent and too long acceleration processes	Check drive dimensioning
			No PTC connected	Connect PTC or switch off monitoring
<b>OU</b> IMP	-	DC bus overvoltage (Message or TRIP configurable in C0310)	Mains voltage too high	Check supply voltage
<b>QUE</b> Trip	22		Braking operation	<ul style="list-style-type: none"> <li>• Increase deceleration times</li> <li>• When operating with an external brake resistor: <ul style="list-style-type: none"> <li>– Check dimensioning, connection and supply cable of the brake resistor</li> <li>– Increase deceleration times</li> </ul> </li> </ul>
			Earth leakage on the motor side	Check motor supply cable and motor for earth fault (disconnect motor from the inverter)
<b>Pr</b> Trip	75	Faulty parameter transfer with the keypad	All parameter sets are defective	Before enabling the controller, repeat the data transfer or load the Lenze setting
<b>Pr1</b> Trip	72	Faulty PAR1 transfer with keypad	Parameter set 1 is defective	
<b>Pr2</b> Trip	73	Faulty PAR2 transfer with keypad	Parameter set 2 is defective	
<b>Pr3</b> Trip	77	Faulty PAR3 transfer with keypad	Parameter set 3 is defective	
<b>Pr4</b> Trip	78	Faulty PAR4 transfer with keypad	Parameter set 4 is defective	
<b>Pr5</b> Trip	79	Internal fault	EEPROM is defective	Contact Lenze
<b>PT5</b> Trip	81	Time error during parameter set transfer	Data flow from keypad or PC interrupted, e.g. because keypad was disconnected during transfer	Before enabling the controller, repeat the data transfer or load the Lenze setting.
<b>rST</b> Trip	76	Error during auto TRIP reset	More than 8 error messages within 10 minutes	Depends on the error message
<b>Sd5</b> Trip	85	Open circuit - analog input 1	Current at analog input < 4 mA at setpoint range 4 ... 20 mA	Close circuit at analog input
<b>Sd7</b> Trip	87	Open circuit - analog input 2		

<sup>1)</sup> LECOM error number, display in Global Drive Control (GDC) parameter setting program