

ControlLogix Analog Servo Modules, Firmware Revision 16

Catalog Numbers 1756-HYD02, 1756-M02AE, 1756-M02AS

When to Use These Release Notes

Use these release notes for information about these firmware revisions.

| Module | Cat. No. | Revision |
|---|------------|----------|
| ControlLogix 2-axis Hydraulic Servo Module | 1756-HYD02 | 16.1 |
| ControlLogix 2-axis Analog Encoder Servo Module | 1756-M02AE | 16.1 |
| ControlLogix 2-axis Analog SSI Servo Module | 1756-M02AS | 16.2 |

Compatible Revisions



To use this revision, update your system as follows.

| Update | To Version/Revision |
|-------------------------|---------------------|
| RSLink software | 2.51 or later |
| RSLogix 5000 software | 16 |
| ControlLogix controller | 16 |

Before You Begin

ATTENTION

Before you upgrade the firmware of your module, you must inhibit the module.



This disables the axes and makes updating the module easier.

Enhancement

This enhancement that has been made in the revision of firmware listed. The left most column of the table indicates the modules where the enhancement has been made.

| Cat. No. | Firmware Revision | Enhancement | Description |
|--------------------------|-------------------|----------------------------|--|
| 1756-HYD02 1756-M02AS | 16.1 | Loss of Feedback detection | With RSLogix 5000 software version 16, the Loss-of-Feedback (LOF) detection has been enhanced for the 1756-M02AS and 1756-HYD02 modules to now recognize the LOF while the servo loop is off or disabled (MSF), as well as the prior check for LOF while the servo loop is on (MSO). |

Corrected Anomaly

The following anomaly has been identified and corrected in the module firmware revision listed. The left most column of the table indicates the module that the anomaly was corrected in.

| Cat. No. | Firmware Revision | Anomaly | Description |
|------------|-------------------|--|---|
| 1756-M02AS | 16.2 | Actual Position of a rotary axis calculated beyond the unwind limit. | For an axis configured on the 1756-M02AS module as rotary, and the feedback configured as absolute SSI feedback, the resulting Actual Position when crossing the rollover unwind position could result in a value greater than the configured Position Unwind. Modification to the calculation of the Actual Position to avoid Actual Position values higher than the Unwind Position were made. |

Known Anomaly

This table lists a confirmed anomaly in the module firmware revision listed. The left most column of the table indicates the module where the anomaly occurs.

| Cat. No. | Firmware Revision | Anomaly | Description |
|------------|-------------------|--|--|
| 1756-M02AE | 16.1 | Axis fault occurs after updating the 1756-M02AE Analog Servo Module Firmware to revision 16.1 using Firmware Supervisor. | <p>Use this workaround to correct this anomaly.</p> <p>For more information about updating modules with Firmware Supervisor, refer to the Logix5000 Controllers Design Considerations Reference Manual, publication 1756-RM094.</p> <ol style="list-style-type: none"> 1. Use ControlFlash software to install the 1756-M02AE Analog Servo Module revision 16.1 (Kit 2) firmware update. You can also obtain the firmware update by downloading it from the MySupport website at http://support.rockwellautomation.com/firmware.asp. 2. Use Windows Explorer to navigate to the directory where ControlFlash is installed. The default directory is C:\Program Files\ControlFlash. 3. From the install directory, navigate to this subdirectory. <Directory where ControlFlash is installed>\0001\0010\0003 4. If present, delete these .NVS files: <ul style="list-style-type: none"> • 99523201.NVS • 99523202.NVS • PN-15038.NVS 5. Use Windows Explorer to navigate to this directory. C:\Program Files\Common Files\Rockwell\CFOldKits\0001\0010\0003 6. If present, delete these NVS files: <ul style="list-style-type: none"> • 99523201.NVS • 99523202.NVS • PN-15038.NVS 7. Clear the CompactFlash image on all controllers that will be used to update 1756-M02AE cards. <ol style="list-style-type: none"> a. In RSLogix 5000 software, go online with the controller. b. On the Controller Properties dialog, click on the Nonvolatile Memory tab. c. Click Load/Store. d. From the Automatic Firmware Updates pull-down menu, select Disable and Delete Files From Image. e. Click Store. 8. Store the new image to the controller's CompactFlash card. <ol style="list-style-type: none"> a. In RSLogix 5000 software, go online with the controller. b. On the Controller Properties dialog, click on the Nonvolatile Memory tab. c. From the Automatic Firmware Updates pull-down menu, choose Enable and Store Files to Image. d. Click Store. <p>Lgx00077339</p> |

Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products. At <http://support.rockwellautomation.com>, you can find technical manuals, a knowledge base of FAQs, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools.

For an additional level of technical phone support for installation, configuration, and troubleshooting, we offer TechConnect support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://support.rockwellautomation.com>.

Installation Assistance

If you experience a problem within the first 24 hours of installation, please review the information that's contained in this manual. You can also contact a special Customer Support number for initial help in getting your product up and running.

| | |
|-----------------------|--|
| United States | 1.440.646.3434 Monday – Friday, 8 a.m. – 5 p.m. EST |
| Outside United States | Please contact your local Rockwell Automation representative for any technical support issues. |

New Product Satisfaction Return

Rockwell Automation tests all of its products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

| | |
|-----------------------|---|
| United States | Contact your distributor. You must provide a Customer Support case number (see phone number above to obtain one) to your distributor in order to complete the return process. |
| Outside United States | Please contact your local Rockwell Automation representative for the return procedure. |

Allen-Bradley, Rockwell Automation, Logix5000, ControlLogix, RSLogix 5000, ControlFlash and TechConnect are trademarks of Rockwell Automation, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 1756-RN643C-EN-E - November 2007

Supersedes Publication 1756-RN643B-EN-E - October 2007

PN 18128

Copyright © 2007 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.