



Installation Instructions

ControlLogix™ Battery Module

Catalog Number: 1756-BATM

IMPORTANT

Installation instructions ship with each component. If you want other documentation, you must order it separately. Refer to Additional Manuals on page 31.

Before You Begin

Use this document to install a ControlLogix™ Battery Module:

- You can use a battery module only with a 1756-L55Mxx controller.
- You can install only one battery module per controller.

Important User Information

Because of the variety of uses for the products described in this publication, those responsible for the application and use of these products must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards. In no event will Allen-Bradley be responsible or liable for indirect or consequential damage resulting from the use or application of these products.

Any illustrations, charts, sample programs, and layout examples shown in this publication are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Allen-Bradley does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.

Allen-Bradley publication SGI-1.1, *Safety Guidelines for the Application, Installation and Maintenance of Solid-State Control* (available from your local Allen-Bradley office), describes some important differences between solid-state equipment and electromechanical devices that should be taken into consideration when applying products such as those described in this publication.

Reproduction of the contents of this copyrighted publication, in whole or part, without written permission of Rockwell Automation, is prohibited.

Throughout this publication, notes may be used to make you aware of safety considerations. The following annotations and their accompanying statements help you to identify a potential hazard, avoid a potential hazard, and recognize the consequences of a potential hazard:

WARNING

Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.

ATTENTION

Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss.

IMPORTANT

Identifies information that is critical for successful application and understanding of the product.

WARNING

When you insert or remove the module while backplane power is on, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

Repeated electrical arcing causes excessive wear to contacts on both the module and its mating connector. Worn contacts may create electrical resistance that can affect module operation.

ATTENTION**Preventing Electrostatic Discharge**

This equipment is sensitive to electrostatic discharge, which can cause internal damage and affect normal operation. Follow these guidelines when you handle this equipment:

- Touch a grounded object to discharge potential static.
- Wear an approved grounding wriststrap.
- Do not touch connectors or pins on component boards.
- Do not touch circuit components inside the equipment.
- If available, use a static-safe workstation.
- When not in use, store the equipment in appropriate static-safe packaging.

Equipment that You Need

The equipment that you need to install the battery module depends on how you mount the module. You have these options:

- Mount the Battery Module Directly to a Panel
- Mount the Battery Module to a DIN Rail

Mount the Battery Module Directly to a Panel

To mount the battery module directly to a panel, you need the following equipment:

- #2 phillips screwdriver
- drill
- screws and washers

For this:	You need:	
	Quantity	Description:
top mounting tabs	2	M4 or M5 (#10 or #12) phillips screw
	2	flat washer
	2	split lock washer
bottom mounting tab	1	M4 or M5 (#10 or #12) phillips screw or SEM screw (phillips screw with attached star washer)
	1	star washer (not required for SEM screws)

Mount the Battery Module to a DIN Rail

To mount the battery module to a DIN rail, you need the following equipment:

- #2 phillips screwdriver

What You Need to Do

Before you install a battery module, do these preliminary tasks:

- ☑ Install a ControlLogix chassis according to the *ControlLogix Chassis Installation Instructions*, publication 1756-IN080.
- ☑ Install a ControlLogix power supply according to the corresponding installation instructions:

Install this power supply:	According to this publication:
1756-PA72	<i>ControlLogix Power Supplies Installation Instructions</i> , publication 1756-5.67
1756-PB72	
1756-PA75	<i>ControlLogix Power Supplies Installation Instructions</i> , publication 1756-5.78
1756-PB75	
1756-PA75R	<ul style="list-style-type: none"> • <i>ControlLogix Redundant Power Supplies Installation Instructions</i>, publication 1756-IN573 • <i>ControlLogix Redundant Power Supplies Chassis Adapter Module Installation Instructions</i>, publication 1756-IN574
1756-PB75R	







- ☑ Install a ControlLogix controller according to the *ControlLogix Controller and Memory Board Installation Instructions*, publication 1756-IN101.

To install a battery module, do these tasks:

- ☐ Make Sure that You Have All the Components
- ☐ Select a Location for the Module
- ☐ Select a Mounting Option
- ☐ Mount the Battery Module to a DIN Rail
- ☐ Mount the Battery Module Directly to a Panel
- ☐ Attach the Cable to the Controller
- ☐ Install the Battery Assembly
- ☐ Check the BAT LED
- ☐ Estimate Battery Life


Make Sure that You Have All the Components

The 1756-BATM battery module includes these components:

Component:	Description:
 31298	battery module The cable is already attached to the module.
 31325	1756-BATA battery assembly
	battery label
	universal mounting brackets
	screws for the universal mounting brackets
	DIN rail locks

Select a Location for the Module


Mount the battery module as follows:



Select a Mounting Option


If you want to:	Then go to page:
Mount the Battery Module to a DIN Rail	9
Mount the Battery Module Directly to a Panel	11

Mount the Battery Module to a DIN Rail




1. Align the holes on the mounting brackets with the holes on the back of the battery module.
2. Insert and tighten the screws.
3. Attach the battery module to the DIN rail.

- 4.** Attach a DIN rail lock (A-B catalog number 1492-EA35) on each side of the battery module.



31330

- 5.** Ground the battery module to the enclosure.



- 6.** Go to “Attach the Cable to the Controller” on page 14.

Mount the Battery Module Directly to a Panel

To mount the battery module directly to a panel:


- Drill the Mounting Holes
- Mount the Battery Module

Drill the Mounting Holes

1. Are you installing the battery module above existing components?

If:	Then:
Yes	Protect the existing components from metal chips that may fall as you drill the mounting holes.
No	Go to step 2.


2. On the panel of the enclosure, mark the holes for the mounting tabs of the battery module. Use the template on page 27.
3. Drill the holes for the mounting tabs.



31301-M


Mount the Battery Module

1. To make an electrical connection between the battery module and the enclosure, scrape the paint off the panel of the enclosure.
2. Install the hardware for the top mounting tabs.




31301-M

3. Slide the top tabs of the battery module over the screws.



31302-M



5. Install and tighten the hardware for the bottom tab.

31302-M

Attach the Cable to the Controller

WARNING



An electrical arc can occur when you:


- connect or disconnect the battery
- connect or disconnect the battery module from the controller

This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

For Safety information on the handling of lithium batteries, including handling and disposal of leaking batteries, see Guidelines for Handling Lithium Batteries, publication AG 5-4.


1. Is a 1756-BA1 battery connected to the controller?

If:	Then:
Yes	Go to step 2.
No	Go to step 3



42964

2. Disconnect the 1756-BA1 battery.



31303-M

top	white lead
middle	black lead (-)
bottom	red lead (+)

to the battery module

3. Attach the cable from the battery module to the controller.

Install the Battery Assembly


ATTENTION



Only install a 1756-BATA battery. If you install a different battery, you may damage the controller

IMPORTANT

Connect the battery assembly to the battery module only when you are ready to use it. Even if the battery module is not connected to the controller, the battery assembly begins to discharge once you connect it to the battery module.



1. Remove the door of the battery module.


31298

- Put the battery assembly into the battery module with the wires facing outward.

WARNING

When you connect or disconnect the battery an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

For Safety information on the handling of lithium batteries, including handling and disposal of leaking batteries, see Guidelines for Handling Lithium Batteries, publication AG 5-4.



- Connect the battery assembly to the battery module.

18 ControlLogix™ Battery Module


4. Replace the door of the battery module.
 5. Write on the battery label the date that you install the battery assembly.
-

EXAMPLE

7/9/01


Battery was installed on this date.

6. Attach the label to the front of the battery module.



Check the BAT LED

1. Turn on the chassis power.



2. Is the BAT LED off?

If:	Then:
Yes	The battery module is correctly installed.
No	Go to step 3.

3. Check that the battery module is correctly connected to the controller.
4. Check that the battery assembly is correctly connected to the battery module.
5. If the BAT LED remains on, install another battery assembly (catalog # 1756-BATA)..
6. If the BAT LED remains on after you complete step 5, contact your Rockwell Automation representative or local distributor.

Estimate Battery Life

When the battery is about 50 percent discharged, the controller provides the following warnings:

- On the front of the controller, the BAT LED turns on (solid red).
- A minor fault occurs (type 10, code 10).

To estimate how long the battery will support the memory of the controller:

1. Determine the temperature (° C) 1 in. below the battery module.
2. Determine the percentage of time that the controller is powered *off* per week.

EXAMPLE

If a controller is off:

- 8 hr/day during a 5-day work week
- all day Saturday and Sunday

Then the controller is off 52% of the time:

1. total hours per week = $7 \times 24 + 168$ hours
2. total off hours per week = $(5 \text{ days} \times 8 \text{ hr/day}) + \text{Saturday} + \text{Sunday} = 88$ hours
3. percentage off time = $88/168 = 52\%$

-
4. Using “Table 1 Worst-case estimates of life for the 1756-BATA battery” on page 21, determine the estimated worst-case battery life before and after the BAT LED turns on.
 5. For each year of battery life, decrease the time before the BAT LED turns on by the percentage that is shown in the table. (Do not decrease the time after the BAT LED turns on.)

IMPORTANT

If the BAT LED turns on when you apply power to the controller, the battery life may be less than the table below indicates. Some of the battery life may have been used up while the controller was off and unable to turn on the BAT LED.

Table 1 Worst-case estimates of life for the 1756-BATA battery

Controller:	Temp:	Time before BAT LED turns on:			Time after BAT LED turns on and then power off 100%:
		Power off 100%	Power off 50%	Yearly decrease:	
1756-L55M12 1756-L55M13	60° C	190 days	396 days	11%	190 days
	25° C	299 days	562 days	5%	299 days
	0° C	268 days	562 days	6%	268 days
1756-L55M14	60° C	130 days	270 days	11%	139 days
	25° C	213 days	391 days	5%	228 days
	0° C	180 days	381 days	6%	193 days
1756-L55M16	60° C	71 days	160 days	13%	76 days
	25° C	133 days	253 days	5%	142 days
	0° C	105 days	220 days	6%	112 days
1756-L55M22 1756-L55M23	Use the values for the 1756-L55M13 controller.				
1756-L55M24	Use the values for the 1756-L55M14 controller.				

Specifications

Description:	Value:
Supply Power	input power 15 mA max @ 5.1V dc
	output power 20 mA max @ 3.6V dc
Maximum Continuous Discharge Current	20 mA
Operating Temperature ⁽¹⁾	0° to 60° C (32 to 140° F)
Storage Temperature ⁽²⁾	≤30°C (86°F)
Relative Humidity ⁽³⁾	operating 5 to 95% non-condensing
	storage ≤30%
Shock ⁽⁴⁾	panel mounted operating: 30g
	non-operating: 50g
	DIN rail mounted operating: 15g
	non-operating: 15g
Emissions ⁽⁵⁾	Group 1, Class A
ESD Immunity ⁽⁶⁾	6kV contact discharges
Cable	1 m category 3 ⁽⁷⁾
Replacement Battery Assembly	1756-BATA

Description:	Value:
Certifications: (when product is marked)	UR UL Recognized Component Industrial Control Equipment
	CSA CSA Certified Component Process Control Equipment
	CSA CSA Certified Component Process Control Equipment for use in Class I, Division 2 Group A,B,C,D Hazardous Locations
	CE ⁽⁸⁾ European Union 89/336/EEC EMC Directive, compliant with: <ul style="list-style-type: none"> • EN 50081-2; Industrial Emissions • EN 50082-2; Industrial Immunity • EN 61326; Meas./Control/Lab., Industrial Requirements • EN 61000-6-2; Industrial Immunity
	C-Tick ⁽⁸⁾ Australian Radiocommunications Act, compliant with: <ul style="list-style-type: none"> • AS/NZS 2064; Industrial Emissions

⁽¹⁾ IEC 60068-2-1 (Test Ad, Operating Cold), IEC 60068-2-2 (Test Bd, Operating Dry Heat), IEC 60068-2-14 (Test Nb, Operating Thermal Shock):

⁽²⁾ IEC 60068-2-1 (Test Ab, Un-packaged Non-operating Cold), IEC 60068-2-2 (Test Bc, Un-packaged Non-operating Dry Heat), IEC 60068-2-14 (Test Na, Un-packaged Non-operating Thermal Shock):

⁽³⁾ IEC 60068-2-30 (Test Db, Un-packaged Non-operating Damp Heat):

⁽⁴⁾ IEC 60068-2-27:1987, Test Ea (Unpackaged shock, ES#002)

⁽⁵⁾ CISPR 11

⁽⁶⁾ IEC 61000-4-2

⁽⁷⁾ See *Industrial Automation Wiring and Grounding Guidelines*, publication 1770-4.1.

⁽⁸⁾ See the Product Certification link at www.ab.com for Declarations of Conformity, Certificates, and other certification details.

ATTENTION



Environment and Enclosure


This equipment is intended for use in a Pollution Degree 2 industrial environment, in overvoltage Category II applications (as defined in IEC publication 60664-1), at altitudes up to 2000 meters without derating.


This equipment is considered Group 1, Class A industrial equipment according to IEC/CISPR Publication 11. Without appropriate precautions, there may be potential difficulties ensuring electromagnetic compatibility in other environments due to conducted as well as radiated disturbance.

This equipment is supplied as "open type" equipment. It must be mounted within an enclosure that is suitably designed for those specific environmental conditions that will be present and appropriately designed to prevent personal injury resulting from accessibility to live parts. The interior of the enclosure must be accessible only by the use of a tool. Subsequent sections of this publication may contain additional information regarding specific enclosure type ratings that are required to comply with certain product safety certifications.

See NEMA Standards publication 250 and IEC publication 60529, as applicable, for explanations of the degrees of protection provided by different types of enclosure. Also, see the appropriate sections in this publication, as well as the Allen-Bradley publication 1770-4.1 ("Industrial Automation Wiring and Grounding Guidelines"), for additional installation requirements pertaining to this equipment.



Dimensions



Mounting Template

31299

Hazardous Location information

The following information applies when operating this equipment in hazardous locations:	Informations sur l'utilisation de cet équipement en environnements dangereux :
<p>Products marked "CL I, DIV 2, GP A, B, C, D" are suitable for use in Class I Division 2 Groups A, B, C, D, Hazardous Locations and nonhazardous locations only. Each product is supplied with markings on the rating nameplate indicating the hazardous location temperature code. When combining products within a system, the most adverse temperature code (lowest "T" number) may be used to help determine the overall temperature code of the system. Combinations of equipment in your system are subject to investigation by the local Authority Having Jurisdiction at the time of installation.</p>	<p>Les produits marqués "CL I, DIV 2, GP A, B, C, D" ne conviennent qu'à une utilisation en environnements de Classe I Division 2 Groupes A, B, C, D dangereux et non dangereux. Chaque produit est livré avec des marquages sur sa plaque d'identification qui indiquent le code de température pour les environnements dangereux. Lorsque plusieurs produits sont combinés dans un système, le code de température le plus défavorable (code de température le plus faible) peut être utilisé pour déterminer le code de température global du système. Les combinaisons d'équipements dans le système sont sujettes à inspection par les autorités locales qualifiées au moment de l'installation.</p>
<div data-bbox="122 647 269 692"> WARNING </div> <div data-bbox="142 700 269 821">  </div> <div data-bbox="290 639 481 662"> EXPLOSION HAZARD </div> <ul data-bbox="303 662 481 1333" style="list-style-type: none"> • Do not disconnect equipment unless power has been removed or the area is known to be nonhazardous. • Do not disconnect connections to this equipment unless power has been removed or the area is known to be nonhazardous. Secure any external connections that mate to this equipment by using screws, sliding latches, threaded connectors, or other means provided with this product. • Substitution of components may impair suitability for Class I, Division 2. • If this product contains batteries, they must only be changed in an area known to be nonhazardous. 	<div data-bbox="512 647 681 692"> AVERTISSEMENT </div> <div data-bbox="533 700 666 821">  </div> <div data-bbox="704 639 896 662"> RISQUE D'EXPLOSION </div> <ul data-bbox="717 662 913 1333" style="list-style-type: none"> • Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher l'équipement. • Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher les connecteurs. Fixer tous les connecteurs externes reliés à cet équipement à l'aide de vis, loquets coulissants, connecteurs filetés ou autres moyens fournis avec ce produit. • La substitution de composants peut rendre cet équipement inadapté à une utilisation en environnement de Classe I, Division 2. • S'assurer que l'environnement est classé non dangereux avant de changer les piles.

Additional Manuals

This product has the following manuals:

- *Logix5000 Controllers Common Procedures*, publication 1756-PM001
- *Logix5000 Controllers General Instructions Reference Manual*, publication 1756-RM003
- *ControlLogix System User Manual*, publication 1756-UM001

If you want to:

- view or download a manual, visit either of these locations:
 - www.ab.com/manuals
 - www.theautomationbookstore.com
- purchase a printed manual, use one of these options:
 - contact your local distributor or Rockwell Automation representative
 - visit www.theautomationbookstore.com and place an order
 - call 800.963.9548 (USA/Canada) or 001.320.725.1574 (outside USA/Canada)

Rockwell Automation Support

For technical assistance, call your local Rockwell Automation representative or contact Rockwell Automation in one of the following ways:

Phone	United States/Canada	1.440.646.5800
	Outside United States/Canada	You can access the phone number for your country via the Internet: <ol style="list-style-type: none">1. Go to http://www.ab.com2. Click on <i>Product Support</i> (http://support.automation.rockwell.com)3. Under <i>Support Centers</i>, click on <i>Contact Information</i>
Internet	⇒	<ol style="list-style-type: none">1. Go to http://www.ab.com2. Click on <i>Product Support</i> (http://support.automation.rockwell.com)

Allen-Bradley and ControlLogix are trademarks of Rockwell Automation.

www.rockwellautomation.com

Corporate Headquarters

Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36-BP 3A/B, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Headquarters for Dodge and Reliance Electric Products

Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4800, Fax: (1) 864.281.2433

Europe: Rockwell Automation, Brühlstraße 22, D-74834 Elztal-Dallau, Germany, Tel: (49) 6261 9410, Fax: (49) 6261 17741

Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 351 6723, Fax: (65) 355 1733

Publication 1756-IN576A-EN-P - December 2001

PN 957536-89

Copyright © 2001 Rockwell Automation. All rights reserved. Printed in the U.S.A.