



## CompactLogix Controllers, Revision 16

Catalog Numbers 1768-L43, 1768-L45

Topic	Page
About This Publication	1
Compatible Versions of Software	2
Before You Begin	3
Enhancements	4
Corrected Anomalies	9
Known Anomalies	14
Restrictions	18
Additional Memory Requirements	23
Additional Resources	24

### IMPORTANT

Before updating your controller, we strongly recommend that you review information related to the most recent previous major firmware revision, revision 15, in publication [1768-RN015](#).

Firmware release notes contain material for all minor revisions subsequent to each major revision. If your controller, for example, is at minor revision 15.3 rather than 15.5, we recommend that you download and read the latest firmware release note to be aware of information pertinent to each of these firmware upgrades before upgrading your controller to the next major revision.

Previous revision release notes, that is, publication 1768-RN015, are available at <http://literature.rockwellautomation.com>.

## About This Publication

This publication describes enhancements and anomalies (known and corrected) for the CompactLogix controllers, revision 16.

Information that has been added or changed since the last revision of this publication is indicated by a change bar as shown to the right of this paragraph.

The controllers and their most-recent corresponding major and minor revision numbers are listed in the table below. This publication describes enhancements and anomalies (known and corrected) for these CompactLogix Controllers.

Controller	Catalog No.	Major and Minor Revision No.
CompactLogix L43	1768-L43	16.20
CompactLogix L45	1768-L45	16.20

This release note, 1768-RN016E, is specific to firmware revision 16.20 for all CompactLogix controllers.

The previous revisions of this publication included the following controllers and firmware revisions. The information from previous minor revisions is retained in these release notes

#### Firmware Revisions Identified in Publication 1768-RN016D

Controller	Catalog No.	Major and Minor Revision No.
CompactLogix L43	1768-L43	16.09

We strongly recommend that you review the information provided regarding previous firmware revisions. We recommend that you do so because, if you are upgrading your firmware through multiple previous revisions, all of the information specific to all of the revisions is applicable.

## Compatible Versions of Software

To use this controller revision, the following minimum software versions are required.

Software	Required Version
RSLogix Classic	2.51
RSLogix Enterprise	4.00
RSLogix 5000	16.00 <sup>(1)</sup>
RSNetWorx for ControlNet	8.00
RSNetWorx for DeviceNet	
RSNetWorx for EtherNet/IP	

<sup>(1)</sup> Note that firmware revision 16.20 is compatible with RSLogix 5000, version 16.00 software. However, many of the corrected anomalies and restrictions described in these release notes are only available when firmware revision 16.20 is used with RSLogix 5000, version 16.03 software.

# Before You Begin

Before you upgrade your firmware, please consider the following.

**IMPORTANT**

Loss of communication or power during a controller firmware flash upgrade may result in the controller’s rejection of the new firmware. If the controller firmware upgrade fails due to the conditions described, the following corrective actions may be required:

- Cycle controller power and successfully complete the flash upgrade.
- If a non-recoverable fault, then return the controller for factory repair.

The following preliminary actions are required before upgrading your controller firmware.

If	Then
Your controller is close to its limits of memory	This revision may require more memory than previous revisions.  To see what components of your current project require more memory, see Additional Memory Requirements page 23.
Your controller is connected to a DH-485 network	Disconnect it from the DH-485 network before you update the firmware of the controller. If you update the firmware of a controller while it is connected to a DH-485 network, communication on the network may stop.

## Enhancements

These enhancements have been made in firmware revision 16.20.

### Enhancements Provided with Firmware Revision 16.20

Enhancement	Description
1768-L45 CompactLogix Controller Support	This firmware revision supports the 1768-L45 CompactLogix controller.
Radio Modem Protocol Support	With this revision, the DF1 Radio Modem protocol, already supported by SLC 500 and MicroLogix products, has been implemented and enabled in the ControlLogix, CompactLogix, FlexLogix, and DriveLogix controllers. Legacy and Logix5000 controllers can be mixed and can support both master and slave and store and forward configurations.
Motion Planner Enhancements	<p>Several Motion Planner enhancements have been made and enabled by this firmware revision.</p> <p>For more information about Motion Planner enhancements, see the Motion Planner Application Solution, publication <a href="#">RA-AP031</a>.</p>

The following enhancements have been made in previous controller revisions.

### Enhancements Provided with Previous Firmware Revisions

Enhancement	Description
Add-On Instructions	<p>With version 16 of RSLogix 5000 programming software, you can design and configure sets of commonly used instructions to increase project consistency. Similar to the built-in instructions contained in Logix5000 controllers, these instructions you create are called Add-On Instructions. Add-On Instructions reuse common control algorithms. With Add-On Instructions, you can:</p> <ul style="list-style-type: none"> <li>• ease maintenance by animating logic for a single instance.</li> <li>• protect intellectual property with password-protected instructions.</li> <li>• reduce documentation development time.</li> </ul> <p>For more information about using Add-On Instructions, see the Logix5000 Controllers Common Procedures Programming Manual, publication <a href="#">1756-PM001</a>.</p>
Logix5000 Firmware Supervisor	<p>Use of the Logix5000 Firmware Supervisor with ControlLogix controllers and certain I/O modules enables you to program the controller to complete firmware updates by using a GSV or SSV instruction. The controller uses a firmware kit loaded on a CompactFlash card and can complete firmware updates in Program and Run modes.</p> <p>In GuardLogix controllers, this enhancement is available for use with standard I/O modules.</p>
FactoryTalk Alarms and Events	<p>Alarms are now embedded in the controller with two new instructions, ALMD and ALMA, available in RSLogix 5000 software. These digital and analog alarm instructions are fully self-contained.</p>
Ability to Unicast Producer/Consumer Tags on EtherNet/IP Networks	<p>Revision 16 enables you to use RSLogix 5000 software to set Producer and Consumer tag connections to Unicast. Setting the tags to Unicast decreases the network bandwidth and simplifies Ethernet switch configuration.</p>
Logix Date Base Changed to be January 1, 1970	<p>The Logix real-time clock operates as a 64-bit binary number that counts microseconds from a fixed date. Prior to version 16, the base date was January 1, 1972. Recent developments with the Common Industrial Protocol (CIP) specification have resulted in the selection of a different base date of January 1, 1970 by the Open DeviceNet Vendors Association (ODVA). With revision 16, the date base that Logix products use has been changed to bring it into alignment with the CIP specification. Additionally, in support of the changes to the real-time clock, several other GSV attributes were also added: LocalDateTime, TimeZoneString, ApplyDST (daylight savings time), and DSTAdjustment.</p> <p>Generally, the date and time were accessed via the GSV instruction within a Logix program by using the "DateTime" attribute, which breaks down the date and time to its various components (μsec, sec, min, hour, day, month, year). Applications that use this attribute to the real-time clock should not be impacted by this change. However, the time was also available in its 64-bit form by using the "CurrentValue" GSV attribute. A GSV to "CurrentValue" of wall clock was changed to the number of microseconds from the new base date. Any applications that interpreted the old 1972 64-bit number may now require a change.</p>

Enhancements Provided with Previous Firmware Revisions

Enhancement	Description
EtherNet/IP Reduced Heartbeat	<p>The Reduced Heartbeat feature reduces the rate at which heartbeat packets are sent from a device in an I/O connection or a Produced/Consumed connection. This feature preserves bandwidth in EtherNet/IP network installations.</p> <p>The change is automatic and requires no selection. You will notice a reduction in the packets per second used on your EtherNet/IP network for several cases including all input modules and Produce/Consume tags.</p> <div><div>IMPORTANT</div><p>If you upgrade your Logix controller's firmware to revision 16.x, you must also upgrade these adapters' firmware revisions to 2.003:</p><ul style="list-style-type: none"><li>1734-AENT, POINT I/O EtherNet/IP adapter</li><li>1738-AENT, ArmorPoint I/O EtherNet/IP adapter</li></ul><p>Failure to upgrade your EtherNet/IP adapter firmware may impact your application if more than one Logix controller is connected to POINT I/O or ArmorPoint I/O modules.</p><p>For more information on using the 1734-AENT or 1738-AENT adapters with Logix controllers that have been upgraded to firmware revision 16.x or later, see:</p><ul style="list-style-type: none"><li>POINT I/O EtherNet/IP Adapter Release Notes, publication <a href="#">1734-RN002</a></li><li>ArmorPoint I/O Release Notes, publication <a href="#">1738-RN002</a></li></ul></div>

**Enhancements Provided with Previous Firmware Revisions**

Enhancement	Description
System Overhead Time Slice	<p>The System Overhead Time Slice (SOTS) lets you reserve a percentage of the controller processing resources for the handling of communication. Prior to this release, any unused part of the SOTS was used by the controller to resume the continuous task. This firmware revision lets you configure the unused portion of SOTS to either:</p> <ul style="list-style-type: none"> <li>• run the continuous task (default/legacy mode), allowing for faster execution of application code.</li> <li>• reserve it for communication, providing for more predictable and deterministic continuous task scan time.</li> </ul> <p>This enhancement allows the full impact of communication on the continuous task to be determined if time reserved for communication were always fully used.</p>
AutoFlash for SERCOS Drives	<p>The functionality of the AutoFlash feature has been enhanced to allow for the Kinetix 2000, Kinetix 6000, Kinetix 7000, 1394, Ultra3000, and 8720MC Rockwell Automation SERCOS drives to be firmware flashed. This simplifies the software upgrade process by, in one step, flashing firmware for the controller module, motion modules, and Rockwell Automation SERCOS rings when downloading the application.</p>
Programmable Jerk Control	<p>You can specify acceleration and deceleration jerk rates on single axis moves directly via operands in the instruction faceplate for S-curve profile motion. Jerk rates for S-curve motion can be specified as either “Units/Sec3”, “% of Maximum”, or a new “% of Time”, letting you optimize the need for speed and smoothness. The configured maximum jerk rates are accessible programmatically via GSV/SSV instructions. Earlier revision of projects using S-curve velocity profiles will be automatically migrated forward and repopulate the new Jerk Operands in the MAM, MAJ, and MAS instructions with default values for Jerk rate as “100% of Time”.</p>
Home to Torque (Kinetix 2000, 6000 and 7000)	<p>Motion homing capabilities have been extended to provide two additional homing modes.</p> <ul style="list-style-type: none"> <li>• Torque Level allows the homing position to be set when a configured torque limit is reached.</li> <li>• Torque Level-Marker lets the homing position to be set when the configured torque limit is reached and feedback marker is detected.</li> </ul> <p>These capabilities allow for enhanced application flexibility by removing the need for a home switch.</p>
Kinetix 2000 Drive Support	<p>The Kinetix 2000 Servo Drive 230V ac family, is now supported. Power range is 100 W...1.5 kW. The Kinetix 2000 drive can also be configured to operate with single-phase or three-phase power.</p>
Kinetix 7000 Drive Analog Input Configuration	<p>This feature allows an analog device to be connected to the Kinetix 7000 drive analog inputs. The drive transmits to the controller an integer number with a range of -16,384...16,384 representative of the analog value. The analog values are accessible programmatically via the GSV instruction. These inputs are useful for “converting” applications with load cell (measuring web force on a roller) or “dancer” (measuring web force/position directly) that can be directly connected to the drive controlling the web.</p>

**Enhancements Provided with Previous Firmware Revisions**

<b>Enhancement</b>	<b>Description</b>
Configurable Power Loss Fault Action	A fault action called Phase Loss has been added for the Kinetix 6000 and Kinetix 2000 drives. This addition allows configuration of the fault action during a phase loss situation. The configurable fault actions are Shutdown (default), Disable Drive, Stop Motion, and Status Only. When the Phase Loss fault group is configured as Status Only, Logix5000 motion commands continue and the drive uses available stored DC bus energy to operate axes. This attribute cannot be set via an SSV. For a description of user application logic needed to support this feature on Axis Modules (AMs), refer to the topic titled Phase Loss Fault-action for AM vs. IAM on Kinetix 2000 and 6000 in the Application Note section of the online help.
Positive and Negative Rotary Move Types for MAM Instruction	Previously, the move type of the Motion Axis Move (MAM) instruction generated a directional reversal if the deceleration distance was longer than the distance between the start point and the end point. In this revision, two new rotary move types (Rotary Negative and Rotary Positive) have been added for the MAM instruction. These two move types travel in a unidirectional path to reach the end point. The unidirectional path is continued until the end point is reached even if that means additional turns or unwinds are required.
S-curve MCS stop adjustment via Dynamics Configuration Bits	<p>Bits for user definable configuration have been added to the COORDINATE_SYSTEM data type to allow for more adjustment to the deceleration mechanism for S-curve profile moves. The DynamicsConfigurationBits attribute allows for configuration setting for these three items:</p> <ul style="list-style-type: none"> <li>• Reduced S-curve stop delay</li> <li>• Reduced S-curve velocity reversal</li> <li>• Reduced S-curve velocity overshoot</li> </ul> <p>This attribute can be accessed via GSV/SSV.</p>
Online Changes in Output CAM Editor	Parameter values can be changed for the output CAM profile either on the grid or by using the graphical view. Insertion and/or deletion of points while in Run mode are not allowed. A new status rectangle icon has been added to the Output CAM Editor dialog to show the state of the control. The color of the rectangle is green when the controller is in Run mode, cyan while in Program mode, and gray while in the offline state.



## Corrected Anomalies

These anomalies have been identified and corrected in controller firmware revision 16.20.

### Anomalies Corrected in Firmware Revision 16.20

Anomaly	Description
Changing the controller mode from Run to Program is unsuccessful.	<p>When the controller mode is changed from Run to Program and an alarm instruction has a delivery state of In Progress, the controller does not change modes.</p> <p>To view the delivery state, open the Alarm Properties dialog and click the Messages tab.</p> <p>This anomaly may occur even when the controller is not connected to a FactoryTalk Alarm server.</p> <p>Lgx00075913</p>
Simultaneous branches in a Sequential Function Chart may not execute at the same time or in the same scan.	<p>When executing a simultaneous branch, it may take two scans of the routine before all of the simultaneous branches execute. It does not take more than two scans for all simultaneous branches to completely execute.</p> <p>Lgx00075143</p>
During Prescan, a Major Recoverable Fault, Type 6, Code 1, occurs.	<p>Each task programmed for a Logix controller has a Prescan Watchdog of 5 seconds. You cannot change this setting in RSLogix 5000 software.</p> <p>The fault typically occurs when these elements are present in the program:</p> <ul style="list-style-type: none"> <li>• Add-On Instructions that use PreScan mode.</li> <li>• A large program with many tasks and subroutines where a majority of the application memory is used by the application code and not tags.</li> </ul> <p>Other elements and factors may also cause the fault, however, those listed are the most common.</p> <p>When the fault occurs, the Prescan Watchdog has been exceeded. With this firmware revision, the Prescan Watchdog has been increased to 60 seconds.</p> <p>Lgx00077337</p>
Use of an ACL with other ASCII Serial Port instructions may result in a Major Non-Recoverable Fault.	<p>If an ACL instruction is executed while other ASCII instructions are active, a Major Non-Recoverable Fault may occur.</p> <p>Lgx00076857</p>
Add-On Instructions yield unexpected results.	<p>When calling an Add-On Instruction, if the data types of the tags passed into or out of the instruction do not match the parameter definitions, unexpected behavior can result.</p> <p>In the logic of an Add-On Instruction, reading a tag of type INT can also yield incorrect results.</p> <p>Lgx00075524</p>
Digital alarms (ALMD) may prematurely report an in-alarm state.	<p>The tag InAlarm reports the alarm (InAlarm=1) before the time entered in the MinDurationPRE tag expires.</p> <p>Lgx00075889</p>

**Anomalies Corrected in Firmware Revision 16.20**

<b>Anomaly</b>	<b>Description</b>
Circular colinearity error.	<p>In addition to the circular colinearity error (44) for a coordinate system with three primary axis, we have now added the same error check for a coordinate system with two primary axes. The current error check for a three-axes system generates the error if the specified start, end, and center points are colinear in any order. However, for a two-axis coordinate system, the error is generated only if the specified points are both colinear and in this order:</p> <p>Start Point -&gt; End Point -&gt; Center Point</p> <p>For example, for a two-axis coordinate system with these three points:</p> <ul style="list-style-type: none"> <li>• Error 44 is generated: Start Point = (0,0) -&gt; End Point = (10,0) -&gt; Center Point = (20,0)</li> <li>• No error is generated: Start Point = (0,0) -&gt; End Point = (20,0) -&gt; Center Point = (10,0)</li> </ul> <p>Lgx00069493</p>
MAS IP bits may remain set if an MGS instruction is initiated.	<p>If an MGS instruction is issued while MAS-All instructions are being executed, the MAS instruction in process bit would remain latched true. All axis motion would stop, but the MAS instructions would remain in process.</p> <p>Lgx00076212</p>
Position overshoot on velocity-limited moves.	<p>For moves with very special combinations of fast velocities, slow decelerations and distances that produced velocity-limited moves, it was possible to sometimes overshoot a programmed end point and then return to it.</p> <p>Lgx00069310</p>
Configuration of an MAS instruction for a single axis.	<p>If your program has an active MAS instruction with a StopType of All (0), Jog (1), Move (2), Gear (3), Home (4), Tune (5), Test (6), Position Cam (7), Time Cam (8), or Master Offset Move (9) and it is followed by an MAS instruction with a StopType of All (0), then the motion of the axis is not stopped. The process complete bit (.PC) for the MAS (All) instruction may appear to be set; however, the instruction is ignored by the system.</p> <p>To stop motion, you must configure an additional MAS instruction with a StopType of Move (2) that has the same instruction operands and execution time as the MAS instruction with the StopType of All (0).</p> <p>For more information, see the Tech Note titled "Advisory Information for Configuring Motion Axis Stop Instructions for an Axis with CompactLogix, ControlLogix, and SoftLogix Controllers" in the Technical Support Knowledgebase.</p> <p>Lgx00075962</p>

The following table contains descriptions of anomalies corrected in previous firmware revisions.

#### Anomalies Corrected in Previous Firmware Revisions

Firmware Revision	Anomaly	Description
16.09	PanelView Plus operator terminals utilizing the serial port to communicate with the controller will not establish communication at startup.	When the application on the PanelView Plus operator terminal begins to initialize communication with the controller, the controller responds with packets that exceed the 500 byte packet size. The PanelView Plus terminal then stops attempting communication with the controller. When this occurs, data is not updated on the PanelView Plus operator terminal.  Lgx00074400
	Using FFL (FIFO load) or LFL (LIFO load) instructions in the same program as an Add-On Instruction may cause the controller to experience a Major Non-Recoverable Fault.	If an Add-On Instruction is executed after a FFL or LFL instruction in a given program, the internal registers are incorrectly written to and the result is a Major Non-Recoverable Fault. For the fault to occur, all of the following must be true: <ul style="list-style-type: none"> <li>The Add-On Instruction and FFL and LFL instruction must be in the same program in a Logix application. If the application has two programs defined and the Add-On Instruction is in program A and the FFL or LFL are in program B, no anomaly will be seen.</li> <li>The FFL/LFL instruction must load a scalar type (SINT, INT, DINT, or REAL). If the source value is a structure, no anomaly will be seen.</li> <li>The FFL/LFL instruction must be scanned before the Add-On Instruction. If the Add-On Instruction comes first in the code, no anomaly will be seen.</li> </ul> The rung condition does not matter. If the required conditions exist, the fault will occur during prescan. Lgx00074725
16.07	Changes to RPI are not correlated between all workstations when multiple workstations are connected to the controller.	If you are online with one controller from two or more workstations and you alter the RPI setting for an I/O connection on one workstation, the change in RPI does not register on the other workstations. The change in RPI registers only if the altered RPI program is uploaded from the controller by the other workstations.  Lgx00070714
	LimitsInv and SelectLimitInv are swapped.	In the High/Low Limit (HLL) instruction: <ul style="list-style-type: none"> <li>LimitsInv parameter is set when the SelectLimit is invalid.</li> <li>SelectLimitInv parameter is set when the HighLimit and LowLimit parameters are invalid.</li> </ul> Lgx00055977

**Anomalies Corrected in Previous Firmware Revisions**

<b>Firmware Revision</b>	<b>Anomaly</b>	<b>Description</b>
16.07	Unexpected motion can happen when you home a rotary axis of a SERCOS drive.	<p>A rotary axis of a SERCOS drive can move with unexpected motion if you use a Homing Offset when you home the axis. The axis starts to move at a high speed until a position error fault happens. Once the fault happens, the axis responds with the configured fault action. For example, the default fault action is Disable Drive. In that case, the controller disables the axes and the drive stops the axis.</p> <p>This issue happens under this specific combination of circumstances.</p> <ul style="list-style-type: none"> <li>• The type of axis is AXIS_SERVO_DRIVE (SERCOS interface drive).</li> <li>• The Positioning mode of the axis is Rotary.</li> <li>• The axis has a <b>Homing</b> Offset that is near or greater than the Position Unwind value of the axis.</li> <li>• A Motion Axis Home (MAH) instruction executes when the axis is near its unwind position.</li> </ul> <p>For more information, see TechNote 34404.</p> <p>Lgx00061613 and Lgx00056675</p>
	MAOC instruction output remains ON when enable input is low.	<p>An Output CAM element is configured with a Latch type of Position and Enable, and Unlatch type of Position and Enable. While the CAM element is active (the output is ON) the application sets the Unlatch Position to the value of the Latch Position. The output remains ON even if the Enable Input is dropped.</p> <p>For more information, see Technote 37835.</p> <p>Lgx00069685</p>
	In coordinated motion a rotary axis always moves.	<p>When there is a rotary axis configured for the Coordinate System, the rotary axis makes one complete revolution even if the current command position is equal to the position in the Motion Coordinated Linear Move (MCLM) instruction.</p> <p>Lgx00056359</p>
	SlaveAxis.PositionCamLockStatus is reset when master axis stops/starts quickly using a Motion Axis Jog (MAJ) instruction.	<p>When the manual jog input is cycled ON and OFF at a rapid rate, the SlaveAxis.PositionCamLockStatus gets reset and the SlaveAxis.PositionCamStatus remains set.</p> <p>Lgx00066064</p>
	While an axis is accelerating an MAS is initiated, a delay is experienced before the axis begins to decelerate to a stop.	<p>This occurs with Stop Move and Stop Jog in combination with S-curve velocity profiles. While an MAM or MAJ is accelerating, an MAS is initiated to stop it. Even though the deceleration rate is higher than the ones specified in the MAM or MAJ, the axis begins to slow at a lower rate before decelerating at the higher rate programmed in the MAS.</p> <p>Lgx00055080</p>

**Anomalies Corrected in Previous Firmware Revisions**

<b>Firmware Revision</b>	<b>Anomaly</b>	<b>Description</b>
16.07	A Cam Profile can become locked such that an MCCP instruction can no longer update it.	<p>This anomaly may occur if an MCSV executing in an application task is interrupted by the motion task, which has a MAPC instruction currently in-process.</p> <p>Lgx00060994</p>
	On a uni-directional home, the.IP bit is cleared, the AxisHomedStatus attribute is set, but the .PC bit is not set.	<p>If the home direction is uni-directional and the home offset is less than the distance to decelerated, then the axis is simply decelerated to a stop. The axis does not reverse direction to move to the home position. In this case, the .PC bit of the MAH instruction is not set. The .PC bit is set when the axis stops at the configured home position.</p> <p>Lgx00063431</p>
	Processing of denormalized number exceptions causes a Major Non-Recoverable Fault.	<p>A denormalized number is any 32-bit, floating-point value that is less than <math>1.75494210 \times 10^{-38}</math> or greater than <math>-1.75494210 \times 10^{-38}</math>, excluding zero. Denormalized numbers typically occur when very small real numbers are divided by very large real numbers.</p> <p>This anomaly typically occurs when the following sequence takes place.</p> <ol style="list-style-type: none"> <li>1. The controller is handling an exception of a floating-point denormalized number in task A.</li> <li>2. Then task B begins to execute and handles an exception of a floating-point denormalized number.</li> <li>3. And, task B completes as task A begins again.</li> </ol> <p>Lgx00057774</p>

## Known Anomalies

This table lists known anomalies of controller revisions 16.00 . . . 16.20.

For more information about controller revisions and firmware revisions, see the tables on page 2.

### Known Anomalies for Firmware Revisions 16.00 . . . 16.20

Anomaly	Description
Use of revision 16 firmware and the controller serial port results in extended program scan times.	<p>If you use firmware at revision 16, including revisions 16.02...16.20, and the controller's serial port, the program scan time may increase. The program scan time increase in revision 16 may be two...ten times the scan time of the same program with revision 15.</p> <p>This anomaly only occurs when the controller serial port is used and there is no workaround.</p> <p>Lgx00077845</p>
Indirectly addressing an instance tag in an Add-On Instruction results in a Major Non-Recoverable Fault.	<p>When an indirectly-addressed instance tag is used instead of a directly- addressed instance tag within an Add-On Instruction, a Major Non-Recoverable Fault occurs. Typically the major fault occurs during the prescan of the controller.</p> <p>See the Restrictions section on page 18 for more information about this anomaly.</p> <p>Lgx00077261</p>
Motion Redefine Position (MRP) Error 13 for Positions within the range.	<p>You may get the error "Parameter out of Range" if the MRP is executed when:</p> $\text{Current Position} + \text{MRP Position} > 2^{31}/\text{Axis Conversion Constant}.$ <p style="text-align: center;">Or</p> $\text{Current Position} + \text{MRP Position} < -2^{31}/\text{Axis Conversion Constant}.$ <p>For example, assume that the:</p> <ul style="list-style-type: none"> <li>axis conversion constant = 120,000.0 feedback counts/1.0 unit.</li> <li>current command position = 17,893.0 units.</li> </ul> <p>If you MRP with a position of five units, which exceeds <math>2^{31}/\text{Axis Conversion Constant}</math>, the MRP will error.</p> <p>To work around this anomaly, move the axis to a value within the acceptable range specified above.</p> <p>Lgx00073719</p>
SSV of MotionGroup Average Scan Time causes a jump in scan time.	<p>If an SSV instruction with a value of zero is executed against the MotionGroup attribute TaskAverageScanTime, then a GSV instruction is executed. The average scan time jumps to an incorrect value. The larger the Coarse Update Period, the larger the jump will be. For example, with a Coarse Update Period of 26 ms, the average scan time value can increase to over 300 ms.</p> <p>Lgx00071520</p>

**Known Anomalies for Firmware Revisions 16.00 . . . 16.20**

Anomaly	Description
Axis ActualAcceleration tag is not updated for virtual axes.	<p>For the virtual axis, the Axis_tag.ActualAcceleration does not update, but the Axis_tag.CommandedAcceleration does. The actual position of a physical axis is based on actual motor feedback, which is why the virtual Actual Acceleration tag does not update on a virtual axis. To work around this anomaly, use these command-based tags:</p> <ul style="list-style-type: none"> <li>• Virtual_Axis.CommandPosition</li> <li>• Virtual_Axis.CommandVelocity</li> <li>• Virtual_Axis.CommandAcceleration</li> </ul> <p>Lgx00073829</p>
Setting invalid home sequence value via SSV instruction.	<p>Do not attempt to program a set system value (SSV) instruction to set the home sequence to torque or torque marker if the drive is not a SERCOS drive. If you do so on a non-SERCOS drive, any subsequent attempt to program this attribute via an SSV will produce a minor controller fault.</p> <p>Lgx00068281</p>
Duration Cam - Latch and Unlatch Delays.	<p>Duration cams enable an application to turn an output on at a specific position and off after the configured Duration time. Latch and unlatch delays adjust the point at which an output turns on and off, regardless of axis speed.</p> <p>If you enter a latch delay, your application will adjust the point at which your output turns on. For example, a latch delay of 0.5 seconds will cause your output to turn on 0.5 seconds sooner and then remain on for the configured Duration time, in addition to the 0.5-second head start. However, using this example, currently, the total time your application's output remains on is being decreased by 0.5 seconds.</p> <p>If you enter an unlatch delay, your application will adjust the point at which your output turns off. For example, an unlatch delay of 0.5 seconds will cause your output to turn off 0.5 seconds sooner. However, using this example, currently, the total time your application's output remains on is extended by 0.5 seconds above and beyond the configured Duration time.</p> <p>If you execute a latch and unlatch delay for the identical value, no anomaly occurs, and the output will remain on for the configured Duration time.</p> <p>Lgx00068599</p>

**Known Anomalies for Firmware Revisions 16.00 . . . 16.20**

<b>Anomaly</b>	<b>Description</b>
PI function block appears to stop executing as the output does not change and no instruction faults are logged.	<p>If the PI instruction is being used in Linear mode, this floating-point equation is used to calculate the ITerm.</p> $Kp \times Wld \times \frac{WldInput + WldInput_{n-1}}{2} \times DeltaT + ITerm_{n-1}$ <p>Due to the use of the single-precision floating point values, it may be possible, depending on the values of WLD and KP, for the ITerm value to be small enough, less than 0.0000001, to be lost when adding to the ITerm<sub>n-1</sub>.</p> <p>For more information regarding the PI instruction, see the Logix5000 Controllers Process Control and Drives Instructions User Manual, publication <a href="#">1756-RM006</a>.</p> <p>Lgx00070832</p>
Changes made to a timeout in the alarms system require a new download of the program to controller.	<p>To verify that the timeout change is used by the controller, you must download the program to the controller after each change to the timeout variable.</p> <p>Lgx00069461</p>
The Slot Status bit for an I/O connection is slow to update if the connection is lost.	<p>When using I/O on an Ethernet network, if the connection to the network is lost at the adapter, the SlotStatusBit for that connection will not register the disconnect for 9 seconds or more.</p> <p>If you require loss-of-connection data more quickly than the 9 seconds, use the GSV instruction to monitor the entry status of the connection as it updates more quickly than the SlotStatusBit.</p> <p>Lgx00072697</p>
When the SFC instruction's Last Scan of Active Steps option is set to Automatic Reset, a Major Non-Recoverable Fault occurs.	<p>A Major Non-Recoverable Fault may occur when these elements are present in the program:</p> <ul style="list-style-type: none"> <li>• Within an SFC, a JSR instruction is used to jump to another SFC, also known as a nested SFC.</li> <li>• One or more of the nested SFC instructions contains Simultaneous Branches.</li> <li>• The Last Scan of Active Steps option (specified in the SFC Execution tab of the controller Properties dialog) is set to Automatic Reset.</li> </ul> <p>To avoid a Major Non-Recoverable Fault when these elements are present, set the Last Scan of Active Steps to Don't Scan or to Programmatic Reset.</p> <p>Lgx00072702</p>



**Known Anomalies for Firmware Revisions 16.00 . . . 16.20**

Anomaly	Description
A function block is initiated, either directly or indirectly by an SFC instruction, when the parent step becomes active.	<p data-bbox="592 331 1469 485">During the first scan of an SFC step, the Step.FS bit is set. In addition, the S:FS bit is set, which allows the logic in any associated actions to easily detect the first scan state. This behavior is useful when a subroutine that is called by multiple actions (actions that may be connected to other steps) is used. The first scan state can be detected without programming a reference to the tag of a specific step.</p> <p data-bbox="592 520 1469 611">Many function blocks contain internal data that must be initialized before the block can be used. One of the methods a block uses to determine if it should initialize is by evaluating the S:FS bit, which the function block identifies as the first scan following a prescan.</p> <p data-bbox="592 646 711 680">Lgx00071558</p>
An SFC R action continues to post-scan on the specified action.	<p data-bbox="592 688 1469 751">This anomaly occurs only if the SFC Last Scan of Active Steps option is set to Programmatic Reset or Automatic Reset. When the default, Don't Scan, is set, the anomaly does not occur.</p> <p data-bbox="592 787 1469 877">The intention of a reset action, type R, is to terminate the execution of another action that was previously stored. When configured as described above, the reset action causes logic to execute a final scan.</p> <p data-bbox="592 913 1469 1003">The reset action does not check to verify that an action is stored before it completes the final scan. As a result, each time the reset action is scanned, the target logic will be scanned one last time.</p> <p data-bbox="592 1039 974 1073">These observable behaviors may result:</p> <ul data-bbox="604 1108 1469 1423" style="list-style-type: none"> <li data-bbox="604 1108 1469 1171">• The timer of the stored action will continue to time even though the action is no longer active.</li> <li data-bbox="604 1207 1299 1241">• The logic in the stored action will be executed in the configured mode.</li> <li data-bbox="604 1276 1153 1310">• At Automatic Reset, non-retentive outputs are cleared.</li> <li data-bbox="604 1346 1469 1423">• At Programmatic Reset, the logic will execute. In this situation, the action logic checks for the final scan condition (action.A = 1 and action.Q = 0) and performs some shutdown operations. This is the code that will be executed.</li> </ul> <p data-bbox="592 1459 711 1486">Lgx00069295</p>
MCT instruction .PC bit operational but not defined.	<p data-bbox="592 1495 1469 1633">Within an MCT instruction control word there is a default .PC bit. When the MCT instruction transitions from true to false, the .PC bit may set to 1. The MCT instruction is not intended to have operation associated with this bit and we recommend that you do not use the .PC bit in your application.</p> <p data-bbox="592 1669 711 1692">Lgx00073233</p>

**Known Anomalies for Firmware Revisions 16.00 . . . 16.20**

<b>Anomaly</b>	<b>Description</b>
Attempts to download a program to a controller following a failed firmware upgrade are successful. (Failure is indicated by the OK status indicator flashing red after the upgrade is complete.)	<p>After a firmware upgrade attempt fails during the upgrade, (for example, the cable is disconnected or communication is interrupted) the controller's OK status indicator flashes red and any user attempts to clear the fault by toggling the controller's keyswitch are unsuccessful.</p> <p>You can download a program to the controller, place the controller in Run mode, and run the program (the RUN status indicator displays run status). The outputs behave as specified by the program. However, when controller power is cycled, the program is lost and the controller properties indicate a firmware revision different from that most recently downloaded to the controller.</p> <p>Lgx00071250</p>
A major fault may occur during rapid power cycles.	<p>Occasionally, when power is cycled (with specific timing), a timing parameter is not re-initialized properly. This results in an early timeout being declared in the handshake with the backplane ASIC, which precipitates a major fault condition.</p> <p>Lgx00077713</p>
Messages through the 1769-SDN scanner to a missing node may not report error.	<p>In rare instances, messaging to missing nodes on DeviceNet through the 1769-SDN scanner may complete without error. Use the DeviceStatus fields located in the 1769-SDN I/O structure to determine device status on the network.</p> <p>Lgx00073904</p>

**Restrictions**

These restrictions apply to the use of ControlLogix controllers.

**Restrictions with Firmware Revision 16.20**

<b>Firmware Revision</b>	<b>Restriction</b>	<b>Description</b>
16.20	Outputs controlled by an MAOC instruction can remain ON in some configurations.	<p>This anomaly occurs when the output CAM ON window positions are redefined while the output controlled by the output CAM element is active. In some instances, the Motion Planner may not detect the off-crossing of the window and the output controlled by the output CAM element remains ON. This issue is applicable to any output point or virtual output controlled by an MAOC instruction.</p> <p>For more information, see Tech Note 37835.</p>

**Restrictions with Firmware Revision 16.20**

<b>Firmware Revision</b>	<b>Restriction</b>	<b>Description</b>
16.20	Use of an indirectly-indexed tag within an Add-On Instruction instance tag is not accepted by the RSLogix 5000 program.	<p>In RSLogix 5000, version 16.00 software, if you use an indirectly-indexed array in an instance tag of an Add-On Instruction, anomalous behavior may result.</p> <p>For example, in the instruction call <code>MyAOI (AOIData [ Index ] )</code>, the value <code>[ Index ]</code> selects the <code>AOIData</code> tag element used to call <code>MyAOI</code>. The use of <code>[ Index ]</code> results in anomalous behavior when the program is executed.</p> <p>In RSLogix 5000, version 16.03 software, and controllers firmware revision 16.20, if an indirectly-indexed tag is used in an instance tag, the edit is not accepted by the program. Instead, use a directly-indexed instance tag. For example, instead of using tag <code>MyAOI (AOIData [ Index ] )</code>, use tag <code>MyAOI (AOIData [ 2 ] )</code> or similar so that the exact element of the array is directly-indexed. The program accepts directly-indexed instance tags.</p> <p>You may continue to use indirectly-addressed tags in Add-On Instruction parameters without anomalous behavior in RSLogix 5000 software, versions 16.00 and 16.03.</p> <p>Lgx00077261</p>

**Restrictions with Firmware Revision 16.20**

<b>Firmware Revision</b>	<b>Restriction</b>	<b>Description</b>
16.20	Passing a User-defined Data Type (UDT) into an Add-On Instruction results in a Major Recoverable Fault or data memory corruption.	<p>An anomaly occurs when you pass a tag based on a User-defined Data Type (UDT) into an Add-On Instruction, and certain conditions are met that result in a Major Recoverable Fault or data memory corruption.</p> <p>Conditions required for Major Recoverable Fault or data memory corruption include:</p> <ul style="list-style-type: none"> <li>• A one-dimensional array tag that is based on a UDT is passed into the Add-On Instruction.</li> <li>• The UDT tag contains a member that is a one-dimensional array.</li> <li>• Inside the Add-On Instruction, an operand address that specifies an immediate member of the UDT tag array and a variable element of the member array (for example, array[0].memberArray[x]) is used.</li> </ul> <p>Examples:</p> <pre>UDT array[0].memberArray[x]</pre> <p>When the size of the UDT array is smaller than that of the memberArray and the [x] value of the memberArray is larger than the size of the UDT array, a Major Recoverable Fault Code 4 Type 20 occurs.</p> <pre>UDT array[0].memberArray[x]</pre> <p>When the size of the UDT array is bigger than the memberArray and the [x] value is smaller than the size of the UDT Array but larger than the size of the memberArray, the expected fault does not occur and the data is written to a location outside the bounds of the memberArray.</p> <p>Lgx00077270 and Lgx00076136</p>
16.20	Upload of Add-On Instruction With Literal Boolean Input Parameter Modifies Offline Image	<p>When an Add-On Instruction containing a literal value for one of its Boolean Input parameters is referenced from a Ladder Diagram routine, an upload of the project will modify the display of the literal value by appending a ".0". Each time the project is downloaded and re-uploaded, another ".0" is appended, so that after the second download/upload sequence, the project file will not verify and can no longer be downloaded without first editing the modified literal value. The edit may be successfully performed either online or offline. Note, however, that when editing online, because the rung is in an unverified state, the "Finalize All Edits in Program" will not operate. In this case, use of the Accept/Test/Assemble sequence of operations will allow the edit to be completed. This condition does not affect the executing image, which will continue execution using the unmodified literal value. To avoid exposure to this problem, replace the literal value with a reference to a tag having the desired value.</p> <p>Lgx00077802</p>

## Install the Controller Revision

To install the latest ControlLogix controllers revision, go to <http://support.rockwellautomation.com> to download your revision. Then use the ControlFlash utility to upgrade your controller.

Alternatively, if you have installed RSLogix 5000 software, version 16, and related firmware, you may not need to complete the tasks described. The AutoFlash feature of RSLogix 5000 software, version 16, detects if your controller firmware needs upgraded upon a program download to the controller. If a firmware upgrade is necessary, AutoFlash will initiate an update.

After you have completed your firmware upgrade, you should complete these steps to verify that the upgrade was successful.

1. Cycle power to the controller.
2. Go online with the controller and view controller properties.
3. Verify that the firmware revision listed matches the firmware to which you intended to upgrade.
4. If the controller's firmware is not correct, initiate another firmware upgrade.

For more information about errors when completing a ControlFlash upgrade, see the ControlFlash Firmware Upgrade Kit Quick Start, publication [1756-QS105](#).

## Additional Memory Requirements

Revision 16.00 or later may require more memory than previous revisions (for example, 10.x, 11.x). To estimate the additional memory that your project may require, use this table.

If you have this firmware revision	Then add the following memory requirements to your project		Which comes from this type of memory	
	Component	Increase per instance	I/O (base)	Data and Logic (expansion)
15.x	Input module	4 bytes	✓	
	Produced tag	12 bytes	✓	
	Consumed tag	4 bytes	✓	
	Task	20 bytes		✓
	Program or equipment phase	24 bytes		✓
	Routine	4 bytes		✓
	Tag that uses COORDINATE_SYSTEM data type	748 bytes		✓
	Tag the uses any AXIS data type	800 bytes		✓
	Serial Port	1120 bytes		✓
	Project	4012 bytes		✓

## Additional Resources

These documents contain additional information concerning related Rockwell Automation products.

Resource	Description
Logix5000 Controllers Common Procedures Reference Manual, publication <a href="#">1756-PM001</a>	Contains information specific to Add-On Instructions.
CompactLogix Controllers Revision 15 Release Notes, publication <a href="#">1768-RN015</a>	Describes anomalies and enhancements related to controller revision 15.
Logix5000 Process Control and Drives Instructions Reference Manual, publication <a href="#">1756-RM006</a>	Contains information specific to the PI instruction.
Outputs Controlled by MAOC Instruction Tech Note, ID 37835	Further describes the MAOC instruction anomaly.
ControlFlash Firmware Upgrade Kit Quick Start, publication <a href="#">1756-QS105</a>	Contains informations about firmware upgrades, installation instructions, and error messages.
POINT I/O EtherNet/IP Adapter Release Notes, publication <a href="#">1734-RN002</a>	Further describes the firmware upgrade to 2.003.
ArmorPoint I/O Release Notes, publication <a href="#">1738-RN002</a>	Further describes the firmware upgrade to 2.003.

You can view or download Rockwell Automation publications at <http://literature.rockwellautomation.com>. To order paper copies of technical documentation, contact your local Rockwell Automation distributor or sales representative.

Tech Notes and other resources are available at the Technical Support Knowledgebase, <http://www.rockwellautomation.com/knowledgebase>.

## Notes:





# Rockwell Automation Support

Rockwell Automation provides technical information on the Web to assist you in using its products. At <http://support.rockwellautomation.com>, you can find technical manuals, a knowledge base of FAQs, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools.

For an additional level of technical phone support for installation, configuration, and troubleshooting, we offer TechConnect Support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://support.rockwellautomation.com>.

## Installation Assistance

If you experience a problem with a hardware module within the first 24 hours of installation, please review the information that's contained in this manual. You can also contact a special Customer Support number for initial help in getting your module up and running.

United States	1.440.646.3434 Monday – Friday, 8am – 5pm EST
Outside United States	Please contact your local Rockwell Automation representative for any technical support issues.

## New Product Satisfaction Return

Rockwell tests all of its products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning, it may need to be returned.

United States	Contact your distributor. You must provide a Customer Support case number (see phone number above to obtain one) to your distributor in order to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for return procedure.

Allen-Bradley, Rockwell Automation, RSLogix 5000, CompactLogix, ControlLogix, RSLinx Classic, RSLinx Enterprise, RSLinx, ControlFlash, RSLogix 5000, RSNetWorx for ControlNet, RSNetWorx for DeviceNet, RSNetWorx for EtherNet/IP, Ultra3000, PanelView Plus, GuardShield Safety Light Curtain, Logix, Logix5000, FactoryTalk Alarms and Events, SLC 500, MicroLogix, CompactLogix, FlexLogix, DriveLogix, POINT I/O, ArmorPoint and TechConnect are trademarks of Rockwell Automation, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

**[www.rockwellautomation.com](http://www.rockwellautomation.com)**

### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 1768-RN016E-EN-E - August 2007

Supersedes Publication 1768-RN016D-EN-P - April 2007

PN 14540

Copyright © 2007 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.