

# PowerXL PC Tools 101



# Agenda

---

- Power Xpert InControl
  - Overview
  - Connecting
  - Parameter Editing
- Power Xpert InControl Firmware Upgrade Tool
  - Overview
  - Configuring
  - Loading Processors



# Part 1: PowerXpert *in*Control Overview

# Power Xpert *inControl*

An Eaton developed FDT/DTM device configuration and control tool assisting in streamlining network commissioning over fieldbus communication systems.

## **Customer Value:**

- Standardized Configuration interface
- Remote parameter download and upload abilities
- Monitoring and data logging capabilities
- Device parameter backup files available



## **Compatible Products:**


- PowerXL DG1 Drives
- C445 Overload Relay
- Planned future intergration of other Eaton product platforms

## **Competitive Products:**


- Industry standard software allowing integration of non-Eaton devices

# FDT & DTM Software Concept

- FDT program can be related to Internet Explorer which is the underlying program which opens / interacts with different web pages



- DTM programs can be related to individual web pages which can load multiple pages from different organizations in Internet Explorer





# Software Framework

- Underlying software based on industry standard coding requirements called a field device tool (FDT) framework
- Base generic framework provided and maintained by FDT Group ([www.fdtgroup.org](http://www.fdtgroup.org))
- Provides common software interface for multiple products and over a variety of communication protocols




# Software Structure

---

- Three main navigation and configuration sections of software
  - **Network View** – displays status of devices with quick access to configuration interfaces
  - **DTM Interface Windows** – device-specific information including parameterization, monitoring, and control screens
  - **Device Catalog** – library of device software available for loading onto the network

# Network View



- Provides visual structure of network hierarchy
- Quick access to device configuration, integration, and advanced functions
- Device status color-coded to allow quick network status
  - **Online** / offline / **timed-out**
  - Status determines available configuration & control abilities




# Device Catalog

Device Catalogue X General Node Info				
Category ▲				
Add ▼	Name	Vendor	FDT Version	Protocol(s)
▼				
Category: Communication				
+	Modbus Serial	Eaton Corporation	2.0.0.0	Modbus over Serial Line
+	Modbus TCP	Eaton Corporation	2.0.0.0	Modbus over TCP

- Used to add devices to new or existing network
- Displays all DTMs loaded on host computer
- 1-Click catalog updater simplifies updating process of DTM programs

# DTM Configuration Interface



- Monitor, parameterize, or control networked devices
- Multiple interfaces / devices can be opened simultaneously
- Device network and operational status displayed on window status bars
- Common layout / structure across device manufactures based on FDT Standards

# Standard Functionality

**Provides Live Monitor Mode**

GMAX Parameters

P6.1	Output Frequency	0	Hz
P6.2	Frequency Reference	0	Hz
P6.3	Motor Shaft Speed	0	rpm

**Search**

**Supports Multiple Languages**

**Provides Detailed Parameter Descriptions**

P1.2 Max Frequency 60

P1.3 Max Frequency

code	Modbus ID	Parameter	Application	R0/Rn
P1.2	102	Max Frequency	1, 2, 3, 4	Rn

P1.5 These define the frequency limits of the frequency converter. The maximum value for these parameters is 400 Hz.

P1.7 Default: 0

P1.8 Minimum: 0


P1.9 Maximum: 400

**Provides Detailed Fault History**

Fault Type	Fault Code	Fault Time
Fault	External Fault	01/01/13 04:51:02
Fault	External Fault	01/01/13 04:59:20
Fault	External Fault	01/01/13 05:02:36
Fault	Emergency Stop	01/01/13 05:05:07
Fault	External Fault	01/01/13 05:05:15
Fault	External Fault	01/01/13 05:13:55
Fault	Power Board EEPROM Fault	02/01/13 00:23:20
Alarm	Replace Fan	02/01/13 00:23:20
Alarm	Replace Fan	02/01/13 01:23:22
Fault	Emergency Stop	03/01/13 00:00:45


Refresh Faults

# Device Status Bar



- **Control Place:**
  - Local or Remote
  - Device control location
  - Can configure parameters in either mode
- **Device Status:**
  - ● Ready / ○ Not Ready
  - Indicates if device is ready without faults
- **Device Run Status:**
  - ● Run / ○ Run (Stop)
  - Indicates state of device
- **Fault / Warning Status:**
  - ● Fault / ● Warning/No Fault
  - Indicates if fault or warning is active

# Network Status Bar



- **Device Network Status**
  - Indicates devices connection status to software
  - Disturbed – Communication timeout has occurred
- **Locked / Unlocked Data Set**
  - Indicates if parameters can be edited and saved to device
- **Sync Status**
  - Data set synced with device status
- **Parameter Value Status**
  - ✎ Edited parameter
  - ❓ Device time out
  - ! Value out of Range




# Part 2: Device Connection

## PowerXL DG1




# RJ-45 Ethernet Connection (1 of 3)



- Supports fieldbus configuration and control
- Does **NOT** support firmware upgrade tool
- Communication protocols supported:
  - Ethernet/IP
  - Modbus TCP
- Shielded CAT-5E or higher required
- Supports 10/100 Mb speeds in both full / half duplex



Ethernet Port LED Indications




Ethernet LED

1. Ethernet Link Status
2. Ethernet Link Speed

LED	Meaning
Ethernet link status	Flashes with Ethernet message activity.
Ethernet link speed	Displays the link speed. Yellow LED on the Ethernet Jack is ON when link speed is 100 mbps Yellow LED on the Ethernet Jack is OFF when link speed is 10 mbps

# USB to RJ45 (RS485) Connection (2 of 3)



- Supports full fieldbus configuration and control activated
- Supports firmware upgrade tool
- Communication protocols:
  - Modbus RTU
- Data transmission through pins 1 and 2
- Removes need to uninstall drive cover
- Can use with remote keypad mounts
- Catalog Number: DXG-CBL-PCCABLE

## Port settings

Baud Rate - 38.4k\*

Parity – Even\*

Stop Bits – 1\*

Data Bits – 8\*

\*Hard coded

## USB to RS-485 Connection (3 of 3)



## Port settings

Baud Rate – 19.2k\*

## Parity – Even\*

Stop Bits – 1\*


Data Bits – 8\*

\*can be changed on keypad


- Supports fieldbus configuration and control
  - Supports firmware upgrade tool
  - Communication protocols supported:
    - Modbus RTU
  - Connected through control board terminals A (25) and B (26)
- When networking multiple drives, a built-in resistor for network termination is located between expansion card slots


# Step 1: Open PowerXpert *inControl*

1. To begin setting up a device network, open PowerXpert *inControl* located in Start Menu
  - a. Under “EATON”
  - b. Executable through desktop shortcut
  - c. Blank network will appear




# Step 2: Initial Network Setup

2. Communication protocol must be added to network first.  
Add Communications protocol DTM by either
  - a. Click-and-drag DTM from device catalog to unnamed network node
  - b. Click on Network, then  symbol next to desired protocol
  - c. Right click on Network and select Add, then select desired protocol




or





## Step 2.2: PC USB Connection

- Under “Network View”, double-click the “Modbus Serial” DTM. The tool will open a window to set Connection device settings. Select the USB communication port you are connected to the drive through. Then select apply.




Note: If port is unknown, go to Control Panel, then Device Manager, then Ports to identify.






# Step 3: Initial Network Setup

3. Select communication protocol node under Network View
4. Add PowerXL DG1 to comm. node (same as previous)




or




# Step 3.1: Modbus TCP/Ethernet IP

1. Device address will auto appear when added DG1 DTM  
Set the IP address for the drive  
(Default = 192.168.001.254)  
Note: Must match static IP in drive (P20.3.2)



2. Address mode must be changed on the drive. Use the keypad to change P20.3.1: IP Address Mode to “Static IP”.
3. Power cycle drive for new IP Address Mode to save





# Step 3.1: PC Ethernet Port Configuration

4. The IP Address for the Ethernet port on the host computer must be set. The computer should detect the connected drive and display it in the “Network and Sharing” section of the control panel as an unidentified network.

Set IP address of Ethernet port on PC to “192.168.001.050”


- a. First 3 octets ( 192.168.001 ) MUST match that of the drive
- b. Last octet ( .050 ) CANNOT match that of the drives IP

Note: Go to Control Panel, Network & Sharing , Local Area Conn., Int. Protocol Ver. 4, Properties




# Step 3.2 How to Setup – Modbus Serial

1. Device slave address will auto appear  
Set the slave address of the drive  
(Software Default = 1) Click Set.




1. If using RS45-to-RJ45 – Must be 18
2. If using RS485 – no restriction

2. The slave address on the drive must match what is set in step 1. Use the drives keypad to change P20.2.2: Slave Address to match what was set in the software




# Step 4: Connecting the Drive

1. After setting up Communication device, Right click on the added Drive and select "Connect". Then Double Click on the Drive. The drive window will Open, bottom of window shows drive is connected.



2. The PowerXL DG1 is now ready for programming and configuration.







# Firmware Upgrade

PowerXL DG1





# USB to RJ45 (RS485) Connection




- Catalog Number: DXG-CBL-PCCABLE

# Firmware Upgrade Tool



- Installed with One Installer or via separate link
- Download Bundled DG\_VXX.XX.XXXX
  - Firmware File - DG\_BXX.XX.XXXX
  - Configuration File - DG\_CXX.XX.XXXX – Select this file in Config file area
- Select Com port
- Select Slave Address of Drive
- Click “Connect”

# Firmware Upgrade Tool



- All processors will be checked by default if code is not updated.
- Click “Program”
- Progress bars are shown for each processor
- When finished click “Disconnect”.
- Plug Keypad in
- Upload firmware to keypad, press “Ok”



*Powering Business Worldwide*