

Allen-Bradley

ControlLogix™ Motion Module

(Cat.No. 1756-M02AE, -M08SE)

**Setup and Configuration
Manual**

**Rockwell
Automation**

Important User Information

Because of the variety of uses for the products described in this publication, those responsible for the application and use of this control equipment must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards.

The illustrations, charts, sample programs and layout examples shown in this guide are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Allen-Bradley does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.

Allen-Bradley publication SGI-1.1, *Safety Guidelines for the Application, Installation and Maintenance of Solid-State Control* (available from your local Allen-Bradley office), describes some important differences between solid-state equipment and electromechanical devices that should be taken into consideration when applying products such as those described in this publication.

Reproduction of the contents of this copyrighted publication, in whole or part, without written permission of Rockwell Automation, is prohibited.

Throughout this manual we use notes to make you aware of safety considerations:

WARNING



Identifies information about practices or circumstances that can lead to personal injury or death, property damage or economic loss

Attention statements help you to:

- identify a hazard
- avoid a hazard
- recognize the consequences

IMPORTANT

Identifies information that is critical for successful application and understanding of the product.

European Communities (EC) Directive Compliance

If this product has the CE mark it is approved for installation within the European Union and EEA regions. It has been designed and tested to meet the following directives.

EMC Directive

This product is tested to meet the Council Directive 89/336/EC Electromagnetic Compatibility (EMC) by applying the following standards, in whole or in part, documented in a technical construction file:

- EN 50081-2 EMC — Generic Emission Standard, Part 2 — Industrial Environment
- EN 50082-2 EMC — Generic Immunity Standard, Part 2 — Industrial Environment

This product is intended for use in an industrial environment.

Low Voltage Directive

This product is tested to meet Council Directive 73/23/EEC Low Voltage, by applying the safety requirements of EN 61131-2 Programmable Controllers, Part 2 - Equipment Requirements and Tests. For specific information required by EN 61131-2, see the appropriate sections in this publication, as well as the Allen-Bradley publication Industrial Automation Wiring and Grounding Guidelines For Noise Immunity, publication 1770-4.1.

This equipment is classified as open equipment and must be mounted in an enclosure during operation to provide safety protection.

Preface	Using This Manual	P-1
	Who Should Use This Manual	P-1
	The Purpose of This Manual	P-1
	Related Documentation	P-2
	Rockwell Automation Support	P-3
	Local Product Support	P-3
	Technical Product Assistance	P-3
	On the Web	P-4
The ControlLogix Motion Control System	ControlLogix Motion Control	1-1
	Components of the ControlLogix Motion System	1-2
	The ControlLogix Controller	1-2
	The Analog/Encoder Servo Module (1756-MO2AE)	1-2
	The 8 Axis SERCOS interface Module (1756-MO8SE)	1-3
	RSLogix5000 Programming Software	1-3
	Developing a Motion Control Application Program	1-3
	Application Program Development	1-4
	The MOTION_INSTRUCTION Tag	1-4
	Motion Status and Configuration Parameters	1-5
	Modifying Motion Configuration Parameters	1-5
	Handling Motion Faults	1-5
Getting Started	Introduction	2-1
	Accessing the New Controller dialog	2-2
	New Controller Dialog	2-2
	Vendor	2-3
	Type	2-3
	Redundancy Enabled	2-4
	Name	2-4
	Description	2-4
	Chassis Type	2-4
	Slot Number	2-4
	Revision	2-5
	Create In:	2-5
	Browse	2-5
	Editing Controller Properties	2-5
	General Tab	2-6
	Vendor	2-6
	Type	2-6
	Name	2-6
	Description	2-7
	Chassis Type	2-7
	Slot	2-7
	Revision	2-7
	Change Type	2-7

Change Controller Type Dialog Box Overview	2-7
Select a processor to change to	2-8
Serial Port Tab	2-8
Mode	2-9
Baud Rate	2-9
Data Bits	2-9
Parity	2-9
Stop Bits	2-9
Control Line	2-10
Continuous Carrier	2-10
RTS Send Delay	2-10
RTS Off Delay	2-10
System Protocol Tab	2-10
Common Parameters	2-11
Protocol	2-11
Station Address	2-11
Error Detection	2-12
Enable Duplicate Detection	2-12
ACK Timeout	2-12
DF1 Point to Point Parameters	2-12
ENQ Transmit Limit	2-12
NAK Receive Limit	2-12
Embedded Responses	2-12
DF1 Slave Parameters	2-13
Transmit Retries	2-13
Slave Poll Timeout	2-13
EOT Suppression	2-13
DF1 Master Parameters	2-13
Transmit Retries	2-13
Reply Message Wait	2-13
Polling Mode	2-13
Master Transmit	2-14
Normal Poll Node Tag	2-14
Normal Poll Group Size	2-14
Priority Poll Node Tag	2-14
Active Station Tag	2-14
DH485 Parameters	2-14
Max Station Address	2-14
Token Hold Factor	2-15
User Protocol Tab	2-15
Protocol	2-15
Buffer Size	2-15
Termination Character 1 and 2	2-15
Append Character 1 and 2	2-16
XON/OFF	2-16
Echo Mode	2-16

Delete Mode	2-17
Major Faults Tab	2-17
Number of Major Faults Since Last Cleared	2-18
Recent Faults	2-18
Clear Majors	2-18
Minor Faults Tab	2-18
Number of Minor Faults Since Last Cleared	2-18
Recent Faults	2-19
Clear Minors	2-19
Fault Bits	2-19
Date/Time Tab	2-19
Date	2-20
Time	2-20
Set	2-20
Make this controller the Coordinated System Time master	
2-20	
Status	2-20
Advanced Tab	2-21
Memory Used	2-21
Memory Unused	2-21
Memory Total	2-21
Controller Fault Handler	2-22
Power-Up Handler	2-22
System Overhead Time Slice	2-22
File Tab	2-22
Name	2-23
Path	2-23
Created	2-23
Edited	2-23

Adding and Configuring Your 1756-M02AE Motion Module

Adding the 1756-M02AE Module	3-1
New Module	3-3
Type	3-3
Major Revision	3-3
Type (list box)	3-3
Description (list box)	3-3
Show:	3-3
Select All	3-4
Clear All	3-4
Editing Your Motion Module Settings	3-6
General Tab	3-8
Type	3-8
Vendor	3-8
Name	3-8
Description	3-8
Slot	3-8

Revision	3-9
Electronic Keying.	3-9
Connection Tab	3-9
Requested Packet Interval	3-10
Inhibit Module checkbox	3-10
Major Fault on Controller if Connection Fails checkbox.	3-11
Module Fault	3-11
Associated Axes Tab	3-12
Servo Update Period	3-13
Channel 0	3-13
Channel 1	3-13
New Axis button	3-13
Module Info Tab	3-13
Identification	3-14
Major/Minor Fault Status	3-15
Internal State Status	3-15
Configured	3-15
Owned	3-16
Module Identity	3-16
Refresh	3-16
Reset Module.	3-16
Backplane Tab.	3-17
ControlBus Status.	3-17
ControlBus Parameters.	3-17
Multicast CRC Error Threshold	3-18
Transmit Retry Limit.	3-18
Set Limit Button.	3-18
Receive Error Counters.	3-18
Transmit Error Counters	3-18
Refresh	3-18
Assigning Additional Motion Modules	3-19

Configuring the 1756-M08SE Module

Adding the 1756-M08SE.	4-1
1756-M08SE 8 Axis Motion Module Overview.	4-4
Editing 1756-M08SE Module Properties	4-5
General Tab	4-5
Type	4-5
Vendor	4-6
Name	4-6
Description	4-6
Slot	4-6
Revision	4-6
Electronic Keying.	4-6
Connection Tab	4-7
Requested Packet Interval	4-8

Inhibit Module checkbox	4-8
Major Fault on Controller if Connection Fails checkbox	4-9
Module Fault	4-9
SERCOS Interface Tab	4-10
Data Rate	4-11
Cycle Time	4-11
Transmit Power	4-11
SERCOS Interface Info Tab	4-11
Ring Comm. Phase	4-12
Fault Type	4-12
Refresh	4-12
Module Info Tab	4-13
Identification	4-14
Major/Minor Fault Status	4-15
Internal State Status	4-15
Configured	4-15
Owned	4-16
Module Identity	4-16
Refresh	4-16
Reset Module	4-16
Backplane Tab	4-17
ControlBus Status	4-17
ControlBus Parameters	4-17
Multicast CRC Error Threshold	4-18
Transmit Retry Limit	4-18
Set Limit Button	4-18
Receive Error Counters	4-18
Transmit Error Counters	4-18
Refresh	4-18

The Motion Group

Creating A Motion Group	5-1
Editing the Motion Group Properties	5-4
Axis Assignment Tab	5-4
Unassigned	5-4
Assigned	5-4
Add	5-4
Remove	5-5
Attribute Tab	5-5
Coarse Update Period	5-5
Auto Tag Update	5-6
General Fault Type	5-6
Scan Times (elapsed time)	5-6
Reset Max	5-6
Tag Tab	5-7
Name	5-7

	Description	5-7
	Tag Type (read-only)	5-8
	Data Type (read-only)	5-8
	Scope	5-8
	Style	5-8
	Produce this tag for up to	5-8
	Base Tag	5-8
Naming & Configuring Your Motion Axis		
	Naming an Axis	6-1
	Entering Tag Information	6-2
	Common Parameters	6-3
	Name	6-3
	Description	6-3
	Tag Type	6-3
	Data Type	6-3
	Editing Motion Axis Properties	6-4
	General Tab – SERVO_AXIS	6-6
	Axis Configuration	6-7
	Assigned Motion Group	6-7
	Ellipsis (...) button	6-7
	New Group button	6-7
	Module	6-7
	Module Type	6-7
	Channel	6-8
	Output Cam Execution Targets	6-8
	General Tab - AXIS_SERVO_DRIVE	6-8
	Axis Configuration	6-9
	Assigned Motion Group	6-9
	Ellipsis (...) button	6-9
	New Group button	6-9
	Module	6-9
	Module Type	6-9
	Node	6-10
	Output Cam Execution Targets	6-10
	General Tab - AXIS_VIRTUAL	6-10
	Assigned Motion Group	6-10
	Ellipsis (...) button	6-11
	New Group button	6-11
	Output Cam Execution Targets	6-11
	Units Tab	6-12
	Position Units	6-12
	Average Velocity Timebase	6-12
	Conversion Tab	6-13
	Positioning Mode	6-13
	Conversion Constant	6-14
	Position Unwind	6-14

Servo Tab - AXIS_SERVO	6-15
External Drive Configuration	6-15
Loop Configuration	6-16
Enable Drive Fault Input	6-16
Drive Fault Input	6-16
Real Time Axis Information	6-16
Drive Tab - (AXIS_SERVO_DRIVE)	6-17
Amplifier Catalog Number	6-17
Loop Configuration	6-17
Drive Resolution	6-18
Real Time Axis Information	6-18
Attribute 1/Attribute 2	6-18
Set Custom Scaling...button	6-18
Motor/Feedback Tab - AXIS_SERVO_DRIVE	6-19
(Motor) Catalog Number	6-19
(Motor) Feedback Type	6-20
(Motor) Interpolation Factor	6-20
(Motor) Cycles	6-20
(Auxiliary Feedback) Type	6-20
(Aux) Interp Factor	6-21
(Aux) Cycles	6-21
(Aux) Ratio	6-21
Homing Tab - SERVO_AXIS and SERVO_AXIS_DRIVE	6-21
Mode	6-22
Position	6-22
Offset	6-23
Sequence	6-23
Limit Switch	6-23
Direction	6-24
Speed	6-24
Return Speed	6-24
Homing Configurations	6-25
Homing Tab - AXIS_VIRTUAL	6-25
Mode	6-25
Position	6-25
Sequence	6-26
Hookup Tab - AXIS_SERVO	6-26
Test Increment	6-26
Feedback Polarity	6-27
Output Polarity	6-27
Test Marker	6-27
Test Feedback	6-28
Test Output & Feedback	6-28
Hookup Tab Overview - AXIS_SERVO_DRIVE	6-28
Test Increment	6-28
Drive Polarity	6-28

Test Marker	6-29
Test Feedback	6-29
Test Output & Feedback	6-29
Tune Tab - AXIS_SERVO, AXIS_SERVO_DRIVE	6-30
Travel Limit	6-30
Speed	6-30
Torque	6-30
Direction	6-31
Damping Factor	6-31
Tune	6-31
Start Tuning	6-32
Dynamics Tab	6-32
Maximum Velocity	6-33
Maximum Acceleration	6-34
Maximum Deceleration	6-34
Program Stop Action	6-35
Manual Tune	6-35
Gains Tab - AXIS_SERVO	6-35
Velocity Feedforward	6-37
Acceleration Feedforward	6-37
Proportional (Position) Gain	6-37
Integral (Position) Gain	6-38
Proportional (Velocity) Gain	6-39
Integral (Velocity) Gain	6-39
Integrator Hold	6-39
Manual Tune	6-40
Gains Tab - AXIS_SERVO_DRIVE	6-40
Velocity Feedforward	6-41
Acceleration Feedforward	6-42
Proportional (Position) Gain	6-42
Integral (Position) Gain	6-43
Proportional (Velocity) Gain	6-43
Integral (Velocity) Gain	6-44
Integrator Hold	6-45
Set Custom Gains	6-45
Manual Tune	6-45
Output Tab - SERVO_AXIS	6-45
Velocity Scaling	6-46
Torque Scaling	6-47
Enable Low-pass Output Filter	6-47
Low-pass Output Filter Bandwidth	6-48
Manual Tune	6-48
Output Tab Overview - AXIS_SERVO_DRIVE	6-48
Torque Scaling	6-49
Enable Notch Filter	6-50
Notch Filter	6-50

Enable Low-pass Output Filter	6-50
Low-pass Output Filter Bandwidth	6-51
Manual Tune	6-51
Limits Tab - AXIS_SERVO	6-51
Soft Travel Limits	6-52
Maximum Positive	6-53
Maximum Negative	6-53
Position Error Tolerance	6-53
Position Lock Tolerance	6-53
Output Limit	6-54
Manual Tune	6-54
Limits Tab - AXIS_SERVO_DRIVE	6-54
Hard Travel Limits	6-55
Soft Travel Limits	6-55
Maximum Positive	6-55
Maximum Negative	6-56
Position Error Tolerance	6-56
Position Lock Tolerance	6-56
Set Custom Limits	6-56
Manual Tune	6-56
Offset Tab - AXIS_SERVO	6-57
Friction Compensation	6-58
Velocity Offset	6-58
Torque Offset	6-58
Output Offset	6-59
Manual Tune	6-59
Offset Tab - AXIS_SERVO_DRIVE	6-59
Friction Compensation	6-60
Velocity Offset	6-60
Torque Offset	6-60
Manual Tune	6-61
Fault Actions Tab - AXIS_SERVO	6-61
Drive Fault	6-63
Feedback Noise	6-63
Feedback Loss	6-63
Position Error	6-64
Soft Overtravel	6-64
Fault Actions Tab - AXIS_SERVO_DRIVE	6-64
Drive Thermal	6-66
Motor Thermal	6-67
Feedback Noise	6-67
Feedback	6-67
Position Error	6-67
Hard Overtravel	6-67
Soft Overtravel	6-67
Set Custom Stop Action	6-67

Tag Tab.	6-68
Name	6-68
Description	6-68
Tag Type.	6-68
Scope	6-69
Style	6-69
Produce this tag for up to	6-69
Base Tag.	6-69
Manual Tune	6-69
Assigning Additional Motion Axes	6-70
Developing a Motion Application Program.	6-70
Understanding a Programming Example.	6-71

Configuring a 1394C-SJT05/10/ 22-D Digital Servo Drive

1394C-SJT05/10/22-D Digital Servo Drive Overview	7-3
General Tab	7-4
Type	7-5
Vendor	7-5
Name	7-5
Description	7-5
Base Node.	7-5
Revision	7-5
Electronic Keying.	7-6
Connection Tab	7-7
Requested packet Interval	7-7
Inhibit Module checkbox	7-8
Major Fault on Controller if Connection Fails	7-9
Module Fault.	7-9
Associated Axes Tab.	7-10
Node X0	7-10
Node X1	7-10
Node X2	7-10
Node X3	7-11
New Axis button	7-11
Power Tab	7-11
Bus Regulator ID	7-11
Module Info tab.	7-12
Identification	7-13
Product Name	7-13
Major/Minor Fault Status	7-13
Internal State Status	7-14
(16#xxxx) unknown.	7-14
Configured	7-14
Owned	7-14
Module Identity.	7-15
Refresh	7-15
Reset Module.	7-15

Configuring an Ultra 3000 Drive	Editing the Ultra Drive Properties.	8-7
	General Tab	8-8
	Type	8-8
	Vendor	8-8
	Name	8-8
	Description	8-8
	Node.	8-8
	Revision	8-8
	Slot	8-9
	Electronic Keying.	8-9
	Status	8-10
	Connection Tab	8-10
	Requested Packet Interval	8-11
	Inhibit Module.	8-12
	Major Fault on Controller if Connection Fails	8-13
	Module Fault.	8-13
	Associated Axes Tab (Ultra3000 Drives)	8-14
	Node.	8-14
	Ellipsis (...)	8-14
	New Axis	8-14
	Power Tab - Ultra Drive.	8-14
	Bus Regulator ID	8-14
	Module Info	8-14
	Identification	8-15
	Major/Minor Fault Status	8-16
	Internal State Status	8-16
	Configured	8-16
	Owned	8-16
	Module Identity.	8-17
	Reset Module.	8-17
	Refresh	8-17
Motion Instructions	Motion State Instructions	9-1
	Motion Move Instructions	9-2
	Motion Group Instructions.	9-3
	Motion Event Instructions	9-3
	Understanding Motion Configuration Instructions	9-4
Troubleshooting	1756-M02AE Module Status Using the OK Indicator	10-1
	1756-M02AE Module Status Using the FDBK Indicator	10-2
	1756-M02AE Module Status Using the DRIVE Indicator	10-2
	1756-M08SE SERCOS Communication – CP Indicator	10-3
	1756-M08SE Module Status Using the OK Indicator.	10-4
	1756-M08SE SERCOS Ring Status	10-4

Specifications and Performance	1756-M02AE Motion Module Specifications.	A-1
	1756-M08SE Motion Module Specifications.	A-3
	Coarse Update Period Calculations.	A-4
	Understanding Action Timing.	A-4
	Using the Sample Calculations Worksheet.	A-6
	Sample Calculation	A-7
	Output Cam Timing For 1756 Controller	A-9
	For the 1756-L50 Controller	A-10
	For the 1756-L53 Controller	A-10
Loop and Interconnect Diagrams	Understanding Block Diagrams	B-1
	1756-M02AE Module With a Torque Servo Drive.	B-2
	1756-M02AE Module With a Velocity Servo Drive	B-3
	Understanding Wiring Diagrams	B-4
	Wiring to a Servo Module RTB.	B-4
	Wiring to an Ultra 100 Series Drive.	B-5
	Wiring to an Ultra 200 Series Drive.	B-6
	1398-CFLAExx Cable Diagram	B-7
	Pinouts for 1398-CFLAExx Cable	B-7
	Wiring to a 1394 Servo Drive (in Torque Mode only)	B-8
	The 1394-CFLAExx Cable Wiring Diagram.	B-9
	Pinouts for the 1394-CFLAE	B-9
	Wiring Registration Sensors	B-10
	24V Registration Sensor	B-10
	5V Registration Sensor	B-10
	Wiring the Home Limit Switch Input.	B-11
	Wiring the OK Contacts	B-11
The Motion Control Structures	AXIS Structures	C-1
	AXIS_CONSUMED Structure	C-1
	AXIS_SERVO Structure	C-5
	AXIS_SERVO_DRIVE Structure	C-12
	AXIS_VIRTUAL Structure	C-21
	Servo Configuration Update Status Bits attributes	C-25
	The MOTION_GROUP Structure	C-26
	The MOTION_INSTRUCTION Structure	C-27
	Error codes (.ERR)	C-29
	Message status (.STATUS).	C-30
	Execution status (.STATE)	C-30
	Profile Segment (.SEGMENT)	C-30
	CAM Structure.	C-31
	CAM_PROFILE Structure	C-31
	OUTPUT_CAM Structure	C-32
	OUTPUT_COMPENSATION Structure.	C-33

The Motion Attributes	Motion Attribute Folders	D-1
	Data Type Groups	D-1
	Motion Attributes	D-2
Instruction Timing	Immediate Type Instructions	E-1
	Message Type Instructions.	E-2
	Process Type Instructions	E-3
Fault Handling	Handling Motion Faults	F-1
	Errors	F-1
	Minor/Major Faults	F-1

Using This Manual

This preface describes how to use this manual.

Who Should Use This Manual

To use this manual, you should be able to program and operate the Allen-Bradley Logix5550™ controller to efficiently use your motion control modules.

If you need more information about programming and operating the Logix5550 controller, refer to the Logix5550 Controller User Manual, publication number 1756-6.5.12.

The Purpose of This Manual

This manual describes how to configure and troubleshoot your ControlLogix motion module.

The following table shows the contents of each section in this manual:

Section	Contains
Chapter 1 The ControlLogix Motion Control System	Information about the ControlLogix motion control system.
Chapter 2 Controller Properties	Explains how to create and edit your controller.
Chapter 3 Adding and Configuring Your 1756-M02AE Motion Module	How to add and configure your 1756-M02AE motion module using the RSLogix™ 5000 programming software.
Chapter 4 Adding and Configuring Your 1756-M08SE Motion Module	How to add and configure your 1756-M08SE motion module using the RSLogix™ 5000 programming software.
Chapter 5 The Motion Group	How to create and edit your Motion Group.
Chapter 6 Adding and Configuring Motion Axes	How to name and configure a motion axis using the RSLogix™ 5000 programming software.
Chapter 7 Configuring a 1394C-SJT05/10/22-D Digital Servo Drive	How to add and configure a 1394C Digital Servo Drive.
Chapter 8 Configuring an Ultra 3000 Drive	How to add and configure an Ultra 3000 drive.

Chapter 9 The Motion Instructions	Information about the 32 motion instructions provided in the RSLogix 5000 programming software.
Chapter 10 Troubleshooting	Information about troubleshooting your ControlLogix motion control system.
Appendix A Specifications and Performance	Specifications and performance guidelines for the motion module.
Appendix B Loop and Interconnect Diagrams	Loop diagrams and wiring diagrams for your ControlLogix motion control system.
Appendix C The Motion Control Structures	An explanation of the motion control structures.
Appendix D The Motion Attributes	Information about the motion attributes.
Appendix E Instruction Timing	Information about types of timing for motion instructions.
Appendix F Fault Handling	Information about motion control faults.

Related Documentation

The following table lists related ControlLogix documentation:

Publication Number	Publication	Description
1756-IN047	Analog Encoder (AE) Servo Module Installation Instructions	Provides instructions for installing, wiring, and troubleshooting your 1756-M02AE servo module.
1756-UM001	Logix5550 Controller User Manual	Provides information for using your Logix5550 controller and its components.
1756-RM0003	Logix5550 Controller Instruction Set Reference Manual	Provides descriptions of all the instructions supported by the RSLogix 5000 programming software.
1756-RM007	Motion Instructions Reference Set Manual	Provides descriptions of all of the motion instructions used in the RSLogix 5000 software.
1756-IN572	8 Axis SERCOS interface Module Installation Instructions	Provides instructions for installing, wiring, and troubleshooting your 1756-M08SE SERCOS module.

Publication Number	Publication	Description
1394C-5.20	1394 SERCOS Interface Multi Axis Motion Control System	Information on installation, wiring, and setup for the 1394C-SJTxx-D
1394-IN024	1394 SERCOS Integration Manual	Information on integrating the 1394 drive with the 1756-M08SE
2098-IN003	Ultra3000 Hardware Installation Manual	Information on Ultra3000 installation
2098-IN001	Ultra5000 Hardware Installation Manual	Information on Ultra5000 installation
2098-IN005	Ultra3000 SERCOS Integration Manual	Information on integrating the Ultra3000 with the 1756-M08SE

For more information on the documentation, refer to the Allen-Bradley Publication Index, publication number SD499.

Rockwell Automation Support

Rockwell Automation offers support services worldwide, with over 75 sales/support offices, 512 authorized distributors, and 260 authorized systems integrators located throughout the United States. In addition, Rockwell Automation representatives are located in every major country in the world.

Local Product Support

Contact your local Rockwell Automation representative for:

- sales and order support
- product technical training
- warranty support
- support service agreements

Technical Product Assistance

If you need to contact Rockwell Automation for technical assistance, please review the information in this manual. If the problem persists, call your local Rockwell Automation representative.

The Rockwell Automation Technical Support number is:

1-603-443-5419

On the Web

For information about Allen-Bradley, visit the following World Wide Web site:

<http://www.ab.com/>


The ControlLogix Motion Control System

This chapter describes the ControlLogix motion control system.

ControlLogix Motion Control

The ControlLogix controller, 1756-M02AE servo module, 1756-M08SE SERCOS interface module, and RSLogix5000 programming software provide integrated motion control support.

- The ControlLogix controller contains a high-speed motion task, which executes ladder motion commands and generates position and velocity profile information. The controller sends this profile information to one or more 1756-M02AE servo modules. You can use several Logix controllers in each chassis. Each controller can control up to 16 1756-M02AE servo modules.
- The 1756-M02AE servo module connects to a servo drive and closes a high-speed position and velocity loop. Each Logix controller can support up to 16 1756-M02AE servo modules. Each 1756-M02AE module can control up to two axes.
- The 1756-M08SE SERCOS interface module serves as the interface between one ControlLogix processor and 1 to 8 axes operating in either position or velocity mode. The module has a programmable ring Cycle Period of 1ms or 2ms depending on the number of axes and a ring Data Rate of 4 Mbaud.
- RSLogix5000 programming software provides complete axis configuration and motion programming support.



Components of the ControlLogix Motion System

The ControlLogix Controller

The ControlLogix controller is the main component in the ControlLogix system. It supports sequential and motion functions, and it performs all of the motion command execution and motion trajectory planner functions. You can use one or more ControlLogix controllers in each chassis, and each controller can control up to 16 motion modules.

The ControlLogix controller provides the following motion support:

- Thirty motion instructions
- A high-speed motion task, which manages motion functions and generates move profiles
- The ability to control up to 16 Analog/Encoder servo modules for a total of 32 axes

The Analog/Encoder Servo Module (1756-M02AE)

The Analog/Encoder servo module provides an analog/quadrature encoder servo drive interface. The servo module receives configuration and move information from the ControlLogix controller and manages motor position and velocity.

The servo module supports:

- Connection capability for up to two drives
- $\pm 10\text{V}$ analog outputs
- Quadrature encoder inputs
- Home limit switch inputs
- Drive fault inputs
- Drive enable outputs
- 5V or 24V position registration inputs
- 200 μs position and velocity loop updates

The 8 Axis SERCOS interface Module (1756-M08SE)

The 8 Axis SERCOS interface module (1756-M08SE) serves as a link between the ControlLogix platform and intelligent drives. The communication link between the module and the drive(s) is via IEC 1491 **S**ERIAL **R**eal-time **C**OMMUNICATION **S**YSTEM (SERCOS) using fiber optic medium.

The SERCOS interface module supports:

- reliable high speed data transmission
- excellent noise immunity
- elimination of interconnect wiring
- ASA messages converted to SERCOS formatted messages

RSLogix5000 Programming Software

The RSLogix5000 programming software provides complete programming and commissioning support for the ControlLogix system. RSLogix5000 is the only programming software needed to fully configure and program ControlLogix motion control systems.

RSLogix5000 software provides the following motion support:

- Wizards for servo axis configuration including drive hookup diagnostics and auto tuning
- Ladder-based application programming including support for 30 motion commands

Developing a Motion Control Application Program

This section provides an introduction to concepts used in developing application programs for motion control. These concepts include:

- Application program development
- The MOTION_INSTRUCTION tag
- Motion status and configuration parameters
- Modifying motion configuration parameters
- Handling motion faults


Application Program Development

Developing a motion control application program involves the following:

Task	Description
Select the master coordinated system time	Sets one controller as the master controller. Once you complete this step, you can synchronize all the motion modules and ControlLogix controllers in your chassis
Name and Configure an axis	Adds an axis to your application program
Develop a motion application program	Create a program for your motion control application
Add a motion module	Adds a motion module to your application program
Assign additional servo modules and axes	Adds additional modules and axes to your application program
Run hookup diagnostics and auto tuning	Completes hookup diagnostics and auto tuning for each axis

The MOTION_INSTRUCTION Tag

The controller uses the MOTION_INSTRUCTION tag (structure) to store status information during the execution of motion instructions. Every motion instruction has a motion control parameter that requires a MOTION_INSTRUCTION tag to store status information.



WARNING



Tags used for the motion control parameter of instructions should only be used once. Re-use of the motion control parameter in other instructions can cause unintended operation of the control variables.

For more information about the MOTION_INSTRUCTION tag, refer to Appendix C - *The Motion Control Structures*.

Motion Status and Configuration Parameters

You can read motion status and configuration parameters in your ladder logic program using two methods.

Method	Example	For more information
Directly accessing the AXIS and MOTION_GROUP structures	<ul style="list-style-type: none"> • Axis faults • Motion status • Servo status 	Refer to Appendix C - <i>The Motion Control Structures</i>
Using the GSV instruction	<ul style="list-style-type: none"> • Actual position • Command position • Actual velocity 	Refer to the <i>Input/Output Instructions</i> chapter of the Logix Controller Instruction Set Reference Manual, publication 1756-RM003B

Modifying Motion Configuration Parameters

In your ladder logic program, you can modify motion configuration parameters using the SSV instruction. For example, you can change position loop gain, velocity loop gain, and current limits within your program.

For more information about the SSV instruction, refer to the Logix Controller Instruction Set Reference Manual, publication 1756-RM003.

Handling Motion Faults

Two types of motion faults exist.

Type	Description	Example
Motion Instruction Errors	<ul style="list-style-type: none"> • Do not impact controller operation • Should be corrected to optimize execution time and ensure program accuracy 	A Motion Axis Move (MAM) instruction with a parameter out of range
Minor/ Major Faults	<ul style="list-style-type: none"> • Caused by a problem with the servo loop • Can shutdown the controller if you do not correct the fault condition 	The application exceeded the PositionErrorTolerance value

For more information about handling faults, see *Handling Controller Faults* in the Logix Controller User Manual, publication 1756-UM001 and *Appendix F Fault Handling* in this manual.

Getting Started

Introduction

Before you can begin programming or configuring your controller, you must create a project file in which to store it.

Create a Project

1. From the Type pull-down menu, choose the controller type that you wish to use for this project.
2. Enter the name you wish to use for the controller.

The same name is used for the project file with the .acd extension.

3. Enter a description of the controller.
4. Choose the appropriate chassis type in which the controller resides.

Note: This field is disabled if you have chosen a FlexLogix controller type. FlexLogix does not have a physical chassis, and therefore you do not need to select a chassis type.

5. Enter the slot number for the controller.

In ControlLogix, controllers occupy a numbered slot in the chassis and can be placed in any slot. It is also possible to place multiple controllers in the same chassis.

For FlexLogix, since there is no physical chassis, this field is disabled, and slot number 0 is displayed.

6. Verify the appropriate revision information for your controller. This field defaults to the latest revision for the given controller type.
7. Enter the directory in which you want to store the project file.

The directory defaults to the one you configured in the Workstation Options dialog. If you want to use a different directory, type its path or click on the Browse button to find the directory.

The project file is created in this directory with the same name as the controller with a .ACD file extension. For example, if your controller name is Oven1, the project file name becomes Oven1.ACD.

8. Click on OK to create the project.

Once the project file is created, you can see the Controller Organizer, which shows everything in the controller. The default configuration contains a continuous task, called Main Task. The Main Task contains a program called Main Program. The Main Program contains a routine called Main Routine, which is configured as the main routine `def_main_routine@gloss.hlp`.

In addition, if you have chosen a FlexLogix controller, 2 FlexBus adapters are created in slots 3 and 4 under the I/O Configuration folder. These 2 folders contain all local I/O for FlexLogix, other than the 2 local slots for communication. The first folder contains all I/O configured on the local Flex rail housing the Flex controller; the second folder contains all I/O configured for the local non-controller rail.


Note: You cannot delete, copy, cut, paste, or drag and drop the FlexBus adapters. Once you create a FlexLogix controller, the adapters appear under the I/O Configuration folder and cannot be altered unless you delete the FlexLogix controller.

Accessing the New Controller dialog

From the File menu, choose New to access the New Controller dialog.

New Controller Dialog

Create a new controller (i.e., project) from this dialog.

The image shows a 'New Controller' dialog box with a title bar containing a close button. The dialog contains several fields and controls: 'Vendor' is a text field with 'Allen-Bradley' entered; 'Type' is a pull-down menu showing '1756-L1 ControlLogix5550 Controller'; below it is a checkbox for 'Redundancy Enabled' which is unchecked; 'Name' is an empty text field; 'Description' is a larger empty text area; 'Chassis Type' is a pull-down menu showing '1756-A10 10-Slot ControlLogix Chassis'; 'Slot' is a spinner box set to '0'; 'Revision' consists of two spinner boxes set to '9' and '1'; 'Create In' is a text field showing 'C:\RSLogix 5000\Projects' with a 'Browse...' button to its right. On the right side of the dialog are three buttons: 'OK', 'Cancel', and 'Help'.**Vendor**

Displays the name of the controller's manufacturer.

Type

Select the controller type from the pull-down menu, shown here by catalog number, platform, and processor. The default controller is the 1756-L1 ControlLogix 5550 controller.

Choose from:

- 1756-L1 ControlLogix 5550 controller
- 1756-L53/A ControlLogix 5553 controller
- 1756-L55/A ControlLogix 5555 controller
- 1769-L20 CompactLogix 5320 controller
- 1769-L30 CompactLogix 5330 controller
- 1789-L60/A SoftLogix 5860 controller
- 1794-L33/A FlexLogix 5433 controller
- 1794-L34/A FlexLogix 5434 controller
- PowerFlex700S DriveLogix 5720 controller

Redundancy Enabled

Check this box if you wish to enable redundancy for this controller. Note that this option is disabled if you have chosen a controller that does not support redundancy.

Note: Redundancy is not supported in this release of RSLogix 5000.

Name

Enter the name you wish to use for the new controller. This name is also used for the project file, with a .acd extension.

Description

Enter a description of the controller.

Chassis Type

Select the appropriate chassis type from the pull-down menu, shown here by catalog number. The software uses this information to determine the number of slots in the chassis. Depending on the controller type you chose, the available options in this menu vary:

For this platform:	Choose from these chassis types:
ControlLogix	1756-A4, 4-slot ControlLogix chassis 1756-A7, 7-slot ControlLogix chassis 1756-A10, 10-slot ControlLogix chassis 1756-A13, 13-slot ControlLogix chassis 1756-A17, 17-slot ControlLogix chassis
CompactLogix	Not applicable
SoftLogix	1789-17, 17-slot SoftLogix virtual chassis
FlexLogix	Not applicable
DriveLogix	Not applicable

Slot Number

Choose the slot number where the controller resides on the backplane.

For ControlLogix controllers, the default value is 0. If the slot number exceeds the chassis size, an error message appears, prompting you to enter a number within the valid range.

For SoftLogix controllers, the default value is 1.

For CompactLogix, FlexLogix, and DriveLogix controllers, the value in this field is always 0 and cannot be edited.

Revision

Enter the controller revision.

For this release of RSLogix 5000, this field is not editable. The revision defaults to the latest revision for the given controller type.

Create In:

Enter the directory in which you want the project file to be created. The file name is the same as the controller name, with a .acd extension.

Browse


Click on this button to bring up the Choose Directory dialog from which you can browse for the appropriate directory.

Editing Controller Properties

The Controller Properties dialog displays controller configuration information for the open project and, when online, for the attached controller. This section describes the fields on each of the dialogs for the Controller Properties.

General Tab

The General tab displays the controller name and description, as well as the physical properties of the controller.



Vendor

Displays the name of the controller's manufacturer.

Type

The catalog number and description of the controller. When online, this field includes the catalog number of the memory card (if any).

Name

The name of the controller. When you create a project, this is the same as the name of the project file. When you change the name of the controller, however, the name of the project file does not change. If you want to keep the two the same, then you must rename the file using Windows Explorer or a similar file management tool.

IMPORTANT

This name must be IEC_1131 compliant. If you enter an invalid character in this field, or if the name you enter exceeds 40 characters, the software ignores the character.

You cannot change the name when online.

Description

Enter a description for the controller here, up to 128 characters. You can use any printable character in this field. If you exceed the maximum length, the software ignores any extra characters.

Chassis Type

Select a supported chassis type from the pull-down list. Each entry in the list consists of the catalog number of the chassis, as well as a brief description.

The chassis type cannot be changed when online.

Slot

Enter the chassis slot number in which the controller resides. The spin button contains values that range from 0 to 1 less than the chassis size (e.g., if you have a 4-slot chassis, the spin button spins from 0 to 3). If you enter a slot number that is out of this range, you receive an error message when you go to apply your changes.

The slot number cannot be changed when online.

Revision

Displays the major and minor revision of the controller. The minor revision is available only when you are online.

Change Type

Click on this button to access the Change Processor Type dialog. This dialog lets you change your controller to another controller within the same platform.

Change Controller Type Dialog Box Overview

Use this dialog to change your controller to another controller within the same platform (e.g. changing from a 1756-L1 ControlLogix 5550 Controller to a 1756-L53/A ControlLogix 5553 controller).



IMPORTANT

At this time, RSLogix 5000 does not support changing to a controller from within another platform (e.g., changing from a ControlLogix controller type to a FlexLogix controller type).

Select a processor to change to

Choose the controller you wish to change to from the pull-down menu. The list of available controllers includes all controller types within the same platform as the current processor, with the exception of the current processor itself.

Serial Port Tab

The Serial Port tab allows you to view and configure the controller's serial port.



Mode

The type of protocol you want to use. Choose from System or User (default).

Baud Rate

The baud rate assigned to the serial port on the Logix5550. Choose from 110, 300, 600, 1200, 2400, 4800, 9600, and 19200 (default).

Data Bits

The actual number of bits of data per character. Choose from 7 (ASCII only) or 8 (default).

Parity

The parity for the link. Choose from Even, Odd (ASCII only) or No Parity (default).

Stop Bits

The actual number of stop bits per character. Choose from 2 (ASCII only) or 1 (default).

Control Line

Choose the type of handshaking you wish to use during communications. The choices available to you vary, depending on the protocol you have selected:

For this mode:	And this protocol:	Choose from:
User	ASCII	No Handshake (default) Full Duplex Half Duplex
System	Point-to-Point	No Handshake (default) Full Duplex
	Slave	No Handshake (default) Half Duplex
	Master	No Handshake (default) Full Duplex Half Duplex

Continuous Carrier

Check this box if you wish to use Half Duplex communication with continuous carrier. This checkbox is disabled if you have chosen something other than Half Duplex communication, or if you have chosen Master as your protocol. By default, this option is unchecked when enabled.

RTS Send Delay


Enter the time (in ms) to delay transmitting the first character of a message after turning on the RTS line. The default value is 0.

RTS Off Delay

Enter the time (in ms) to delay turning off the RTS line after the last character has been transmitted. The default value is 0.

System Protocol Tab

The System Protocol tab allows you to configure the controller's serial port for DF1 Point to Point, DF1 Master, DF1 Slave or DH485. The parameters present on this tab are dependent upon the protocol you select.

**IMPORTANT**

Note: If you wish to configure your system for ASCII, click on the User Protocol tab.

The parameters present on this tab are dependent upon the protocol you select.

Common Parameters***Protocol***

Choose the protocol from the pull-down menu. Choose from DF1 Point to Point (default), DF1 Slave, DF1 Master or DH485.

Station Address

Enter the current station link address of the com port to which the DF1 object is now associated. Valid values are from 0 to 254; the default value is 0.

Error Detection

Click on one of the radio buttons to specify the error detection scheme used for all messages.

- BCC - the processor sends and accepts messages that end with a BCC byte.
- CRC - the processor sends and accepts messages with a 2-byte CRC.

Enable Duplicate Detection

Check this box to enable duplicate message detection, which causes the object to ignore all duplicate messages. This option is disabled by default.

ACK Timeout

Enter the time the object waits for an acknowledgment to a message transmission. Valid values are from 0 to 65535, in 20 ms increments; the default value is 50 ms.

DF1 Point to Point Parameters

ENQ Transmit Limit

Enter the number of inquiries you want the processor to send after an ACK Timeout. Valid values are from 0 to 255; the default value is 3.

NAK Receive Limit

Enter the number of NAKs the processor can receive in response to a message before stopping the transmission. Valid values are from 0 to 255; the default value is 3.

Embedded Responses

This parameter sets the flag that enables the embedded response functionality. Your options are:

- Autodetect – embedded responses are initiated only after one is received.
- Enabled – embedded responses are enabled unconditionally.

DF1 Slave Parameters

Transmit Retries

Enter the number of attempted transmits without getting an acknowledgment before a message is deemed undeliverable. Valid values are from 0 to 255; the default value is 3.

Slave Poll Timeout

Enter the amount of time that the master waits for an acknowledgment to a message sent to the slave.

EOT Suppression

Check this box if you want to suppress "End of Text" transmissions at the end of a slave message.

DF1 Master Parameters

Transmit Retries

Enter the number of attempted transmits without getting an acknowledgment before a message is deemed undeliverable. Valid values are from 0 to 255; the default value is 3.

Reply Message Wait

Enter the time (in ms) that the master waits after receiving an acknowledgment to a master-initiated message before polling the slave for a reply. Specify this time in 20 ms increments; the default value is 50 (i.e., 50*20 ms, or 1000 ms, or 1 second).

Polling Mode

Choose a polling mode from the pull-down menu. Choose from:

- Message Based - slave can initiate messages.
- Message Based - slave cannot initiate messages.
- Standard - Multiple message transfers per node scan.
- Standard - Single message transfer per node scan.

The default mode is Message Based, allowing a slave to initiate messages.

Master Transmit

Choose the master message transmit that designates when to send any DF1 master message. Choose from:

- Between Station Polls - The master transmits a message before the next station.
- In Poll Sequence - The master transmits messages only when the station number is encountered in the poll list.

The default is Between Station Polls.

Normal Poll Node Tag

Choose the tag name of the structure that contains the normal poll node list. Use the Tag Browser to select the appropriate tag name.

The default tag is <none>.

Normal Poll Group Size

Enter the total number of active stations polled from the poll node list. Valid values are 0 to 255; the default value is 0.

Priority Poll Node Tag

Choose the tag name of the structure to store the priority poll node list. Use the Tag Browser to select the appropriate tag name.

The default tag is <none>.

Active Station Tag

Choose the tag name of the structure to store the status (active/non-active) of each node. Use the Tag Browser to select the appropriate tag name.

The default tag is <none>.

DH485 Parameters***Max Station Address***


This field is available when you choose DH485 as the protocol. It sets the maximum value allowable for the Station Address. The range is from 0 to 31.

Token Hold Factor

A value between 1 and 4.

User Protocol Tab

The User Protocol tab allows you to configure the controller's serial port for the ASCII protocol.



Protocol

Choose the ASCII protocol.

Buffer Size

Enter the maximum size (in bytes) of the data array that you are planning on sending and receiving. Valid values are from 1 to 65536; the default size is 82.

When the controller sends out the data, if it detects an array that is larger than this buffer size, a minor fault occurs and the extra data is truncated. When the controller receives data, if it detects data that is larger than the size of the buffer, the extra characters are dropped.

Termination Character 1 and 2

Enter the characters that be used to define the end of a line. Valid hex range values are from 0 to 255. The default value for Termination

Character 1 is \$0D, and the default value for Termination Character 2 is \$FF.

The ARL and ABL instructions use these characters to signal the end of a line. If you do not wish to use these characters, you can either avoid the use of these instructions, or you can define Termination Character 1 as \$FF, where \$FF tells the controller not to use any definable termination characters when using the ARL or ABL instructions.

If you want to use only one character to signal the end of a line, use Termination Character 1, and define Termination Character 2 as \$FF.

Append Character 1 and 2

Enter the characters that are appended to the end of a line. Valid hex range values are from 0 to 255. The default value for Append Character 1 is \$0D, and the default value for Append Character 2 is \$0A.

The AWA instruction appends the specified characters to the end of the messages it sends out. If you do not wish to use these characters, you can either avoid the use of the AWA instruction, or you can define Append Character 1 as \$FF, where \$FF tells the controller not to append characters when using the AWA instruction.

If you want to append only one character, define Termination Character 1 as the desired character, and define Termination Character 2 as 0xFF.

XON/OFF

Check this option to regulate the flow of incoming data.

For example, when this option is checked and the receive buffer gets to be 80% full, an XOFF (0x13) character is transmitted to tell the sending device to stop sending. When the buffer has been processed so that it is less than 80% full, the XON (0x11) character is sent to tell the device to resume sending.

This option is disabled when the Control Line option is configured for Half Duplex.

Echo Mode

Check this option to cause any data received in the ASCII port to be sent right back out to the device that sent it. For example, you could use this option with a dumb terminal that is unable to display what it sends, but can display what is echoed to it.

This option is disabled when the Control Line option is configured for Half Duplex.


Delete Mode

The character received just before the delete character sequence (0x7F) is removed by the serial port driver before it is given to the ladder logic. Choose from:

- Ignore - The delete character sequence is treated the same as any other character that is read in.
- CRT or Printer - The preceding character in the string buffer is removed before being given to the ladder logic. The only difference between CRT and Printer modes is the type of device sending the string to the controller. If Echo mode is disabled, CRT and Printer do exactly the same thing.

Major Faults Tab

The Major Faults tab displays information on the major faults that have occurred in the controller.



Number of Major Faults Since Last Cleared

Displays the number of major fault events that have been reported since the log was last cleared.

Recent Faults


Displays a description of the last three major faults that have occurred. These faults are stored in reverse chronological order. When offline, this field contains the stored contents of the last online session.

Clear Majors

Click on this button to clear the Major Fault log.

Minor Faults Tab

The Minor Faults tab displays information on the minor faults that have occurred in the controller.



Number of Minor Faults Since Last Cleared

Displays the number of minor fault events that have been reported since the log was last cleared.

Recent Faults

Displays a description of the last eight minor faults that have occurred. These faults are stored in reverse chronological order. When offline, this field contains the stored contents of the last online session.

Clear Minors

Click on this button to clear the Minor Fault log.


Fault Bits

Lists the minor fault bits that have a specific fault type assigned to them. If the bit is set, the checkbox is set.

When offline, these checkboxes are disabled, but display the contents of the last online session.

Date/Time Tab

The Date/Time tab allows you to view and edit the controller's wall clock time and the coordinated system time status.



Date

The wall clock date, in the format currently selected in the Regional Settings application in your Windows NT Control Panel.

This parameter is read-only. When offline, this parameter is empty.

Time

The wall clock time, in the format currently selected in the Regional Settings application in your Windows NT Control Panel.

This parameter is read-only. When offline, this parameter is empty.

Set

Click on this button to bring up the Set Date/Time dialog, from which you can set the date and/or time.

This button is disabled when offline.

Make this controller the Coordinated System Time master

Click on this checkbox to select this controller as the CST master. This does not mean that this controller IS the master, it means that you intend for this controller to be the master. If another controller is already the CST master, “duplicate master detected” appears in the status field.

If you are using a Servo card on this controller, set the CST Master.

Status


Indicates the state of the coordinated system time. There are four status fields, with a circular indicator to the left of each. This indicator is blue if the corresponding status condition is true; otherwise, it is clear. The status conditions are:

- Is the master - you checked the “Make this controller the master” box, and this controller is the CST master.
- Synchronized with a master - this controller is not the master; its time is being synchronized by a master.
- Duplicate master detected - you checked the “Make this controller the master” box, but there is already a CST master.
- Timer hardware faulted - there is a hardware fault.

All of the circular indicators are clear when you are offline.

Advanced Tab

The Advanced tab allows you to view and edit advanced controller properties.



Memory Used

The amount of memory used in the controller. When offline, this parameter is empty.

Memory Unused

The amount of memory available in the controller. When offline, this parameter is empty.

Memory Total

The total amount of memory in the controller (used plus unused). If a memory daughter card is present, this total includes that memory. When offline, this parameter is empty.

Controller Fault Handler

Choose the program that runs as the result of a system fault from the pull-down menu. The list contains all of the unscheduled programs.

Power-Up Handler

Choose the program the processor executes when it powers up in Run mode after a power-down in Run mode. The list contains all of the unscheduled programs.


System Overhead Time Slice

Enter or select the percentage of time the controller spends running its system task, relative to running user tasks.

File Tab

The File tab displays information about the project file.

The fields on this tab cannot be edited. To change the file name or path, you must use the Save As command.



Name

The name of the project file

Path

The drive and directory of the project file.

Created

The creation date and time of the project file, in the format currently selected in the Regional Settings application in your Windows NT Control Panel.

Edited

The date and time that the project file was last edited, in the format currently selected in the Regional Settings application in your Windows NT Control Panel.

Adding and Configuring Your 1756-M02AE Motion Module

This chapter describes how to add, configure, and edit your 1756-M02AE motion module for use in your motion control application.


This chapter describes each of the tasks for adding and configuring a motion module.

Adding the 1756-M02AE Module


To use your motion module in a control system, you must add your motion module to the application program.

To add a motion module:


1. Right-click the I/O Configuration folder.



2. Select **New Module**. The Select Module Type window appears.



3. Click on the Clear All button to clear the dialog window then click on Motion to list the available Motion Controllers.



New Module

Use this dialog to select and create a new module. Highlight the 1756-M02AE. The context sensitive menu appears, from which you can select a New Module.

Type

The Type field displays the catalog number of the module highlighted in the Type list box. You can either type in a module catalog number in this field to quickly select/find the module you want to create or you can scroll through the list of modules in the Type list box.

Major Revision

Select the major revision number of the physical module that you think want to reside in the chassis.

The major revision is used to indicate the revision of the interface to the module.

Type (list box)

This box lists the installed module catalog numbers based on the selected check boxes.

Description (list box)

This portion of the list box contains descriptions of the modules.

Show:

Displays check boxes, which support filtering on particular types of modules.

Check this box:	If you want to:
Digital	display digital modules supported by the software
Analog	display analog modules supported by the software
Communication	display communication modules supported by the software
Motion	display motion modules supported by the software
Controller	display controller modules supported by the software
Vendor	display a particular vendor's module profiles that are installed on the system.
Other	display modules that do not fit under the rest of the check box categories.

Select All

Click on this button to display all modules in the list box; all the check boxes in the Show field are checked.

Clear All

Click on this button to clear all check boxes in the Show field.

4. In the *Type* field, select **1756-M02AE 2 Axis Analog/Encoder Servo**.

5. Select **OK**. The Module Crate Wizard displays.

The screenshot shows the 'Module Properties - Local [1756-M02AE 5.1]' dialog box. It contains the following fields and controls:

- Type:** 1756-M02AE 2 Axis Analog/Encoder Servo
- Vendor:** Allen-Bradley
- Name:** A text input field.
- Slot:** A numeric input field with the value '1'.
- Description:** A text input field.
- Revision:** A numeric input field with the value '1'.
- Electronic Keying:** A dropdown menu set to 'Compatible Module'.


At the bottom of the dialog are five buttons: Cancel, < Back, Next >, Finish >>, and Help.

6. Make entries in the following fields.

Field	Entry
Name	Type a name for the servo module. The name can: <ul style="list-style-type: none"> • have a maximum of 40 characters • contain letters, numbers and underscores (_).
Slot	Enter the number of the chassis slot that contains your module.
Description	Type a description for your motion module. This field is optional.

Field	Entry	
Electronic keying	Select the electronic keying level.	
	To	Select
	Match the vendor, catalog number, and major revision attributes of the physical module and the software configured module	Compatible module
	Disable the electronic keying protection mode	Disable keying
	Match the vendor, catalog number, major revision, and minor revision attributes of the physical module and the software configured module	Exact match

- Press the Next button to proceed to the next Create Wizard screen.



- This screen is where you determine how faults are to be handled. The choices are to inhibit module or to configure the module so that a loss of connection to this module causes a major fault. Make your entries and press the Next button to

proceed to the next wizard screen.




9. This screen lets you associate an axis with the module. Make the appropriate choices for your situation. At this point, the rest of the screens are informational only and it would be best to press the Finish button to create the module.

All of the above screens can be accessed and edited by going to the tabbed Module Property screens. Further explanations of the fields in this dialog are detailed below.


Editing Your Motion Module Settings

The following section provides explanations of the Motion Module Properties screens. Use these screens to edit the properties of the module when changes need to be made. You can access the Module Properties screen by highlighting the motion module and right

clicking the mouse. Select **Properties** from the displayed pop-up menu screen as shown in the following figure.



This accesses the Module Properties screen. This screen is tabbed to take you to the particular dialog you require.



General Tab

Use this tab to create/view module properties for 1756-M02AE motion module. This dialog provides you with the means to view the type, description, vendor, and the name of the parent module. You can also enter the name and a description for the module. Other fields and buttons on this dialog let you set the slot location of the module, review information for both channels, go to the New Tag dialog to create an axis to associate with one of the channels, select the minor revision number and select an electronic keying option. You can also view the status the controller has about the module but, only when online.

Type

Displays the type and description of the module being created (read only).

Vendor

Displays the vendor of the module being created (read only).

Name

Enter the name of the module.

The name must be IEC 1131-3 compliant. If you attempt to enter an invalid character or exceed the maximum length, the software beeps and ignores the character.

Description

Enter a description for the module here, up to 128 characters. You can use any printable character in this field. If you exceed the maximum length, the software beeps to warn you, and ignores any extra characters.

Slot

Enter the slot number where the module resides. The spin button contains values that range from 0 to 1 less than the chassis size (e.g., if you have a 4-slot chassis, the spin button will spin from 0 to 3). If you enter a slot number that is out of this range, you will receive an error message when you go to apply your changes.

The slot number cannot be changed when online.

Revision

Select the minor revision number of your module.

The revision is divided into the major revision and minor revision. The major revision displayed statically is chosen on the Select Module Type dialog.

Electronic Keying

Select one of these keying options for your module during initial module configuration:

- Exact Match - all of the parameters described below must match or RSLogix will reject the inserted module.
- Compatible Module
 - the Module Types, Catalog Number, and Major Revision must match
 - the Minor Revision of the physical module must be equal to or greater than the one specified in the software or RSLogix 5000 will reject the inserted module.
- Disable Keying - RSLogix 5000 will not employ keying at all.

When you insert a module into a slot in a ControlLogix chassis, RSLogix 5000 compares the following information for the inserted module to that of the configured slot:


- Vendor
- Product Type
- Catalog Number
- Major Revision
- Minor Revision

This feature prevents the inadvertent insertion of the wrong module in the wrong slot.

Connection Tab

The Connection Tab is used to define controller to module behavior. This is where you select a requested packet interval, choose to inhibit

the module, configure the controller so loss of the connection to this module causes a major fault, and view module faults.



The data on this tab comes directly from the controller. This tab displays information about the condition of the connection between the module and the controller.

Requested Packet Interval

This does not apply to motion module.

Inhibit Module checkbox

Check/Uncheck this box to inhibit/uninhibit your connection to the module. Inhibiting the module causes the connection to the module to be broken.

TIP

Inhibiting/uninhibiting connections applies mainly to direct connections, and not to the CNB module



ATTENTION

Inhibiting the module causes the connection to the module to be broken and may result in loss of data



When you check this box and go online, the icon representing this module in the controller organizer displays the Attention Icon.

If you are:	Check this checkbox to:
offline	put a place holder for a module you are configuring
online	<p>stop communication to a module</p> <p>If you inhibit the module while you are online and connected to the module, the connection to the module is nicely closed. The module's outputs go to the last configured Program mode state.</p> <p>If you inhibit the module while online but a connection to the module has not been established (perhaps due to an error condition or fault), the module is inhibited. The module status information changes to indicate that the module is 'Inhibited' and not 'Faulted'.</p> <p>If you uninhibit a module (clear the checkbox) while online, and no fault condition occurs, a connection is made to the module and the module is dynamically reconfigured (if you are the owner controller) with the configuration you have created for that module.</p> <p>If you are a listener (have chosen a "Listen Only" Communications Format), you can not re-configure the module.</p> <p>If you uninhibit a module while online and a fault condition occurs, a connection is not made to the module.</p>

Major Fault on Controller if Connection Fails checkbox

Check this box to configure the controller so that failure of the connection to this module causes a major fault on the controller if the connection for the module fails.

Module Fault

Displays the fault code returned from the controller (related to the module you are configuring) and the text detailing the Module Fault that has occurred.

The following are common categories for errors:

- Connection Request Error - The controller is attempting to make a connection to the module and has received an error. The connection was not made.
- Service Request Error - The controller is attempting to request a service from the module and has received an error. The service was not performed successfully.
- Module Configuration Invalid - The configuration in the module is invalid. (This error is commonly caused by the Electronic Key Passed fault).
- Electronic Keying Mismatch - Electronic Keying is enabled and some part of the keying information differs between the software and the module.

Associated Axes Tab

This tab lets you assign axis tags to specific channels of the servo module. Use this tab to configure the selected 1756-M02AE motion modules by:

- setting the selected 1756-M02AE motion module's Servo Update Period
- associating axis tags, of the type AXIS_SERVO, with channels 0 and 1



Servo Update Period

Selects the periodic rate at which the 1756-M02AE module closes the servo loop for the axis, in microseconds (μ s).

Channel 0

Represents Channel 0 on the servo module. This field allows you to associate an AXIS_SERVO tag with channel 0. This field transitions to a read-only state while online. Click on the button to the right of this field to open the Axis Properties dialog for the associated axis.

Channel 1

Represents Channel 1 on the servo module. This field allows you to associate an AXIS_SERVO tag with channel 1. This field transitions to a read-only state while online. Click on the button to the right of this field to open the Axis Properties dialog for the associated axis.

New Axis button

Click on this button to navigate to the New Tag dialog to create an AXIS_SERVO tag to associate with one of the channels.

Module Info Tab

The Module Info tab contains information about the selected module, however, you can click on:

- Refresh – to display new data from the module.
- Reset Module – to return the module to its power-up state by emulating the cycling of power. By doing this, you also clear all faults.

The Module Info Tab displays module and status information about the module. It also allows you to reset a module to its power-up state. The information on this tab is not displayed if you are offline or currently creating a module.

Use this tab to determine the identity of the module.

The data on this tab comes directly from the module. If you selected a Listen-Only communication format when you created the module, this tab is not available.



Identification

Displays the module's:

- Vendor
- Product Type
- Product Code
- Revision Number
- Serial Number
- Product Name

The name displayed in the Product Name field is read from the module. This name displays the series of the module. If the module is a 1756-L1 module, this field displays the catalog number of the memory expansion board (this selection applies to any controller catalog number even if additional memory cards are added: 1756-L1M1, 1756-L1M2).

Major/Minor Fault Status

If you are configuring a:	This field displays one of the following:
digital module	EEPROM fault Backplane fault None
analog module	Comm. Lost with owner Channel fault None
any other module	None Unrecoverable Recoverable

Internal State Status

This field displays the module's current operational state.

- Self-test
- Flash update
- Communication fault
- Unconnected
- Flash configuration bad
- Major Fault
- Run mode
- Program mode
- (16#xxxx) unknown

If you selected the wrong module from the module selection tab, this field displays a hexadecimal value. A textual description of this state is only given when the module identity you provide is a match with the actual module.

Configured

This field displays a yes or no value indicating whether the module has been configured by an owner controller connected to it. Once a module has been configured, it stays configured until the module is

reset or power is cycled, even if the owner drops connection to the module.

Owned

This field displays a yes or no value indicating whether an owner controller is currently connected to the module.

Module Identity

Displays:	If the module in the physical slot:
Match	agrees with what is specified on the General Tab. In order for the Match condition to exist, all of the following must agree: <ul style="list-style-type: none">• Vendor• Module Type (the combination of Product Type and Product Code for a particular Vendor)• Major Revision
Mismatch	does not agree with what is specified on the General Tab

This field does not take into account the Electronic Keying or Minor Revision selections for the module that were specified on the General Tab.

Refresh

Click on this button to refresh the tab with new data from the module.

Reset Module

Click on this button to return a module to its power-up state by emulating the cycling of power.

Resetting a module causes all connections to or through the module to be closed, and this may result in loss of control.

IMPORTANT

The following modules return an error if a reset is attempted: 1756-L1 ControlLogix 5550 Programmable Controller; 1336T AC Vector Drive; 1395 Digital DC Drive.

A controller cannot be reset.


Backplane Tab

The Backplane tab on the Module Properties window is displayed for informational purposes. You can use this tab to review diagnostic information about the module's communications over the backplane and the chassis in which it is located, clear a fault, and set the transmit retry limit.

Information on this tab is displayed only if you are online.

If you selected a Listen-Only communication format when you created the module, this tab is not available.

The data on this tab comes directly from the module.



ControlBus Status

This box either displays OK or one of the following errors:

- Receiver disabled
- Multicast addresses disabled
- RA/GA miscompare

To clear the module's backplane fault, click the Clear Fault button.

ControlBus Parameters

This box contains the following fields and button.

Multicast CRC Error Threshold

This value is the point where it enters a fault state because of Cyclic Redundancy Check (CRC) errors.

Transmit Retry Limit

Not applicable to motion module.

Set Limit Button

You must click on the Reset Limit button to make the new Transmit Retry Limit effective. If you do not and then click either the OK or the Apply button, this limit is not set.

Receive Error Counters

This box displays the number of receiving errors that occurred in the following categories:

- Bad CRC – errors that occurred on received frames (messages)
- Bus time-out – when the receiver timed out
- CRC error – multicast receive errors

Transmit Error Counters

This box displays the number of transmitting errors that occurred in the following categories:

- Bad CRC – errors that occurred on transmitted frames
- Bus Time-out – when the transmitter bus timed out

Refresh

Click on the Refresh button to refresh the tab. When you refresh the tab:

if you're using:	then:
digital, analog, or motion modules	counters are cleared
another module	the tab is refreshed but the counters are not cleared

Assigning Additional Motion Modules

You can assign additional modules by repeating the preceding sections. You can assign up to 16 1756-M02AE modules to each Logix5550 controller. Each module uses a maximum of two axes.


Configuring the 1756-M08SE Module

Adding the 1756-M08SE


This chapter reviews the necessary steps for configuring the 1756-M08SE motion module. Much of this information is the same as for adding and configuring the 1756-M02AE as discussed in the previous chapter.

To configure a 1756-M08SE motion module:


1. In the Controller Organizer, select the I/O Configuration branch.



2. In the File menu, select New Component then Module...



3. The Select Module Type screen displays. Select Clear All. Select Motion. The list displays only available motion modules.



4. Select 1756-M08SE.
5. Press the OK button to close the Select Module Type dialog. The Create Module Wizard opens.

Module Properties - Local (1756-M08SE 1.1)

Type: 1756-M08SE 8 Axis SERCOS Interface

Vendor: Allen-Bradley

Name: Slot: 3

Description:

Revision: 1 Electronic Keying: Compatible Module

Buttons: Cancel, < Back, Next >, Finish >>, Help

6. Name is the only required field that must be entered to create the M08SE module. It must conform to the IEC 1131-3 standard. You can also enter a description for the module, select the minor revision number of your module, and select the method for Electronic Keying. Fill in the at least the required Name field and click the Next> button to advance to the next wizard screen to enter Connection information. (See the section titled *1756-M08SE 8 Axis Motion Module Overview* in this chapter for more information on the fields in these screens.)

7. The Connection Screen displays.

Module Properties - Local:1 (1756-M02AE 5.1)

Requested Packet Interval (RPI): 0 ms (2.0 - 750.0 ms)

☐ Inhibit Module


☐ Major Fault On Controller II Connection Fails While in Run Mode

Module Fault:

Buttons: Cancel, < Back, Next >, Finish >>, Help

8. On this screen there are no required fields but you can enter how you want to handle connection faults. You can either choose to inhibit the module if the connection fails or you can have a major fault. After checking the appropriate box, click on Next> to advance the SERCOS interface Create Wizard screen.


9. The SERCOS interface screen displays.



10. On this screen you can enter the SERCOS ring Cycle time and the transmit power for the SERCOS ring. The rest of the Create Wizard screens are only informational and do not let you enter any information. It saves time if you click on the Finish>> button at this time.
11. The 1756-M08SE motion module appears in the I/O Configuration branch of the Controller Organizer. It can now be put into use or edited as you require.

1756-M08SE 8 Axis Motion Module Overview

The 1756-M08SE 8 Axis SERCOS motion module has been added. To edit the 1756-M08SE Module Properties, go to the I/O Configuration organizer and right click on the 1756-M08SE module and select Properties from the drop down menu. The tabbed Module Properties screen displays.



The Module Properties screen has the following tabs:

- The General tab references the 1756-M08SE 8 Axis motion module.
- The Connection tab references the connection of the module to the controller.
- The SERCOS Interface tab is for configuring SERCOS communication settings for the 1756-M08SE 8 Axis motion module.
- The SERCOS Interface Info tab is used to monitor the status of the SERCOS communication ring.
- The Module Info tab, when Online, displays the current condition of the module.
- The Backplane tab, when Online, displays diagnostic information about the module's communication over the backplane and the chassis in which it is located.

Editing 1756-M08SE Module Properties General Tab

Use this tab to create/view module properties for the 1756-M08SE 8 Axis SERCOS motion module.

On this tab, you can:

- view the type and description of the module being created
- view the vendor of the module being created
- enter the name of the module
- enter a description for the module
- select the slot number of the module on the network
- select the minor revision number of your module
- select Exact Match, Compatible Module, or Disable Keying

Type

Displays the type and description of the module being created (read only).

Vendor

Displays the vendor of the module being created (read only).

Name

Enter the name of the module. The name must be IEC 1131-3 compliant. If you attempt to enter an invalid character or exceed the maximum length, the software beeps and ignores the character.

Description

Enter a description for the module here, up to 128 characters. You can use any printable character in this field. If you exceed the maximum length, the software beeps to warn you, and ignores any extra characters.

Slot

Enter the slot number where the module resides. The spin button contains values that range from 0 to 1 less than the chassis size (e.g., if you have a 4-slot chassis, the spin button spins from 0 to 3). If you enter a slot number that is out of this range, you receive an error message when you apply your changes.

The slot number cannot be changed when online.

Revision

The revision is divided into the major revision and minor revision. The major revision displayed statically is chosen on the Select Module Type dialog.

The major revision is used to indicate the revision of the interface to the module. The minor revision is used to indicate the firmware revision.

Select the minor revision number of your module.

Electronic Keying

Select one of these keying options for your module during initial module configuration:

Exact Match - all of the parameters must match or the inserted module rejects the connection.

Compatible Module - the Module Types, Catalog Number, and Major Revision must match. The Minor Revision of the physical module must be equal to or greater than the one specified in the software or the inserted module rejects the connection.

Disable Keying – Logix5550 does not employ keying at all.

WARNING

Changing the RPI and Electronic Keying selections may cause the connection to the module to be broken and may result in a loss of data.

Be extremely cautious when using this option; if used incorrectly, this option can lead to personal injury or death, property damage or economic loss.


When you insert a module into a slot in a ControlLogix chassis, RSLogix5000 compares the following information for the inserted module to that of the configured slot:

- Vendor
- Product Type
- Catalog Number
- Major Revision
- Minor Revision

This feature prevents the inadvertent insertion of the wrong module in the wrong slot.

Connection Tab

The Connection Tab is used to define controller to module behavior. This is where you select a requested packet interval, choose to inhibit the module, configure the controller so loss of the connection to this module causes a major fault, and view module faults.



The data on this tab comes directly from the controller. This tab displays information about the condition of the connection between the module and the controller.

Requested Packet Interval

This does not apply to motion module.

Inhibit Module checkbox

Check/Uncheck this box to inhibit/uninhibit your connection to the module. Inhibiting the module causes the connection to the module to be broken.

TIP

Inhibiting/uninhibiting connections applies mainly to direct connections, and not to the CNB module



WARNING

Inhibiting the module causes the connection to the module to be broken and may result in loss of data



When you check this box and go online, the icon representing this module in the controller organizer displays the Attention Icon.

If you are:	Check this checkbox to:
offline	put a place holder for a module you are configuring
online	<p>stop communication to a module</p> <p>If you inhibit the module while you are online and connected to the module, the connection to the module is nicely closed. The module's outputs go to the last configured Program mode state.</p> <p>If you inhibit the module while online but a connection to the module has not been established (perhaps due to an error condition or fault), the module is inhibited. The module status information changes to indicate that the module is 'Inhibited' and not 'Faulted'.</p> <p>If you uninhibit a module (clear the checkbox) while online, and no fault condition occurs, a connection is made to the module and the module is dynamically reconfigured (if you are the owner controller) with the configuration you have created for that module.</p> <p>If you are a listener (have chosen a "Listen Only" Communications Format), you can not re-configure the module.</p> <p>If you uninhibit a module while online and a fault condition occurs, a connection is not made to the module.</p>

Major Fault on Controller if Connection Fails checkbox

Check this box to configure the controller so that failure of the connection to this module causes a major fault on the controller if the connection for the module fails.

Module Fault


Displays the fault code returned from the controller (related to the module you are configuring) and the text detailing the Module Fault that has occurred.

The following are common categories for errors:

- Connection Request Error - The controller is attempting to make a connection to the module and has received an error. The connection was not made.
- Service Request Error - The controller is attempting to request a service from the module and has received an error. The service was not performed successfully.
- Module Configuration Invalid - The configuration in the module is invalid. (This error is commonly caused by the Electronic Key Passed fault).
- Electronic Keying Mismatch - Electronic Keying is enabled and some part of the keying information differs between the software and the module.

SERCOS Interface Tab

The SERCOS interface Tab is where you set the specific Data Rate, Cycle Time, and Transmit Power for the named 1756-M08SE SERCOS interface module.



Use the SERCOS Interface Tab to set and display the:

- SERCOS baud rate
- update rate for the SERCOS ring
- fiber optic transmit power range for the SERCOS ring

The SERCOS ring consists of the drives and axes connected to the 1756-M08SE motion controller.

TIP

The settings on this tab are specific to the 1756-M08SE motion controller.



Data Rate

Select the baud rate for the SERCOS ring. (For this release, this value is set to 4 MB and is Read Only.)

Cycle Time


Select the update rate for the SERCOS ring: 1 ms or 2 ms.

Transmit Power

Select the optic transmit power range for the SERCOS ring: High or Low.

SERCOS Interface Info Tab

The SERCOS interface Tab is for monitoring the SERCOS ring of the selected 1756-M08SE while it is on-line. A REFRESH button is available to access the current values.



Use this tab to monitor the following:

Ring Comm. Phase

Displays the communications phase of the SERCOS ring:

- 0: Ring Integrity
- 1: Polling
- 2: Identity
- 3: Configuration
- 4: Cyclic communication

Fault Type

Displays the current fault type, if any, on the SERCOS ring. Values include:

- No Fault
- Open Ring
- Not communicating
- Not responding
- Timing error
- Duplicate node
- Excess nodes on Ring
- Invalid data rate
- Invalid cycle time

Refresh

Click this button to update this page.

Note: this information does not refresh automatically.

Module Info Tab


The Module Info tab contains information about the selected module, however, you can click on:

- Refresh – to display new data from the module.
- Reset Module – to return the module to its power-up state by emulating the cycling of power. By doing this, you also clear all faults.

The Module Info Tab displays module and status information about the module. It also allows you to reset a module to its power-up state. The information on this tab is not displayed if you are offline or currently creating a module.

Use this tab to determine the identity of the module.

The data on this tab comes directly from the module. If you selected a Listen-Only communication format when you created the module, this tab is not available.



Identification

Displays the module's:

- Vendor
- Product Type
- Product Code
- Revision Number
- Serial Number
- Product Name

The name displayed in the Product Name field is read from the module. This name displays the series of the module. If the module is a 1756-L1 module, this field displays the catalog number of the memory expansion board (this selection applies to any controller catalog number even if additional memory cards are added: 1756-L1M1, 1756-L1M2).

Major/Minor Fault Status

If you are configuring a:	This field displays one of the following:
digital module	EEPROM fault Backplane fault None
analog module	Comm. Lost with owner Channel fault None
any other module	None Unrecoverable Recoverable

Internal State Status

This field displays the module’s current operational state.

- Self-test
- Flash update
- Communication fault
- Unconnected
- Flash configuration bad
- Major Fault
- Run mode
- Program mode
- (16#xxxx) unknown

If you selected the wrong module from the module selection tab, this field displays a hexadecimal value. A textual description of this state is only given when the module identity you provide is a match with the actual module.

Configured

This field displays a yes or no value indicating whether the module has been configured by an owner controller connected to it. Once a module has been configured, it stays configured until the module is

reset or power is cycled, even if the owner drops connection to the module.

Owned

This field displays a yes or no value indicating whether an owner controller is currently connected to the module.

Module Identity

Displays:	If the module in the physical slot:
Match	agrees with what is specified on the General Tab. In order for the Match condition to exist, all of the following must agree: <ul style="list-style-type: none">• Vendor• Module Type (the combination of Product Type and Product Code for a particular Vendor)• Major Revision
Mismatch	does not agree with what is specified on the General Tab

This field does not take into account the Electronic Keying or Minor Revision selections for the module that were specified on the General Tab.

Refresh

Click on this button to refresh the tab with new data from the module.

Reset Module

Click on this button to return a module to its power-up state by emulating the cycling of power.

Resetting a module causes all connections to or through the module to be closed, and this may result in loss of control.

IMPORTANT	The following modules return an error if a reset is attempted: 1756-L1 ControlLogix 5550 Programmable Controller; 1336T AC Vector Drive; 1395 Digital DC Drive.
------------------	---

A controller cannot be reset.


Backplane Tab

The Backplane tab on the Module Properties window is displayed for informational purposes. You can use this tab to review diagnostic information about the module's communications over the backplane and the chassis in which it is located, clear a fault, and set the transmit retry limit.

Information on this tab is displayed only if you are online.

If you selected a Listen-Only communication format when you created the module, this tab is not available.

The data on this tab comes directly from the module.



ControlBus Status

This box either displays OK or one of the following errors:

- Receiver disabled
- Multicast addresses disabled
- RA/GA miscompare

To clear the module's backplane fault, click the Clear Fault button.

ControlBus Parameters

This box contains the following fields and button.

Multicast CRC Error Threshold

This value is the point where it enters a fault state because of Cyclic Redundancy Check (CRC) errors.

Transmit Retry Limit

Not applicable to motion module.

Set Limit Button

You must click on the Reset Limit button to make the new Transmit Retry Limit effective. If you do not and then click either the OK or the Apply button, this limit is not set.

Receive Error Counters

This box displays the number of receiving errors that occurred in the following categories:

- Bad CRC – errors that occurred on received frames (messages)
- Bus time-out – when the receiver timed out
- CRC error – multicast receive errors

Transmit Error Counters

This box displays the number of transmitting errors that occurred in the following categories:

- Bad CRC – errors that occurred on transmitted frames
- Bus Time-out – when the transmitter bus timed out

Refresh

Click on the Refresh button to refresh the tab. When you refresh the tab:


if you're using:	then:
digital, analog, or motion modules	counters are cleared
another module	the tab is refreshed but the counters are not cleared

The Motion Group


Creating A Motion Group

Each .acd program must have one motion group. (There can be only one.) You must create it before an axis can be assigned to the group and have it function within the .acd program.

To create the motion group, right click on Motion Group and select New Motion Group from the drop down menu.



This calls the New Tag window.



1. Enter a name for the Motion Group in the Name field.
2. In the Description field, enter a description of the tag.
3. Click on the respective radio button to select one of the following tag types:
 - Base - refers to a normal tag (selected by default)
 - Alias - refers to a tag, which references another tag with the same definition. Special parameters appear on the New Tag dialog that allows you to identify to which base tag the alias refers.
4. Select MOTION_GROUP for the Data Type.
5. From the Scope pull-down menu, select the scope for the tag.
6. If you want to produce this tag for other controllers to consume, check the Produce box and enter the maximum number of consumers.

IMPORTANT


Producing a tag requires a connection for each consumer. Connections are a limited resource in the controller, so only produce tags that you know you are needed in other controllers.

7. Click on OK to create the tag and close the New Tag dialog.

If there are errors, you will be prompted.

8. Click on the Configure button.

The Motion Group Wizard group - Axis Assignment screen displays.




Add any existing axes to the group.

9. Continue on through the Motion Group Wizard to configure your Motion Group tag as necessary. Click on Finish>> to close the wizard.

Editing the Motion Group Properties

The Motion Group properties can be edited by right clicking on the group name and selecting Motion Group Properties from the drop down menu. The Motion Group Properties tabbed screen displays.



Axis Assignment Tab

The Axis Assignment screen is where axes are either assigned or unassigned to the Motion Group. When RSLogix 5000 software is online, all attributes on this dialog transition to a read-only state. When an attribute transitions to a read-only state, all pending attribute changes revert back to their offline status.

Unassigned

Lists the axes that are not assigned to any group in the controller.

Assigned

Lists the axes that are assigned to this motion group.

Add


Click on this button to add axes to the motion group.

Remove

Click on this button to remove axes from the motion group.

Attribute Tab

The Attribute tab is used to modify the group attributes.



When RSLogix 5000 software is online, all of the attributes on this tab transition to a read-only state. When an attribute transitions to a read-only state, all pending attribute changes are reverted.

Coarse Update Period

Selects the periodic rate at which the motion task executes to compute the servo commanded position, velocity, and accelerations to be sent

to the 1756-M02AE or 1756-M08SE modules when executing motion instructions.

TIP

If the coarse update period is too small, the controller may not have time to execute non-motion related ladder logic. As a general rule, one millisecond per axis is needed by the motion task for the controller to have reasonable execution time. As a result, the configuration sets the lower limit on the coarse update period based on the number of axes in the group.

Auto Tag Update

Determines whether axis parameter values will be automatically updated during operation. Choose from:

- Enabled – turns On automatic tag updating
- Disabled – turns Off automatic tag updating

General Fault Type

Selects the general fault type mechanism for the motion group. The available selections are:

- Non Major Fault – Any faults detected by the motion group will not cause the processor to fault. The application programmer needs to handle the fault in the program.
- Major Fault – Any faults detected by the motion group will cause the processor OK light to go blinking red and the fault routine to be invoked. If the fault routine handles the fault and clears it, then the OK light turns green. If the fault routine does not clear the fault, then the OK light becomes solid red and the processor stops executing the program.

Scan Times (elapsed time)

- Max – displays the value from the previous scan; clear this value, if necessary
- Disabled – displays the value from the previous scan

Reset Max

Click on this button to clear the Scan Times Max value.

Tag Tab

Use this tab to modify the name and description of the group.

The screenshot shows the 'Motion Group Properties - group' dialog box with the 'Tag' tab selected. The dialog has four tabs: 'Axis Assignment', 'Attribute', 'Tag', and 'Base'. The 'Tag' tab contains the following fields and controls:

- Name:** A text field containing the word 'group'.
- Description:** A text area with a vertical scrollbar.
- Tag Type:** A dropdown menu set to 'Base'.
- Data Type:** A text field containing 'MOTION_GROUP'.
- Scope:** A text field containing 'fredtst'.
- Style:** A dropdown menu.
- Produce this tag for up to:** A checkbox (unchecked) followed by a numeric spinner set to '0' and the text 'consumers'.
- Base Tag:** A dropdown menu.

At the bottom of the dialog are four buttons: 'OK', 'Cancel', 'Apply', and 'Help'.

When you are online, all of the parameters on this tab transition to a read-only state, and cannot be modified. If you go online before you save your changes, all pending changes revert to their previously-saved state.

Name

Enter the name of the motion group. This name must not exceed 40 characters. If you enter more than 40 characters, the system notifies you and it ignores the extra characters.

Description

Enter a description of the motion group. This description must not exceed 128 characters. If you enter more than 128 characters, the system notifies you and it ignores the extra characters.

Tag Type (read-only)

Displays the type of tag.

- Base - a normal tag
- Alias - a tag that references another tag with the same definition

Data Type (read-only)

The axis data type: MOTION_GROUP

Scope

Displays the scope of the current tag. The scope is either controller scope, or program scope, based on one of the existing programs in the controller.

Style

Not applicable to motion group tags.

Produce this tag for up to

A checked box indicates that this tag is available to remote controllers through controller-to-controller messaging. If this box is checked, the system displays the maximum number of consumers (i.e., connections) allowed for this tag.

The default number of consumers is 2.

Base Tag

If this tag is an alias, this field displays the name of the motion group tag on which this alias was based. The base tag actually defines the memory where the data element is stored.

Naming & Configuring Your Motion Axis

This chapter describes how to name, configure, and edit your axis properties.


Naming an Axis

Naming an axis adds it to your application. To name an axis:

Go to the **File** pull-down menu, select **New Component**, and then select **Tag**.



The New Tag window appears.



Entering Tag Information

A tag allows you to allocate and reference data stored in the controller. A tag can be a simple, single element, or an array, or a structure. There are four types of tags that you can create:

- A base tag allows you to create your own internal data storage.
- An alias tag allows you to assign your own name to an existing tag, structure tag member, or bit.
- A produced tag lets you make the tag available to remote controllers through controller-to-controller messaging.
- A consumed tag allows you to retrieve data from a tag in another controller.

You must set up only one consumed tag to get data from the same producing tag in another controller.

WARNING

Setting up more than one consumed tag results in unpredictable controller to controller behavior.

Use this dialog to create new tags. The parameters that appear on this dialog depend upon the type of tag you are creating.

You can create base tags and alias tags while the controller is online or offline, as long as the new tag is verified. You can only create consumed tags while the controller is offline.

Common Parameters

The following parameters appear on the New Tag dialog whether you are creating a base tag, alias tag, or consumed tag.

Name

Enter the name of the tag you want to create.

Description

Enter a description of the tag.

Tag Type

Check the type of tag you are creating:

- Base – refers to a normal tag (selected by default)
- Alias – refers to a tag, which references another tag with the same definition. Special parameters appear on the New Tag dialog that allow you to identify to which base tag the alias refers.
- Produced – refers to a tag that has been made available to other controllers. If this type is chosen, then you can set the maximum number of consumers allowed for this tag.
- Consumed (only available when the controller is offline) – refers to a tag that is produced by another controller whose data you want to use in this controller. Special parameters appear on the New Tag dialog that allow you to identify from where the consumed tag is to come.

Data Type

In the Data Type field you can either enter the type of tag you want to create directly or click on the ellipsis button to go to the Select Data Type dialog. From this dialog you can select the appropriate axis data type: AXIS_CONSUMED, AXIS_SERVO, AXIS_SERVO_DRIVE, or AXIS_VIRTUAL.

Make entries in the following fields.

Field	Entry	
Name	Type a name for the servo axis. The name can: have a maximum of 40 characters contain letters, numbers and underscores (_).	
Description	Type a description for your motion axis. This field is optional.	
Data type	AXIS_CONSUMED AXIS_SERVO AXIS_SERVO_DRIVE, AXIS_VIRTUAL	
Scope	Select the scope of the axis variable. To use the axis Within the entire program	Select Controller

Editing Motion Axis Properties

Once you have named your axis in the New Tag window, you must then configure it. You can make your configuring options in the Axis Properties screen. These have a series of Tabs that access a specific dialog for configuring the axis. Make the appropriate entries for each of the fields. An asterisk appears on the Tab to indicate changes have been made but not implemented. Press the Apply button at the bottom of each dialog to implement your selections.


TIP

When you configure your axis, some fields may be unavailable (greyed-out) because of choices you made in the New Tag window.




In the Controller Organizer, right click on the axis to edit and select Axis Properties from the drop down menu. The Axis Properties


General window appears. The General screen depicted below is for an AXIS_SERVO data type.



The General screen shown below is for an AXIS_SERVO DRIVE Data Type.



The AXIS_VIRTUAL General Tab is shown below.



General Tab – SERVO_AXIS

Use this tab to do the following for an axis, of the data type AXIS_SERVO:

- Configure the axis for Servo operation, or for position Feedback Only.
- Assign the axis, or terminate the assignment of an axis, to a Motion Group.
- Associate the axis with a 1756-M02AE motion module.
- Select the channel, 0 or 1, on the 1756-M02AE motion module to which the axis is connected.

Note: RSLogix 5000 supports only one Motion Group tag per controller.

When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.

When multiple workstations connect to the same controller using RSLogix 5000 and invoke the Axis Wizard or Axis Properties dialog, the firmware allows only the first workstation to make any changes to axis attributes. The second workstation switches to a Read Only mode, indicated in the title bar, so that you may view the changes from that workstation, but not edit them.

Axis Configuration

Selects and displays the intended use of the axis:

- **Feedback Only:** If the axis is to be used only to display position information from the feedback interface. This selection minimizes the display of axis properties tabs and parameters.
- **Servo:** If the axis is to be used for full servo operation. This selection maximizes the display of axis properties tabs and parameters.

Assigned Motion Group

Selects and displays the Motion Group to which the axis is associated. An axis assigned to a Motion Group appears in the Motion Groups branch of the Controller Organizer, under the selected Motion Group sub-branch. Selecting <none> terminates the Motion Group association, and moves the axis to the Ungrouped Axes sub-branch of the Motions Groups branch.

Ellipsis (...) button

Opens the Motion Group Properties dialog box for the Assigned Motion Group, where you can edit the properties of the Assigned Motion Group. If no Motion Group is assigned to this axis, this button is disabled.

New Group button

Opens the New Tag dialog box, where you can create a new Motion Group tag. This button is enabled only if no Motion Group tag has been created.

Module

Selects and displays the name of the motion module to which the axis is associated. Displays <none> if the axis is not associated with any motion module.

Module Type

This read-only field displays the type of motion module, if any, with which the axis is associated. An axis of the AXIS_SERVO data type can be associated only with 1756-M02AE motion modules. Displays <none> if the axis is not associated with any motion module.

Channel

Selects and displays the 1756-M02AE motion module channel - either 0 or 1 - to which the axis is assigned. Disabled when the axis is not associated with any motion module.

Output Cam Execution Targets

Determines how many Output Cam execution nodes (instances) are created for a specific axis. Note that the Execution Target parameter for the MAOC/MDOC instructions specify which of the configured execution nodes the instruction is affecting. In addition, the number specified in the Axis Properties dialog specifies the number of instances of Output Cam in which the value of zero means “none”, and the value specified for Execution Target in the MAOC instruction references a specific instance in which a value of zero selects the first instance.

General Tab - AXIS_SERVO_DRIVE

Use this tab to do the following for an axis, of the data type AXIS_SERVO_DRIVE:

- Configure the axis for Servo operation, or for position Feedback Only.
- Assign the axis, or terminate the assignment of an axis, to a Motion Group.
- Associate the axis with a 1756-M08SE motion module.
- View the base node of the associated 1756- M08SE motion module.

Note: RSLogix 5000 supports only one Motion Group tag per controller.

When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.

When multiple workstations connect to the same controller using RSLogix 5000 and invoke the Axis Wizard or Axis Properties dialog, the firmware allows only the first workstation to make any changes to axis attributes. The second workstation switches to a Read Only mode, indicated in the title bar, so that you may view the changes from that workstation, but not edit them.

Axis Configuration

Selects and displays the intended use of the axis:

- **Feedback Only:** If the axis is to be used only to display position information from the feedback interface. This selection minimizes the display of axis properties tabs and parameters.
- **Servo:** If the axis is to be used for full servo operation. This selection maximizes the display of axis properties tabs and parameters.

Assigned Motion Group

Selects and displays the Motion Group to which the axis is associated. An axis assigned to a Motion Group appears in the Motion Groups branch of the Controller Organizer, under the selected Motion Group sub-branch. Selecting <none> terminates the Motion Group association, and moves the axis to the Ungrouped Axes sub-branch of the Motions Groups branch.

Ellipsis (...) button

Opens the Motion Group Properties dialog box for the Assigned Motion Group, where you can edit the properties of the Assigned Motion Group. If no Motion Group is assigned to this axis, this button is disabled.

New Group button

Opens the New Tag dialog box, where you can create a new Motion Group tag. This button is enabled only if no Motion Group tag has been created.

Module

Selects and displays the name of the motion module to which the axis is associated. Displays <none> if the axis is not associated with any motion module.

Module Type

This read-only field displays the type of motion module, if any, with which the axis is associated. An axis of the AXIS_SERVO_DRIVE data type can be associated only with 1756- M08SE motion modules. Displays <none> if the axis is not associated with any motion module.

Node

Displays the base node of the associated 1756- M08SE motion module. Disabled when the axis is not associated with any motion module.

Output Cam Execution Targets

Determines how many Output Cam execution nodes (instances) are created for a specific axis. Note that the Execution Target parameter for the MAOC/MDOC instructions specify which of the configured execution nodes the instruction is affecting. In addition, the number specified in the Axis Properties dialog specifies the number of instances of Output Cam in which the value of zero means "none", and the value specified for Execution Target in the MAOC instruction references a specific instance in which a value of zero selects the first instance.

General Tab - AXIS_VIRTUAL

Use this tab to associate the axis, of the data type AXIS_VIRTUAL, to a Motion Group.

Note: RSLogix 5000 supports only one Motion Group tag per controller.

When RSLogix 5000 software is online, the parameters on this tab transition to a read-only state. When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.

When multiple workstations connect to the same controller using RSLogix 5000 and invoke the Axis Wizard or Axis Properties dialog, the firmware allows only the first workstation to make any changes to axis attributes. The second workstation switches to a Read Only mode, indicated in the title bar, so that you may view the changes from that workstation, but not edit them.

Assigned Motion Group

Selects and displays the Motion Group to which the axis is associated. An axis assigned to a Motion Group appears in the Motion Groups branch of the Controller Organizer, under the selected Motion Group sub-branch. Selecting <none> terminates the Motion Group association, and moves the axis to the Ungrouped Axes sub-branch of the Motions Groups branch.

Ellipsis (...) button

Opens the Motion Group Properties dialog box for the Assigned Motion Group, where you can edit the properties of the Assigned Motion Group. If no Motion Group is assigned to this axis, this button is disabled.


New Group button

Opens the New Tag dialog box, where you can create a new Motion Group tag. This button is enabled only if no Motion Group tag has been created.

Output Cam Execution Targets

Determines how many Output Cam execution nodes (instances) are created for a specific axis. Note that the Execution Target parameter for the MAOC/MDOC instructions specify which of the configured execution nodes the instruction is affecting. In addition, the number specified in the Axis Properties dialog specifies the number of instances of Output Cam in which the value of zero means "none", and the value specified for Execution Target in the MAOC instruction references a specific instance in which a value of zero selects the first instance.

Press **Apply** then select the Units tab to access the Axis Properties Units dialog.



Units Tab

The Units Tab is the same for all axis data types. Use this tab to determine the units to define your motion axis.

When RSLogix 5000 software is online and the controller transitions to hard run, or the servo loop is on (i.e., active), then all the attributes on this tab transition to a read only state. When any attribute transitions to a read only state, then any pending attribute changes are reverted.

When multiple workstations connect to the same controller using RSLogix 5000 and invoke the Axis Wizard or Axis Properties dialog, the firmware allows only the first workstation to make any changes to axis attributes. The second workstation switches to a Read Only mode, indicated in the title bar, so that you may view the changes from that workstation, but not edit them.

Position Units

User-defined engineering units (rather than feedback counts) used for labeling all motion-related values (e.g., position, velocity, etc.) These position units can be different for each axis.

Note: Position Units should be chosen for maximum ease of use in your application. For example, linear axes might use position units of Inches, Meters, or mm whereas rotary axes might use units of Revs or Degrees.


Average Velocity Timebase

Specifies the time (in seconds) to be used for calculating the average velocity of the axis. This value is computed by taking the total distance the axis travels in the amount of time specified, and dividing this value by the timebase.

The average velocity timebase value should be large enough to filter out the small changes in velocity that would result in a "noisy" velocity value, but small enough to track significant changes in axis velocity. A value of 0.25 to 0.50 seconds should work well for most applications.

Click on the Apply button to accept your changes.

Click on the Conversion Tab to access the Axis Properties Conversion dialog.



Conversion Tab

Use this tab to view the Positioning Mode and configure the Feedback Resolution for an axis, of the tag types AXIS_SERVO, AXIS_SERVO_DRIVE and AXIS_VIRTUAL.

When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.

When multiple workstations connect to the same controller using RSLogix 5000 and invoke the Axis Wizard or Axis Properties dialog, the firmware allows only the first workstation to make any changes to axis attributes. The second workstation switches to a Read Only mode, indicated in the title bar, so that you may view the changes from that workstation, but not edit them.

Positioning Mode

This parameter is not editable for an axis of the data type AXIS_CONSUMED. Instead, this value is set in and taken from a producing axis in a networked Logix processor. The values that can be passed are:

- Linear - provides a maximum total linear travel of 1 billion feedback counts. With this mode, the unwind feature is disabled and you can limit the linear travel distance traveled by the axis by specifying the positive and negative travel limits for the axis.
- Rotary - enables the rotary unwind capability of the axis. This feature provides infinite position range by unwinding the axis position whenever the axis moves through a complete unwind distance. The number of encoder counts per unwind of the axis is specified by the Position Unwind parameter.

Conversion Constant

Type the number of feedback counts per position unit. This conversion – or “K” – constant allows axis position to be displayed, and motion to be programmed, in the position units set in the Units tab. The conversion constant is used to convert axis position units into feedback counts and vice versa.

Note: For axes of the type `AXIS_SERVO_DRIVE`, the label will indicate the number of counts per motor revolution, as set in the Drive Resolution field of the Drive tab.

Position Unwind

This parameter is not editable for an axis of the data type `AXIS_CONSUMED`. Instead, this value is set in and taken from a producing axis in a networked Logix processor. For a Rotary axis, this value represents the distance (in feedback counts) used to perform automatic electronic unwind. Electronic unwind allows infinite position range for rotary axes by subtracting the unwind distance from both the actual and command position, every time the axis travels the unwind distance.


Note: For axes of the type `AXIS_SERVO_DRIVE`:

- when you save an edited Conversion Constant or a Drive Resolution value, a message box appears, asking you if you want the controller to automatically recalculate certain attribute settings. (Refer to Conversion Constant and Drive Resolution Attributes.)
- the label will indicate the number of counts per motor revolution, as set in the Drive Resolution field of the Drive tab.

Click on Apply to accept your changes.

Servo Tab - AXIS_SERVO

Click on the Servo Tab from the Axis Properties for SERVO_AXIS to access the Servo dialog.



For an axis of the data type AXIS_SERVO, configured for Servo operation in the General tab of this dialog box, use the SERVO tab to:

- configure an external drive
- configure the drive fault input
- select up to two axis attributes whose status can be monitored

When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.

When multiple workstations connect to the same controller using RSLogix 5000 and invoke the Axis Wizard or Axis Properties dialog, the firmware allows only the first workstation to make any changes to axis attributes. The second workstation switches to a Read Only mode, indicated in the title bar, so that you may view the changes from that workstation, but not edit them.

External Drive Configuration

Select the drive type for the servo loop:

- Velocity - disables the servo module's internal digital velocity loop.
- Torque - the servo module's internal digital velocity loop is active, which is the required configuration for interfacing the servo axis to a torque loop servo drive.

Loop Configuration

Select the configuration of the servo loop. For this release, only Position Servo is available.

Enable Drive Fault Input

Check this box if you wish to enable the Drive Fault detection. When the drive fault is detected, appropriate action is taken based on the Drive Fault Action specified in the Fault Actions tab of this dialog box.

Drive Fault Input

Specifies the usual state of the drive fault input – Normally:

- Open
- Closed

Real Time Axis Information

Attribute 1/Attribute 2

Select up to two axis attributes whose status will be transmitted – along with the actual position data – to the Logix processor. The values of the selected attributes can be accessed via the standard GSV or Get Attribute List service.


Note: The servo status data update time is precisely the coarse update period.

If a GSV is done to one of these servo status attributes without having selected this attribute via the Drive Info Select attribute, the attribute value will be static and will not reflect the true value in the servo module.

Click on the Apply button to accept your changes.

Drive Tab - (AXIS_SERVO_DRIVE)

Use this tab to configure the servo loop for an AXIS_SERVO_DRIVE axis, and open the Custom Drive Scaling Attributes dialog box.



When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.

Amplifier Catalog Number

Select the catalog number of the amplifier to which this axis is connected.

Loop Configuration

Select the configuration of the servo loop:

- Motor Feedback Only
- Aux Feedback Only
- Position Servo
- Auxiliary Position Servo (not applicable to Ultra3000 drives)
- Dual Position Servo (not applicable to Ultra3000 drives)
- Motor Dual Command Servo
- Auxiliary Dual Command Servo
- Velocity Servo
- Torque Servo

Drive Resolution

Type in the number of counts per motor revolution. This value will apply to all position data. Valid values range from 1 to $2^{32} - 1$. One Least Significant Bit (LSB) for position data equals $360^\circ / \text{Rotational Position Resolution}$.

Note: Drive Resolution is also referred to as Rotational Position Resolution.

When you save an edited Conversion Constant or a Drive Resolution value, a message box appears, asking you if you want the controller to automatically recalculate certain attribute settings. (Refer to Conversion Constant and Drive Resolution Attributes for a list of these attributes.)

Drive Resolution is especially helpful for either fractional unwind applications or multi-turn applications requiring cyclic compensation. You can modify the Drive Resolution value so that dividing it by the Unwind Value yields a whole integer value. The higher the Drive Resolution setting, the finer the resolution.

Real Time Axis Information

Attribute 1/Attribute 2

Select up to two axis attributes whose status will be transmitted – along with the actual position data – to the Logix processor. The values of the selected attributes can be accessed via the standard GSV or Get Attribute List service.

Note: The servo status data update time is precisely the coarse update period.

If a GSV is done to one of these servo status attributes without the having selected this attribute via the Drive Info Select attribute, the attribute value will be static and will not reflect the true value in the servo module.

Set Custom Scaling...button

Opens the Custom Drive Scaling Attributes dialog, where you can read scaling-related attributes for the axis.

Motor/Feedback Tab - AXIS_SERVO_DRIVE

Use this tab to configure motor and auxiliary feedback device (if any) parameters, for an axis of the type AXIS_SERVO_DRIVE.

Note: The Axis Configuration selection made on the General tab, and the Loop Configuration selection made on the Drive tab determine which sections of this dialog box – Motor and Auxiliary Feedback – are enabled.

When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.

(Motor) Catalog Number

Select the catalog number of the motor associated with this axis. When you change a Motor Catalog Number, the controller recalculates the values of the following values using (among other values) the default Damping Factor of 0.8.

On this tab or dialog:	These attributes are recalculated:
Motor/Feedback tab	Motor Feedback Type Motor Feedback Resolution
Gains tab	Position Proportional Gains Velocity Proportional Gains
Dynamics tab	Maximum Velocity Maximum Acceleration Maximum Deceleration
Limits tab	Position Error Tolerance
Custom Stop Action Attributes dialog	Stopping Torque
Custom Limit Attributes dialog	Velocity Limit Bipolar Velocity Limit Positive Velocity Limit Negative Acceleration Limit Bipolar Acceleration Limit Positive Acceleration Limit Negative Torque Limit Bipolar Torque Limit Positive Torque Limit
Tune Bandwidth dialog	Position Loop Bandwidth Velocity Loop Bandwidth

Note: The Associated Module selection (selected on the General tab), determines available catalog numbers.

(Motor) Feedback Type

This read-only field displays the type of feedback associated with the selected motor (in the Catalog Number field, above). If you selected <None> as the Catalog Number, you must select a Feedback Type.

(Motor) Interpolation Factor

This field displays a fixed, read-only value for each feedback type. This value is used to compute the resolution of the feedback device.

(Motor) Cycles

The number of cycles per revolution of the associated feedback device. This helps the Drive Compute Conversion constant used to convert drive units to feedback counts. Depending on the feedback type you select, this value may be either read-only or editable.

(Auxiliary Feedback) Type

For applications that use auxiliary feedback devices, select the type of auxiliary feedback device type.

Note: The Auxiliary Feedback section of this tab is enabled only if the Drive tab's Loop Configuration field is set to Aux Feedback Only, Aux Position Servo, or Aux Dual Command Servo.

Feedback Type	Description
SRS60	Stegmann Single Turn, Absolute 1024 S-C/Rev (Rotary)
SRM60	Stegmann Multi-Turn, Absolute 1024 S-C/Rev (Rotary)
SCS60	Stegmann Single Turn, Absolute 512 S-C/Rev (Rotary)
SCM60	Stegmann Multi Turn, Absolute 512 S-C/Rev (Rotary)
SNS60	Stegmann High Res Incremental, 1024 S-C/Rev (Rotary)
MHG90	Stegmann Encoder
Resolver	0.25 TR Resolver
Analog Reference	Differential Analog
Sin/Cos	Generic S-C Device w/Z marker
TTL	Generic AQB Device w/Z marker
UVW	Differential Hall Effect
Unknown Stegmann	Unrecognized Stegmann
Endat	Heidenhain Endat SSI Encoder
RCM21S-4	Renco Smart Encoder 4 Pole

Feedback Type	Description
RCM21S-6	Renco Smart Encoder 6 Pole
RCM21S-8	Renco Smart Encoder 8 Pole
LINCODER	5mm Cycle Linear Hiperface Magnetic Encoder

(Aux) Interp Factor

This field displays a fixed constant value for the selected feedback type. This value is used to compute the resolution of the feedback device.

(Aux) Cycles

The number of cycles per revolution of the auxiliary feedback device. This helps the Drive Compute Conversion constant used to convert drive units to feedback counts. Depending on the feedback type selected, this value may either be read-only or editable.


(Aux) Ratio

Represents the quantitative relationship between the auxiliary feedback device and the motor.

Homing Tab - SERVO_AXIS and SERVO_AXIS_DRIVE

Use this tab to configure the attributes related to homing an axis of the type AXIS_SERVO or AXIS_SERVO_DRIVE.

When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.



Mode

Select the homing mode:

- **Active:** In this mode, the desired homing sequence is selected by specifying whether a home limit switch and/or the encoder marker is used for this axis. Active homing sequences always use the trapezoidal velocity profile.
- **Passive:** In this mode, homing redefines the absolute position of the axis on the occurrence of a home switch or encoder marker event. Passive homing is most commonly used to calibrate uncontrolled axes, although it can also be used with controlled axes to create a custom homing sequence. Passive homing, for a given home sequence, works similar to the corresponding active homing sequence, except that no motion is commanded; the controller just waits for the switch and marker events to occur.
- **Absolute:** (AXIS_SERVO_DRIVE only) In this mode, the absolute homing process establishes the true absolute position of the axis by applying the configured Home Position to the reported position of the absolute feedback device. The only valid Home Sequence for an absolute Homing Mode is immediate.

Position

Type the desired absolute position, in position units, for the axis after the specified homing sequence has been completed. In most cases, this position will be set to zero, although any value within the

software travel limits can be used. After the homing sequence is complete, the axis is left in this position.

If the Positioning Mode (set in the Conversion tab) of the axis is Linear, then the home position should be within the travel limits, if enabled. If the Positioning Mode is Rotary, then the home position should be less than the unwind distance in position units.

Offset

Type the desired offset (if any) in position units the axis is to move, upon completion of the homing sequence, to reach the home position. In most cases, this value will be zero.

Sequence

Select the event that will cause the Home Position to be set:

Sequence Type:	Description:
Immediate	Sets the Home Position to the present actual position, without motion.
Switch	Sets the Home Position when axis motion encounters a home limit switch.
Marker	Sets the Home Position when axis encounters an encoder marker.
Switch-Marker	Sets the Home Position when axis first encounters a home limit switch, then encounters an encoder marker.

Note: See the section “Homing Configurations,” below, for a detailed description of each combination of homing mode, sequence and direction.

Limit Switch

If a limit switch is used, indicate the normal state of that switch (i.e., before being engaged by the axis during the homing sequence):

- Normally Open
- Normally Closed

Direction

For active homing sequences, except for the Immediate Sequence type, select the desired homing direction:

Direction	Description
Forward Uni-directional	The axis jogs in the positive axial direction until a homing event (switch or marker) is encountered, then continues in the same direction until axis motion stops (after decelerating or moving the Offset distance).
Forward Bi-directional	The axis jogs in the positive axial direction until a homing event (switch or marker) is encountered, then reverses direction until motion stops (after decelerating or moving the Offset distance).
Reverse Uni-directional	The axis jogs in the negative axial direction until a homing event (switch or marker) is encountered, then continues in the same direction until axis motion stops (after decelerating or moving the Offset distance).
Reverse Bi-directional	The axis jogs in the negative axial direction until a homing event (switch or marker) is encountered, then reverses direction until motion stops (after decelerating or moving the Offset distance).

Speed

Type the speed of the jog profile used in the first leg of an active homing sequence. The homing speed specified should be less than the maximum speed and greater than zero.

Return Speed

The speed of the jog profile used in the return leg(s) of an active homing sequence. The home return speed specified should be less than the maximum speed and greater than zero.

Homing Configurations

The following examples of Active and Passive homing assume that the initial motion, if any, is in a positive axial direction. Click on an individual homing configuration for more information.

- Active Homing Configurations
- Active Immediate Home
- Active Bi-directional Home with Switch
- Active Bi-directional Home with Marker
- Active Bi-directional Home with Switch then Marker
- Active Uni-directional Home with Switch
- Active Uni-directional Home with Marker
- Active Uni-directional Home with Switch then Marker
- Passive Homing Configurations
- Passive Immediate Home
- Passive Home with Switch
- Passive Home with Marker
- Passive Home with Switch then Marker

Homing Tab - AXIS_VIRTUAL

Use this tab to configure the attributes related to homing an axis of the type AXIS_VIRTUAL.

Only an Active Immediate Homing sequence can be performed for an axis of the type AXIS_VIRTUAL. When this sequence is performed, the controller immediately enables the servo drive and assigns the Home Position to the current axis actual position and command position. This homing sequence produces no axis motion.

When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.

Mode

This read-only parameter is always set to Active.

Position

Type the desired absolute position, in position units, for the axis after the specified homing sequence has been completed. In most cases, this position will be set to zero, although any value within the

software travel limits can be used. After the homing sequence is complete, the axis is left at this position.

If the Positioning Mode (set in the Conversion tab) of the axis is Linear, then the home position should be within the travel limits, if enabled. If the Positioning Mode is Rotary, then the home position should be less than the unwind distance in position units.


Sequence

This read-only parameter is always set to Immediate

Hookup Tab - AXIS_SERVO

Use this tab to configure and initiate axis hookup and marker test sequences for an axis of the type AXIS_SERVO.

When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.



Test Increment

Specifies the amount of distance traversed by the axis when executing the Output & Feedback test. The default value is set to approximately a quarter of a revolution of the motor in position units.

Feedback Polarity

The polarity of the encoder feedback, this field is automatically set by executing either the Feedback Test or the Output & Feedback Test:

- Positive
- Negative

Note: When properly configured, this setting insures that axis Actual Position value increases when the axis is moved in the user defined positive direction. This bit can be configured automatically using the MRHD and MAHD motion instructions.

WARNING

Modifying automatically input polarity values by running the Feedback or Output & Feedback Tests can cause a runaway condition.

Output Polarity

The polarity of the servo output to the drive, this field is automatically set by executing the Output & Feedback Test:

- Positive
- Negative

Note: When properly configured, this setting and the Feedback Polarity setting insure that, when the axis servo loop is closed, it is closed as a negative feedback system and not an unstable positive feedback system. This bit can be configured automatically using the MRHD and MAHD motion instructions.

Test Marker

Runs the Marker test, which ensures that the encoder A, B, and Z channels are connected correctly and phased properly for marker detection. When the test is initiated, you must manually move the axis one revolution for the system to detect the marker. If the marker is not detected, check the encoder wiring and try again.

Test Feedback

Runs the Feedback Test, which checks and, if necessary, reconfigures the Feedback Polarity setting. When the test is initiated, you must manually move the axis one revolution for the system to detect the marker. If the marker is not detected, check the encoder wiring and try again.

Test Output & Feedback

Runs the Output & Feedback Test, which checks and, if necessary, reconfigures both the polarity of encoder feedback (the Feedback Polarity setting) and the polarity of the servo output to the drive (the Output Polarity setting), for an axis configured for Servo operation in the General tab of this dialog box.

Note: Executing any test operation automatically saves all changes to axis properties.

Hookup Tab Overview - AXIS_SERVO_DRIVE

Use this tab to configure and initiate axis hookup and marker test sequences for an axis of the type AXIS_SERVO_DRIVE.

When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.

Test Increment

Specifies the amount of distance traversed by the axis when executing the Command & Feedback test. The default value is set to approximately a quarter of a revolution of the motor in position units.

Drive Polarity

The polarity of the servo loop of the drive, set by executing the Command & Feedback Test:

- Positive
- Negative

Note: Proper wiring guarantees that the servo loop is closed with negative feedback. However there is no guarantee that the servo drive has the same sense of forward direction as the user for a given application. Negative Polarity inverts the polarity of

both the command position and actual position data of the servo drive. Thus, selecting either Positive or Negative Drive Polarity makes it possible to configure the positive direction sense of the drive to agree with that of the user. This attribute can be configured automatically using the MRHD and MAHD motion instructions.

WARNING

Modifying polarity values, automatically input by running the Command & Feedback Test, can cause a runaway condition.

Test Marker

Runs the Marker test, which ensures that the encoder A, B, and Z channels are connected correctly and phased properly for marker detection. When the test is initiated, you must manually move the axis one revolution for the system to detect the marker. If the marker is not detected, check the encoder wiring and try again.

Test Feedback

Runs the Feedback Test, which checks and, if necessary, reconfigures the Feedback Polarity setting. When the test is initiated, you must manually move the axis one revolution for the system to detect the marker. If the marker is not detected, check the encoder wiring and try again.


Test Output & Feedback

Runs the Output & Feedback Test, which checks and, if necessary, reconfigures both the polarity of encoder feedback (the Feedback Polarity setting) and the polarity of the servo output to the drive (the Output Polarity setting), for an axis configured for Servo operation in the General tab of this dialog box.

Note: Executing any test operation automatically saves all changes to axis properties.

Tune Tab - AXIS_SERVO, AXIS_SERVO_DRIVE

Use this tab to configure and initiate the axis tuning sequence for an axis of the types AXIS_SERVO or AXIS_SERVO_DRIVE.



Travel Limit

Specifies a limit to the excursion of the axis during the tune test. If the servo module determines that the axis will not be able to complete the tuning process before exceeding the tuning travel limit, it will terminate the tuning profile and report that this limit was exceeded.

Speed

Determines the maximum speed for the tune process. This value should be set to the desired maximum operating speed of the motor (in engineering units) prior to running the tune test.

Torque

The maximum torque of the tune test. This attribute should be set to the desired maximum safe torque level prior to running the tune test. The default value is 100%, which yields the most accurate measure of the acceleration and deceleration capabilities of the system.

Note: In some cases a lower tuning torque limit value may be desirable to limit the stress on the mechanics during the tuning procedure. In this case the acceleration and deceleration capabilities of the system are extrapolated based on the ratio of

the tuning torque to the maximum torque output of the system. Extrapolation error increases as the Tuning Torque value decreases.

Direction

The direction of the tuning motion profile. Negative indicates the reverse direction; positive indicates the forward direction.

Damping Factor

Specifies the dynamic response of the servo axis. The default is set to 0.8. When gains are tuned using a small damping factor, a step response test performed on the axis may generate uncontrolled oscillation. The gains generated using a larger damping factor would produce a system step response that has no overshoot and is stable, but may be sluggish in response to changes.

Note: The tuning procedure uses the Damping Factor that is set in this field. However, when the controller recalculates certain attributes in response to a Motor Catalog Number change (on the Motor/Feedback tab), the controller uses the default Damping Factor value of 0.8, and not a different value set in this field.

Tune

Select the gains to be determined by the tuning test:

- Position Error Integrator
- Velocity Feedforward
- Output Filter
- Velocity Error Integrator
- Acceleration Feedforward

Start Tuning

Click on this button to begin the tuning test. If the tuning process completes successfully the following attributes will be set.


On this tab:	These attributes are set:
Gains tab	Velocity Feedforward Gain (if checked under Tune, above) Acceleration Feedforward Gain (if checked under Tune, above) Position Proportional Gain Position Integral Gain (if checked under Tune, above) Velocity Proportional Gain Velocity Integral Gain (if checked under Tune, above)
Dynamics tab	Maximum Velocity Maximum Acceleration Maximum Deceleration
Output tab	Torque Scaling Velocity Scaling (AXIS_SERVO only) Low Pass Output Filter (see Note, below)
Limits	Position Error Tolerance

The Tune Bandwidth dialog opens for Servo drives, where you can "tweak" bandwidth values.

Note: During tuning, if the controller detects a high degree of tuning inertia, it enables the Low Pass Output Filter and calculates and sets a value for Low Pass Output Filter Bandwidth.

Executing a Tune operation automatically saves all changes to axis properties.

WARNING



This tuning procedure may cause axis motion with the controller in program mode.

Dynamics Tab

Use this tab to view or edit the dynamics related parameters for an axis of the type AXIS_SERVO or AXIS_SERVO_DRIVE configured for

Servo operations in the General tab of this dialog box, or AXIS_VIRTUAL.



IMPORTANT

The parameters on this tab can be edited in either of two ways:

- edit on this tab by typing your parameter changes and then clicking on OK or Apply to save your edits
- edit in the Manual Tune dialog: click on the Manual Tune button to open the Manual Tune dialog to this tab and use the spin controls to edit parameter settings. Your changes are saved the moment a spin control changes any parameter value.

Note: The parameters on this tab become read-only and cannot be edited when the controller is online if the controller is set to Hard Run mode, or if a Feedback On condition exists.

When RSLogix 5000 is offline, the following parameters can be edited and the program saved to disk using either the Save command or by clicking on the Apply button. You must re-download the edited program to the controller before it can be run.

Maximum Velocity

The steady-state speed of the axis, it is initially set to Tuning Speed by the tuning process. This value is typically set to about 90% of the

maximum speed rating of the motor. This provides sufficient “head-room” for the axis to operate at all times within the speed limitations of the motor. Any change in value, caused by manually changing the spin control, is instantaneously sent to the controller.

Maximum Acceleration

The maximum acceleration rate of the axis, in Position Units/second, it is initially set to about 85% of the measured tuning acceleration rate by the tuning process. If set manually, this value should typically be set to about 85% of the maximum acceleration rate of the axis. This provides sufficient “

head-room” for the axis to operate at all times within the acceleration limits of the drive and motor. Any change in value, caused by manually changing the spin control, is instantaneously sent to the controller.

Maximum Deceleration

The maximum deceleration rate of the axis, in Position Units/second, it is initially set to about 85% of the measured tuning deceleration rate by the tuning process. If set manually, this value should typically be set to about 85% of the maximum deceleration rate of the axis. This provides sufficient “head-room” for the axis to operate at all times within the deceleration limits of the drive and motor. Any change in value, caused by manually changing the spin control, is instantaneously sent to the controller.

Program Stop Action

Select how a specific axis will stop when the processor undergoes a mode change, or when an explicit Motion Group Programmed Stop (MGPS) instruction is executed:

- **Fast Disable:** The axis is decelerated to a stop using the current configured value for maximum deceleration. Servo action is maintained until the axis motion has stopped at which time the axis is disabled (i.e., Drive Enable is disabled, and Servo Action is disabled).
- **Fast Shutdown:** The axis is decelerated to a stop using the current configured value for maximum deceleration. Once the axis motion is stopped, the axis is placed in the shutdown state (i.e., Drive Enable is disabled, Servo Action is disabled, and the OK contact is opened). To recover from this state, a reset instruction must be executed.
- **Fast Stop:** The axis is decelerated to a stop using the current configured value for maximum deceleration. Servo action is maintained after the axis motion has stopped. This mode is useful for gravity or loaded systems, where servo control is needed at all times.
- **Hard Disable:** The axis is immediately disabled (i.e. Drive Enable is disabled, Servo Action is disabled, but the OK contact is left closed). Unless the drive is configured to provide some form of dynamic braking, this results in the axis coasting to a stop.
- **Hard Shutdown:** The axis is immediately placed in the shutdown state. Unless the drive is configured to provide some form of dynamic braking, this results in the axis coasting to a stop. To recover from this state, a reset instruction must be executed.

Manual Tune

Click on this button to open the Dynamics tab of the Manual Tune dialog for online editing of the Maximum Velocity, Maximum Acceleration, and Maximum Deceleration parameters.


Note: The Manual Tune button is disabled when RSLogix 5000 is in Wizard mode, and when offline edits to the above parameters have not yet been saved or applied.

Gains Tab - AXIS_SERVO

Use this tab to perform the following offline functions:

- adjust, or “tweak” gain values that have been automatically set by the tuning process (in the Tune tab of this dialog)
- manually configure gains for the velocity and position loops

for an axis of the type `AXIS_SERVO`, which has been configured for Servo operations (set in the General tab of this dialog box), with Position Loop Configuration.



The drive module uses a nested digital servo control loop consisting of a position loop with proportional, integral and feed-forward gains around an optional digitally synthesized inner velocity loop. The parameters on this tab can be edited in either of two ways:

- edit on this tab by typing your parameter changes and then clicking on OK or Apply to save your edits
- edit in the Manual Tune dialog: click on the Manual Tune button to open the Manual Tune dialog to this tab and use the spin controls to edit parameter settings. Your changes are saved the moment a spin control changes any parameter value.

Note: The parameters on this tab become read-only and cannot be edited when the controller is online if the controller is set to Hard Run mode, or if a Feedback On condition exists.

When RSLogix 5000 is offline, the following parameters can be edited and the program saved to disk using either the Save command or by clicking on the Apply button. You must re-download the edited program to the controller before it can be run.

Velocity Feedforward

Velocity Feedforward Gain scales the current Command Velocity by the Velocity Feedforward Gain and adds it as an offset to the Velocity Command. Hence, the Velocity Feedforward Gain allows the following error of the servo system to be reduced to nearly zero when running at a constant speed. This is important in applications such as electronic gearing, position camming, and synchronization applications, where it is necessary that the actual axis position not significantly lag behind the commanded position at any time. The optimal value for Velocity Feedforward Gain is 100%, theoretically. In reality, however, the value may need to be tweaked to accommodate velocity loops with non-infinite loop gain and other application considerations.

Acceleration Feedforward

Acceleration Feedforward Gain scales the current Command Acceleration by the Acceleration Feedforward Gain and adds it as an offset to the Servo Output generated by the servo loop. With this done, the servo loops do not need to generate much of a contribution to the Servo Output, hence the Position and/or Velocity Error values are significantly reduced. Hence, when used in conjunction with the Velocity Feedforward Gain, the Acceleration Feedforward Gain allows the following error of the servo system during the acceleration and deceleration phases of motion to be reduced to nearly zero. This is important in applications such as electronic gearing, position camming, and synchronization applications, where it is necessary that the actual axis position not significantly lag behind the commanded position at any time. The optimal value for Acceleration Feedforward is 100%, theoretically. In reality, however, the value may need to be tweaked to accommodate velocity loops with non-infinite loop gain and other application considerations.

Note: Acceleration Feedforward Gain is not applicable for applications employing velocity loop servo drives. Such systems would require the acceleration feedforward functionality to be located in the drive itself.

Proportional (Position) Gain

Position Error is multiplied by the Position Loop Proportional Gain, or Pos P Gain, to produce a component to the Velocity Command that ultimately attempts to correct for the position error. Too little Pos P Gain results in excessively compliant, or mushy, axis behavior. Too large a Pos P Gain, on the other hand, can result in axis oscillation due to classical servo instability.

To set the gain manually, you must first set the appropriate output scaling factor (either the Velocity Scaling factor or Torque Scaling factor) in the Output tab of this dialog. Your selection of External Drive Configuration type – either Torque or Velocity – in the Servo tab of this dialog will determine which scaling factor you must configure before manually setting gains.

If you know the desired loop gain in inches per minute per mil or millimeters per minute per mil, use the following formula to calculate the corresponding P gain:

$$\text{Pos P Gain} = 16.667 * \text{Desired Loop Gain (IPM/mil)}$$

If you know the desired unity gain bandwidth of the position servo in Hertz, use the following formula to calculate the corresponding P gain:

$$\text{Pos P Gain} = \text{Bandwidth (Hertz)} / 6.28$$

The typical value for the Position Proportional Gain is ~100 Sec-1.

Integral (Position) Gain

The Integral (i.e., summation) of Position Error is multiplied by the Position Loop Integral Gain, or Pos I Gain, to produce a component to the Velocity Command that ultimately attempts to correct for the position error. Pos I Gain improves the steady-state positioning performance of the system. Increasing the integral gain generally increases the ultimate positioning accuracy of the system. Excessive integral gain, however, results in system instability.

In certain cases, Pos I Gain control is disabled. One such case is when the servo output to the axis' drive is saturated. Continuing integral control behavior in this case would only exacerbate the situation. When the Integrator Hold parameter is set to Enabled, the servo loop automatically disables the integrator during commanded motion.

While the Pos I Gain, if employed, is typically established by the automatic servo tuning procedure (in the Tuning tab of this dialog), the Pos I Gain value may also be set manually. Before doing this it must be stressed that the Output Scaling factor for the axis must be established for the drive system. Once this is done, the Pos I Gain can be computed based on the current or computed value for the Pos P Gain using the following formula:

$$\text{Pos I Gain} = .025 * 0.001 \text{ Sec/mSec} * (\text{Pos P Gain})^2$$

Assuming a Pos P Gain value of 100 Sec-1 this results in a Pos I Gain value of 2.5 ~0.1 mSec-1 - Sec-1.

Proportional (Velocity) Gain

Note: This parameter is enabled only for external drives configured for Torque loop operation in the Servo tab of this dialog box.

Velocity Error is multiplied by the Velocity Proportional Gain to produce a component to the Servo Output or Torque Command that ultimately attempts to correct for the velocity error, creating a damping effect. Thus, increasing the Velocity Proportional Gain results in smoother motion, enhanced acceleration, reduced overshoot, and greater system stability. However, too much Velocity Proportional Gain leads to high frequency instability and resonance effects.

The typical value for the Velocity Proportional Gain is ~250 mSec-1.

Integral (Velocity) Gain

Note: This parameter is enabled only for external drives configured for Torque loop operation in the Servo tab of this dialog box.

At every servo update the current Velocity Error is accumulated in a variable called the Velocity Integral Error. This value is multiplied by the Velocity Integral Gain to produce a component to the Servo Output or Torque Command that attempts to correct for the velocity error. The higher the Vel I Gain value, the faster the axis is driven to the zero Velocity Error condition. Unfortunately, I Gain control is intrinsically unstable. Too much I Gain results in axis oscillation and servo instability.

In certain cases, Vel I Gain control is disabled. One such case is when the servo output to the axis' drive is saturated. Continuing integral control behavior in this case would only exacerbate the situation. When the Integrator Hold parameter is set to Enabled, the servo loop automatically disables the integrator during commanded motion.

Due to the destabilizing nature of Integral Gain, it is recommended that Position Integral Gain and Velocity Integral Gain be considered mutually exclusive. If Integral Gain is needed for the application, use one or the other, but not both. In general, where static positioning accuracy is required, Position Integral Gain is the better choice.

The typical value for the Velocity Proportional Gain is ~15 mSec-2.

Integrator Hold

If the Integrator Hold parameter is set to:

- Enabled, the servo loop temporarily disables any enabled position or velocity integrators while the command position is changing. This feature is used by point-to-point moves to minimize the integrator wind-up during motion.
- Disabled, all active position or velocity integrators are always enabled.

Manual Tune

Click on this button to access the Gains tab of the Manual Tune dialog for online editing.


Note: The Manual Tune button is disabled when RSLogix 5000 is in Wizard mode, and when you have not yet saved or applied your offline edits to the above parameters.

Gains Tab - AXIS_SERVO_DRIVE

Use this tab to perform the following offline functions:

- Adjust, or "tweak" gain values that have been automatically set by the tuning process (in the Tune tab of this dialog)
- Manually configure gains for the velocity and position loops

for an axis of the type AXIS_SERVO_DRIVE.



The drive module uses a nested digital servo control loop consisting of a position loop with proportional, integral and feed-forward gains around an optional digitally synthesized inner velocity loop. The specific design of this nested loop depends upon the Loop Configuration selected in the Drive tab of this dialog box. For a discussion, including a diagram, of a loop configuration, click on the following loop configuration types:

- Motor Position Servo Loop
- Auxiliary Position Servo Loop
- Dual Position Servo Loop
- Motor Dual Command Servo Loop
- Auxiliary Dual Command Servo Loop
- Velocity Servo Loop
- Torque Servo Loop

The parameters on this tab can be edited in either of two ways:

- edit on this tab by typing your parameter changes and then clicking on OK or Apply to save your edits
-
- edit in the Manual Tune dialog: click on the Manual Tune button to open the Manual Tune dialog to this tab and use the spin controls to edit parameter settings. Your changes are saved the moment a spin control changes any parameter value.

Note: The parameters on this tab become read-only and cannot be edited when the controller is online if the controller is set to Hard Run mode, or if a Feedback On condition exists.

When RSLogix 5000 is offline, the following parameters can be edited and the program saved to disk using either the Save command or by clicking on the Apply button. You must re-download the edited program to the controller before it can be run.

Velocity Feedforward

Velocity Feedforward Gain scales the current command velocity (derivative of command position) by the Velocity Feedforward Gain and adds it as an offset to the Velocity Command. Hence, the Velocity Feedforward Gain allows the following error of the servo system to be reduced to nearly zero when running at a constant speed. This is important in applications such as electronic gearing and synchronization applications, where it is necessary that the actual axis position not significantly lag behind the commanded position at any time. The optimal value for Velocity Feedforward Gain is 100%, theoretically. In reality, however, the value may need to be tweaked

to accommodate velocity loops with non-infinite loop gain and other application considerations.

Acceleration Feedforward

Acceleration Feedforward Gain scales the current Command Acceleration by the Acceleration Feedforward Gain and adds it as an offset to the Servo Output generated by the servo loop. With this done, the servo loops do not need to generate much of a contribution to the Servo Output, hence the Position and/or Velocity Error values are significantly reduced. Hence, when used in conjunction with the Velocity Feedforward Gain, the Acceleration Feedforward Gain allows the following error of the servo system during the acceleration and deceleration phases of motion to be reduced to nearly zero. This is important in applications such as electronic gearing and synchronization applications, where it is necessary that the actual axis position not significantly lag behind the commanded position at any time. The optimal value for Acceleration Feedforward is 100%, theoretically. In reality, however, the value may need to be tweaked to accommodate velocity loops with non-infinite loop gain and other application considerations.

Note: Acceleration Feedforward Gain is not applicable for applications employing velocity loop servo drives. Such systems would require the acceleration feedforward functionality to be located in the drive itself.

This value is also not applicable for Ultra3000 drives.

Proportional (Position) Gain

Position Error is multiplied by the Position Loop Proportional Gain, or Pos P Gain, to produce a component to the Velocity Command that ultimately attempts to correct for the position error. Too little Pos P Gain results in excessively compliant, or mushy, axis behavior. Too large a Pos P Gain, on the other hand, can result in axis oscillation due to classical servo instability.

Note: To set the gain manually, you must first set the Torque scaling in the Output tab of this dialog.

If you know the desired loop gain in inches per minute per mil or millimeters per minute per mil, use the following formula to calculate the corresponding P gain:

$$\text{Pos P Gain} = 16.667 * \text{Desired Loop Gain (IPM/mil)}$$

If you know the desired unity gain bandwidth of the position servo in Hertz, use the following formula to calculate the corresponding P gain:

$$\text{Pos P Gain} = \text{Bandwidth (Hertz)} / 6.28$$

The typical value for the Position Proportional Gain is ~100 Sec⁻¹.

Integral (Position) Gain

The Integral (i.e., summation) of Position Error is multiplied by the Position Loop Integral Gain, or Pos I Gain, to produce a component to the Velocity Command that ultimately attempts to correct for the position error. Pos I Gain improves the steady-state positioning performance of the system. Increasing the integral gain generally increases the ultimate positioning accuracy of the system. Excessive integral gain, however, results in system instability.

In certain cases, Pos I Gain control is disabled. One such case is when the servo output to the axis' drive is saturated. Continuing integral control behavior in this case would only exacerbate the situation. When the Integrator Hold parameter is set to Enabled, the servo loop automatically disables the integrator during commanded motion.

While the Pos I Gain, if employed, is typically established by the automatic servo tuning procedure (in the Tuning tab of this dialog), the Pos I Gain value may also be set manually. Before doing this it must be stressed that the Torque Scaling factor for the axis must be established for the drive system (in the Output tab of this dialog box). Once this is done, the Pos I Gain can be computed based on the current or computed value for the Pos P Gain using the following formula:

$$\text{Pos I Gain} = .025 * 0.001 \text{ Sec/mSec} * (\text{Pos P Gain})^2$$

Assuming a Pos P Gain value of 100 Sec⁻¹ this results in a Pos I Gain value of 2.5 ~0.1 mSec⁻¹ - Sec⁻¹.

Proportional (Velocity) Gain

Note: This parameter is enabled only for external drives configured for Torque loop operation in the Servo tab of this dialog box.

Velocity Error is multiplied by the Velocity Proportional Gain to produce a component to the Torque Command that ultimately attempts to correct for the velocity error, creating a damping effect. Thus, increasing the Velocity Proportional Gain results in smoother motion, enhanced acceleration, reduced overshoot, and greater

system stability. However, too much Velocity Proportional Gain leads to high frequency instability and resonance effects.

If you know the desired unity gain bandwidth of the velocity servo in Hertz, you can use the following formula to calculate the corresponding P gain.

$$\text{Vel P Gain} = \text{Bandwidth (Hertz)} / 6.28$$

The typical value for the Velocity Proportional Gain is ~250 mSec-1.

Integral (Velocity) Gain

Note: This parameter is enabled only for external drives configured for Torque loop operation in the Servo tab of this dialog box.

At every servo update the current Velocity Error is accumulated in a variable called the Velocity Integral Error. This value is multiplied by the Velocity Integral Gain to produce a component to the Torque Command that attempts to correct for the velocity error. The higher the Vel I Gain value, the faster the axis is driven to the zero Velocity Error condition. Unfortunately, I Gain control is intrinsically unstable. Too much I Gain results in axis oscillation and servo instability.

In certain cases, Vel I Gain control is disabled. One such case is when the servo output to the axis' drive is saturated. Continuing integral control behavior in this case would only exacerbate the situation. When the Integrator Hold parameter is set to Enabled, the servo loop automatically disables the integrator during commanded motion.

Due to the destabilizing nature of Integral Gain, it is recommended that Position Integral Gain and Velocity Integral Gain be considered mutually exclusive. If Integral Gain is needed for the application, use one or the other, but not both. In general, where static positioning accuracy is required, Position Integral Gain is the better choice.

While the Vel I Gain, if employed, is typically established by the automatic servo tuning procedure (in the Tune tab of this dialog box), the Pos I Gain value may also be set manually. Before doing this it must be stressed that the Torque Scaling factor for the axis must be established for the drive system, in the Output tab of this dialog box. Once this is done the Vel I Gain can be computed based on the current or computed value for the Vel P Gain using the following formula:

$$\text{Vel I Gain} = 0.25 * 0.001 \text{ Sec/mSec} * (\text{Vel P Gain})^2$$

The typical value for the Velocity Proportional Gain is ~15 mSec-2.

Integrator Hold

If the Integrator Hold parameter is set to:

- Enabled, the servo loop temporarily disables any enabled position or velocity integrators while the command position is changing. This feature is used by point-to-point moves to minimize the integrator wind-up during motion.
- Disabled, all active position or velocity integrators are always enabled.

Set Custom Gains

Click on this button to open the Custom Gain Attributes dialog.

Manual Tune

Click on this button to access the Gains tab of the Manual Tune dialog for online editing.


Note: The Manual Tune button is disabled when RSLogix 5000 is in Wizard mode, and when you have not yet saved or applied your offline edits to the above parameters.

Output Tab - SERVO_AXIS

Use this dialog for offline configuration of:

- scaling values, which are used to generate gains, and
- the servo's low-pass digital output filter

for an axis of the type AXIS_SERVO configured as a Servo drive in the General tab of this dialog.



The parameters on this tab can be edited in either of two ways:

- edit on this tab by typing your parameter changes and then clicking on OK or Apply to save your edits
- edit in the Manual Tune dialog: click on the Manual Tune button to open the Manual Tune dialog to this tab and use the spin controls to edit parameter settings. Your changes are saved the moment a spin control changes any parameter value.

Note: The parameters on this tab become read-only and cannot be edited when the controller is online if the controller is set to Hard Run mode, or if a Feedback On condition exists.

When RSLogix 5000 is offline, the following parameters can be edited and the program saved to disk using either the Save command or by clicking on the Apply button. You must re-download the edited program to the controller before it can be run.

Velocity Scaling

The Velocity Scaling attribute is used to convert the output of the servo loop into equivalent voltage to an external velocity servo drive. This has the effect of “normalizing” the units of the servo loop gain parameters so that their values are not affected by variations in feedback resolution, drive scaling, or mechanical gear ratios. The Velocity Scaling value is typically established by servo’s automatic

tuning procedure but these values can be calculated, if necessary, using the following guidelines.

If the axis is configured for a velocity external servo drive (in the Servo tab of this dialog), the software velocity loop in the servo module is disabled. In this case the Velocity Scaling value can be calculated by the following formula:

$$\text{Velocity Scaling} = 100\% / (\text{Speed @ 100\%})$$

For example, if this axis is using position units of motor revolutions (revs), and the servo drive is scaled such that with an input of 100% (e.g. 10 Volts) the motor goes 5,000 RPM (or 83.3 RPS), the Velocity Scaling attribute value would be calculated as:

$$\text{Velocity Scaling} = 100\% / (83.3 \text{ RPS}) = 1.2\% / \text{Revs Per Second}$$

Torque Scaling

The Torque Scaling attribute is used to convert the acceleration of the servo loop into equivalent % rated torque to the motor. This has the effect of “normalizing” the units of the servo loops gain parameters so that their values are not affected by variations in feedback resolution, drive scaling, motor and load inertia, and mechanical gear ratios. The Torque Scaling value is typically established by the controller’s automatic tuning procedure but the value can be manually calculated, if necessary, using the following guidelines:

$$\text{Torque Scaling} = 100\% \text{ Rated Torque} / (\text{Acceleration @ 100\% Rated Torque})$$

For example, if this axis is using position units of motor revolutions (revs), with 100% rated torque applied to the motor, if the motor accelerates at a rate of 3000 Revs/Sec², the Torque Scaling attribute value would be calculated as shown below:

$$\text{Torque Scaling} = 100\% \text{ Rated} / (3000 \text{ RPS}^2) = 0.0333\% \text{ Rated} / \text{Revs Per Second}^2$$

Note: If the Torque Scaling value does not reflect the true torque to acceleration characteristic of the system, the gains also does not reflect the true performance of the system.

Enable Low-pass Output Filter

Select this to enable the servo’s low-pass digital output filter. De-select this to disable this filter.

Note: During tuning, if the controller detects a high degree of tuning inertia, it enables the Low Pass Output Filter and calculates and sets a value for Low Pass Output Filter Bandwidth.

Low-pass Output Filter Bandwidth

With Enable Low-pass Output Filter selected, this value sets the bandwidth, in Hertz, of the servo's low-pass digital output filter. Use this output filter to filter out high frequency variation of the servo module output to the drive. All output from the servo module greater than the Filter Bandwidth setting will be filtered-out, and not sent to the drive.

If the Low-pass Output Filter Bandwidth value is set to zero, the low-pass output filter is disabled. The lower the Filter Bandwidth value, the greater the attenuation of these high frequency components of the output signal. Because the low-pass filter adds lag to the servo loop, which pushes the system towards instability, decreasing the Filter Bandwidth value usually requires lowering the Position or Velocity Proportional Gain settings to maintain stability. The output filter is particularly useful in high inertia applications where resonance behavior can severely restrict the maximum bandwidth capability of the servo loop.

Manual Tune

Click on this button to access the Gains tab of the Manual Tune dialog for online editing.


Note: The Manual Tune button is disabled when RSLogix 5000 is in Wizard mode, and when you have not yet saved or applied your offline edits to the above parameters.

Output Tab Overview - AXIS_SERVO_DRIVE

Use this dialog box to make the following offline configurations:

- set the torque scaling value, which is used to generate gains
- enable and configure the Notch Filter
- enable and configure servo's low-pass digital output filter

for an axis of the type AXIS_SERVO_DRIVE, configured as a Servo drive in the General tab of this dialog.



The parameters on this tab can be edited in either of two ways:

- edit on this tab by typing your parameter changes and then clicking on OK or Apply to save your edits
- edit in the Manual Tune dialog: click on the Manual Tune button to open the Manual Tune dialog to this tab and use the spin controls to edit parameter settings. Your changes are saved the moment a spin control changes any parameter value.

Note: The parameters on this tab become read-only and cannot be edited when the controller is online if the controller is set to Hard Run mode, or if a Feedback On condition exists.

When RSLogix 5000 is offline, the following parameters can be edited and the program saved to disk using either the Save command or by clicking on the Apply button. You must re-download the edited program to the controller before it can be run.

Torque Scaling

The Torque Scaling attribute is used to convert the acceleration of the servo loop into equivalent % rated torque to the motor. This has the effect of "normalizing" the units of the servo loops gain parameters so that their values are not affected by variations in feedback resolution, drive scaling, motor and load inertia, and mechanical gear ratios. The Torque Scaling value is typically established by the controller's automatic tuning procedure but the value can be manually calculated, if necessary, using the following guidelines:

$$\text{Torque Scaling} = 100\% \text{ Rated Torque} / (\text{Acceleration @ } 100\% \text{ Rated Torque})$$

For example, if this axis is using position units of motor revolutions (revs), with 100% rated torque applied to the motor, if the motor accelerates at a rate of 3000 Revs/Sec², the Torque Scaling attribute value would be calculated as shown below:

$$\text{Torque Scaling} = 100\% \text{ Rated} / (3000 \text{ RPS}^2) = 0.0333\% \text{ Rated/ Revs Per Second}^2$$

Note: If the Torque Scaling value does not reflect the true torque to acceleration characteristic of the system, the gains will also not reflect the true performance of the system.

Enable Notch Filter

Select this to enable the drive's notch filter. De-select this to disable this filter.

Notch Filter

With Enable Notch Filter selected, this value sets the center frequency of the drive's digital notch filter. If the Notch Filter value is set to zero, the notch filter is disabled.

Currently implemented as a 2nd order digital filter with a fixed Q, the Notch Filter provides approximately 40DB of output attenuation at the Notch Filter frequency. This output notch filter is particularly useful in attenuating mechanical resonance phenomena. The output filter is particularly useful in high inertia applications where mechanical resonance behavior can severely restrict the maximum bandwidth capability of the servo loop.

Note: This value is not applicable for Ultra3000 drives.

Enable Low-pass Output Filter

Select this to enable the servo's low-pass digital output filter. De-select this to disable this filter.

Note: During tuning, if the controller detects a high degree of tuning inertia, the controller enables the Low Pass Output Filter and calculates and sets a value for Low Pass Output Filter Bandwidth.

Low-pass Output Filter Bandwidth

With Enable Low-pass Output Filter selected, this value sets the bandwidth, in Hertz, of the servo's low-pass digital output filter. Use this output filter to filter out high frequency variation of the servo module output to the drive. All output from the servo module greater than the Filter Bandwidth setting will be filtered-out, and not sent to the drive.

If the Low-pass Output Filter Bandwidth value is set to zero, the low-pass output filter is disabled. The lower the Filter Bandwidth value, the greater the attenuation of these high frequency components of the output signal. Because the low-pass filter adds lag to the servo loop, which pushes the system towards instability, decreasing the Filter Bandwidth value usually requires lowering the Position or Velocity Proportional Gain settings to maintain stability. The output filter is particularly useful in high inertia applications where resonance behavior can severely restrict the maximum bandwidth capability of the servo loop.

Manual Tune

Click on this button to open the Dynamics tab of the Manual Tune dialog for online editing of the Maximum Velocity, Maximum Acceleration, and Maximum Deceleration parameters.


Note: The Manual Tune button is disabled when RSLogix 5000 is in Wizard mode, and when offline edits to the above parameters have not yet been saved or applied.

Limits Tab - AXIS_SERVO

Use this tab to make the following offline configurations:

- enable and set maximum positive and negative software travel limits, and
- configure both Position Error Tolerance and Position Lock Tolerance, and
- set the servo drive's Output Limit

for an axis of the type AXIS_SERVO configured as a Servo drive in the General tab of this dialog.



The parameters on this tab can be edited in either of two ways:

- edit on this tab by typing your parameter changes and then clicking on OK or Apply to save your edits
- edit in the Manual Tune dialog: click on the Manual Tune button to open the Manual Tune dialog to this tab and use the spin controls to edit parameter settings. Your changes are saved the moment a spin control changes any parameter value.

Note: The parameters on this tab become read-only and cannot be edited when the controller is online if the controller is set to Hard Run mode, or if a Feedback On condition exists.

When RSLogix 5000 is offline, the following parameters can be edited and the program saved to disk using either the Save command or by clicking on the Apply button. You must re-download the edited program to the controller before it can be run.

Soft Travel Limits

Enables software overtravel checking for an axis when Positioning Mode is set to Linear (in the Conversion tab of this dialog). If an axis is configured for software overtravel limits and if that axis passes beyond these maximum travel limits (positive or negative), a software overtravel fault is issued. The response to this fault is specified by the Soft Overtravel setting (in the Fault Actions tab of this dialog). Software overtravel limits are disabled during the tuning process.

Maximum Positive

Type the maximum positive position to be used for software overtravel checking, in position units.

Note: The Maximum Positive limit must always be greater than the Maximum Negative limit.

Maximum Negative

Type the maximum negative position to be used for software overtravel checking, in position units.

Note: The Maximum Negative limit must always be less than the Maximum Positive limit.

Position Error Tolerance

Specifies how much position error the servo will tolerate before issuing a position error fault. This value is interpreted as a +/- quantity.

For example, setting Position Error Tolerance to 0.75 position units means that a position error fault will be generated whenever the position error of the axis is greater than 0.75 or less than -0.75 position units, as shown here:

Note: This value is set to twice the following error at maximum speed based on the measured response of the axis, during the autotuning process. In most applications, this value provides reasonable protection in case of an axis fault or stall condition without nuisance faults during normal operation. If you need to change the calculated position error tolerance value, the recommended setting is 150% to 200% of the position error while the axis is running at its maximum speed.

Position Lock Tolerance

Specifies the maximum position error the servo module will accept in order to indicate the Position Lock status bit is set. This is useful in determining when the desired end position is reached for position moves. This value is interpreted as a +/- quantity.

For example, specifying a lock tolerance of 0.01 provides a minimum positioning accuracy of +/- 0.01 position units, as shown here:

Output Limit

Provides a method of limiting the maximum servo output voltage of a physical axis to a specified level. The servo output for the axis as a function of position servo error, both with and without servo output limiting, is shown below.

The servo output limit may be used as a software current or torque limit if you are using a servo drive in torque loop mode. The percentage of the drive's maximum current that the servo controller will ever command is equal to the specified servo output limit. For example, if the drive is capable of 30 Amps of current for a 10Volt input, setting the servo output limit to 5V limits the maximum drive current to 15 Amps.

The servo output limit may also be used if the drive cannot accept the full ± 10 Volt range of the servo output. In this case, the servo output limit value effectively limits the maximum command sent to the amplifier. For example, if the drive can only accept command signals up to ± 7.5 Volts, set the servo output limit value to 7.5 volts.

Manual Tune

Click on this button to open the Dynamics tab of the Manual Tune dialog for online editing of the Maximum Velocity, Maximum Acceleration, and Maximum Deceleration parameters.

Note: The Manual Tune button is disabled when RSLogix 5000 is in Wizard mode, and when offline edits to the above parameters have not yet been saved or applied.

Limits Tab - AXIS_SERVO_DRIVE

Use this tab to make the following offline configurations:

- enable and set maximum positive and negative software travel limits, and
- configure both Position Error Tolerance and Position Lock Tolerance,

for an axis of the type AXIS_SERVO_DRIVE configured as a Servo drive in the General tab of this dialog.

The parameters on this tab can be edited in either of two ways:

- edit on this tab by typing your parameter changes and then clicking on OK or Apply to save your edits
- edit in the Manual Tune dialog: click on the Manual Tune button to open the Manual Tune dialog to this tab and use the spin controls to edit parameter settings. Your changes are saved the moment a spin control changes any parameter value.

Note: The parameters on this tab become read-only and cannot be edited when the controller is online if the controller is set to Hard Run mode, or if a Feedback On condition exists.

When RSLogix 5000 is offline, the following parameters can be edited and the program saved to disk using either the Save command or by clicking on the Apply button. You must re-download the edited program to the controller before it can be run.

Hard Travel Limits

Enables a periodic test that monitors the current state of the positive and negative overtravel limit switch inputs, when Positioning Mode is set to Linear (in the Conversion tab of this dialog). If an axis is configured for hardware overtravel checking and if that axis passes beyond a positive or negative overtravel limit switch, a Positive Hard Overtravel Fault or Negative Hard Overtravel Fault is issued. The response to this fault is specified by the Hard Overtravel setting (in the Fault Actions tab of this dialog).

Soft Travel Limits

Enables software overtravel checking for an axis when Positioning Mode is set to Linear (in the Conversion tab of this dialog). If an axis is configured for software overtravel limits and if that axis passes beyond these maximum travel limits (positive or negative), a software overtravel fault is issued. The response to this fault is specified by the Soft Overtravel setting (in the Fault Actions tab of this dialog). Software overtravel limits are disabled during the tuning process.

Maximum Positive

Type the maximum positive position to be used for software overtravel checking, in position units.

Note: The Maximum Positive limit must always be greater than the Maximum Negative limit.

Maximum Negative

Type the maximum negative position to be used for software overtravel checking, in position units.

Note: The Maximum Negative limit must always be less than the Maximum Positive limit.

Position Error Tolerance

Specifies how much position error the servo will tolerate before issuing a position error fault. This value is interpreted as a +/- quantity.

For example, setting Position Error Tolerance to 0.75 position units means that a position error fault will be generated whenever the position error of the axis is greater than 0.75 or less than -0.75 position units, as shown here:

Note: This value is set to twice the following error at maximum speed based on the measured response of the axis, during the autotuning process. In most applications, this value provides reasonable protection in case of an axis fault or stall condition without nuisance faults during normal operation. If you need to change the calculated position error tolerance value, the recommended setting is 150% to 200% of the position error while the axis is running at its maximum speed.

Position Lock Tolerance

Specifies the maximum position error the servo module will accept in order to indicate the Position Lock status bit is set. This is useful in determining when the desired end position is reached for position moves. This value is interpreted as a +/- quantity.

For example, specifying a lock tolerance of 0.01 provides a minimum positioning accuracy of +/- 0.01 position units, as shown here:

Set Custom Limits

Click this button to open the Custom Limit Attributes dialog.

Manual Tune

Click on this button to open the Dynamics tab of the Manual Tune dialog for online editing of the Maximum Velocity, Maximum Acceleration, and Maximum Deceleration parameters.


Note: The Manual Tune button is disabled when RSLogix 5000 is in Wizard mode, and when offline edits to the above parameters have not yet been saved or applied.

Offset Tab - AXIS_SERVO

Use this tab to make offline adjustments to the following Servo Output values:

- Friction Compensation
- Velocity Offset
- Torque Offset
- Output Offset

for an axis of the type AXIS_SERVO configured as a Servo drive in the General tab of this dialog.



The parameters on this tab can be edited in either of two ways:

- edit on this tab by typing your parameter changes and then clicking on OK or Apply to save your edits

- edit in the Manual Tune dialog: click on the Manual Tune button to open the Manual Tune dialog to this tab and use the spin controls to edit parameter settings. Your changes are saved the moment a spin control changes any parameter value.

Note: The parameters on this tab become read-only and cannot be edited when the controller is online if the controller is set to Hard Run mode, or if a Feedback On condition exists.

When RSLogix 5000 is offline, the following parameters can be edited and the program saved to disk using either the Save command or by clicking on the Apply button. You must re-download the edited program to the controller before it can be run.

Friction Compensation

The percentage of output level added to a positive current Servo Output value, or subtracted from a negative current Servo Output value, for the purpose of moving an axis that is stuck in place due to static friction.

It is not unusual for an axis to have enough static friction – called “sticktion” – that, even with a significant position error, the axis refuses to budge. Friction Compensation is used to break “

sticktion” in the presence of a non-zero position error. This is done by adding, or subtracting, a percentage output level), called Friction Compensation to the Servo Output value.

The Friction Compensation value should be just less than the value that would break the “sticktion”

A larger value will cause the axis to “dither”, i.e. move rapidly back and forth about the commanded position.

Velocity Offset

Provides a dynamic velocity correction to the output of the position servo loop, in position units per second. Because the position servo loop output value is updated synchronously every Coarse Update Period, the Velocity Offset can be tied into custom outer control loop algorithms using Function Block programming.

Torque Offset

Provides a dynamic torque command correction to the output of the velocity servo loop, as a percentage of velocity servo loop output. Because velocity servo loop output is updated synchronously every

Coarse Update Period, the Torque Offset can be tied into custom outer control loop algorithms using Function Block programming.

Output Offset

Corrects the problem of axis “drift”, by adding a fixed voltage value (not to exceed ± 10 Volts) to the Servo Output value. Input a value to achieve near zero drive velocity when the uncompensated Servo Output value is zero.

When interfacing an external Servo Drive – especially for velocity servo drives, it is necessary to compensate for the effect of drive offset. Cumulative offsets of the servo module’s DAC output and the Servo Drive Input result in a situation where a zero commanded Servo Output value causes the axis to “drift”. If the drift is excessive, it can play havoc on the Hookup Diagnostic and Tuning procedures, as well as result in a steady-state non-zero position error when the servo loop is closed.

Manual Tune

Click on this button to open the Dynamics tab of the Manual Tune dialog for online editing of the Maximum Velocity, Maximum Acceleration, and Maximum Deceleration parameters.

Note: The Manual Tune button is disabled when RSLogix 5000 is in Wizard mode, and when offline edits to the above parameters have not yet been saved or applied.

Offset Tab - AXIS_SERVO_DRIVE

Use this tab to make offline adjustments to the following Servo Output values:

- Friction Compensation,
- Velocity Offset, and
- Torque Offset

for an axis of the type AXIS_SERVO_DRIVE configured as a Servo drive in the General tab of this dialog.

The parameters on this tab can be edited in either of two ways:

- edit on this tab by typing your parameter changes and then clicking on OK or Apply to save your edits
- edit in the Manual Tune dialog: click on the Manual Tune button to open the Manual Tune dialog to this tab and use the spin controls to edit parameter settings. Your changes are saved the moment a spin control changes any parameter value.

Note: The parameters on this tab become read-only and cannot be edited when the controller is online if the controller is set to Hard Run mode, or if a Feedback On condition exists.

When RSLogix 5000 is offline, the following parameters can be edited and the program saved to disk using either the Save command or by clicking on the Apply button. You must re-download the edited program to the controller before it can be run.

Friction Compensation

The percentage of output level added to a positive current Servo Output value, or subtracted from a negative current Servo Output value, for the purpose of moving an axis that is stuck in place due to static friction.

It is not unusual for an axis to have enough static friction – called "sticktion" – that, even with a significant position error, the axis refuses to budge. Friction Compensation is used to break "sticktion" in the presence of a non-zero position error. This is done by adding, or subtracting, a percentage output level), called Friction Compensation to the Servo Output value.

The Friction Compensation value should be just less than the value that would break the "sticktion". A larger value will cause the axis to "dither", i.e. move rapidly back and forth about the commanded position.

Velocity Offset

Provides a dynamic velocity correction to the output of the position servo loop, in position units per second. Because the position servo loop output value is updated synchronously every Coarse Update Period, the Velocity Offset can be tied into custom outer control loop algorithms using Function Block programming.

Torque Offset

Provides a dynamic torque command correction to the output of the velocity servo loop, as a percentage of velocity servo loop output.

Because velocity servo loop output is updated synchronously every Coarse Update Period, the Torque Offset can be tied into custom outer control loop algorithms using Function Block programming.

Manual Tune

Click on this button to open the Dynamics tab of the Manual Tune dialog for online editing of the Maximum Velocity, Maximum Acceleration, and Maximum Deceleration parameters.


Note: The Manual Tune button is disabled when RSLogix 5000 is in Wizard mode, and when offline edits to the above parameters have not yet been saved or applied.

Fault Actions Tab - AXIS_SERVO

Use this tab to specify the actions that will be taken in response to the following faults:

- Drive Fault
- Feedback Noise Fault
- Feedback Loss Fault
- Position Error Fault
- Soft Overtravel Fault

for an axis of the type AXIS_SERVO.



When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.

When multiple workstations connect to the same controller using RSLogix 5000 and invoke the Axis Wizard or Axis Properties dialog, the firmware allows only the first workstation to make any changes to axis attributes. The second workstation switches to a Read Only mode, indicated in the title bar, so that you may view the changes from that workstation, but not edit them.

Select one of the following fault actions for each fault type:

- **Shutdown** - If a fault action is set to Shutdown, then when the associated fault occurs, axis servo action is immediately disabled, the servo amplifier output is zeroed, and the appropriate drive enable output is deactivated. Furthermore, this fault action opens the OK contact associated with the servo module which can be used to open the E-stop string to the drive power supply. Shutdown is the most severe action to a fault and it is usually reserved for faults that could endanger the machine or the operator if power is not removed as quickly and completely as possible.
- **Disable Drive** - If a fault action is set to Disable Drive, then when the associated fault occurs, axis servo action is immediately disabled, the servo amplifier output is zeroed, and the appropriate drive enable output is deactivated.

- **Stop Motion** - If a fault action is set to Stop Motion, then when the associated fault occurs, the axis immediately starts decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo modules Drive Enable output. This is the gentlest stopping mechanism in response to a fault. It is usually used for less severe faults. After the stop command fault action has stopped the axis, no further motion can be generated until the fault is first cleared.
- **Status Only** - If a fault action is set to Status Only, then when the associated fault occurs, no action is taken. The application program must handle any motion faults. In general, this setting should only be used in applications where the standard fault actions are not appropriate.

WARNING

Selecting the wrong fault action for your application can cause a dangerous condition. Keep clear of moving machinery.

Drive Fault

Specifies the fault action to be taken when a drive fault condition is detected, for an axis with the Drive Fault Input enabled (in the Servo tab of this dialog) that is configured as Servo (in the General tab of this dialog). The available actions for this fault are Shutdown and Disable Drive.

Feedback Noise

Specifies the fault action to be taken when excessive feedback noise is detected. The available actions for this fault are Shutdown, Disable Drive, Stop Motion and Status Only.

Feedback Loss

Specifies the fault action to be taken when feedback loss condition is detected. The available actions for this fault are Shutdown, Disable Drive, Stop Motion and Status Only.

Position Error

Specifies the fault action to be taken when position error exceeds the position tolerance set for the axis, for an axis configured as Servo (in the General tab of this dialog). The available actions for this fault are Shutdown, Disable Drive, Stop Motion and Status Only.

Soft Overtravel


Specifies the fault action to be taken when a software overtravel error occurs, for an axis with Soft Travel Limits enabled and configured (in the Limits tab of this dialog) that is configured as Servo (in the General tab of this dialog). The available actions for this fault are Shutdown, Disable Drive, Stop Motion and Status Only.

Fault Actions Tab - AXIS_SERVO_DRIVE

Use this tab to specify the actions that will be taken in response to the following faults:

- Drive Thermal Fault
- Motor Thermal Fault
- Feedback Noise Fault
- Feedback Fault
- Position Error Fault
- Hard Overtravel Fault
- Soft Overtravel Fault

for an axis of the type `AXIS_SERVO_DRIVE`.



When a parameter transitions to a read-only state, any pending changes to parameter values are lost, and the parameter reverts to the most recently saved parameter value.

When multiple workstations connect to the same controller using RSLogix 5000 and invoke the Axis Wizard or Axis Properties dialog, the firmware allows only the first workstation to make any changes to axis attributes. The second workstation switches to a Read Only mode, indicated in the title bar, so that you may view the changes from that workstation, but not edit them.

Select one of the following fault actions for each fault type:

- **Shutdown** - If a fault action is set to Shutdown, then when the associated fault occurs, axis servo action is immediately disabled, the servo amplifier output is zeroed, and the appropriate drive enable output is deactivated. Furthermore, this fault action opens the OK contact associated with the servo module which can be used to open the E-stop string to the drive power supply. Shutdown is the most severe action to a fault and it is usually reserved for faults that could endanger the machine or the operator if power is not removed as quickly and completely as possible.
- **Disable Drive** - If a fault action is set to Disable Drive, then when the associated fault occurs, axis servo action is immediately disabled, the servo amplifier output is zeroed, and the appropriate drive enable output is deactivated.
- **Stop Motion** - If a fault action is set to Stop Motion, then when the associated fault occurs, the axis immediately starts decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo modules Drive Enable output. This is the gentlest stopping mechanism in response to a fault. It is usually used for less severe faults. After the stop command fault action has stopped the axis, no further motion can be generated until the fault is first cleared.
- **Status Only** - If a fault action is set to Status Only, then when the associated fault occurs, no action is taken. The application program must handle any motion faults. In general, this setting should only be used in applications where the standard fault actions are not appropriate.

WARNING

Selecting the wrong fault action for your application can cause a dangerous condition. Keep clear of moving machinery.

Drive Thermal

Specifies the fault action to be taken when a Drive Thermal Fault is detected, for an axis configured as Servo (in the General tab of this dialog). The available actions for this fault are Shutdown, Disable Drive, Stop Motion, and Status Only.

Motor Thermal

Specifies the fault action to be taken when a Motor Thermal Fault is detected, for an axis configured as Servo (in the General tab of this dialog). The available actions for this fault are Shutdown, Disable Drive, Stop Motion, and Status Only.

Feedback Noise

Specifies the fault action to be taken when excessive feedback noise is detected. The available actions for this fault are Shutdown, Disable Drive, Stop Motion, and Status Only.

Feedback

Specifies the fault action to be taken when Feedback Fault is detected. The available actions for this fault are Shutdown, Disable Drive, Stop Motion, and Status Only.

Position Error

Specifies the fault action to be taken when position error exceeds the position tolerance set for the axis, for an axis configured as Servo (in the General tab of this dialog). The available actions for this fault are Shutdown, Disable Drive, Stop Motion and Status Only.

Hard Overtravel

Specifies the fault action to be taken when an axis encounters a travel limit switch, for an axis configured as Servo (in the General tab of this dialog). The available actions for this fault are Shutdown, Disable Drive, Stop Motion, and Status Only.

Soft Overtravel


Specifies the fault action to be taken when a software overtravel error occurs, for an axis with Soft Travel Limits enabled and configured (in the Limits tab of this dialog) that is configured as Servo (in the General tab of this dialog). The available actions for this fault are Shutdown, Disable Drive, Stop Motion and Status Only.

Set Custom Stop Action

Opens the Custom Stop Action Attributes dialog

Tag Tab

Use this tab to modify the name and description of the axis. When you are online, all of the parameters on this tab transition to a read-only state, and cannot be modified. If you go online before you save your changes, all pending changes revert to their previously-saved state.



Name

Displays the name of the current tag. You can rename this tag, if you wish.

Description

Displays the description of the current tag, if any is available. You can edit this description, if you wish.

Tag Type

Indicates the type of the current tag. This type may be:

- Base
- Alias
- Consumed

Displays the data type associated with the current tag.

Scope

Displays the scope of the current tag. The scope is either controller scope, or program scope, based on one of the existing programs in the controller.

Style

Displays the default style in which to display the value of the tag. Note that style is only applicable to an atomic tag; a structure tag does not have a display style.

Produce this tag for up to

A checked box indicates that this tag is available to remote controllers through controller-to-controller messaging. If this box is checked, the system displays the maximum number of consumers (i.e., connections) allowed for this tag.

The default number of consumers is 2.

Base Tag

If this tag is an alias, this field displays the name of the underlying tag on which this alias was based. The base tag actually defines the memory where the data element is stored.

Manual Tune

Click on this button to open the Dynamics tab of the Manual Tune dialog for online editing of the Maximum Velocity, Maximum Acceleration, and Maximum Deceleration parameters.

Note: The Manual Tune button is disabled when RSLogix 5000 is in Wizard mode, and when offline edits to the above parameters have not yet been saved or applied.

Assigning Additional Motion Axes

You can assign additional axes by repeating the preceding sections. To name and assign another axis, refer to the *Naming an Axis* section.

You can assign up to 16 1756-M02AE modules to each Logix5550 controller. Each module uses a maximum of two axes.

Developing a Motion Application Program

To write a motion application program, you can insert motion instructions directly into the ladder diagram application program. The motion instruction set consists of five groups of motion instructions:

- Motion state instructions
- Motion move instructions
- Motion group instructions
- Motion event instructions
- Motion configuration instructions

For more information about these instructions, refer to the Logix5550 Controller Motion Instruction Set Reference Manual – publication 1756-6.4.3.

Understanding a Programming Example

The following figure shows several rungs of a motion control application program.

Rung 0:

Enables the Feed and Cut axes when you press the servo_on button.

Rung 1:


Jogs the Feed axis in the positive direction when you press the jog_plus button.

Rung 2:

Jogs the Feed axis in the reverse direction when you press the jog_minus button.

Rung 3:

Stops the Feed axis when you release with the jog_plus button or the jog_minus button.




For more information about instructions and creating application programs, refer to the *Logix5550 Controller Instruction Set Reference Manual*, publication 1756-RM003 and the *Logix5550 Motion Instruction Reference Set Manual*, publication 1756-RM007.


Configuring a 1394C-SJT05/10/22-D Digital Servo Drive

To configure a 1394C-SJT05-D, 1394C-SJT10-D or 1394C-SJT22-D drive module:


1. In the Controller Organizer, in the I/O Configuration branch, select a 1756-M08SE motion module.
2. In the File menu, select New Component then Module.



3. In the Select Module Type dialog, select the desired drive module: 1394C-SJT05-D, 1394C-SJT10-D or 1394C-SJT22-D



4. Press the OK button to close the Select Module Type dialog. The Module Properties wizard opens.
5. Fill in the required parameters for each page, then click the Next> button.



6. When you complete the last page, click the Finish> button. A new drive module displays beneath the selected 1756-M08SE motion module.


1394C-SJT05/10/22-D Digital Servo Drive Overview

The 1756-M08SE 8 Axis SERCOS interface motion module can be connected to any of three drives:

- 1394C-SJT05-D 5 KW digital servo drive
- 1394C-SJT10-D 10 KW digital servo drive
- 1394C-SJT22-D 22 KW digital servo drive.

Each drive can be associated with up to 4 axes of the AXIS_SERVO_DRIVE tag type. The 1756-M08SE 8 Axis SERCOS interface module can support up to 8 axes (using varying combinations of from 2 to 8 drives).


The module for a 1394C-SJT05/10/22-D drive has 5 tabs:



- General tab
- Connection tab
- Axes Association
- Power tab
- Module Info tab.

General Tab

Use this tab to enter the module properties for a 1394C-SJT05-D 5 KW, 1394C-SJT10-D 10 KW or 1394C-SJT22-D 22 KW digital servo drive module.



IMPORTANT

To create any one of the 1394C-SJT modules, the parent module must be a 1756-M08SE 8 Axis SERCOS interface module.

On this tab, you can:

- view the type and description of the module being created
- view the vendor of the module being created
- enter the name of the module
- enter a description for the module
- set the Base Node for the module
- select the minor revision number of your module
- select Electronic Keying (Exact Match, Compatible Module, or Disable Keying)
- view the status the controller has about the module (you can only view the status while online)

Type

Displays the module type of the module being created: 1394C-SJT05-D 5 KW, 1394C-SJT10-D 10 KW, or 1394C-SJT22-D 22 KW digital servo drive module (read only).

Vendor

Displays the vendor of the module being created (read only).

Name

Enter the name of the module. The name must be IEC 1131-3 compliant. If you attempt to enter an invalid character or exceed the maximum length, the software beeps and ignores the character.

Description

Enter a description for the module here, up to 128 characters. You can use any printable character in this field. If you exceed the maximum length, the software beeps to warn you, and ignores any extra characters.

Base Node

Type or select the Base Node number of the drive module. This node number is determined by multiplying the node number from the module's rotary switch (1 to 9) by a factor of ten. Thus, valid Base Node values are 10, 20, 30, 40, 50, 60, 70, 80 or 90.

Revision

Select the minor revision number of your module.

The revision is divided into the major revision and minor revision. The major revision displayed statically is chosen on the Select Module Type dialog.

The major revision is used to indicate the revision of the interface to the module. The minor revision is used to indicate the firmware revision.

Electronic Keying

Select one of these keying options for your module during initial module configuration:

- Exact Match - all of the parameters described below must match or the inserted module will reject the connection.
- Compatible Module
 - the Module Types, Catalog Number, and Major Revision must match
 - the Minor Revision of the physical module must be equal to or greater than the one specified in the softwareor the inserted module will reject the connection
- Disable Keying – Logix5550 will not employ keying at all.

WARNING

Changing the RPI and Electronic Keying selections may cause the connection to the module to be broken and may result in a loss of data.

Be extremely cautious when using this option; if used incorrectly, this option can lead to personal injury or death, property damage or economic loss.


When you insert a module into a slot in a ControlLogix chassis, RSLogix 5000 compares the following information for the inserted module to that of the configured slot:

- Vendor
- Product Type
- Catalog Number
- Major Revision
- Minor Revision

This feature prevents the inadvertent insertion of the wrong module in the wrong slot.

Connection Tab

Use this tab to define controller to drive module behavior.



On this tab, you can:

- choose to inhibit the module
- configure the controller so loss of the connection to this module causes a major fault
- view module faults

TIP



The data on this tab comes directly from the controller. This tab displays information about the condition of the connection between the module and the controller.

Requested packet Interval

The amount of time (in milliseconds) between updates of data from the remote controller. This value is scaled as a real value from the microseconds stored in the controller. The local controller will receive data at least this fast. (Not enabled for this release.)

Inhibit Module checkbox

Check/Uncheck this box to inhibit/uninhibit your connection to the module. Inhibiting the module causes the connection to the module to be broken.

IMPORTANT

Inhibiting/uninhibiting connections applies mainly to direct connections, and not to the CNB module.

WARNING

Inhibiting the module causes the connection to the module to be broken and may result in loss of data.

When you check this box and go online, the icon representing this module in the controller organizer displays the Attention Icon.

If you are:**Check this checkbox to:**

offline

put a place holder for a module you are configuring

online

stop communication to a module. If you inhibit the module while you are online and connected to the module, the connection to the module is nicely closed. The module's outputs will go to the last configured Program mode state. If you inhibit the module while online but a connection to the module has not been established (perhaps due to an error condition or fault), the module is inhibited. The module status information will change to indicate that the module is 'Inhibited' and not 'Faulted'. If you uninhibit a module (clear the checkbox) while online, and no fault condition occurs, a connection is made to the module and the module is dynamically reconfigured (if you are the owner controller) with the configuration you have created for that module. If you are a listener (have chosen a "Listen Only" Communications Format), you can not re-configure the module. If you uninhibit a module while online and a fault condition occurs, a connection is not made to the module.

Major Fault on Controller if Connection Fails checkbox

Check this box to configure the controller so that failure of the connection to this module causes a major fault on the controller if the connection for the module fails.

Module Fault


Displays the fault code returned from the controller (related to the module you are configuring) and the text detailing the Module Fault that has occurred.

The following are common categories for errors:

- Connection Request Error - The controller is attempting to make a connection to the module and has received an error. The connection was not made.
- Service Request Error - The controller is attempting to request a service from the module and has received an error. The service was not performed successfully.
- Module Configuration Invalid - The configuration in the module is invalid. (This error is commonly caused by the Electronic Key Passed fault).
- Electronic Keying Mismatch - Electronic Keying is enabled and some part of the keying information differs between the.

Associated Axes Tab

Use this tab to configure the selected 1394C-SJT05-D, 1394C-SJT10-D or 1394C-SJT22-D drive module by associating up to four AXIS_SERVO_DRIVE axis tags with configured axis modules.



Node X0

Represents Axis 0 on the 1756-M08SE SERCOS module. The node number is the sum of the Base Node set in the General page of this dialog box (X0) and the axis number (1). This field allows you to associate an AXIS_SERVO_DRIVE tag with Axis 0. This field transitions to a read only state while online. Click on the Ellipses (...) button to the right of this field to open the Axis properties dialog box for the associated axis.

Node X1

Represents Axis 1 on the 1756-M08SE SERCOS module. The node number is the sum of the Base Node set in the General page of this dialog box (X0) and the axis number (1). This field allows you to associate an AXIS_SERVO_DRIVE tag with Axis 1. This field transitions to a read only state while online. Click on the Ellipses (...) button to the right of this field to open the Axis properties dialog box for the associated axis.

Node X2

Represents Axis 2 on the 1756-M08SE SERCOS module. The node number is the sum of the Base Node set in the General page of this dialog box (X0) and the axis number (2). This field allows you to associate an AXIS_SERVO_DRIVE tag with Axis 2. This field transitions

to a read only state while online. Click on the Ellipses (...) button to the right of this field to open the Axis properties dialog box for the associated axis.

Node X3


Represents Axis 3 on the 1756-M08SE SERCOS module The node number is the sum of the Base Node set in the General page of this dialog box (X0) and the axis number (3). This field allows you to associate an AXIS_SERVO_DRIVE tag with Axis 3. This field transitions to a read only state while online. Click on the Ellipses (...) button to the right of this field to open the Axis properties dialog box for the associated axis.

New Axis button

Click this button to navigate to the New Tag dialog to create an AXIS_SERVO_DRIVE tag to associate with one of the channels.

Power Tab

Use this tab to select a bus regulator for your 1394C-SJT05-D, 1394C-SJT10-D or 1394C-SJT22-D drive module.



Bus Regulator ID


Select the catalog number that describes bus regulator device used by the 1394C-SJT05-D, 1394C-SJT10-D or 1394C-SJT22-D drive module.

Depending upon the Drive Module you have selected, one or more of the following are available:

Bus Regulator ID	Description
1394-SR10A	1400 Watt Resistor, for 5 and 10 kW modules
1394-SR9A	300 Watt External Shunt, No Fan, for 22 kW modules
1394-SR9AF	900 Watt External Shunt, No Fan, for 22 kW modules
1394-SR36A	1800 Watt External Shunt, No Fan, for 22 kW modules
1394-SR36AF	3600 Watt External Shunt, No Fan, for 22 kW modules
<none>	No bus regulator
Internal	The bus regulator is internal to the drive and need not be specified
Custom	A bus regulator not listed above

Module Info tab

Use this tab to display identifying and status information about the 1394C-SJT05/10/22-D drive module. It also allows you to refresh a module and reset a module to its power-up state.



The information on this tab is not displayed if you are:

- offline, or
- currently creating a module

TIP

The data on this tab comes directly from the module. If you selected a Listen-Only communication format when you created the module, this tab is not available.

Identification

Displays the module's:

- Vendor
- Product Type
- Product Code
- Revision
- Serial Number

Product Name

The name displayed in the Product Name field is read from the module. This name displays the series of the module.

Major/Minor Fault Status

Statuses are: EEPROM fault, Backplane fault, None

Internal State Status

Displays the module's current operational state.

- Self-test
- Flash update
- Communication fault
- Unconnected
- Flash configuration bad
- Major Fault (please refer to “Major/Minor Fault Status” above)
- Run mode
- Program mode

(16#xxxx) unknown

If you selected the wrong module from the module selection tab, this field displays a hexadecimal value. A textual description of this state is only given when the module identity you provide is a match with the actual module.

Configured

Displays a yes or no value indicating whether the module has been configured by an owner controller connected to it. Once a module has been configured, it stays configured until the module is reset or power is cycled, even if the owner drops connection to the module. This information does not apply to adapters.

Owned

Displays a yes or no value indicating whether an owner controller is currently connected to the module. This information does not apply to adapters.

Module Identity

Displays:	If the module in the physical slot:
Match	agrees with what is specified on the General Tab. In order for the Match condition to exist, all of the following must agree: Vendor Module Type (the combination of Product Type and Product Code for a particular Vendor) Major Revision
Mismatch	does not agree with what is specified on the General Tab

This field does not take into account the Electronic Keying or Minor Revision selections for the module that were specified on the General Tab.


Refresh

Click on this button to refresh the tab with the new data from the module.

Reset Module

Click on this button to return a module to its power-up state by emulating the cycling of power.

WARNING




Resetting a module causes all connections to or through the module to be closed; this may result in loss of control.

Configuring an Ultra 3000 Drive

The Ultra3000 Digital Servo Drive with fiber optic SERCOS interface simplifies the integration of the Ultra3000 with the ControlLogix architecture by providing single point drive commissioning through RSLogix5000 software and reducing the control wiring to a single fiber optic cable.


You can initiate the configuration of an Ultra3000 drive module by either of two methods:

1. In the Controller Organizer, in the I/O Configuration branch, select a 1756-M08SE motion module.
2. In the File menu, select New Component then Module.



OR

3. Right click on the selected 1756-M08SE in the I/O Configuration branch of the Controller Organizer.
4. Select New Module from the pop up menu.




The following fields are displayed only if you are viewing this tab through the Create wizard.

Next> – Click this button to view the next Create wizard page.


<Back – Click this button to view the previous Create wizard page.

Finish>> – Click this button to close the Create wizard.

The Select Module Type dialog displays.




5. In the Select Module Type dialog, select the desired drive module. The Ultra drives begin with the 2098 prefix.
6. Press the OK button to close the Select Module Type dialog. The Ultra Drive Create Wizard Module Properties dialog opens.




7. You must fill in a name for the drive; this is a required field. Fill in the responses for the other parameters as needed, then click

the Next> button to advance to the next wizard screen.



8. Fill in the required information and click on the Next button to advance to the next screen.



9. Fill in the node information for the drive and press Next.

Module Properties - seccos1 (2098-D5D-030-SE 1.1)

Bus Regulator Catalog Number:

Cancel < Back Next > Finish >> Help

10. Enter the Bus regulator information and press Next to continue.

Module Properties - seccos1 (2098-D5D-030-SE 1.1)


Identification:	Status:
Vendor:	Major Fault:
Product Type:	Minor Fault:
Product Code:	Internal State:
Revision:	Configured:
Serial Number:	Owned:
Product Name:	Module Identity:

Refresh Reset Module

Cancel < Back Next > Finish >> Help


11. When you complete the last page, click the Finish> button. A new drive module displays beneath the selected 1756-M08SE

motion module.




Editing the Ultra Drive Properties

The Module Properties for any of the Ultra3000 drives can be edited by highlighting the drive to be edited, right click with the mouse and selecting Properties.



The Module Properties screen displays.



General Tab

The General Tab is where you edit the basic values for the Ultra drive.

Type

Displays the type and description of the module being created (read only).

Vendor

Displays the vendor of the module being created (read only).

Name

Enter the name of the module.

The name must be IEC 1131-3 compliant. This is a required field and must be completed, otherwise you receive an error message when you exit this tab. An error message is also displayed if a duplicate name is detected, or you enter an invalid character. If you exceed the maximum name length allowed by the software, the extra character(s) are ignored.

Description

Enter a description for the module here, up to 128 characters. You can use any printable character in this field. If you exceed the maximum length, the software ignores any extra character(s).

Node

Select the network node number of the module on the network. Valid values include those network nodes not in use between 1 to 99.

Revision

Select the minor revision number of your module.

The revision is divided into the major revision and minor revision. The major revision displayed statically is chosen on the Select Module Type dialog.

The major revision is used to indicate the revision of the interface to the module. The minor revision is used to indicate the firmware revision.

Slot

Enter the slot number in which the module resides.

Electronic Keying

Select one of these keying options for your module during initial module configuration:

- Exact Match - all of the parameters described below must match or the inserted module will reject the connection.
- Compatible Modules – The following criteria must be met, or else the inserted module will reject the connection:
 - The Module Types, Catalog Number, and Major Revision must match.
 - The Minor Revision of the physical module must be equal to or greater than the one specified in the software.
- Disable Keying – Logix5550 does not employ keying at all.

WARNING



Changing the RPI and Electronic Keying selections may cause the connection to the module to be broken and may result in a loss of data.

Be extremely cautious when using this option; if used incorrectly, this option can lead to personal injury or death, property damage or economic loss.

When you insert a module into a slot in a ControlLogix chassis, RSLogix 5000 compares the following information for the inserted module to that of the configured slot:

- Vendor
- Product Type
- Catalog Number
- Major Revision
- Minor Revision

This feature prevents the inadvertent insertion of the wrong module in the wrong slot.

Status

Displays the status the controller has about the module:

This status:	Indicates:
Standby	A transient state that occurs when shutting down.
Faulted	The controller is unable to communicate with the module. When the status is Faulted, the Connection tab displays the fault.
Validating	A transient state that occurs before connecting to the module.
Connecting	A state that occurs while the connection(s) are being established to the module.
Running	The module is communicating and everything is working as expected.
Shutting Down	The connections are closing.
Inhibited	The connection to the module is inhibited.
Waiting	The connection to this module has not yet been made due to one of the following: <ul style="list-style-type: none">• its parent has not yet made a connection to it• its parent is inhibited• its parent is faulted
Offline	You are not online.

Connection Tab

Use this tab to define controller to module behavior. On this tab, you can:

- Select a requested packet interval.
- Choose to inhibit the module.
- Configure the controller so loss of the connection to this module causes a major fault.
- View module faults.

TIP

The data on this tab comes directly from the controller. This tab displays information about the condition of the connection between the module and the controller.

Requested Packet Interval

Enter the requested rate of packet arrival (connection update rate). The connection will be scheduled to move data to or from the module at least this often or the connection will fail with the Connection Not Scheduled fault. The minimum and maximum RPI values are shown parenthetically to the right of the box/spin control.

Note: These minimum and maximum values are module-dependent and will differ depending on the limits of the module. For instance, for the 1769-MODULE, this value is limited to 2.0 ms and cannot be changed. For the CompactBus 1769 Virtual Backplane adapter, this value must be 0. And for the 1756-DM modules, valid values range from 1.0 to 750.0 ms.

The RPI is determined by the Owner Controller(s) of a module. If a Listen-Only connection is established, the RPI for that connection cannot be faster than the fastest RPI configured for all owner controllers (for input modules), or faster than the RPI configured for the one owner controller (for output modules).

WARNING

Changing the RPI while online temporarily disables the connection and can result in a loss of data.

For a remote module – if the RPI is changed online, the connection to the module is broken until RSNetWorx is re-run to schedule the network. Breaking the connection may result in a loss of data.

For modules in remote racks, when communicating on a ControlNet network, the fastest the RPI should be set to is 2ms.

Note: The RPI for the CNB module affects only the CNB Rack Object; no other direct connections are affected.

Note: This field is disabled for all motion modules (e.g., 1756-MO2AE, 1756-MO8SE, and all 1394- and Ultra3000 modules).

Inhibit Module

Check/Uncheck this box to inhibit/uninhibit your connection to the module. Inhibiting the module causes the connection to the module to be broken.

Note: Inhibiting/uninhibiting connections applies mainly to direct connections, and not to the CNB module.

Note: A FLEX I/O module using rack communication cannot be inhibited; the Inhibit checkbox on the Connection tab is disabled in this case.

WARNING



Inhibiting the module causes the connection to the module to be broken and may result in loss of data.

When you check this box and go online, the icon representing this module in the controller organizer displays the Warning Icon.

If you are:	Check this checkbox to:
offline	put a place holder for a module you are configuring
online	stop communication to a module <ul style="list-style-type: none"> • If you inhibit the module while you are online and connected to the module, the connection to the module is nicely closed. The module's outputs go to the last configured Program mode state. • If you inhibit the module while online but a connection to the module has not been established (perhaps due to an error condition or fault), the module is inhibited. The module status information changes to indicate that the module is 'Inhibited' and not 'Faulted'. • If you uninhibit a module (clear the checkbox) while online, and no fault condition occurs, a connection is made to the module and the module is dynamically reconfigured (if you are the owner controller) with the configuration you have created for that module. If you are a listener (have chosen a "Listen Only" Communications Format), you can not re-configure the module. • If you uninhibit a module while online and a fault condition occurs, a connection is not made to the module.

Major Fault on Controller if Connection Fails checkbox

Check this box to configure the controller so that failure of the connection to this module causes a major fault on the controller if the connection for the module fails.

Module Fault

Displays the fault code returned from the controller (related to the module you are configuring) and the text detailing the Module Fault that has occurred.

The following are common categories for errors:

- Connection Request Error - The controller is attempting to make a connection to the module and has received an error. The connection was not made.
- Service Request Error - The controller is attempting to request a service from the module and has received an error. The service was not performed successfully.
- Module Configuration Invalid - The configuration in the module is invalid. (This error is commonly caused by the Electronic Key Passed fault).
- Electronic Keying Mismatch - Electronic Keying is enabled and some part of the keying information differs between the software and the module.

Associated Axes Tab (Ultra3000 Drives)

Use this tab to configure the selected 1756-MO8SE motion module by associating axis tags (of the type AXIS_SERVO_DRIVE) with nodes available on the module.

Node

Displays the selected node of the Ultra3000 drive, as selected on the General tab. This field allows you to associate an AXIS_SERVO_DRIVE tag with the driver's node.

Note: This field is read-only while you are online.

Ellipsis (...)

Click on this button to access the Axis Properties dialog for the associated axis.

New Axis

Click on this button to access the New Tag dialog, with the scope, data type, and produced settings appropriate for a produced axis tag.

Power Tab - Ultra Drive

Use this tab to select a bus regulator for your Ultra 3000 drive module.

Note: This parameter does not apply to the Ultra3000 SERCOS drives. The only available selection in the Bus Regulator ID pull-down menu is <none>.

Bus Regulator ID

Select the catalog number that describes bus regulator device used by the Ultra 3000 drive module. Depending upon the Drive Module you have selected, one or more of the following are available:

Note: This parameter does not apply to the Ultra3000 SERCOS drives. The only available selection in the pull-down menu is <none>.

Module Info

The Module Info Tab displays module and status information about the module. It also allows you to reset a module to its power-up state.

The information on this tab is not displayed if you are either offline or currently creating a module

TIP

You can use this tab to determine the identity of the module.



The data on this tab comes directly from the module. If you selected a Listen-Only communication format when you created the module, this tab is not available.

- Refresh to display new data from the module.
- Reset Module to return the module to its power-up state by emulating the cycling of power. By doing this, you also clear all faults.

Identification

Displays the module's:

- Vendor
- Product Type
- Product Code
- Revision
- Serial Number
- Product Name

The name displayed in the Product Name field is read from the module. This name displays the series of the module. If the module is a 1756-L1 module, this field displays the catalog number of the memory expansion board (this selection applies to any controller catalog number even if additional memory cards are added).

Major/Minor Fault Status

If you are configuring a:	This field displays one of the following:
digital module	EEPROM fault Backplane fault None
analog module	Comm. Lost with owner Channel fault None
Any other module	None Unrecoverable Recoverable

Internal State Status

Displays the module's current operational state.

- Self-test
- Flash update
- Communication fault
- Unconnected
- Flash configuration bad
- Major Fault (please refer to "Major/Minor Fault Status" above)
- Run mode
- Program mode
- (16#xxxx) unknown

If you selected the wrong module from the module selection tab, this field displays a hexadecimal value. A textual description of this state is only given when the module identity you provide is a match with the actual module.

Configured

Displays a yes or no value indicating whether the module has been configured by an owner controller connected to it. Once a module has been configured, it stays configured until the module is reset or power is cycled, even if the owner drops connection to the module. This information applies to I/O modules only and does not apply to adapters, scanners, bridges, or other communications modules.

Owned

Displays a yes or no value indicating whether an owner controller is currently connected to the module. This information applies to I/O

modules only and does not apply to adapters, scanners, bridges, or other communications modules.

Module Identity

Displays:	If the physical module:
Match	agrees with what is specified on the General Tab order for the Match condition to exist, all of the following must agree: <ul style="list-style-type: none"> • Vendor • Module Type (the combination of Product Type and Product Code for a particular Vendor) • Major Revision
Mismatch	does not agree with what is specified on the General Tab

This field does not take into account the Electronic Keying or Minor Revision selections for the module that were specified on the General Tab.

Note: The Generic modules, such as the 1756-MODULE, always show a Mismatch because the configured Generic Key does not match any target device.

Reset Module

Click on this button to return a module to its power-up state by emulating the cycling of power.

Resetting a module causes all connections to or through the module to be closed, and this may result in loss of control.

Note: The following modules return an error if a reset is attempted:

- 1756-L1 ControlLogix5550 Programmable Controller
- 1336T AC Vector Drive
- 1395 Digital DC Drive

Note: A controller cannot be reset.

Refresh

Click on this button to refresh the tab with new data from the module.

If you are online in Program, Remote Program or Remote Run mode, and this controller is the owner controller, and you have changed the module's configuration in the software, then when you click the Apply or the OK button, the information is automatically sent to the

controller. The controller tries to send the information to the module (if the module's connection is not inhibited). If you don't click Apply, your changes are not sent to the controller.

Motion Instructions

This chapter describes the 32 motion instructions for RSLogix 5000 programming software.

The motion instructions for the RSLogix 5000 programming software consist of five main categories:

- Motion state instructions – to control or change the operating state of an axis.
- Motion move instructions – to control all aspects of axis position.
- Motion group instructions – to control a group of axes.
- Motion event instructions – control the arming and disarming of special event checking functions.
- Motion configuration instructions – to tune an axis and to run diagnostic tests for the system.

For more information about	Refer to
Motion instructions	The Logix5550 Controller Motion Instruction Set Reference Manual, publication 1756-RM007
Types of motion instruction timing	Appendix E - <i>Instruction Timing</i>

Motion State Instructions

Motion state instructions directly control or change the operating state of an axis.

The motion state instructions are:

Instruction	Abbreviation	Description	Type of Timing
Motion Servo On	MSO	Enables the servo drive and activates the axis servo loop	Message
Motion Servo Off	MSF	Disables the servo drive and deactivates the axis servo loop	Message

Motion Axis Shutdown	MASD	Forces an axis into the shutdown operating state Once the axis is in the shutdown state, the controller will block any instructions that initiate axis motion.	Message
Motion Axis Shutdown Reset	MASR	Changes an axis from an existing shutdown operating state to an axis ready operating state If all of the axes of a servo module are removed from the shutdown state as a result of this instruction, the OK relay contacts for the module will close.	Message
Motion Direct Drive On	MDO	Enables the servo drive and sets the servo output voltage of an axis	Message
Motion Direct Drive Off	MDF	Disables the servo drive and sets the servo output voltage to the output offset voltage	Message
Motion Axis Fault Reset	MAFR	Clears all motion faults	Message

For more information about motion state instructions, refer to the *Motion State Instructions* chapter of the Logix5550 Controller Motion Instruction Set Reference Manual, publication 1756-RM007.

For more information about instruction timing, refer to Appendix E - *Instruction Timing*.

Motion Move Instructions

Motion move instructions control all aspects of axis position.

The motion move instructions are:

Instruction	Abbreviation	Description	Type of Timing
Motion Axis Stop	MAS	Initiates a controlled stop of any motion process on an axis	Immediate Process
Motion Axis Home	MAH	Homes an axis	Message Process
Motion Axis Jog	MAJ	Initiates a jog motion profile for an axis	Immediate Process
Motion Axis Move	MAM	Initiates a move profile for an axis	Immediate Process
Motion Axis Gear	MAG	Enables electronic gearing between two axes	Immediate Process
Motion Change Dynamics	MCD	Changes the speed, acceleration rate, or deceleration rate of a move profile or jog profile in progress	Immediate
Motion Redefine Position	MRP	Changes the command or actual position of an axis	Message

Motion Calculate Cam Profile	MCCP	Calculates a Cam Profile based on an array of cam points.	Immediate
Motion Axis Position Cam	MAPC	Performs electronic camming between any two axes designated in the specified Cam Profile.	Immediate Process
Motion Axis Time Cam	MATC	Performs electronic camming as a function of time designated in the specified Cam Profile.	Immediate Process

For more information about motion state instructions, refer to the *Motion Move Instructions* chapter of Logix5550 Controller Motion Instruction Set Reference Manual, publication 1756-RM007.

For more information about instruction timing, refer to Appendix E - *Instruction Timing*.

Motion Group Instructions

Motion group instructions initiate action on all axes in a group.

The motion group instructions are:

Instruction	Abbreviation	Description	Type of Timing
Motion Group Stop	MGS	Initiates a stop of motion on a group of axes	Process
Motion Group Programmed Stop	MGPS	Initiates a stop of all motion on all the axes in a group using the method that you set for each axis.	Message Process
Motion Group Shutdown	MGSD	Forces all the axes in a group into the shutdown operating state	Message
Motion Group Shutdown Reset	MGSR	Transitions a group of axes from the shutdown operating state to the axis ready operating state	Message
Motion Group Strobe Position	MGSP	Latches the current command and actual positions of all the axes in a group	Immediate

For more information about motion state instructions, refer to the *Motion Group Instructions* chapter of Logix5550 Controller Motion Instruction Set Reference Manual, publication 1756-RM007.

For more information about instruction timing, refer to Appendix E - *Instruction Timing*.

Motion Event Instructions

Motion event instructions control the arming and disarming of special event checking functions, such as registration and watch position.

The motion event instructions are:

Instruction	Abbreviation	Description	Type of Timing
Motion Arm Watch Position	MAW	Arms watch-position event checking for an axis	Message Process
Motion Disarm Watch Position	MDW	Disarms watch-position event checking for an axis	Message
Motion Arm Registration	MAR	Arms servo module registration event checking for an axis	Message Process
Motion Disarm Registration	MDR	Disarms servo module registration event checking for an axis	Message
Motion Arm Output Cam	MAOC	Arms an Output Cam for a particular Axis and Output as determined by the operands for the instruction.	Immediate Process
Motion Disarm Output Cam	MDOC	Disarms either one or all Output Cams connected to a specified axis depending on the selection in the Disarm Type operand.	Immediate Process

For more information about motion state instructions, refer to the *Motion Event Instructions* chapter of Logix5550 Controller Motion Instruction Set Reference Manual, publication 1756-RM007.

For more information about instruction timing, refer to Appendix E - *Instruction Timing*.

Understanding Motion Configuration Instructions

Motion configuration instructions allow you to tune an axis and to run diagnostic tests for your control system. These tests include:

- A motor/encoder hookup test
- An encoder hookup test
- A marker test

The motion configuration instructions are:

Instruction	Abbreviation	Description	Type of Timing
Motion Apply Axis Tuning	MAAT	Computes a complete set of servo gains and dynamic limits based on a previously executed MRAT instruction The MAAT instruction also updates the servo module with the new gain parameters.	Message
Motion Run Axis Tuning	MRAT	Commands the servo module to run a tuning motion profile for an axis	Message Process

Motion Apply Hookup Diagnostic	MAHD	Applies the results of a previously executed MRHD instruction The MAHD instruction generates a new set of encoder and servo polarities based on the observed direction of motion during the MRHD instruction.	Message
Motion Run Hookup Diagnostic	MRHD	Commands the servo module to run one of three diagnostic tests on an axis	Message Process

For more information about motion state instructions, refer to the *Motion Configuration Instructions* chapter of Logix5550 Controller Motion Instruction Set Reference Manual, publication 1756-RM007.

For more information about instruction timing, refer to Appendix E - *Instruction Timing*.

Troubleshooting

This chapter describes how to troubleshoot your ControlLogix motion control system.

1756-M02AE Module Status Using the OK Indicator

If the OK LED displays	Then the module status is	Take this action
Off	The module is not operating.	<ul style="list-style-type: none"> • Apply chassis power. • Verify the module is completely inserted into the chassis and backplane.
Flashing green light	The module has passed internal diagnostics, but it is not communicating axis data over the backplane.	<ul style="list-style-type: none"> • None, if you have not configured the module. • If you have configured the module, check the slot number in the 1756-M02AE Properties dialog box.
Steady green light	<ul style="list-style-type: none"> • Axis data is being exchanged with the module. • The module is in the normal operating state. 	None. The module is ready for action.
Flashing red light	<ul style="list-style-type: none"> • A major recoverable failure has occurred. • A communication fault, timer fault, or NVS update is in progress. • The OK contact has opened. 	<ul style="list-style-type: none"> • Check the servo fault word for the source of the error. • Clear the fault condition using the motion instructions. • Resume normal operation. • If the flashing persists, reconfigure the module.
Solid red light	<ul style="list-style-type: none"> • A potential non-recoverable fault has occurred. • The OK contact has opened. 	<ul style="list-style-type: none"> • Reboot the module. • If the solid red persists, replace the module.

1756-M02AE Module Status Using the FDBK Indicator

If the FDBK LED displays	Then the module status is	Take this action
Off	The axis is not used.	<ul style="list-style-type: none"> None, if you are not using this axis. If you are using this axis, make sure you configured the module and associated an axis tag with the module.
Flashing green light	The axis is in the normal servo loop inactive state.	None. You can change the servo axis state by executing motion instructions.
Steady green light	The axis is in the normal servo loop active state.	None. You can change the servo axis state by executing motion instructions.
Flashing red light	The axis servo loop error tolerance has been exceeded.	<ul style="list-style-type: none"> Correct the source of the problem. Clear the servo fault using a fault reset instruction. Resume normal operation.
Solid red light	An axis encoder feedback fault has occurred.	<ul style="list-style-type: none"> Correct the source of the problem by checking the encoder and power connections. Clear the servo fault using the MAFR instruction. Resume normal operation.

1756-M02AE Module Status Using the DRIVE Indicator

If the DRIVE LED displays	Then the module status is	Take this action
Off	<ul style="list-style-type: none"> The axis is not used. The axis is a position-only axis type. 	<ul style="list-style-type: none"> None, if you are not using the axis or have configured it as a position-only axis. Otherwise, make sure you have configured the module, associated an axis tag with the module, and configured the axis as a servo axis.

If the DRIVE LED displays	Then the module status is	Take this action
Flashing green light	The axis drive is in the normal disabled state.	None. You can change the servo axis state by executing a motion instruction.
Steady green light	The axis drive is in the normal enabled state.	None. You can change the servo axis state by executing a motion instruction.
Flashing red light	The axis drive output is in the Shutdown state.	<ul style="list-style-type: none"> • Check for faults that may have generated this state. • Execute the shutdown reset motion instruction. • Resume normal operation.
Solid red light	The axis drive is faulted.	<ul style="list-style-type: none"> • Check the drive status. • Clear the drive fault condition at the drive. • Execute a fault reset motion instruction. • Resume normal operation. • Check the configuration for the Drive Fault. <ul style="list-style-type: none"> • If configured to be normally open and there is no voltage, this is the normal condition. • If configured to be normally closed and there is 24V applied, this is the normal condition.

1756-M08SE SERCOS Communication Phase Status Using the CP Indicator

If the CP LED displays:	Then the module status is:
Off	The module is not operating.
Solid red light	<ul style="list-style-type: none"> • In Phase 0: looking for a closed ring.
Flashing red light	<ul style="list-style-type: none"> • In Phase 1: looking for active nodes.
Alternating Red/Green light	<ul style="list-style-type: none"> • In Phase 2: configuring nodes for communication.
Flashing green light	<ul style="list-style-type: none"> • In Phase 3: configuring device specific parameters
Solid green light	<ul style="list-style-type: none"> • In Phase 4: configured and active.

1756-M08SE Module Status Using the OK Indicator

If the OK LED displays:	Then the module status is:	Take this action:
Off	The module is not operating.	<ul style="list-style-type: none"> • Apply chassis power. • Verify the module is completely inserted into the chassis and backplane.
Flashing green light	The module has passed internal diagnostics, but has not established active communications.	<ul style="list-style-type: none"> • None, if you have not configured the module.
Solid green light	<ul style="list-style-type: none"> • Data is being exchanged. • The module is in the normal operating state. 	None. The module is ready for action.
Flashing red light	<ul style="list-style-type: none"> • A major recoverable failure has occurred. • An NVS update is in progress. 	<p>If an NVS update is in progress, complete the NVS update.</p> <p>If an NVS update is not in progress:</p> <ul style="list-style-type: none"> • Reboot
Solid red light	<ul style="list-style-type: none"> • A potential nonrecoverable fault has occurred. 	<ul style="list-style-type: none"> • Reboot the module. • If the solid red persists, replace the module.

1756-M08SE SERCOS Ring Status

If the SERCOS Ring LED displays:	Then the ring status is:	Take this action:
Solid green light	The ring, drive, and axes are configured and are actively communicating through to the nodes on the ring.	None.
Flashing red light	The module has detected a setup or configuration fault with the ring.	<p>Check your system setup and configuration as follows:</p> <ul style="list-style-type: none"> • Ensure drive and axes addresses are correct. • Eliminate duplicate drive or axes addresses on ring. • Remove excess axes from ring. • Make sure application program has selected the proper Ring Cycle Period and Baud Rate.




If the SERCOS Ring LED displays:	Then the ring status is:	Take this action:
Solid red light	The module has detected a hardware or installation fault with the ring.	<p>Check your system hardware and installation as follows:</p> <ul style="list-style-type: none"> • Make sure all cables are properly installed. • Make sure cable is of the correct type and length. • Make sure application program has configured the module's ring transmit level to High when using specified cables. • Make sure the drive's transmit levels are set appropriately. • Inspect cables for degradation. • Inspect drives for any faults and correct them.
Off	The module has detected no ring data on its receiver.	<p>Check your system and installation as follows:</p> <ul style="list-style-type: none"> • Make sure all cables are properly installed • Inspect cable for degradation and breakage. • Inspect drives for faults.
Flashing green light	The ring, drive, or axes are not configured.	<p>Not a problem if the system has not been configured. If you are having trouble configuring the ring, drive, and axes:</p> <ul style="list-style-type: none"> • Make sure that the application program is setup properly for the equipment in use.

Specifications and Performance

This appendix shows specifications and performance guidelines for the motion modules.

1756-M02AE Motion Module Specifications

Number of axes per chassis	Configurable
Motion commands	32
Number of axes per module	2 axes maximum
Servo loop	
Type	Nested PI digital position and velocity servo
Gain resolution	32-bit floating point
Absolute position range	$\pm 1,000,000,000$ encoder counts
Rate	5 kHz
Module location	1756 ControlLogix chassis
Module keying	Electronic
Power dissipation	5.5W maximum
Backplane current	5V dc @ 700 mA 24V dc @ 2.5 mA
Encoder input	
Type	Incremental AB quadrature with marker
Mode	4X quadrature
Rate	4 MHz counts per second maximum
Electrical interface	Optically isolated 5V differential
Voltage range	
On state	3.4V to 5.0V
Off state	0V to 1.8V
Input impedance	531 Ohms differential
Registration inputs	
Type	Optically isolated, current sourcing input
24V input voltage	+24V dc nominal
Maximum	26.4V
Minimum on	18.5V
Maximum off	3.5V
5V input voltage	+5V dc nominal
Maximum	5.5V
Minimum on	3.7V
Maximum off	1.5V
Input impedance	
24V input	1.2 kOhms
5V input	9.5 kOhms
Response time (position latched)	1 μ s



All other inputs	
Type	Optically isolated, current sinking input
Input voltage	+24V dc nominal
Maximum	26.4V
Minimum on	17.0V
Maximum off	8.5V
Input impedance	7.5 kOhms
Servo output	
Type	Analog voltage
Isolation	200 kOhms
Voltage range	±10V
Voltage resolution	16 bits
Load	5.6 kOhms resistive minimum
Maximum offset	25 mV
Gain error	±4%
All other outputs	
Type	Solid-state isolated relay contacts
Operating voltage	+24V dc nominal
Maximum	26.4V
Operating current	75 mA
RTB keying	User-defined
Field wiring arm	36-position RTB (1756-TBCH or -TBS6H) ¹
RTB screw torque (cage clamp)	5lb-in. (0.5 Nm) maximum
Conductors	
Wire size	22 gauge (3.1 mm ²) minimum to copper ¹
Category	3/64 inch (1.2 mm) insulation maximum 1,2,3
Screwdriver blade width for RTB	1/8 inch (3.2 mm) maximum
Environmental conditions	
Operating temperature	0 to 60°C (32 to 140°F)
Storage temperature	-40 to 85°C (-40 to 185°F)
Relative humidity	5 to 95% noncondensing
Agency certification (when product or packaging is marked)	  Class 1, Division 2, hazardous location  marked for all applicable directives

¹ Maximum wire size will require the extended depth RTB housing (1756-TBE).

² Use this conductor category information for planning conductor routing as described in the system level installation manual.

³ Refer to *Industrial Automation Wiring and Grounding Guidelines*, publication number 1770-4.1.

1756-M08SE Motion Module Specifications

Number of Nodes	8 axes maximum
Module location	1756 ControlLogix chassis
Module keying	Electronic
Power dissipation	3.2W maximum
Backplane current	5.1V dc @ 600 mA 24V dc @ 2.5 mA
Environmental Specifications Operational Temperature Storage temperature Relative Humidity	0 to 60° C (32-140° F) -40 to 85°C (-40 to 185°F) 5 to 95% non condensing IEC 68-2-30
Shock Operating Non-operating	30g peak acceleration, 11(±2)ms pulse width 50g peak acceleration, 11(±2)ms pulse width
Vibration	2g @ 10-500Hz per IEC 68-2-6
Plastic Fiber Optic Specifications Transmission Range Core Diameter Cladding Diameter Cable Attenuation Operating Temperature Connector Bend Radius	1-32 meters 980µm ± 60µm 1000µm ± 60µm 140 dB/km @ 650nm -55 to 85° C F-SMA standard screw-type connector 2.5 cm
Glass Fiber Optic Specifications Transmission Range Core Diameter Cladding Diameter Cable Attenuation Operating Temperature Connector Bend Radius	1-200 meters 200µm ± 4µm 230µm +0/-10µm 6.0 dB/km @ 820nm -20 to 85° C F-SMA standard screw-type connector 2.5cm
SERCOS SERCOS Class Data Rate Operating cycle	Class B (Position or Velocity) 4 Mbits per second 1 ms for 1-4 axes 2 ms for 5-8 axes
Agency certification (when product or packaging is marked)	<div>  UL508 – Industrial Control Equipment UL1604 – Class I, Division 2, Groups A, B, C, D Hazardous location  marked for all applicable directives </div>

Coarse Update Period Calculations

To calculate the coarse update period for the number axes in your application, you can use the following formula:

$$2 * \left(\text{Baseline task time} + \left[\text{(Actions for axis 1)} + \text{(Actions for axis 2)} + \dots + \text{(Actions for axis n)} \right] \right) = \text{Coarse Update Period}$$

The result of the above calculation must be divided by 1000 rounded up to the nearest milliseconds.

You can use the sample calculation worksheet in this section to determine your coarse update period. To determine the values for your equation, refer to the following table.

The coarse update period can have a significant bearing on the quality of motion control for a given application. If an application requires commanded acceleration or deceleration times that are comparable to the coarse update period, significant velocity and position overshoot can occur as the axis attempts to follow the command profile. The amount of velocity overshoot can be calculated as the product of the acceleration or deceleration rate and the coarse update period. As a general rule of thumb the acceleration and deceleration times for a motion application should be at least 10 times the coarse update period to avoid significant velocity or position overshoot.

For example, an application that requires an axis to accelerate and decelerate to full speed in 100 milliseconds is best handled by choosing a coarse update period of 10 milliseconds or shorter. Be sure to check what the minimum coarse update period is for the associated controller before selecting the coarse update period. The minimum coarse update period can be determined based on the number of axes and the worst case motion activity according to the execution time tables provided.

Understanding Action Timing

Every action performed by an axis requires an amount of motion task time. For example to perform a trapezoidal move requires 310 μ s.

The following table shows execution times for common motion actions.

State/Action (Δ = per axis)	Typical Execution Time (in μs)
Motion Task Overhead	190
Servo Axis Δ	205
Virtual Axis Δ	175
Consumed Axis Δ^*	900*
Servo On Δ	40
Trap Move Δ	310
S-Curve Move Δ	435
Trap Jog Δ	210
S-Curve Jog Δ	340
Gearing (Actual) Δ	290
Clutch Δ	105
Gearing (Command) Δ	125
Clutch Δ	110
Position Camming (Actual,linear) Δ	495
Position Camming (Actual,cubic) Δ	550
Position Camming (Command,linear) Δ	295
Position Camming (Command,cubic) Δ	380
Time Camming (linear) Δ	260
Time Camming (cubic) Δ	320

* The task time of a consumed axis can be lowered to approximately 650 μ s by using a consumer coarse update period that is an integer multiple of the producer coarse update period. The value of 900 μ s reported above is the worst case (producer/consumer update ratio = 2/3). Using 2/4 would yield ~ 650 μ s.

Using the Sample Calculations Worksheet

You can use this sample calculation worksheet to determine the coarse update period for the group in your application.

1. Complete the following table.

System			
Describe the type of system you are using.			
	1	Enter baseline task time = Motion Task Overhead + (# of Servo Axes * Servo Axis Δ) + (# of Virtual Axes * Virtual Axis Δ) + (# of Consumed Axes * Consumed Axis Δ)	μs

2. For each axis in your application, use the following table to determine the action value for each axis.

Actions			
If you are using an action, enter its execution time from the Action Timing table. If you are not using an action, enter zero (0).			
	2	Servo on	μs
	3	Trapezoidal move	μs
	4	S-curve move	μs
	5	Trapezoidal jog	μs
	6	S-curve jog	μs
	7	Actual gear	μs
	8	Command gear	μs
	9	Actual PCAM	μs
	10	Command PCAM	μs
	11	TCAM	μs
	12	Total Axis Action Value (Add lines 2 through 11). Place total here.	μs

3. Calculate the Total Axes Action Value by adding all of the Total Axis Action Values (line 12) for all axes in the group.
4. The Recommended Coarse Update Period is calculated by:

$$(\text{Baseline Task Time}(\text{line 1}) + \text{Total of Axes Action Values}(\text{line 12})) * 2 / 1000$$
 then round up to the milliseconds to get your Recommended Coarse Update Period.

Sample Calculation

You have the following situation:

- You have a system consisting of 2 modules, 3 Servo axes, and 1 virtual axis.
- You are turning the servo on and performing a trapezoidal move for axis1.
- You are turning the servo on and doing an S-Curve jog for axis2.
- Axis3 is a virtual axis and you are doing a command gear for on it.
- You are turning the servo on and doing a cubic command position cam for axis4.

1. Complete the following table.

System Describe the type of system you are using.			
	1	Enter baseline task time = Motion Task Overhead + (3 * Servo Axis) + (1 * Virtual Axis).	980 μ s

2. For each axis in your application, use the following tables to determine the action value for each axis.

Axis 1:

Actions If you are using an action, enter its execution time from the Action Timing table. If you are not using an action, enter zero (0).		
2	Servo on	40 μ s
3	Trapezoidal move	310 μ s
4	S-curve move	0 μ s
5	Trapezoidal jog	0 μ s
6	S-curve jog	0 μ s
7	Actual gear	0 μ s
8	Command gear	0 μ s
9	Actual PCAM	0 μ s
10	Command PCAM	0 μ s
11	TCAM	0 μ s
12	Total Axis Action Value (Add lines 2 through 11).	350 μ s

Axis 2:**Actions**

If you are using an action, enter its execution time from the Action Timing table.
If you are not using an action, enter zero (0).

2	Servo on	40 μ s
3	Trapezoidal move	0 μ s
4	S-curve move	0 μ s
5	Trapezoidal jog	0 μ s
6	S-curve jog	340 μ s
7	Actual gear	0 μ s
8	Command gear	0 μ s
9	Actual PCAM	0 μ s
10	Command PCAM	0 μ s
11	TCAM	0 μ s
12	Total Axis Action Value (Add lines 2 through 11).	380 μ s

Axis 3:**Actions**

If you are using an action, enter its execution time from the Action Timing table.
If you are not using an action, enter zero (0).

2	Servo on	0 μ s
3	Trapezoidal move	0 μ s
4	S-curve move	0 μ s
5	Trapezoidal jog	0 μ s
6	S-curve jog	0 μ s
7	Actual gear	0 μ s
8	Command gear	125 μ s
9	Actual PCAM	0 μ s
10	Command PCAM	0 μ s
11	TCAM	0 μ s
12	Total Axis Action Value (Add lines 2 through 11).	125 μ s

Axes 4:**Actions**

If you are using an action, enter its execution time from the Action Timing table.
If you are not using an action, enter zero (0).

2	Servo on	40 μ s
3	Trapezoidal move	0 μ s
4	S-curve move	0 μ s
5	Trapezoidal jog	0 μ s
6	S-curve jog	0 μ s
7	Actual gear	0 μ s
8	Command gear	0 μ s
9	Actual PCAM	0 μ s
10	Command PCAM	380 μ s
11	TCAM	0 μ s
12	Total Axis Action Value (Add lines 2 through 11).	420 μ s

3. The calculated coarse rate for this application is

Baseline task time (line 2)	980 μ s
Total Axis Action Value for axis 1 (line 12)	350 μ s
Total Axis Action Value for axis 2 (line 12)	380 μ s
Total Axis Action Value for axis 3 (line 12)	125 μ s
Total Axis Action Value for axis 4 (line 12)	420 μ s
Total Axes Action Value (add all of the above)	2255 μ s
TOTAL (Total Axes Action Value * 2)	4510 μ s
Recommended Coarse Update Period = (TOTAL / 1000) rounded up to nearest ms	5 ms

Output Cam Timing For 1756 Controller

The impact on the coarse update period is primarily dependent on three factors:

- total number of output cam array entries
- total number of output compensation array entries
- number of outputs compensation array entries with non-zero latch/unlatch time delay values

The following formulas ballpark additional coarse update time required for each unique Output Cam execution target being used.

In the following formulas:

- A = number of Output Cam array elements
- B = number of Output Compensation array elements
- C = number of Output Compensation array elements with Latch/Unlatch non-zero delay values

All values are expressed in micro-seconds.

For the 1756-L50 Controller

$$1200 + (A * 130) + (B * 140) + (C * 90)$$

For the 1756-L53 Controller

$$1000 + (A * 100) + (B * 110) + (C * 60)$$

Loop and Interconnect Diagrams


This appendix shows the loop interconnect diagrams for common motion configurations.

Understanding Block Diagrams


The control block diagrams in this section use the following terms for motion attributes.

Diagram term	Motion attribute name (as used in the GSV and SSV instructions)
Acc FF Gain	AccelerationFeedforwardGain
Vel FF Gain	VelocityFeedforwardGain
Pos P Gain	PositionProportionalGain
Pos I Gain	PositionIntegralGain
Vel P Gain	VelocityProportionalGain
Vel I Gain	VelocityIntegralGain
Output Filter BW	OutputFilterBandwidth
Output Scaling	OutputScaling
Friction Comp	FrictionCompensation
Output Limit	OutputLimit
Output Offset	OutputOffset
Position Error	PositionError
Position Integrator Error	PositionIntegratorError
Velocity Error	VelocityError
Velocity Integrator Error	VelocityIntegratorError
Velocity Feedback	VelocityFeedback
Velocity Command	VelocityCommand
Servo Output Level	ServoOutputLevel
Registration Position	RegistrationPosition
Watch Position	WatchPosition

Using a 1756-M02AE Module With a Torque Servo Drive




Using a 1756-M02AE Module With a Velocity Servo Drive




Understanding Wiring Diagrams

Wiring to a Servo Module RTB




This is a general wiring example illustrating Axis 1 wiring only. Other configurations are possible with Axis 0 wiring identical to Axis 1.

Wiring to an Ultra 100 Series Drive




This is a general wiring example only. Other configurations are possible. For more information, refer to the Ultra 100 Series Drive Installation Manual, publication number 1398-5.2.

Wiring to an Ultra 200 Series Drive




This is a general wiring example only. Other configurations are possible. For more information, refer to the Ultra 200 Series Drive Installation Manual, publication number 1398-5.0.

1398-CFLAExx Cable Diagram




The 1398-CFLAE Cable is available in 10, 25, and 50 foot lengths.

Pinouts for 1398-CFLAExx Cable



Wiring to a 1394 Servo Drive (in Torque Mode only)




The wiring diagram illustrates Axis 1 wiring only. Other configurations are possible.

The 1394CCAExx cable is wired to connect to torque command reference input pins.

An external +5V power supply is required to power the encoder driver circuit of the 1394 servo drive. Because this connection is shared by all four axis encoder driver circuits, only one connection is needed to the +5V field supply.


The xx in the cable number is the length of the cable. Options are 5, 10, 25, and 50 feet.

The 1394-CFLAExx Cable Wiring Diagram



The 1394-CFLAE cable is available in 1, 3, 8, and 15 meter lengths.


Pinouts for the 1394-CFLAE




Wiring Registration Sensors

The registration inputs to the servo module can support 24V or 5V registration sensors. These inputs should be wired to receive source current from the sensor. Current sinking sensor configurations are not allowed because the registration input common (IN_COM) is shared with the other 24V servo module inputs.

24V Registration Sensor




5V Registration Sensor




Wiring the Home Limit Switch Input

The home limit switch inputs to the servo module are designed for 24V nominal operation. These inputs should be wired for current sourcing operation.



Wiring the OK Contacts

A set of isolated solid-state OK relay contacts is provided for optional interface to an E-stop string, which controls power to the associated drives. The OK contacts are rated to drive an external 24V pilot relay (for example, Allen-Bradley 700-HA32Z24) whose contacts can be incorporated into the E-Stop string as shown below.



The Motion Control Structures

This appendix shows the structures for the AXIS, MOTION_GROUP, MOTION_INSTRUCTION, CAM, and CAM_PROFILE data tags.

AXIS Structures

There are four axis related data types that each have their own structure. The four types are: Axis Consumed, Axis Servo, Axis Servo Drive, and Axis Virtual. The following sections describe the structures for each of these axis data types.

AXIS_CONSUMED Structure

A Consumed Axis is a conduit for axis motion data produced by a motion axis on another Logix processor.

The Axis_Consumed structure has the following status attributes:

Mnemonic:	Data Type:	Description:
MotionStatus	DINT	The motion status bits for your axis.
		Bit: Number: Data Type: Description:
		AccelStatus 00 BOOL Acceleration Status
		DecelStatus 01 BOOL Deceleration Status
		MoveStatus 02 BOOL Move Status
		JogStatus 03 BOOL Jog Status
		GearingStatus 04 BOOL Gearing Status
		HomingStatus 05 BOOL Homing Status
		StoppingStatus 06 BOOL Stopping Status
		AxisHomedStatus 07 BOOL Homed Status
		PositionCamStatus 08 BOOL Position Cam Status
		TimeCamStatus 09 BOOL Time Cam Status
		PositionCamPendingStatus 10 BOOL Position Cam Pending Status
		TimeCamPendingStatus 11 BOOL Time Cam Pending Status
		GearingLockStatus 12 BOOL Gearing Lock Status
		PositionCamLockStatus 13 BOOL Position Cam Lock Status
		TimeCamLockStatus 14 BOOL Time Cam Lock Status
		MasterOffsetMoveStatus 15 BOOL Master Offset Move Status

Mnemonic:	Data Type:	Description:																																				
AxisStatus	DINT	<div>The status bits for your axis</div> <table><tr><td>Bit:</td><td>Number:</td><td>Data Type:</td><td>Description:</td></tr><tr><td>ServoActStatus</td><td>00</td><td>BOOL</td><td>Servo Action Status</td></tr><tr><td>DriveEnableStatus</td><td>01</td><td>BOOL</td><td>Drive Enable Status</td></tr><tr><td>ShutdownStatus</td><td>02</td><td>BOOL</td><td>Axis Shutdown Status</td></tr><tr><td>ConfigUpdateInProgress</td><td>03</td><td>BOOL</td><td>Configuration Update in Process</td></tr></table>	Bit:	Number:	Data Type:	Description:	ServoActStatus	00	BOOL	Servo Action Status	DriveEnableStatus	01	BOOL	Drive Enable Status	ShutdownStatus	02	BOOL	Axis Shutdown Status	ConfigUpdateInProgress	03	BOOL	Configuration Update in Process																
Bit:	Number:	Data Type:	Description:																																			
ServoActStatus	00	BOOL	Servo Action Status																																			
DriveEnableStatus	01	BOOL	Drive Enable Status																																			
ShutdownStatus	02	BOOL	Axis Shutdown Status																																			
ConfigUpdateInProgress	03	BOOL	Configuration Update in Process																																			
AxisFault	DINT	<div>The axis faults for your axis:</div> <table><tr><td>Bit:</td><td>Number:</td><td>Data Type:</td><td>Description:</td></tr><tr><td>PhysicalAxisFault</td><td>00</td><td>BOOL</td><td>Physical Axis Fault</td></tr><tr><td>ModuleFault</td><td>01</td><td>BOOL</td><td>Module Fault</td></tr><tr><td>ConfigFault</td><td>02</td><td>BOOL</td><td>Configuration Fault</td></tr></table>	Bit:	Number:	Data Type:	Description:	PhysicalAxisFault	00	BOOL	Physical Axis Fault	ModuleFault	01	BOOL	Module Fault	ConfigFault	02	BOOL	Configuration Fault																				
Bit:	Number:	Data Type:	Description:																																			
PhysicalAxisFault	00	BOOL	Physical Axis Fault																																			
ModuleFault	01	BOOL	Module Fault																																			
ConfigFault	02	BOOL	Configuration Fault																																			
AxisEvent	DINT	<div>The event status for your axis:</div> <table><tr><td>Bit:</td><td>Number:</td><td>Data Type:</td><td>Description:</td></tr><tr><td>WatchEvArmStatus</td><td>00</td><td>BOOL</td><td>Watch Event Armed Status</td></tr><tr><td>WatchEvStatus</td><td>01</td><td>BOOL</td><td>Watch Event Status</td></tr><tr><td>RegEvArmStatus</td><td>02</td><td>BOOL</td><td>Registration Event 1 Armed Status</td></tr><tr><td>RegEvStatus</td><td>03</td><td>BOOL</td><td>Registration Event 1 Status</td></tr><tr><td>RegEv2ArmStatus</td><td>04</td><td>BOOL</td><td>Registration Event 2 Armed Status</td></tr><tr><td>RegEv2Status</td><td>05</td><td>BOOL</td><td>Registration Event 2 Status</td></tr><tr><td>HomeEvArmStatus</td><td>06</td><td>BOOL</td><td>Home Event Armed Status</td></tr><tr><td>HomeEvStatus</td><td>07</td><td>BOOL</td><td>Home Event Status</td></tr></table>	Bit:	Number:	Data Type:	Description:	WatchEvArmStatus	00	BOOL	Watch Event Armed Status	WatchEvStatus	01	BOOL	Watch Event Status	RegEvArmStatus	02	BOOL	Registration Event 1 Armed Status	RegEvStatus	03	BOOL	Registration Event 1 Status	RegEv2ArmStatus	04	BOOL	Registration Event 2 Armed Status	RegEv2Status	05	BOOL	Registration Event 2 Status	HomeEvArmStatus	06	BOOL	Home Event Armed Status	HomeEvStatus	07	BOOL	Home Event Status
Bit:	Number:	Data Type:	Description:																																			
WatchEvArmStatus	00	BOOL	Watch Event Armed Status																																			
WatchEvStatus	01	BOOL	Watch Event Status																																			
RegEvArmStatus	02	BOOL	Registration Event 1 Armed Status																																			
RegEvStatus	03	BOOL	Registration Event 1 Status																																			
RegEv2ArmStatus	04	BOOL	Registration Event 2 Armed Status																																			
RegEv2Status	05	BOOL	Registration Event 2 Status																																			
HomeEvArmStatus	06	BOOL	Home Event Armed Status																																			
HomeEvStatus	07	BOOL	Home Event Status																																			
ActualPosition	REAL	Actual Position in Position Units																																				
StrobeActualPosition	REAL	Strobe Actual Position in Position Units																																				
StartActualPosition	REAL	Start Actual Position in Position Units																																				
AverageVelocity	REAL	Average Velocity in Position Units / Sec																																				
ActualVelocity	REAL	Actual Velocity in Position Units / Sec																																				
ActualAcceleration	REAL	Actual Acceleration in Position Units / Sec2																																				
WatchPosition	REAL	Watch Position in Position Units																																				
RegistrationPosition	REAL	Registration 1 Position in Position Units																																				
Registration2Position	REAL	Registration 2 Position in Position Units																																				
Registration1Time	DINT	Registration 1 Time as CST time in microseconds																																				
Registration2Time	DINT	Registration 2 Time as CST time in microseconds																																				
InterpolationTime	DINT	Interpolation Time as CST time in microseconds																																				
InterpolatedActualPosition	REAL	Interpolated Actual Position in Position Units																																				
MasterOffset	REAL	Master Offset in Master Position Units																																				
StrobeMasterOffset	REAL	Strobe Master Offset in Master Position Units																																				
StartMasterOffset	REAL	Start Master Offset in Master Position Units																																				
CommandPosition	REAL	Command Position in Position Units																																				
StrobeCommandPosition	REAL	Strobe Command Position in Position Units																																				
StartCommandPosition	REAL	Start Command Position in Position Units																																				
CommandVelocity	REAL	Command Velocity in Position Units / Sec																																				

Mnemonic:	Data Type:	Description:
CommandAcceleration	REAL	Command Acceleration in Position Units / Sec ²
InterpolatedCommandPosition	REAL	Interpolated Command Position in Position Units
AccelStatus	BOOL	Set if the axis is currently being commanded to accelerate.
DecelStatus	BOOL	Set if the axis is currently being commanded to decelerate.
MoveStatus	BOOL	Set if a Move motion profile is currently in progress. Cleared when the Move is complete or is superseded by some other motion operation.
JogStatus	BOOL	Set if a Jog motion profile is currently in progress. Cleared when the Jog is complete or is superseded by some other motion operation.
GearingStatus	BOOL	Set if the axis is a slave that is currently Gearing to another axis. Cleared when the gearing operation is stopped or is superseded by some other motion operation.
HomingStatus	BOOL	Set if a Home motion profile is currently in progress. Cleared when the homing operation is stopped or is superseded by some other motion operation.
StoppingStatus	BOOL	Set if there is a stopping process currently in progress. Cleared when the stopping process is complete. Note: The stopping process is used to stop an axis (initiated by an MAS, MGS, Stop Motion fault action, or mode change).
AxisHomedStatus	BOOL	Cleared at power-up or reconnection. Set by the MAH instruction upon successful completion of the configured homing sequence, and later cleared when the axis enters the shutdown state.
PositionCamStatus	BOOL	Set if a Position Cam motion profile is currently in progress. Cleared when the Position Cam is complete or is superseded by some other motion operation.
TimeCamStatus	BOOL	Set if a Time Cam motion profile is currently in progress. Cleared when the Time Cam is complete or is superseded by some other motion operation.
PositionCamPendingStatus	BOOL	Set if a Position Cam motion profile is currently pending the completion of a currently executing cam profile. This would be initiated by executing an MAPC instruction with Pending execution selected. This bit is cleared when the current position cam profile completes, initiating the start of the pending cam profile. This bit is also cleared if the position cam profile completes, or is superseded by some other motion operation.
TimeCamPendingStatus	BOOL	Set if a Time Cam motion profile is currently pending the completion of a currently executing cam profile. This would be initiated by executing an MATC instruction with Pending execution selected. This bit is cleared when the current time cam profile completes, initiating the start of the pending cam profile. This bit is also cleared if the time cam profile completes, or is superseded by some other motion operation.
GearingLockStatus	BOOL	Set whenever the slave axis is locked to the master axis in a gearing relationship according to the specified gear ratio. The clutch function of the gearing planner is used to ramp an axis up, or down, to speed in a gearing process (MAG with Clutch selected). This bit is cleared during the intervals where the axis is clutching.
PositionCamLockStatus	BOOL	Set whenever the master axis satisfies the starting condition of a currently active Position Cam motion profile. The starting condition is established by the Start Control and Start Position parameters of the MAPC instruction. This bit is cleared when the current position cam profile completes, or is superseded by some other motion operation. In uni-directional master direction mode, the Position Cam Lock Status bit is cleared when moving in the "wrong" direction and sets when moving in the "correct" direction.
MasterOffsetMoveStatus	BOOL	Set if a Master Offset Move motion profile is currently in progress. This bit is cleared when the Master Offset Move is complete or is superseded by some other motion operation.
ServoActStatus	BOOL	Set when the associated axis is under servo control. Cleared when servo action is disabled.

Mnemonic:	Data Type:	Description:
DriveEnableStatus	BOOL	Set when the Drive Enable output of the associated physical axis is currently enabled. Cleared when physical servo axis Drive Enable output is currently disabled.
ShutdownStatus	BOOL	Set when the associated axis is currently in the Shutdown state. Cleared when the axis is transitioned from the Shutdown state to another state.
ConfigUpdateInProgress	BOOL	The Configuration Update Status Bits attribute provides a method for monitoring the progress of one or more specific module configuration attribute updates initiated by either a Set Attribute List service (which is internal to the firmware) or an SSV in the user program. When such an update is initiated, the ControlLogix processor sets this bit. This bit will remain set until the Set Attribute List reply comes back from the servo module indicating that the data update process was successful. Thus the Configuration Update Status Bits attribute provides a method of waiting until the servo configuration data update to the connected motion module is complete before starting a dependent operation.
PhysicalAxisFault	BOOL	Set when one or more fault conditions have been reported by the physical axis. The specific fault conditions can then be determined through access to the fault attributes of the associated physical axis. A PhysicalAxisFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
ModuleFault	DINT	Set when a serious fault has occurred with the motion module associated with the selected axis. Usually a module fault affects all axes associated with the motion module. A module fault generally results in the shutdown of all associated axes. Reconfiguration of the motion module is required to recover from a module fault condition. A ModuleFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
ConfigFault	BOOL	Set when an update operation targeting an axis configuration attribute of an associated motion module has failed. Specific information concerning the Configuration Fault may be found in the Attribute Error Code and Attribute Error ID attributes associated with the motion module. A ConfigFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
ControlSyncFault	BOOL	Set when the Logix controller detects that several position update messages in a row from the motion module have been missed due to a failure of the synchronous communications connection. This condition results in the automatic shutdown of the associated servo module. The Logix controller is designed to "ride-through" a maximum of four missed position updates without issuing a fault or adversely affecting motion in progress. Missing more than four position updates in a row constitutes a problematic condition that warrants shutdown of the servo module. This fault bit is cleared when the connection is reestablished.
WatchEvArmStatus	BOOL	Set when a watch event has been armed through execution of the MAW (Motion Arm Watch) instruction. Cleared when either a watch event occurs or a MDW (Motion Disarm Watch) instruction is executed.
WatchEvStatus	BOOL	Set when a watch event has occurred. Cleared when either another MAW (Motion Arm Watch) instruction or a MDW (Motion Disarm Watch) instruction is executed.
RegEvArmStatus	BOOL	Set when a registration checking has been armed for registration input 1 through execution of the MAR (Motion Arm Registration) instruction. Cleared when either a registration event occurs or a MDR (Motion Disarm Registration) instruction is executed for registration input 1.
RegEvStatus	BOOL	Set when a registration event has occurred on registration input 1. Cleared when either another MAR (Motion Arm Registration) instruction or a MDR (Motion Disarm Registration) instruction is executed for registration input 1.
RegEv2ArmStatus	BOOL	Set when a registration checking has been armed for registration input 2 through execution of the MAR (Motion Arm Registration) instruction. Cleared when either a registration event occurs or a MDR (Motion Disarm Registration) instruction is executed for registration input 2.

Mnemonic:	Data Type:	Description:
RegEv2Status	BOOL	Set when a registration event has occurred on registration input 2. Cleared when either another MAR (Motion Arm Registration) instruction or a MDR (Motion Disarm Registration) instruction is executed for registration input 2.
HomeEvArmStatus	BOOL	Set when a home event has been armed through execution of the MAH (Motion Axis Home) instruction. Cleared when a home event occurs.
HomeEvStatus	BOOL	Set when a home event has occurred. Cleared when another MAH (Motion Axis Home) instruction is executed.
OutputCamStatus	DINT	A set of bits* that are set when the Output Cam has been initiated.
OutputCamPendingStatus	DINT	A set of bits* that are set when an Output Cam is waiting for an armed Output Cam to move beyond its cam start/cam end position.
OutputCamLockStatus	DINT	A set of bits* that are set when an Output Cam is locked to the Master Axis.
OutputCamTransitionStatus	DINT	A set of bits* that are set when the transition from the current armed Output Cam to the pending Output Cam is in process.
* The bit number corresponds with the execution target number. One bit per execution target.		

AXIS_SERVO Structure

A servo object represents an axis with full motion planner functionality and integrated configuration support. It is associated with modules that close a servo loop and send an analog command to an external drive, such as a 1756-M02AE module.

The AXIS_SERVO structure contains and following status attributes.

Mnemonic:	Data Type:	Description:																																																																				
MotionStatus	DINT	The motion status bits for your axis.																																																																				
<table><tr><th>Bit:</th><th>Number:</th><th>Data Type:</th><th>Description:</th></tr><tr><td>AccelStatus</td><td>00</td><td>BOOL</td><td>Acceleration Status</td></tr><tr><td>DecelStatus</td><td>01</td><td>BOOL</td><td>Deceleration Status</td></tr><tr><td>MoveStatus</td><td>02</td><td>BOOL</td><td>Move Status</td></tr><tr><td>JogStatus</td><td>03</td><td>BOOL</td><td>Jog Status</td></tr><tr><td>GearingStatus</td><td>04</td><td>BOOL</td><td>Gearing Status</td></tr><tr><td>HomingStatus</td><td>05</td><td>BOOL</td><td>Homing Status</td></tr><tr><td>StoppingStatus</td><td>06</td><td>BOOL</td><td>Stopping Status</td></tr><tr><td>AxisHomedStatus</td><td>07</td><td>BOOL</td><td>Homed Status</td></tr><tr><td>PositionCamStatus</td><td>08</td><td>BOOL</td><td>Position Cam Status</td></tr><tr><td>TimeCamStatus</td><td>09</td><td>BOOL</td><td>Time Cam Status</td></tr><tr><td>PositionCamPendingStatus</td><td>10</td><td>BOOL</td><td>Position Cam Pending Status</td></tr><tr><td>TimeCamPendingStatus</td><td>11</td><td>BOOL</td><td>Time Cam Pending Status</td></tr><tr><td>GearingLockStatus</td><td>12</td><td>BOOL</td><td>Gearing Lock Status</td></tr><tr><td>PositionCamLockStatus</td><td>13</td><td>BOOL</td><td>Position Cam Lock Status</td></tr><tr><td>TimeCamLockStatus</td><td>14</td><td>BOOL</td><td>Time Cam Lock Status</td></tr><tr><td>MasterOffsetMoveStatus</td><td>15</td><td>BOOL</td><td>Master Offset Move Status</td></tr></table>			Bit:	Number:	Data Type:	Description:	AccelStatus	00	BOOL	Acceleration Status	DecelStatus	01	BOOL	Deceleration Status	MoveStatus	02	BOOL	Move Status	JogStatus	03	BOOL	Jog Status	GearingStatus	04	BOOL	Gearing Status	HomingStatus	05	BOOL	Homing Status	StoppingStatus	06	BOOL	Stopping Status	AxisHomedStatus	07	BOOL	Homed Status	PositionCamStatus	08	BOOL	Position Cam Status	TimeCamStatus	09	BOOL	Time Cam Status	PositionCamPendingStatus	10	BOOL	Position Cam Pending Status	TimeCamPendingStatus	11	BOOL	Time Cam Pending Status	GearingLockStatus	12	BOOL	Gearing Lock Status	PositionCamLockStatus	13	BOOL	Position Cam Lock Status	TimeCamLockStatus	14	BOOL	Time Cam Lock Status	MasterOffsetMoveStatus	15	BOOL	Master Offset Move Status
Bit:	Number:	Data Type:	Description:																																																																			
AccelStatus	00	BOOL	Acceleration Status																																																																			
DecelStatus	01	BOOL	Deceleration Status																																																																			
MoveStatus	02	BOOL	Move Status																																																																			
JogStatus	03	BOOL	Jog Status																																																																			
GearingStatus	04	BOOL	Gearing Status																																																																			
HomingStatus	05	BOOL	Homing Status																																																																			
StoppingStatus	06	BOOL	Stopping Status																																																																			
AxisHomedStatus	07	BOOL	Homed Status																																																																			
PositionCamStatus	08	BOOL	Position Cam Status																																																																			
TimeCamStatus	09	BOOL	Time Cam Status																																																																			
PositionCamPendingStatus	10	BOOL	Position Cam Pending Status																																																																			
TimeCamPendingStatus	11	BOOL	Time Cam Pending Status																																																																			
GearingLockStatus	12	BOOL	Gearing Lock Status																																																																			
PositionCamLockStatus	13	BOOL	Position Cam Lock Status																																																																			
TimeCamLockStatus	14	BOOL	Time Cam Lock Status																																																																			
MasterOffsetMoveStatus	15	BOOL	Master Offset Move Status																																																																			

Mnemonic:	Data Type:	Description:																																				
AxisStatus	DINT	<div>The status bits for your axis</div> <table><tr><th>Bit:</th><th>Number:</th><th>Data Type:</th><th>Description:</th></tr><tr><td>ServoActStatus</td><td>00</td><td>BOOL</td><td>Servo Action Status</td></tr><tr><td>DriveEnableStatus</td><td>01</td><td>BOOL</td><td>Drive Enable Status</td></tr><tr><td>ShutdownStatus</td><td>02</td><td>BOOL</td><td>Axis Shutdown Status</td></tr><tr><td>ConfigUpdateInProgress</td><td>03</td><td>BOOL</td><td>Configuration Update in Process</td></tr></table>	Bit:	Number:	Data Type:	Description:	ServoActStatus	00	BOOL	Servo Action Status	DriveEnableStatus	01	BOOL	Drive Enable Status	ShutdownStatus	02	BOOL	Axis Shutdown Status	ConfigUpdateInProgress	03	BOOL	Configuration Update in Process																
Bit:	Number:	Data Type:	Description:																																			
ServoActStatus	00	BOOL	Servo Action Status																																			
DriveEnableStatus	01	BOOL	Drive Enable Status																																			
ShutdownStatus	02	BOOL	Axis Shutdown Status																																			
ConfigUpdateInProgress	03	BOOL	Configuration Update in Process																																			
AxisFault	DINT	<div>The axis faults for your axis:</div> <table><tr><th>Bit:</th><th>Number:</th><th>Data Type:</th><th>Description:</th></tr><tr><td>PhysicalAxisFault</td><td>00</td><td>BOOL</td><td>Physical Axis Fault</td></tr><tr><td>ModuleFault</td><td>01</td><td>BOOL</td><td>Module Fault</td></tr><tr><td>ConfigFault</td><td>02</td><td>BOOL</td><td>Configuration Fault</td></tr></table>	Bit:	Number:	Data Type:	Description:	PhysicalAxisFault	00	BOOL	Physical Axis Fault	ModuleFault	01	BOOL	Module Fault	ConfigFault	02	BOOL	Configuration Fault																				
Bit:	Number:	Data Type:	Description:																																			
PhysicalAxisFault	00	BOOL	Physical Axis Fault																																			
ModuleFault	01	BOOL	Module Fault																																			
ConfigFault	02	BOOL	Configuration Fault																																			
AxisEvent	DINT	<div>The event status for your axis:</div> <table><tr><th>Bit:</th><th>Number:</th><th>Data Type:</th><th>Description:</th></tr><tr><td>WatchEvArmStatus</td><td>00</td><td>BOOL</td><td>Watch Event Armed Status</td></tr><tr><td>WatchEvStatus</td><td>01</td><td>BOOL</td><td>Watch Event Status</td></tr><tr><td>RegEvArmStatus</td><td>02</td><td>BOOL</td><td>Registration Event 1 Armed Status</td></tr><tr><td>RegEvStatus</td><td>03</td><td>BOOL</td><td>Registration Event 1 Status</td></tr><tr><td>RegEv2ArmStatus</td><td>04</td><td>BOOL</td><td>Registration Event 2 Armed Status</td></tr><tr><td>RegEv2Status</td><td>05</td><td>BOOL</td><td>Registration Event 2 Status</td></tr><tr><td>HomeEvArmStatus</td><td>06</td><td>BOOL</td><td>Home Event Armed Status</td></tr><tr><td>HomeEvStatus</td><td>07</td><td>BOOL</td><td>Home Event Status</td></tr></table>	Bit:	Number:	Data Type:	Description:	WatchEvArmStatus	00	BOOL	Watch Event Armed Status	WatchEvStatus	01	BOOL	Watch Event Status	RegEvArmStatus	02	BOOL	Registration Event 1 Armed Status	RegEvStatus	03	BOOL	Registration Event 1 Status	RegEv2ArmStatus	04	BOOL	Registration Event 2 Armed Status	RegEv2Status	05	BOOL	Registration Event 2 Status	HomeEvArmStatus	06	BOOL	Home Event Armed Status	HomeEvStatus	07	BOOL	Home Event Status
Bit:	Number:	Data Type:	Description:																																			
WatchEvArmStatus	00	BOOL	Watch Event Armed Status																																			
WatchEvStatus	01	BOOL	Watch Event Status																																			
RegEvArmStatus	02	BOOL	Registration Event 1 Armed Status																																			
RegEvStatus	03	BOOL	Registration Event 1 Status																																			
RegEv2ArmStatus	04	BOOL	Registration Event 2 Armed Status																																			
RegEv2Status	05	BOOL	Registration Event 2 Status																																			
HomeEvArmStatus	06	BOOL	Home Event Armed Status																																			
HomeEvStatus	07	BOOL	Home Event Status																																			
ActualPosition	REAL	Actual Position in Position Units																																				
StrobeActualPosition	REAL	Strobe Actual Position in Position Units																																				
StartActualPosition	REAL	Start Actual Position in Position Units																																				
AverageVelocity	REAL	Average Velocity in Position Units / Sec																																				
ActualVelocity	REAL	Actual Velocity in Position Units / Sec																																				
ActualAcceleration	REAL	Actual Acceleration in Position Units / Sec2																																				
WatchPosition	REAL	Watch Position in Position Units																																				
RegistrationPosition	REAL	Registration 1 Position in Position Units																																				
Registration2Position	REAL	Registration 2 Position in Position Units																																				
Registration1Time	DINT	Registration 1 Time as CST time in microseconds																																				
Registration2Time	DINT	Registration 2 Time as CST time in microseconds																																				
InterpolationTime	DINT	Interpolation Time as CST time in microseconds																																				
InterpolatedActualPosition	REAL	Interpolated Actual Position in Position Units																																				
MasterOffset	REAL	Master Offset in Master Position Units																																				
StrobeMasterOffset	REAL	Strobe Master Offset in Master Position Units																																				
StartMasterOffset	REAL	Start Master Offset in Master Position Units																																				
CommandPosition	REAL	Command Position in Position Units																																				
StrobeCommandPosition	REAL	Strobe Command Position in Position Units																																				
StartCommandPosition	REAL	Start Command Position in Position Units																																				
CommandVelocity	REAL	Command Velocity in Position Units / Sec																																				

Mnemonic:	Data Type:	Description:																																																				
CommandAcceleration	REAL	Command Acceleration in Position Units / Sec2																																																				
InterpolatedCommandPosition	REAL	Interpolated Command Position in Position Units																																																				
ServoStatus	DINT	<div>The status bits for your servo loop:</div> <table><tr><th>Bit:</th><th>Number:</th><th>Data Type:</th><th>Description:</th></tr><tr><td>- no tag -</td><td>00</td><td>BOOL</td><td>Servo Action Status</td></tr><tr><td>- no tag -</td><td>01</td><td>BOOL</td><td>Drive Enable Status</td></tr><tr><td>- no tag -</td><td>02</td><td>BOOL</td><td>Axis Shutdown Status</td></tr><tr><td>ProcessStatus</td><td>03</td><td>BOOL</td><td>Process Status</td></tr><tr><td>OutLmtStatus</td><td>04</td><td>BOOL</td><td>Output Limit Status</td></tr><tr><td>PosLockStatus</td><td>05</td><td>BOOL</td><td>Position Lock Status</td></tr><tr><td>HomeSwitchStatus</td><td>06</td><td>BOOL</td><td>Home Input Status</td></tr><tr><td>Reg1InputStatus</td><td>07</td><td>BOOL</td><td>Registration 1 Input Status</td></tr><tr><td>Reg2InputStatus</td><td>08</td><td>BOOL</td><td>Registration 12Input Status</td></tr><tr><td>PosOvertravellInputStatus</td><td>09</td><td>BOOL</td><td>Positive Overtravel Input Status</td></tr><tr><td>NegOvertravellInputStatus</td><td>10</td><td>BOOL</td><td>Negative Overtravel Input Status</td></tr><tr><td>DriveFaultInputStatus</td><td>11</td><td>BOOL</td><td>Drive Fault Input Status</td></tr></table>	Bit:	Number:	Data Type:	Description:	- no tag -	00	BOOL	Servo Action Status	- no tag -	01	BOOL	Drive Enable Status	- no tag -	02	BOOL	Axis Shutdown Status	ProcessStatus	03	BOOL	Process Status	OutLmtStatus	04	BOOL	Output Limit Status	PosLockStatus	05	BOOL	Position Lock Status	HomeSwitchStatus	06	BOOL	Home Input Status	Reg1InputStatus	07	BOOL	Registration 1 Input Status	Reg2InputStatus	08	BOOL	Registration 12Input Status	PosOvertravellInputStatus	09	BOOL	Positive Overtravel Input Status	NegOvertravellInputStatus	10	BOOL	Negative Overtravel Input Status	DriveFaultInputStatus	11	BOOL	Drive Fault Input Status
Bit:	Number:	Data Type:	Description:																																																			
- no tag -	00	BOOL	Servo Action Status																																																			
- no tag -	01	BOOL	Drive Enable Status																																																			
- no tag -	02	BOOL	Axis Shutdown Status																																																			
ProcessStatus	03	BOOL	Process Status																																																			
OutLmtStatus	04	BOOL	Output Limit Status																																																			
PosLockStatus	05	BOOL	Position Lock Status																																																			
HomeSwitchStatus	06	BOOL	Home Input Status																																																			
Reg1InputStatus	07	BOOL	Registration 1 Input Status																																																			
Reg2InputStatus	08	BOOL	Registration 12Input Status																																																			
PosOvertravellInputStatus	09	BOOL	Positive Overtravel Input Status																																																			
NegOvertravellInputStatus	10	BOOL	Negative Overtravel Input Status																																																			
DriveFaultInputStatus	11	BOOL	Drive Fault Input Status																																																			
ServoFault	DINT	<div>The servo fault bits for your servo loop:</div> <table><tr><th>Bit:</th><th>Number:</th><th>Data Type:</th><th>Description:</th></tr><tr><td>POtrvIFault</td><td>00</td><td>BOOL</td><td>Positive Software Overtravel Fault</td></tr><tr><td>NOtrvIFault</td><td>01</td><td>BOOL</td><td>Negative Software Overtravel Fault</td></tr><tr><td>PosHardOvertravelFault</td><td>02</td><td>BOOL</td><td>Positive Hardware Overtravel Fault</td></tr><tr><td>NegHardOvertravelFault</td><td>03</td><td>BOOL</td><td>Negative Hardware Overtravel Fault</td></tr><tr><td>FeedbackFault</td><td>04</td><td>BOOL</td><td>Feedback Fault</td></tr><tr><td>FeedbackNoiseFault</td><td>05</td><td>BOOL</td><td>Feedback Noise Fault</td></tr><tr><td>AuxFeedbackFault</td><td>06</td><td>BOOL</td><td>Auxiliary Feedback Fault</td></tr><tr><td>AuxFeedbackNoiseFault</td><td>07</td><td>BOOL</td><td>Auxiliary Feedback Noise Fault</td></tr><tr><td>PosErrorFault</td><td>08</td><td>BOOL</td><td>Position Error Fault</td></tr><tr><td>DriveFault</td><td>09</td><td>BOOL</td><td>Drive Fault</td></tr></table>	Bit:	Number:	Data Type:	Description:	POtrvIFault	00	BOOL	Positive Software Overtravel Fault	NOtrvIFault	01	BOOL	Negative Software Overtravel Fault	PosHardOvertravelFault	02	BOOL	Positive Hardware Overtravel Fault	NegHardOvertravelFault	03	BOOL	Negative Hardware Overtravel Fault	FeedbackFault	04	BOOL	Feedback Fault	FeedbackNoiseFault	05	BOOL	Feedback Noise Fault	AuxFeedbackFault	06	BOOL	Auxiliary Feedback Fault	AuxFeedbackNoiseFault	07	BOOL	Auxiliary Feedback Noise Fault	PosErrorFault	08	BOOL	Position Error Fault	DriveFault	09	BOOL	Drive Fault								
Bit:	Number:	Data Type:	Description:																																																			
POtrvIFault	00	BOOL	Positive Software Overtravel Fault																																																			
NOtrvIFault	01	BOOL	Negative Software Overtravel Fault																																																			
PosHardOvertravelFault	02	BOOL	Positive Hardware Overtravel Fault																																																			
NegHardOvertravelFault	03	BOOL	Negative Hardware Overtravel Fault																																																			
FeedbackFault	04	BOOL	Feedback Fault																																																			
FeedbackNoiseFault	05	BOOL	Feedback Noise Fault																																																			
AuxFeedbackFault	06	BOOL	Auxiliary Feedback Fault																																																			
AuxFeedbackNoiseFault	07	BOOL	Auxiliary Feedback Noise Fault																																																			
PosErrorFault	08	BOOL	Position Error Fault																																																			
DriveFault	09	BOOL	Drive Fault																																																			
ServoModuleFault	DINT	<table><tr><th>Bit:</th><th>Number:</th><th>Data Type:</th><th>Description:</th></tr><tr><td>ControlSyncFault</td><td>00</td><td>BOOL</td><td>Control Sync Fault</td></tr><tr><td>ModuleSyncFault</td><td>01</td><td>BOOL</td><td>Module Sync Fault</td></tr><tr><td>TimerEventFault</td><td>02</td><td>BOOL</td><td>Timer Event Fault</td></tr><tr><td>ModuleHardwareFault</td><td>03</td><td>BOOL</td><td>Module Hardware Fault</td></tr></table>	Bit:	Number:	Data Type:	Description:	ControlSyncFault	00	BOOL	Control Sync Fault	ModuleSyncFault	01	BOOL	Module Sync Fault	TimerEventFault	02	BOOL	Timer Event Fault	ModuleHardwareFault	03	BOOL	Module Hardware Fault																																
Bit:	Number:	Data Type:	Description:																																																			
ControlSyncFault	00	BOOL	Control Sync Fault																																																			
ModuleSyncFault	01	BOOL	Module Sync Fault																																																			
TimerEventFault	02	BOOL	Timer Event Fault																																																			
ModuleHardwareFault	03	BOOL	Module Hardware Fault																																																			
AttributeErrorCode	INT	ASA Error code returned by erred set attribute list service to the module.																																																				
AttributeErrorID	INT	Attribute ID associated with non-zero Attribute Error Code.																																																				
PositionCommand	REAL	Position Command in Position Units																																																				
PositionFeedback	REAL	Position Feedback in Position Units																																																				
AuxPositionFeedback	REAL	Auxiliary Position Feedback in Position Units																																																				
PositionError	REAL	Position Error in Position Units																																																				
PositionIntegratorError	REAL	Position Integrator Error in Position Units - mSec																																																				
VelocityCommand	REAL	Velocity Command in Position Units / Sec																																																				
VelocityFeedback	REAL	Velocity Feedback in Position Units / Sec																																																				
VelocityError	REAL	Velocity Error in Position Units / Sec																																																				
VelocityIntegratorError	REAL	Velocity Integrator Error in Position Units – mSec / Sec																																																				
AccelerationCommand	REAL	Acceleration Command in Position Units / Sec2																																																				

Mnemonic:	Data Type:	Description:
AccelerationFeedback	REAL	Acceleration Feedback in Position Units / Sec ²
ServoOutputLevel	REAL	Servo Output Level in Volts
MarkerDistance	REAL	Marker Distance in Position Units
VelocityOffset	REAL	Velocity Offset in Position Units / Sec
TorqueOffset	REAL	Torque Offset from –100% to +100%
AccelStatus	BOOL	Set if the axis is currently being commanded to accelerate.
DecelStatus	BOOL	Set if the axis is currently being commanded to decelerate.
MoveStatus	BOOL	Set if a Move motion profile is currently in progress. Cleared when the Move is complete or is superseded by some other motion operation.
JogStatus	BOOL	Set if a Jog motion profile is currently in progress. Cleared when the Jog is complete or is superseded by some other motion operation.
GearingStatus	BOOL	Set if the axis is a slave that is currently Gearing to another axis. Cleared when the gearing operation is stopped or is superseded by some other motion operation.
HomingStatus	BOOL	Set if a Home motion profile is currently in progress. Cleared when the homing operation is stopped or is superseded by some other motion operation.
StoppingStatus	BOOL	Set if there is a stopping process currently in progress. Cleared when the stopping process is complete. Note: The stopping process is used to stop an axis (initiated by an MAS, MGS, Stop Motion fault action, or mode change).
AxisHomedStatus	BOOL	Cleared at power-up or reconnection. Set by the MAH instruction upon successful completion of the configured homing sequence, and later cleared when the axis enters the shutdown state.
PositionCamStatus	BOOL	Set if a Position Cam motion profile is currently in progress. Cleared when the Position Cam is complete or is superseded by some other motion operation.
TimeCamStatus	BOOL	Set if a Time Cam motion profile is currently in progress. Cleared when the Time Cam is complete or is superseded by some other motion operation.
PositionCamPendingStatus	BOOL	Set if a Position Cam motion profile is currently pending the completion of a currently executing cam profile. This would be initiated by executing an MAPC instruction with Pending execution selected. This bit is cleared when the current position cam profile completes, initiating the start of the pending cam profile. This bit is also cleared if the position cam profile completes, or is superseded by some other motion operation.
TimeCamPendingStatus	BOOL	Set if a Time Cam motion profile is currently pending the completion of a currently executing cam profile. This would be initiated by executing an MATC instruction with Pending execution selected. This bit is cleared when the current time cam profile completes, initiating the start of the pending cam profile. This bit is also cleared if the time cam profile completes, or is superseded by some other motion operation.
GearingLockStatus	BOOL	Set whenever the slave axis is locked to the master axis in a gearing relationship according to the specified gear ratio. The clutch function of the gearing planner is used to ramp an axis up, or down, to speed in a gearing process (MAG with Clutch selected). This bit is cleared during the intervals where the axis is clutching.
PositionCamLockStatus	BOOL	Set whenever the master axis satisfies the starting condition of a currently active Position Cam motion profile. The starting condition is established by the Start Control and Start Position parameters of the MAPC instruction. This bit is cleared when the current position cam profile completes, or is superseded by some other motion operation. In uni-directional master direction mode, the Position Cam Lock Status bit is cleared when moving in the “wrong” direction and sets when moving in the “correct” direction.

Mnemonic:	Data Type:	Description:
MasterOffsetMoveStatus	BOOL	Set if a Master Offset Move motion profile is currently in progress. This bit is cleared when the Master Offset Move is complete or is superseded by some other motion operation.
ServoActStatus	BOOL	Set when the associated axis is under servo control. Cleared when servo action is disabled.
DriveEnableStatus	BOOL	Set when the Drive Enable output of the associated physical axis is currently enabled. Cleared when physical servo axis Drive Enable output is currently disabled.
ShutdownStatus	BOOL	Set when the associated axis is currently in the Shutdown state. Cleared when the axis is transitioned from the Shutdown state to another state.
ConfigUpdateInProgress	BOOL	The Configuration Update Status Bits attribute provides a method for monitoring the progress of one or more specific module configuration attribute updates initiated by either a Set Attribute List service (which is internal to the firmware) or an SSV in the user program. When such an update is initiated, the ControlLogix processor sets this bit. This bit will remain set until the Set Attribute List reply comes back from the servo module indicating that the data update process was successful. Thus the Configuration Update Status Bits attribute provides a method of waiting until the servo configuration data update to the connected motion module is complete before starting a dependent operation.
PhysicalAxisFault	BOOL	Set when one or more fault conditions have been reported by the physical axis. The specific fault conditions can then be determined through access to the fault attributes of the associated physical axis. A PhysicalAxisFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
ModuleFault	BOOL	Set when a serious fault has occurred with the motion module associated with the selected axis. Usually a module fault affects all axes associated with the motion module. A module fault generally results in the shutdown of all associated axes. Reconfiguration of the motion module is required to recover from a module fault condition. A ModuleFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
ConfigFault	BOOL	Set when an update operation targeting an axis configuration attribute of an associated motion module has failed. Specific information concerning the Configuration Fault may be found in the Attribute Error Code and Attribute Error ID attributes associated with the motion module. A ConfigFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
WatchEvArmStatus	BOOL	Set when a watch event has been armed through execution of the MAW (Motion Arm Watch) instruction. Cleared when either a watch event occurs or a MDW (Motion Disarm Watch) instruction is executed.
WatchEvStatus	BOOL	Set when a watch event has occurred. Cleared when either another MAW (Motion Arm Watch) instruction or a MDW (Motion Disarm Watch) instruction is executed.
RegEvArmStatus	BOOL	Set when a registration checking has been armed for registration input 1 through execution of the MAR (Motion Arm Registration) instruction. Cleared when either a registration event occurs or a MDR (Motion Disarm Registration) instruction is executed for registration input 1.
RegEvStatus	BOOL	Set when a registration event has occurred on registration input 1. Cleared when either another MAR (Motion Arm Registration) instruction or a MDR (Motion Disarm Registration) instruction is executed for registration input 1.
RegEv2ArmStatus	BOOL	Set when a registration checking has been armed for registration input 2 through execution of the MAR (Motion Arm Registration) instruction. Cleared when either a registration event occurs or a MDR (Motion Disarm Registration) instruction is executed for registration input 2.
RegEv2Status	BOOL	Set when a registration event has occurred on registration input 2. Cleared when either another MAR (Motion Arm Registration) instruction or a MDR (Motion Disarm Registration) instruction is executed for registration input 2.

Mnemonic:	Data Type:	Description:
HomeEvArmStatus	BOOL	Set when a home event has been armed through execution of the MAH (Motion Axis Home) instruction. Cleared when a home event occurs.
HomeEvStatus	BOOL	Set when a home event has occurred. Cleared when another MAH (Motion Axis Home) instruction is executed.
ProcessStatus	BOOL	Set when there is an axis tuning operation or an axis hookup diagnostic test operation in progress on the associated physical axis.
OutLmtStatus	BOOL	Set when the magnitude of the output of the associated physical servo axis has reached or exceeded the configured Output Limit value.
PosLockStatus	BOOL	Set when the magnitude of the axis position error has become less than or equal to the configured Position Lock Tolerance value for the associated physical axis.
HomeSwitchStatus	BOOL	Set when the current state of the dedicated Home input is active. Cleared when the Home input is inactive.
DriveFaultInputStatus	BOOL	Set when the current state of the Drive Fault input is active. Cleared when the Drive Fault input is inactive.
Reg1InputStatus	BOOL	Set when the current state of the dedicated Registration 1 input is active. Clear when the Registration 1 input is inactive.
Reg2InputStatus	BOOL	Set when the current state of the dedicated Registration 1 input is active. Clear when the Registration 1 input is inactive.
PosOvertravelInputStatus	BOOL	Set when the current state of the dedicated Positive Overtravel input is active. Clear when the Positive Overtravel input is inactive.
NegOvertravelInputStatus	BOOL	Set when the current state of the dedicated Negative Overtravel input is active. Clear when the Negative Overtravel input is inactive.
POtravlFault	BOOL	Set when the axis has traveled, or attempted to travel, beyond the current configured value for Maximum Positive Travel. Cleared when the axis is moved back within this travel limit.
NOtravlFault	BOOL	Set when the axis has traveled, or attempted to travel, beyond the current configured value for Maximum Negative Travel. Cleared when the axis is moved back within this travel limit.
PosHardOvertravelFault	BOOL	Set when the axis has traveled beyond the current positive direction position limits as established by hardware limit switches mounted on the machine. To recover, the axis must be moved back with normal operation limits of the machine and the limit switch reset. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
NegHardOvertravelFault	BOOL	Set when the axis has traveled beyond the current negative direction position limits as established by hardware limit switches mounted on the machine. To recover, the axis must be moved back with normal operation limits of the machine and the limit switch reset. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
FeedbackFault	BOOL	Set for a specific feedback source when one of the following conditions occurs: <ul style="list-style-type: none"> • The differential electrical signals for one or more of the feedback channels (e.g., A+ and A-, B+ and B-, or Z+ and Z-) are at the same level (both high or both low). Under normal operation, the differential signals are always at opposite levels. The most common cause of this situation is a broken wire between the feedback transducer and the servo module or drive; • Loss of feedback “power” or feedback “common” electrical connection between the servo module or drive and the feedback device. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.

Mnemonic:	Data Type:	Description:
FeedbackNoiseFault	BOOL	Set for a specific feedback source when the servo module has detected simultaneous transitions of the feedback A and B channels (called "feedback noise"). Feedback noise is most often caused by loss of quadrature in the feedback device itself or radiated common-mode noise signals being picked up by the feedback device wiring, both of which may be able to be seen on an oscilloscope. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
AuxFeedbackFault	BOOL	Set for an auxiliary feedback source when one of the following conditions occurs: <ul style="list-style-type: none"> • The differential electrical signals for one or more of the feedback channels (e.g., A+ and A-, B+ and B-, or Z+ and Z-) are at the same level (both high or both low). Under normal operation, the differential signals are always at opposite levels. The most common cause of this situation is a broken wire between the feedback transducer and the servo module or drive; • Loss of feedback "power" or feedback "common" electrical connection between the servo module or drive and the feedback device. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
AuxFeedbackNoiseFault	BOOL	Set for an auxiliary feedback source when the servo module has detected simultaneous transitions of the feedback A and B channels (called "feedback noise"). Feedback noise is most often caused by loss of quadrature in the feedback device itself or radiated common-mode noise signals being picked up by the feedback device wiring, both of which may be able to be seen on an oscilloscope. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
PosErrorFault	BOOL	Set when the servo has detected that the axis position error has exceeded the current configured value for Position ErrorTolerance. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
DriveFault	BOOL	Set when the external servo drive has detected a fault and has communicated the existence of this fault to the servo module via the Drive Fault input. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
ControlSyncFault	BOOL	Set when the Logix controller detects that several position update messages in a row from the motion module have been missed due to a failure of the synchronous communications connection. This condition results in the automatic shutdown of the associated servo module. The Logix controller is designed to "ride-through" a maximum of four missed position updates without issuing a fault or adversely affecting motion in progress. Missing more than four position updates in a row constitutes a problematic condition that warrants shutdown of the servo module. This fault bit is cleared when the connection is reestablished.
ModuleSyncFault	BOOL	Set when the motion module detects that several position update messages in a row from the ControlLogix processor module have been missed due to a failure of the synchronous communications connection. This condition results in the automatic shutdown of the servo module. The servo module is designed to "ride-through" a maximum of four missed position updates without issuing a fault or adversely affecting motion in progress. Missing more than four position updates in a row constitutes a problematic condition that warrants shutdown of the servo module. This fault bit is cleared when the connection is reestablished.
TimerEventFault	BOOL	Set when the associated servo module has detected a problem with the module's timer event functionality used to synchronize the motion module's servo loop to the master timebase of the Logix rack (i.e. Coordinated System Time). This fault bit can be cleared only by reconfiguration of the motion module.
ModuleHardwareFault	BOOL	Set when the associated servo module has detected a hardware problem that, in general, is going to require replacement of the module to correct.

Mnemonic:	Data Type:	Description:
OutputCamStatus	DINT	A set of bits* that are set when the Output Cam has been initiated.
OutputCamPendingStatus	DINT	A set of bits* that are set when an Output Cam is waiting for an armed Output Cam to move beyond its cam start/cam end position.
OutputCamLockStatus	DINT	A set of bits* that are set when an Output Cam is locked to the Master Axis.
OutputCamTransitionStatus	DINT	A set of bits* that are set when the transition from the current armed Output Cam to the pending Output Cam is in process.
* The bit number corresponds with the execution target number. One bit per execution target.		

AXIS_SERVO_DRIVE Structure

A servo-drive axis object represents an axis with full motion planner functionality and integrated configuration support. It is associated with digital drive interface modules sending digital commands to an external drive, such as a 1756-M08SE (SERCOS). The AXIS_SERVO_DRIVE structure contains the following status and configuration attributes.

Mnemonic:	Data Type:	Description:
MotionStatus	DINT	The motion status bits for your axis.
		Bit: Number: Data Type: Description:
		AccelStatus 00 BOOL Acceleration Status
		DecelStatus 01 BOOL Deceleration Status
		MoveStatus 02 BOOL Move Status
		JogStatus 03 BOOL Jog Status
		GearingStatus 04 BOOL Gearing Status
		HomingStatus 05 BOOL Homing Status
		StoppingStatus 06 BOOL Stopping Status
		AxisHomedStatus 07 BOOL Homed Status
		PositionCamStatus 08 BOOL Position Cam Status
		TimeCamStatus 09 BOOL Time Cam Status
		PositionCamPendingStatus 10 BOOL Position Cam Pending Status
		TimeCamPendingStatus 11 BOOL Time Cam Pending Status
		GearingLockStatus 12 BOOL Gearing Lock Status
		PositionCamLockStatus 13 BOOL Position Cam Lock Status
		TimeCamLockStatus 14 BOOL Time Cam Lock Status
MasterOffsetMoveStatus 15 BOOL Master Offset Move Status		
AxisStatus	DINT	The status bits for your axis
		Bit: Number: Data Type: Description:
		ServoActStatus 00 BOOL Servo Action Status
		DriveEnableStatus 01 BOOL Drive Enable Status
		ShutdownStatus 02 BOOL Axis Shutdown Status
		ConfigUpdateInProgress 03 BOOL Configuration Update in Process

Mnemonic:	Data Type:	Description:
AxisFault	DINT	The axis faults for your axis: Bit: Number: Data Type: Description: PhysicalAxisFault 00 BOOL Physical Axis Fault ModuleFault 01 BOOL Module Fault ConfigFault 02 BOOL Configuration Fault
AxisEvent	DINT	The event status for your axis: Bit: Number: Data Type: Description: WatchEvArmStatus 00 BOOL Watch Event Armed Status WatchEvStatus 01 BOOL Watch Event Status RegEvArmStatus 02 BOOL Registration Event 1 Armed Status RegEvStatus 03 BOOL Registration Event 1 Status RegEv2ArmStatus 04 BOOL Registration Event 2 Armed Status RegEv2Status 05 BOOL Registration Event 2 Status HomeEvArmStatus 06 BOOL Home Event Armed Status HomeEvStatus 07 BOOL Home Event Status
ActualPosition	REAL	Actual Position in Position Units
StrobeActualPosition	REAL	Strobe Actual Position in Position Units
StartActualPosition	REAL	Start Actual Position in Position Units
AverageVelocity	REAL	Average Velocity in Position Units / Sec
ActualVelocity	REAL	Actual Velocity in Position Units / Sec
ActualAcceleration	REAL	Actual Acceleration in Position Units / Sec ²
WatchPosition	REAL	Watch Position in Position Units
RegistrationPosition	REAL	Registration 1 Position in Position Units
Registration2Position	REAL	Registration 2 Position in Position Units
Registration1Time	DINT	Registration 1 Time as CST time in microseconds
Registration2Time	DINT	Registration 2 Time as CST time in microseconds
InterpolationTime	DINT	Interpolation Time as CST time in microseconds
InterpolatedActualPosition	REAL	Interpolated Actual Position in Position Units
MasterOffset	REAL	Master Offset in Master Position Units
StrobeMasterOffset	REAL	Strobe Master Offset in Master Position Units
StartMasterOffset	REAL	Start Master Offset in Master Position Units
CommandPosition	REAL	Command Position in Position Units
StrobeCommandPosition	REAL	Strobe Command Position in Position Units
StartCommandPosition	REAL	Start Command Position in Position Units
CommandVelocity	REAL	Command Velocity in Position Units / Sec
CommandAcceleration	REAL	Command Acceleration in Position Units / Sec ²
InterpolatedCommandPosition	REAL	Interpolated Command Position in Position Units

Mnemonic:	Data Type:	Description:			
ServoModuleFault	DINT	Bit: ControlSyncFault ModuleSyncFault TimerEventFault ModuleHardwareFault	Number: 00 01 02 03	Data Type: BOOL BOOL BOOL BOOL	Description: Control Sync Fault Module Sync Fault Timer Event Fault Module Hardware Fault
AttributeErrorCode	INT	ASA Error code returned by erred set attribute list service to the module.			
AttributeErrorID	INT	Attribute ID associated with non-zero Attribute Error Code.			
PositionCommand	REAL	Position Command in Position Units			
PositionFeedback	REAL	Position Feedback in Position Units			
AuxPositionFeedback	REAL	Auxiliary Position Feedback in Position Units			
PositionError	REAL	Position Error in Position Units			
PositionIntegratorError	REAL	Position Integrator Error in Position Units - mSec			
VelocityCommand	REAL	Velocity Command in Position Units / Sec			
VelocityFeedback	REAL	Velocity Feedback in Position Units / Sec			
VelocityError	REAL	Velocity Error in Position Units / Sec			
VelocityIntegratorError	REAL	Velocity Integrator Error in Position Units – mSec / Sec			
AccelerationCommand	REAL	Acceleration Command in Position Units / Sec2			
AccelerationFeedback	REAL	Acceleration Feedback in Position Units / Sec2			
ServoOutputLevel	REAL	Servo Output Level in Volts			
MarkerDistance	REAL	Marker Distance in Position Units			
VelocityOffset	REAL	Velocity Offset in Position Units / Sec			
TorqueOffset	REAL	Torque Offset from –100% to +100%			
TorqueCommand	REAL	The command when operating in Torque Mode in terms of % rated.			
TorqueFeedback	REAL	The torque feedback when operating in Torque Mode in terms of % rated.			
PosDynamicTorqueLimit	REAL	The currently operative maximum positive torque/current limit magnitude. It should be the lowest value of all torque/current limits in the drive at a given time, including: amplifier peak limit, motor peak limit, user current limit, amplifier thermal limit, and motor thermal limit.			
NegDynamicTorqueLimit	REAL	The currently operative negative positive torque/current limit magnitude. It should be the lowest value of all torque/current limits in the drive at a given time, including: amplifier peak limit, motor peak limit, user current limit, amplifier thermal limit, and motor thermal limit.			
MotorCapacity	REAL	The present utilization of motor capacity as a percent of rated capacity.			
DriveCapacity	REAL	The present utilization of drive capacity as a percent of rated capacity.			
PowerCapacity	REAL	The present utilization of the axis power supply as a percent of rated capacity.			
BusRegulatorCapacity	REAL	The present utilization of the axis bus regulator as a percent of rated capacity.			
MotorElectricalAngle	REAL	The present electrical angle of the motor shaft.			
TorqueLimitSource	DINT	The present source (if any) of any torque limiting for the axis.			

Mnemonic:	Data Type:	Description:																																																																																																								
DriveStatus	DINT	<div>The status bits for your servo drive:</div> <table><tr><th>Bit:</th><th>Number:</th><th>Data Type:</th><th>Description:</th></tr><tr><td>- no tag -</td><td>00</td><td>BOOL</td><td>Servo Action Status</td></tr><tr><td>- no tag -</td><td>01</td><td>BOOL</td><td>Drive Enable Status</td></tr><tr><td>- no tag -</td><td>02</td><td>BOOL</td><td>Axis Shutdown Status</td></tr><tr><td>ProcessStatus</td><td>03</td><td>BOOL</td><td>Process Status</td></tr><tr><td>- no tag -</td><td>04</td><td>BOOL</td><td>(Reserved)</td></tr><tr><td>- no tag -</td><td>05</td><td>BOOL</td><td>(Reserved)</td></tr><tr><td>HomeSwitchStatus</td><td>06</td><td>BOOL</td><td>Home Input Status</td></tr><tr><td>Reg1InputStatus</td><td>07</td><td>BOOL</td><td>Registration 1 Input Status</td></tr><tr><td>Reg2InputStatus</td><td>08</td><td>BOOL</td><td>Registration 12Input Status</td></tr><tr><td>PosOvertravelInputStatus</td><td>09</td><td>BOOL</td><td>Positive Overtravel Input Status</td></tr><tr><td>NegOvertravelInputStatus</td><td>10</td><td>BOOL</td><td>Negative Overtravel Input Status</td></tr><tr><td>EnableInputStatus</td><td>11</td><td>BOOL</td><td>Enable Input Status</td></tr><tr><td>AccelLimitStatus</td><td>12</td><td>BOOL</td><td>Accel Limit Status</td></tr><tr><td>- no tag -</td><td>13-15</td><td>BOOL</td><td>(Reserved)</td></tr><tr><td>VelocityLockStatus</td><td>16</td><td>BOOL</td><td>Velocity Lock Status</td></tr><tr><td>VelocityStandstillStatus</td><td>17</td><td>BOOL</td><td>Velocity Standstill Status</td></tr><tr><td>VelocityThresholdStatus</td><td>18</td><td>BOOL</td><td>Velocity Threshold Status</td></tr><tr><td>TorqueThresholdStatus</td><td>19</td><td>BOOL</td><td>Torque Threshold Status</td></tr><tr><td>TorqueLimitStatus</td><td>20</td><td>BOOL</td><td>Torque Limit Status</td></tr><tr><td>VelocityLimitStatus</td><td>21</td><td>BOOL</td><td>Velocity Limit Status</td></tr><tr><td>PosLockStatus</td><td>22</td><td>BOOL</td><td>Position Lock Status</td></tr><tr><td>-no tag -</td><td>23</td><td>BOOL</td><td>(Reserved)</td></tr><tr><td>-no tag -</td><td>24</td><td>BOOL</td><td>(Reserved)</td></tr><tr><td>-no tag -</td><td>25</td><td>BOOL</td><td>(Reserved)</td></tr><tr><td>-no tag -</td><td>26</td><td>BOOL</td><td>(Reserved)</td></tr></table>	Bit:	Number:	Data Type:	Description:	- no tag -	00	BOOL	Servo Action Status	- no tag -	01	BOOL	Drive Enable Status	- no tag -	02	BOOL	Axis Shutdown Status	ProcessStatus	03	BOOL	Process Status	- no tag -	04	BOOL	(Reserved)	- no tag -	05	BOOL	(Reserved)	HomeSwitchStatus	06	BOOL	Home Input Status	Reg1InputStatus	07	BOOL	Registration 1 Input Status	Reg2InputStatus	08	BOOL	Registration 12Input Status	PosOvertravelInputStatus	09	BOOL	Positive Overtravel Input Status	NegOvertravelInputStatus	10	BOOL	Negative Overtravel Input Status	EnableInputStatus	11	BOOL	Enable Input Status	AccelLimitStatus	12	BOOL	Accel Limit Status	- no tag -	13-15	BOOL	(Reserved)	VelocityLockStatus	16	BOOL	Velocity Lock Status	VelocityStandstillStatus	17	BOOL	Velocity Standstill Status	VelocityThresholdStatus	18	BOOL	Velocity Threshold Status	TorqueThresholdStatus	19	BOOL	Torque Threshold Status	TorqueLimitStatus	20	BOOL	Torque Limit Status	VelocityLimitStatus	21	BOOL	Velocity Limit Status	PosLockStatus	22	BOOL	Position Lock Status	-no tag -	23	BOOL	(Reserved)	-no tag -	24	BOOL	(Reserved)	-no tag -	25	BOOL	(Reserved)	-no tag -	26	BOOL	(Reserved)
Bit:	Number:	Data Type:	Description:																																																																																																							
- no tag -	00	BOOL	Servo Action Status																																																																																																							
- no tag -	01	BOOL	Drive Enable Status																																																																																																							
- no tag -	02	BOOL	Axis Shutdown Status																																																																																																							
ProcessStatus	03	BOOL	Process Status																																																																																																							
- no tag -	04	BOOL	(Reserved)																																																																																																							
- no tag -	05	BOOL	(Reserved)																																																																																																							
HomeSwitchStatus	06	BOOL	Home Input Status																																																																																																							
Reg1InputStatus	07	BOOL	Registration 1 Input Status																																																																																																							
Reg2InputStatus	08	BOOL	Registration 12Input Status																																																																																																							
PosOvertravelInputStatus	09	BOOL	Positive Overtravel Input Status																																																																																																							
NegOvertravelInputStatus	10	BOOL	Negative Overtravel Input Status																																																																																																							
EnableInputStatus	11	BOOL	Enable Input Status																																																																																																							
AccelLimitStatus	12	BOOL	Accel Limit Status																																																																																																							
- no tag -	13-15	BOOL	(Reserved)																																																																																																							
VelocityLockStatus	16	BOOL	Velocity Lock Status																																																																																																							
VelocityStandstillStatus	17	BOOL	Velocity Standstill Status																																																																																																							
VelocityThresholdStatus	18	BOOL	Velocity Threshold Status																																																																																																							
TorqueThresholdStatus	19	BOOL	Torque Threshold Status																																																																																																							
TorqueLimitStatus	20	BOOL	Torque Limit Status																																																																																																							
VelocityLimitStatus	21	BOOL	Velocity Limit Status																																																																																																							
PosLockStatus	22	BOOL	Position Lock Status																																																																																																							
-no tag -	23	BOOL	(Reserved)																																																																																																							
-no tag -	24	BOOL	(Reserved)																																																																																																							
-no tag -	25	BOOL	(Reserved)																																																																																																							
-no tag -	26	BOOL	(Reserved)																																																																																																							
DriveFault	DINT	<div>The servo fault bits for your servo loop:</div> <table><tr><th>Bit:</th><th>Number:</th><th>Data Type:</th><th>Description:</th></tr><tr><td>PosSoftOtravelFault</td><td>00</td><td>BOOL</td><td>Positive Software Overtravel Fault</td></tr><tr><td>NegSoftOtravelFault</td><td>01</td><td>BOOL</td><td>Negative Software Overtravel Fault</td></tr><tr><td>PosHardOvertravelFault</td><td>02</td><td>BOOL</td><td>Positive Hardware Overtravel Fault</td></tr><tr><td>NegHardOvertravelFault</td><td>03</td><td>BOOL</td><td>Negative Hardware Overtravel Fault</td></tr><tr><td>MotFeedbackFault</td><td>04</td><td>BOOL</td><td>Feedback Fault</td></tr><tr><td>MotFeedbackNoiseFault</td><td>05</td><td>BOOL</td><td>Feedback Noise Fault</td></tr><tr><td>AuxFeedbackFault</td><td>06</td><td>BOOL</td><td>Auxiliary Feedback Fault</td></tr><tr><td>AuxFeedbackNoiseFault</td><td>07</td><td>BOOL</td><td>Auxiliary Feedback Noise Fault</td></tr><tr><td>- no tag -</td><td>08-12</td><td>BOOL</td><td>(Reserved)</td></tr><tr><td>GroundShortFault</td><td>13</td><td>BOOL</td><td>Ground Short Fault</td></tr><tr><td>DriveHardFault</td><td>14</td><td>BOOL</td><td>Drive Hard Fault</td></tr><tr><td>OverSpeedFault</td><td>15</td><td>BOOL</td><td>Overspeed Fault</td></tr><tr><td>MotorOverloadFault</td><td>16</td><td>BOOL</td><td>Overload Fault</td></tr><tr><td>DriveOvertempFault</td><td>17</td><td>BOOL</td><td>Drive Overtemp Fault</td></tr><tr><td>MotorOvertempFault</td><td>18</td><td>BOOL</td><td>Motor Overtemp Fault</td></tr><tr><td>DriveCoolingFault</td><td>19</td><td>BOOL</td><td>Drive Cooling Fault</td></tr><tr><td>DriveControlVoltageFault</td><td>20</td><td>BOOL</td><td>Drive Control Voltage Fault</td></tr><tr><td>FeedbackFault</td><td>21</td><td>BOOL</td><td>Feedback Fault</td></tr><tr><td>CommutationFault</td><td>22</td><td>BOOL</td><td>Commutation Fault</td></tr><tr><td>DriveOvercurrentFault</td><td>23</td><td>BOOL</td><td>Drive Overcurrent Fault</td></tr><tr><td>DriveOvervoltageFault</td><td>24</td><td>BOOL</td><td>Drive Overvoltage Fault</td></tr><tr><td>DriveUndervoltageFault</td><td>25</td><td>BOOL</td><td>Drive Undervoltage Fault</td></tr><tr><td>PowerPhaseLossFault</td><td>26</td><td>BOOL</td><td>Power Phase Loss Fault</td></tr><tr><td>PosErrorFault</td><td>27</td><td>BOOL</td><td>Position Error Fault</td></tr><tr><td>- no tag -</td><td>28</td><td>BOOL</td><td>SERCOS Commutation Fault</td></tr></table>	Bit:	Number:	Data Type:	Description:	PosSoftOtravelFault	00	BOOL	Positive Software Overtravel Fault	NegSoftOtravelFault	01	BOOL	Negative Software Overtravel Fault	PosHardOvertravelFault	02	BOOL	Positive Hardware Overtravel Fault	NegHardOvertravelFault	03	BOOL	Negative Hardware Overtravel Fault	MotFeedbackFault	04	BOOL	Feedback Fault	MotFeedbackNoiseFault	05	BOOL	Feedback Noise Fault	AuxFeedbackFault	06	BOOL	Auxiliary Feedback Fault	AuxFeedbackNoiseFault	07	BOOL	Auxiliary Feedback Noise Fault	- no tag -	08-12	BOOL	(Reserved)	GroundShortFault	13	BOOL	Ground Short Fault	DriveHardFault	14	BOOL	Drive Hard Fault	OverSpeedFault	15	BOOL	Overspeed Fault	MotorOverloadFault	16	BOOL	Overload Fault	DriveOvertempFault	17	BOOL	Drive Overtemp Fault	MotorOvertempFault	18	BOOL	Motor Overtemp Fault	DriveCoolingFault	19	BOOL	Drive Cooling Fault	DriveControlVoltageFault	20	BOOL	Drive Control Voltage Fault	FeedbackFault	21	BOOL	Feedback Fault	CommutationFault	22	BOOL	Commutation Fault	DriveOvercurrentFault	23	BOOL	Drive Overcurrent Fault	DriveOvervoltageFault	24	BOOL	Drive Overvoltage Fault	DriveUndervoltageFault	25	BOOL	Drive Undervoltage Fault	PowerPhaseLossFault	26	BOOL	Power Phase Loss Fault	PosErrorFault	27	BOOL	Position Error Fault	- no tag -	28	BOOL	SERCOS Commutation Fault
Bit:	Number:	Data Type:	Description:																																																																																																							
PosSoftOtravelFault	00	BOOL	Positive Software Overtravel Fault																																																																																																							
NegSoftOtravelFault	01	BOOL	Negative Software Overtravel Fault																																																																																																							
PosHardOvertravelFault	02	BOOL	Positive Hardware Overtravel Fault																																																																																																							
NegHardOvertravelFault	03	BOOL	Negative Hardware Overtravel Fault																																																																																																							
MotFeedbackFault	04	BOOL	Feedback Fault																																																																																																							
MotFeedbackNoiseFault	05	BOOL	Feedback Noise Fault																																																																																																							
AuxFeedbackFault	06	BOOL	Auxiliary Feedback Fault																																																																																																							
AuxFeedbackNoiseFault	07	BOOL	Auxiliary Feedback Noise Fault																																																																																																							
- no tag -	08-12	BOOL	(Reserved)																																																																																																							
GroundShortFault	13	BOOL	Ground Short Fault																																																																																																							
DriveHardFault	14	BOOL	Drive Hard Fault																																																																																																							
OverSpeedFault	15	BOOL	Overspeed Fault																																																																																																							
MotorOverloadFault	16	BOOL	Overload Fault																																																																																																							
DriveOvertempFault	17	BOOL	Drive Overtemp Fault																																																																																																							
MotorOvertempFault	18	BOOL	Motor Overtemp Fault																																																																																																							
DriveCoolingFault	19	BOOL	Drive Cooling Fault																																																																																																							
DriveControlVoltageFault	20	BOOL	Drive Control Voltage Fault																																																																																																							
FeedbackFault	21	BOOL	Feedback Fault																																																																																																							
CommutationFault	22	BOOL	Commutation Fault																																																																																																							
DriveOvercurrentFault	23	BOOL	Drive Overcurrent Fault																																																																																																							
DriveOvervoltageFault	24	BOOL	Drive Overvoltage Fault																																																																																																							
DriveUndervoltageFault	25	BOOL	Drive Undervoltage Fault																																																																																																							
PowerPhaseLossFault	26	BOOL	Power Phase Loss Fault																																																																																																							
PosErrorFault	27	BOOL	Position Error Fault																																																																																																							
- no tag -	28	BOOL	SERCOS Commutation Fault																																																																																																							

Mnemonic:	Data Type:	Description:
SERCOSErrorCode	INT	Error code returned by SERCOS module indicating source of drive parameter update failure.
AccelStatus	BOOL	Set if the axis is currently being commanded to accelerate.
DecelStatus	BOOL	Set if the axis is currently being commanded to decelerate.
MoveStatus	BOOL	Set if a Move motion profile is currently in progress. Cleared when the Move is complete or is superseded by some other motion operation.
JogStatus	BOOL	Set if a Jog motion profile is currently in progress. Cleared when the Jog is complete or is superseded by some other motion operation.
GearingStatus	BOOL	Set if the axis is a slave that is currently Gearing to another axis. Cleared when the gearing operation is stopped or is superseded by some other motion operation.
HomingStatus	BOOL	Set if a Home motion profile is currently in progress. Cleared when the homing operation is stopped or is superseded by some other motion operation.
StoppingStatus	BOOL	Set if there is a stopping process currently in progress. Cleared when the stopping process is complete. Note: The stopping process is used to stop an axis (initiated by an MAS, MGS, Stop Motion fault action, or mode change).
AxisHomedStatus	BOOL	Cleared at power-up or reconnection. Set by the MAH instruction upon successful completion of the configured homing sequence, and later cleared when the axis enters the shutdown state.
PositionCamStatus	BOOL	Set if a Position Cam motion profile is currently in progress. Cleared when the Position Cam is complete or is superseded by some other motion operation.
TimeCamStatus	BOOL	Set if a Time Cam motion profile is currently in progress. Cleared when the Time Cam is complete or is superseded by some other motion operation.
PositionCamPendingStatus	BOOL	Set if a Position Cam motion profile is currently pending the completion of a currently executing cam profile. This would be initiated by executing an MAPC instruction with Pending execution selected. This bit is cleared when the current position cam profile completes, initiating the start of the pending cam profile. This bit is also cleared if the position cam profile completes, or is superseded by some other motion operation.
TimeCamPendingStatus	BOOL	Set if a Time Cam motion profile is currently pending the completion of a currently executing cam profile. This would be initiated by executing an MATC instruction with Pending execution selected. This bit is cleared when the current time cam profile completes, initiating the start of the pending cam profile. This bit is also cleared if the time cam profile completes, or is superseded by some other motion operation.
GearingLockStatus	BOOL	Set whenever the slave axis is locked to the master axis in a gearing relationship according to the specified gear ratio. The clutch function of the gearing planner is used to ramp an axis up, or down, to speed in a gearing process (MAG with Clutch selected). This bit is cleared during the intervals where the axis is clutching.
PositionCamLockStatus	BOOL	Set whenever the master axis satisfies the starting condition of a currently active Position Cam motion profile. The starting condition is established by the Start Control and Start Position parameters of the MAPC instruction. This bit is cleared when the current position cam profile completes, or is superseded by some other motion operation. In uni-directional master direction mode, the Position Cam Lock Status bit is cleared when moving in the "wrong" direction and sets when moving in the "correct" direction.
MasterOffsetMoveStatus	BOOL	Set if a Master Offset Move motion profile is currently in progress. This bit is cleared when the Master Offset Move is complete or is superseded by some other motion operation.
ServoActStatus	BOOL	Set when the associated axis is under servo control. Cleared when servo action is disabled.

Mnemonic:	Data Type:	Description:
DriveEnableStatus	BOOL	Set when the Drive Enable output of the associated physical axis is currently enabled. Cleared when physical servo axis Drive Enable output is currently disabled.
ShutdownStatus	BOOL	Set when the associated axis is currently in the Shutdown state. Cleared when the axis is transitioned from the Shutdown state to another state.
ConfigUpdateInProgress	BOOL	The Configuration Update Status Bits attribute provides a method for monitoring the progress of one or more specific module configuration attribute updates initiated by either a Set Attribute List service (which is internal to the firmware) or an SSV in the user program. When such an update is initiated, the ControlLogix processor sets this bit. This bit will remain set until the Set Attribute List reply comes back from the servo module indicating that the data update process was successful. Thus the Configuration Update Status Bits attribute provides a method of waiting until the servo configuration data update to the connected motion module is complete before starting a dependent operation.
PhysicalAxisFault	BOOL	Set when one or more fault conditions have been reported by the physical axis. The specific fault conditions can then be determined through access to the fault attributes of the associated physical axis. A PhysicalAxisFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
ModuleFault	BOOL	Set when a serious fault has occurred with the motion module associated with the selected axis. Usually a module fault affects all axes associated with the motion module. A module fault generally results in the shutdown of all associated axes. Reconfiguration of the motion module is required to recover from a module fault condition. A ModuleFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
ConfigFault	BOOL	Set when an update operation targeting an axis configuration attribute of an associated motion module has failed. Specific information concerning the Configuration Fault may be found in the Attribute Error Code and Attribute Error ID attributes associated with the motion module. A ConfigFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
WatchEvArmStatus	BOOL	Set when a watch event has been armed through execution of the MAW (Motion Arm Watch) instruction. Cleared when either a watch event occurs or a MDW (Motion Disarm Watch) instruction is executed.
WatchEvStatus	BOOL	Set when a watch event has occurred. Cleared when either another MAW (Motion Arm Watch) instruction or a MDW (Motion Disarm Watch) instruction is executed.
RegEvArmStatus	BOOL	Set when a registration checking has been armed for registration input 1 through execution of the MAR (Motion Arm Registration) instruction. Cleared when either a registration event occurs or a MDR (Motion Disarm Registration) instruction is executed for registration input 1.
RegEvStatus	BOOL	Set when a registration event has occurred on registration input 1. Cleared when either another MAR (Motion Arm Registration) instruction or a MDR (Motion Disarm Registration) instruction is executed for registration input 1.
RegEv2ArmStatus	BOOL	Set when a registration checking has been armed for registration input 2 through execution of the MAR (Motion Arm Registration) instruction. Cleared when either a registration event occurs or a MDR (Motion Disarm Registration) instruction is executed for registration input 2.
RegEv2Status	BOOL	Set when a registration event has occurred on registration input 2. Cleared when either another MAR (Motion Arm Registration) instruction or a MDR (Motion Disarm Registration) instruction is executed for registration input 2.
HomeEvArmStatus	BOOL	Set when a home event has been armed through execution of the MAH (Motion Axis Home) instruction. Cleared when a home event occurs.
HomeEvStatus	BOOL	Set when a home event has occurred. Cleared when another MAH (Motion Axis Home) instruction is executed.

Mnemonic:	Data Type:	Description:
ControlSyncFault	BOOL	Set when the Logix controller detects that several position update messages in a row from the motion module have been missed due to a failure of the synchronous communications connection. This condition results in the automatic shutdown of the associated servo module. The Logix controller is designed to "ride-through" a maximum of four missed position updates without issuing a fault or adversely affecting motion in progress. Missing more than four position updates in a row constitutes a problematic condition that warrants shutdown of the servo module. This fault bit is cleared when the connection is reestablished.
ModuleSyncFault	BOOL	Set when the motion module detects that several position update messages in a row from the ControlLogix processor module have been missed due to a failure of the synchronous communications connection. This condition results in the automatic shutdown of the servo module. The servo module is designed to "ride-through" a maximum of four missed position updates without issuing a fault or adversely affecting motion in progress. Missing more than four position updates in a row constitutes a problematic condition that warrants shutdown of the servo module. This fault bit is cleared when the connection is reestablished.
TimerEventFault	BOOL	Set when the associated servo module has detected a problem with the module's timer event functionality used to synchronize the motion module's servo loop to the master timebase of the Logix rack (i.e. Coordinated System Time). This fault bit can be cleared only by reconfiguration of the motion module.
ModuleHardwareFault	BOOL	Set when the associated servo module has detected a hardware problem that, in general, is going to require replacement of the module to correct.
ProcessStatus	BOOL	Set when there is an axis tuning operation or an axis hookup diagnostic test operation in progress on the associated physical axis.
HomeInputStatus	BOOL	Set when the current state of the dedicated Home input is active. Cleared when the Home input is inactive.
Reg1InputStatus	BOOL	Set when the current state of the dedicated Registration 1 input is active. Clear when the Registration 1 input is inactive.
Reg2InputStatus	BOOL	Set when the current state of the dedicated Registration 1 input is active. Clear when the Registration 1 input is inactive.
PosOvertravelInputStatus	BOOL	Set when the current state of the dedicated Positive Overtravel input is active. Clear when the Positive Overtravel input is inactive.
NegOvertravelInputStatus	BOOL	Set when the current state of the dedicated Negative Overtravel input is active. Clear when the Negative Overtravel input is inactive.
EnableInputStatus	BOOL	Set when the current state of the dedicated Enable Input is active. Clear when the Enable Input is inactive.
AccelLimitStatus	BOOL	Set when the magnitude of the commanded acceleration to the velocity servo loop input is greater than the configured Velocity Limit.
VelocityLockStatus	BOOL	Set when the magnitude of the physical axis Velocity Feedback is within the configured Velocity Window of the current velocity command.
VelocityStandstillStatus	BOOL	Set when the magnitude of the physical axis Velocity Feedback is within the configured Velocity Standstill Window of zero speed.
VelocityThresholdStatus	BOOL	Set when the magnitude of the physical axis Velocity Feedback is less than the configured Velocity Threshold.
TorqueThresholdStatus	BOOL	Set when the magnitude of the physical axis Torque Feedback is less than the configured Torque Threshold.
TorqueLimitStatus	BOOL	Set when the magnitude of the axis torque command is greater than the configured Torque Limit.

Mnemonic:	Data Type:	Description:
VelocityLimitStatus	BOOL	Set when the magnitude of the commanded velocity to the velocity servo loop input is greater than the configured Velocity Limit.
PosLockStatus	BOOL	Set when the magnitude of the axis position error has become less than or equal to the configured Position Lock Tolerance value for the associated physical axis.
PosSoftOvertravelFault	BOOL	Set when the axis has traveled, or attempted to travel, beyond the current configured value for Maximum Positive Travel. Cleared when the axis is moved back within this travel limit.
NegSoftOvertravelFault	BOOL	Set when the axis has traveled, or attempted to travel, beyond the current configured value for Maximum Negative Travel. Cleared when the axis is moved back within this travel limit.
PosHardOvertravelFault	BOOL	Set when the axis has traveled beyond the current positive direction position limits as established by hardware limit switches mounted on the machine. To recover, the axis must be moved back with normal operation limits of the machine and the limit switch reset. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
NegHardOvertravelFault	BOOL	Set when the axis has traveled beyond the current negative direction position limits as established by hardware limit switches mounted on the machine. To recover, the axis must be moved back with normal operation limits of the machine and the limit switch reset. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
MotFeedbackFault	BOOL	Set for a specific feedback source when one of the following conditions occurs: <ul style="list-style-type: none"> • The differential electrical signals for one or more of the feedback channels (e.g., A+ and A-, B+ and B-, or Z+ and Z-) are at the same level (both high or both low). Under normal operation, the differential signals are always at opposite levels. The most common cause of this situation is a broken wire between the feedback transducer and the servo module or drive. • Loss of feedback “power” or feedback “common” electrical connection between the servo module or drive and the feedback device. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
MotFeedbackNoiseFault	BOOL	Set for a specific feedback source when the servo module has detected simultaneous transitions of the feedback A and B channels (called “feedback noise”). Feedback noise is most often caused by loss of quadrature in the feedback device itself or radiated common-mode noise signals being picked up by the feedback device wiring, both of which may be able to be seen on an oscilloscope. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
AuxFeedbackFault	BOOL	Set for an auxiliary feedback source when one of the following conditions occurs: <ul style="list-style-type: none"> • The differential electrical signals for one or more of the feedback channels (e.g., A+ and A-, B+ and B-, or Z+ and Z-) are at the same level (both high or both low). Under normal operation, the differential signals are always at opposite levels. The most common cause of this situation is a broken wire between the feedback transducer and the servo module or drive; • Loss of feedback “power” or feedback “common” electrical connection between the servo module or drive and the feedback device. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.

Mnemonic:	Data Type:	Description:
AuxFeedbackNoiseFault	BOOL	Set for an auxiliary feedback source when the servo module has detected simultaneous transitions of the feedback A and B channels (called "feedback noise"). Feedback noise is most often caused by loss of quadrature in the feedback device itself or radiated common-mode noise signals being picked up by the feedback device wiring, both of which may be able to be seen on an oscilloscope. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
GroundShortFault		Set for an auxiliary feedback source when one of the following conditions occurs: <ul style="list-style-type: none"> • The differential electrical signals for one or more of the feedback channels (e.g., A+ and A-, B+ and B-, or Z+ and Z-) are at the same level (both high or both low). Under normal operation, the differential signals are always at opposite levels. The most common cause of this situation is a broken wire between the feedback transducer and the servo module or drive. • Loss of feedback "power" or feedback "common" electrical connection between the servo module or drive and the feedback device. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
DriveHardFault	BOOL	Set when the drive detects a serious hardware fault.
OverspeedFault	BOOL	Set when the speed of the axis as determined from the feedback has exceeded the overspeed limit which is typically set to 150% of configured velocity limit for the motor.
OverloadFault	BOOL	Set when the load limit of the motor/drive has been exceeded and persists. (This attribute is often tied into the IT limit of the drive.)
DriveOvertempFault	BOOL	Set when the drive's temperature exceeds the drive shutdown temperature.
MotorOvertempFault	BOOL	Set when the motor's temperature exceeds the motor shutdown temperature.
DriveCoolingFault	BOOL	Set when the ambient temperature surrounding the drive's control circuitry temperature exceeds the drive ambient shut-down temperature.
DriveControlVoltageFault	BOOL	Set when the power supply voltages associated with the drive circuitry fall outside of acceptable limits.
FeedbackFault	BOOL	Set when one of the feedback sources associated with the drive axis has a problem that prevents the drive from receiving accurate or reliable position information from the feedback device.
CommutationFault	BOOL	Set when the commutation feedback source associated with the drive axis has a problem that prevents the drive from receiving accurate or reliable motor shaft information to perform commutation.
DriveOvercurrentFault	BOOL	Set when drive output current exceeds the predefined operating limits for the drive.
DriveOvervoltageFault	BOOL	Set when drive DC bus voltage exceeds the predefined operating limits for the bus.
DriveUndervoltageFault	BOOL	Set when drive DC bus voltage is below the predefined operating limits for the bus.
PowerPhaseLossFault	BOOL	Set when the drive detects that one or more of the three power line phases is lost from the 3 phase power inputs.
PosErrorFault	BOOL	Set when the servo has detected that the axis position error has exceeded the current configured value for Position ErrorTolerance. This fault condition is latched and requires execution of an explicit MAFR (Motion Axis Fault Reset) or MASR (Motion Axis Shutdown Reset) instruction to clear.
OutputCamStatus	DINT	A set of bits* that are set when the Output Cam has been initiated.
OutputCamPendingStatus	DINT	A set of bits* that are set when an Output Cam is waiting for an armed Output Cam to move beyond its cam start/cam end position.

Mnemonic:	Data Type:	Description:
OutputCamLockStatus	DINT	A set of bits* that are set when an Output Cam is locked to the Master Axis.
OutputCamTransitionStatus	DINT	A set of bits* that are set when the transition from the current armed Output Cam to the pending Output Cam is in process.
* The bit number corresponds with the execution target number. One bit per execution target.		

AXIS_VIRTUAL Structure

A virtual axis object is an axis with full motion planner operation, but is not associated with any physical device.

The AXIS_VIRTUAL structure contains the following status attributes:

Mnemonic:	Data Type:	Description:
MotionStatus	DINT	The motion status bits for your axis.
		Bit: Number: Data Type: Description:
		AccelStatus 00 BOOL Acceleration Status
		DecelStatus 01 BOOL Deceleration Status
		MoveStatus 02 BOOL Move Status
		JogStatus 03 BOOL Jog Status
		GearingStatus 04 BOOL Gearing Status
		HomingStatus 05 BOOL Homing Status
		StoppingStatus 06 BOOL Stopping Status
		AxisHomedStatus 07 BOOL Homed Status
		PositionCamStatus 08 BOOL Position Cam Status
		TimeCamStatus 09 BOOL Time Cam Status
		PositionCamPendingStatus 10 BOOL Position Cam Pending Status
		TimeCamPendingStatus 11 BOOL Time Cam Pending Status
		GearingLockStatus 12 BOOL Gearing Lock Status
		PositionCamLockStatus 13 BOOL Position Cam Lock Status
		TimeCamLockStatus 14 BOOL Time Cam Lock Status
		MasterOffsetMoveStatus 15 BOOL Master Offset Move Status
AxisStatus	DINT	The status bits for your axis
		Bit: Number: Data Type: Description:
		ServoActStatus 00 BOOL Servo Action Status
		DriveEnableStatus 01 BOOL Drive Enable Status
		ShutdownStatus 02 BOOL Axis Shutdown Status
		ConfigUpdateInProgress 03 BOOL Configuration Update in Process
AxisFault	DINT	The axis faults for your axis:
		Bit: Number: Data Type: Description:
		PhysicalAxisFault 00 BOOL Physical Axis Fault
		ModuleFault 01 BOOL Module Fault
		ConfigFault 02 BOOL Configuration Fault

Mnemonic:	Data Type:	Description:																																				
AxisEvent	DINT	<div>The event status for your axis:</div> <table><tr><th>Bit:</th><th>Number:</th><th>Data Type:</th><th>Description:</th></tr><tr><td>WatchEvArmStatus</td><td>00</td><td>BOOL</td><td>Watch Event Armed Status</td></tr><tr><td>WatchEvStatus</td><td>01</td><td>BOOL</td><td>Watch Event Status</td></tr><tr><td>RegEvArmStatus</td><td>02</td><td>BOOL</td><td>Registration Event 1 Armed Status</td></tr><tr><td>RegEvStatus</td><td>03</td><td>BOOL</td><td>Registration Event 1 Status</td></tr><tr><td>RegEv2ArmStatus</td><td>04</td><td>BOOL</td><td>Registration Event 2 Armed Status</td></tr><tr><td>RegEv2Status</td><td>05</td><td>BOOL</td><td>Registration Event 2 Status</td></tr><tr><td>HomeEvArmStatus</td><td>06</td><td>BOOL</td><td>Home Event Armed Status</td></tr><tr><td>HomeEvStatus</td><td>07</td><td>BOOL</td><td>Home Event Status</td></tr></table>	Bit:	Number:	Data Type:	Description:	WatchEvArmStatus	00	BOOL	Watch Event Armed Status	WatchEvStatus	01	BOOL	Watch Event Status	RegEvArmStatus	02	BOOL	Registration Event 1 Armed Status	RegEvStatus	03	BOOL	Registration Event 1 Status	RegEv2ArmStatus	04	BOOL	Registration Event 2 Armed Status	RegEv2Status	05	BOOL	Registration Event 2 Status	HomeEvArmStatus	06	BOOL	Home Event Armed Status	HomeEvStatus	07	BOOL	Home Event Status
Bit:	Number:	Data Type:	Description:																																			
WatchEvArmStatus	00	BOOL	Watch Event Armed Status																																			
WatchEvStatus	01	BOOL	Watch Event Status																																			
RegEvArmStatus	02	BOOL	Registration Event 1 Armed Status																																			
RegEvStatus	03	BOOL	Registration Event 1 Status																																			
RegEv2ArmStatus	04	BOOL	Registration Event 2 Armed Status																																			
RegEv2Status	05	BOOL	Registration Event 2 Status																																			
HomeEvArmStatus	06	BOOL	Home Event Armed Status																																			
HomeEvStatus	07	BOOL	Home Event Status																																			
ActualPosition	REAL	Actual Position in Position Units																																				
StrobeActualPosition	REAL	Strobe Actual Position in Position Units																																				
StartActualPosition	REAL	Start Actual Position in Position Units																																				
AverageVelocity	REAL	Average Velocity in Position Units / Sec																																				
ActualVelocity	REAL	Actual Velocity in Position Units / Sec																																				
ActualAcceleration	REAL	Actual Acceleration in Position Units / Sec2																																				
WatchPosition	REAL	Watch Position in Position Units																																				
RegistrationPosition	REAL	Registration 1 Position in Position Units																																				
Registration2Position	REAL	Registration 2 Position in Position Units																																				
Registration1Time	DINT	Registration 1 Time as CST time in microseconds																																				
Registration2Time	DINT	Registration 2 Time as CST time in microseconds																																				
InterpolationTime	DINT	Interpolation Time as CST time in microseconds																																				
InterpolatedActualPosition	REAL	Interpolated Actual Position in Position Units																																				
MasterOffset	REAL	Master Offset in Master Position Units																																				
StrobeMasterOffset	REAL	Strobe Master Offset in Master Position Units																																				
StartMasterOffset	REAL	Start Master Offset in Master Position Units																																				
CommandPosition	REAL	Command Position in Position Units																																				
StrobeCommandPosition	REAL	Strobe Command Position in Position Units																																				
StartCommandPosition	REAL	Start Command Position in Position Units																																				
CommandVelocity	REAL	Command Velocity in Position Units / Sec																																				
CommandAcceleration	REAL	Command Acceleration in Position Units / Sec2																																				
InterpolatedCommandPosition	REAL	Interpolated Command Position in Position Units																																				
AccelStatus	BOOL	Set if the axis is currently being commanded to accelerate.																																				
DecelStatus	BOOL	Set if the axis is currently being commanded to decelerate.																																				
MoveStatus	BOOL	Set if a Move motion profile is currently in progress. Cleared when the Move is complete or is superseded by some other motion operation.																																				
JogStatus	BOOL	Set if a Jog motion profile is currently in progress. Cleared when the Jog is complete or is superseded by some other motion operation.																																				

Mnemonic:	Data Type:	Description:
GearingStatus	BOOL	Set if the axis is a slave that is currently Gearing to another axis. Cleared when the gearing operation is stopped or is superseded by some other motion operation.
HomingStatus	BOOL	Set if a Home motion profile is currently in progress. Cleared when the homing operation is stopped or is superseded by some other motion operation.
StoppingStatus	BOOL	Set if there is a stopping process currently in progress. Cleared when the stopping process is complete. Note: The stopping process is used to stop an axis (initiated by an MAS, MGS, Stop Motion fault action, or mode change).
AxisHomedStatus	BOOL	Cleared at power-up or reconnection. Set by the MAH instruction upon successful completion of the configured homing sequence, and later cleared when the axis enters the shutdown state.
PositionCamStatus	BOOL	Set if a Position Cam motion profile is currently in progress. Cleared when the Position Cam is complete or is superseded by some other motion operation.
TimeCamStatus	BOOL	Set if a Time Cam motion profile is currently in progress. Cleared when the Time Cam is complete or is superseded by some other motion operation.
PositionCamPendingStatus	BOOL	Set if a Position Cam motion profile is currently pending the completion of a currently executing cam profile. This would be initiated by executing an MAPC instruction with Pending execution selected. This bit is cleared when the current position cam profile completes, initiating the start of the pending cam profile. This bit is also cleared if the position cam profile completes, or is superseded by some other motion operation.
TimeCamPendingStatus	BOOL	Set if a Time Cam motion profile is currently pending the completion of a currently executing cam profile. This would be initiated by executing an MATC instruction with Pending execution selected. This bit is cleared when the current time cam profile completes, initiating the start of the pending cam profile. This bit is also cleared if the time cam profile completes, or is superseded by some other motion operation.
GearingLockStatus	BOOL	Set whenever the slave axis is locked to the master axis in a gearing relationship according to the specified gear ratio. The clutch function of the gearing planner is used to ramp an axis up, or down, to speed in a gearing process (MAG with Clutch selected). This bit is cleared during the intervals where the axis is clutching.
PositionCamLockStatus	BOOL	Set whenever the master axis satisfies the starting condition of a currently active Position Cam motion profile. The starting condition is established by the Start Control and Start Position parameters of the MAPC instruction. This bit is cleared when the current position cam profile completes, or is superseded by some other motion operation. In uni-directional master direction mode, the Position Cam Lock Status bit is cleared when moving in the "wrong" direction and sets when moving in the "correct" direction.
MasterOffsetMoveStatus	BOOL	Set if a Master Offset Move motion profile is currently in progress. This bit is cleared when the Master Offset Move is complete or is superseded by some other motion operation.
ServoActStatus	BOOL	Set when the associated axis is under servo control. Cleared when servo action is disabled.
DriveEnableStatus	BOOL	Set when the Drive Enable output of the associated physical axis is currently enabled. Cleared when physical servo axis Drive Enable output is currently disabled.
ShutdownStatus	BOOL	Set when the associated axis is currently in the Shutdown state. Cleared when the axis is transitioned from the Shutdown state to another state.

Mnemonic:	Data Type:	Description:
ConfigUpdateInProgress	BOOL	The Configuration Update Status Bits attribute provides a method for monitoring the progress of one or more specific module configuration attribute updates initiated by either a Set Attribute List service (which is internal to the firmware) or an SSV in the user program. When such an update is initiated, the ControlLogix processor sets this bit. This bit will remain set until the Set Attribute List reply comes back from the servo module indicating that the data update process was successful. Thus the Configuration Update Status Bits attribute provides a method of waiting until the servo configuration data update to the connected motion module is complete before starting a dependent operation.
PhysicalAxisFault	BOOL	Set when one or more fault conditions have been reported by the physical axis. The specific fault conditions can then be determined through access to the fault attributes of the associated physical axis. A PhysicalAxisFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
ModuleFault	BOOL	Set when a serious fault has occurred with the motion module associated with the selected axis. Usually a module fault affects all axes associated with the motion module. A module fault generally results in the shutdown of all associated axes. Reconfiguration of the motion module is required to recover from a module fault condition. A ModuleFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
ConfigFault	BOOL	Set when an update operation targeting an axis configuration attribute of an associated motion module has failed. Specific information concerning the Configuration Fault may be found in the Attribute Error Code and Attribute Error ID attributes associated with the motion module. A ConfigFault can be set as either a Major Fault or a Non Major Fault in the Attribute tab of the associated Motion Group properties dialog box.
WatchEvArmStatus	BOOL	Set when a watch event has been armed through execution of the MAW (Motion Arm Watch) instruction. Cleared when either a watch event occurs or a MDW (Motion Disarm Watch) instruction is executed.
WatchEvStatus	BOOL	Set when a watch event has occurred. Cleared when either another MAW (Motion Arm Watch) instruction or a MDW (Motion Disarm Watch) instruction is executed.
RegEvArmStatus	BOOL	Set when a registration checking has been armed for registration input 1 through execution of the MAR (Motion Arm Registration) instruction. Cleared when either a registration event occurs or a MDR (Motion Disarm Registration) instruction is executed for registration input 1.
RegEvStatus	BOOL	Set when a registration event has occurred on registration input 1. Cleared when either another MAR (Motion Arm Registration) instruction or a MDR (Motion Disarm Registration) instruction is executed for registration input 1.
RegEv2ArmStatus	BOOL	Set when a registration checking has been armed for registration input 2 through execution of the MAR (Motion Arm Registration) instruction. Cleared when either a registration event occurs or a MDR (Motion Disarm Registration) instruction is executed for registration input 2.
RegEv2Status	BOOL	Set when a registration event has occurred on registration input 2. Cleared when either another MAR (Motion Arm Registration) instruction or a MDR (Motion Disarm Registration) instruction is executed for registration input 2.
HomeEvArmStatus	BOOL	Set when a home event has been armed through execution of the MAH (Motion Axis Home) instruction. Cleared when a home event occurs.
HomeEvStatus	BOOL	Set when a home event has occurred. Cleared when another MAH (Motion Axis Home) instruction is executed.
OutputCamStatus	DINT	A set of bits* that are set when the Output Cam has been initiated.
OutputCamPendingStatus	DINT	A set of bits* that are set when an Output Cam is waiting for an armed Output Cam to move beyond its cam start/cam end position.

Mnemonic:	Data Type:	Description:
OutputCamLockStatus	DINT	A set of bits* that are set when an Output Cam is locked to the Master Axis.
OutputCamTransitionStatus	DINT	A set of bits* that are set when the transition from the current armed Output Cam to the pending Output Cam is in process.
* The bit number corresponds with the execution target number. One bit per execution target.		

Servo Configuration Update Status Bits attributes

You can use the servo configuration update status bits attributes to monitor the progress of servo configuration attribute updates, which are initiated by an SSV instruction in your application program.

When the SSV instruction initiates an update, the controller sets the update status bit associated with the attribute. The update status bit remains set until the servo module indicates that the data update was successful.

For example, if you use an SSV instruction to change the PositionProportionalGain attribute of an axis and follow it with logic based on the completion of the SSV instruction, you can check for the resetting of the .PosPGainStatus bit to ensure that the servo module attribute is updated.

The following is a list of the servo configuration update status bits attributes.

Variable	Data Type	Description
.AccFfGainStatus	BOOL	The status of an update to the <i>AccelerationFeedforwardGain</i> attribute.
.AxisTypeStatus	BOOL	The status of an update to the <i>AxisType</i> attribute.
.DriveFaultActStatus	BOOL	The status of an update to the <i>DriveFaultAction</i> attribute.
.EncLossFaultActStatus	BOOL	The status of an update to the <i>EncoderLossFaultAction</i> attribute.
.EncNsFaultActStatus	BOOL	The status of an update to the <i>EncoderNoiseFaultAction</i> attribute.
.FricCompStatus	BOOL	The status of an update to the <i>FrictionCompensation</i> attribute.
.MaxNTrvlStatus	BOOL	The status of an update to the <i>MaximumNegativeTravel</i> attribute.
.MaxPTrvlStatus	BOOL	The status of an update to the <i>MaximumPositiveTravel</i> attribute.
.OutFiltBWStatus	BOOL	The status of an update to the <i>OutputFilterBandwidth</i> attribute.
.OutLimitStatus	BOOL	The status of an update to the <i>OutputLimit</i> attribute.
.OutOffsetStatus	BOOL	The status of an update to the <i>OutputOffset</i> attribute.
.OutScaleStatus	BOOL	The status of an update to the <i>OutputScaling</i> attribute.
.PosErrorFaultActStatus	BOOL	The status of an update to the <i>PositionErrorFaultAction</i> attribute.
.PosErrorTolStatus	BOOL	The status of an update to the <i>PositionErrorTolerance</i> attribute.
.PosIGainStatus	BOOL	The status of an update to the <i>PositionIntegralGain</i> attribute.
.PosLockTolStatus	BOOL	The status of an update to the <i>PositionLockTolerance</i> attribute.

Variable	Data Type	Description
.PosPGainStatus	BOOL	The status of an update to the <i>PositionProportionalGain</i> attribute.
.PosUnwindStatus	BOOL	The status of an update to the <i>PositionUnwind</i> attribute.
.POtrvlFactActStatus	BOOL	The status of an update to the <i>SoftOvertravelFaultAction</i> attribute.
.VelFfGainStatus	BOOL	The status of an update to the <i>VelocityFeedforwardGain</i> attribute.
.VelGainStatus	BOOL	The status of an update to the <i>VelocityIntegralGain</i> attribute.
.VelPGainStatus	BOOL	The status of an update to the <i>VelocityProportionalGain</i> attribute.

The MOTION_GROUP Structure

The MOTION_GROUP structure contains status and configuration information for your motion group. There is one MOTION_GROUP structure per controller. You can directly access this information in your motion control program. For example, if you want to use the DriveFault attribute for MOTION_GROUP, you would use MOTION_GROUP.DriveFault to gain access to the attribute.


The bits in the MOTION_GROUP structure are set when any axis in the group experiences the conditions required to set the bit. For example, if one axis in a group of ten axes developed the conditions to set the .POtrvlFault bit, the controller would set the .POtrvlFault bit in the MOTION_GROUP structure.

Mnemonic:	Data Type:	Description:
.GroupStatus	DINT	The status bits for the group.
	Bit:	Number: Data Type: Description:
	.InhibStatus	00 BOOL inhibit status
	.GroupSynced	01 BOOL synchronization status
.MotionFault	DINT	The motion fault bits for the group.
	Bit:	Number: Data Type: Description:
	.ACAsyncConnFault	00 BOOL asynchronous connection fault
	.ACSyncConnFault	01 BOOL synchronous connection fault (controller declared)
.ServoFault	DINT	The servo-module fault bits for the group.
	Bit:	Number: Data Type: Description:
	.POtrvlFault	00 BOOL positive overtravel fault
	.NOtrvlFault	01 BOOL negative overtravel fault
	.PosErrorFault	02 BOOL position error fault
	.EncCHALossFault	03 BOOL encoder channel A loss fault
	.EncCHBLossFault	04 BOOL encoder channel B loss fault
	.EncCHZLossFault	05 BOOL encoder channel Z loss fault
	.EncNsFault	06 BOOL encoder noise fault
	.DriveFault	07 BOOL drive fault
	Bit:	Number: Data Type: Description:
	.SyncConnFault	00 BOOL synchronous connection fault (servo declared)
	.HardFault	01 BOOL servo hardware fault

Mnemonic:	Data Type:	Description:
.GroupFault	DINT	The fault bits for the group.
		Bit:
		Number: Data Type: Description:
		.GroupOverlapFault 00 BOOL group overlap fault
		.CSTLossFault 01 BOOL The controller has lost synchronization with the CST master
		.GroupTaskLoadingFault 02 BOOL The group coarse update period is too low, user application tasks are not getting enough time to execute.

The MOTION_INSTRUCTION Structure


The controller uses the MOTION_INSTRUCTION tag (structure) to store status information during the execution of motion instructions. Every motion instruction has a motion control parameter that requires a MOTION_INSTRUCTION tag for this purpose.



WARNING

Tags used for the motion control attribute of instructions should only be used once. Re-use of the motion control attribute in other instructions can cause unintended operation of the control variables.

The structure of the motion instruction structure is shown below:



Mnemonic:	Data Type:	Description:
.EN	BOOL	The enable bit indicates that the instruction is enabled (the rung-in and rung-out condition is true).
.DN	BOOL	The done bit indicates that all calculations and messaging (if any) are complete.
.ER	BOOL	The error bit indicates when the instruction is used illegally.
.IP	BOOL	The in process bit indicates that a process is being executed.
.PC	BOOL	The process complete bit indicates that the operation is complete. The .DN bit sets after an instruction has completed execution. The .PC bit sets when the initiated process has completed.
.ACCEL	BOOL	The .ACCEL bit indicates that the velocity has increased for the individual instruction that it is tied to i.e jog, move, gearing
.DECEL	BOOL	The .DECEL bit indicates that the velocity has decreased for the individual instruction that it is tied to i.e jog, move, gearing.
.ERR	INT	The error value contains the error code associated with a motion function. See page 1-8.
.STATUS	SINT	The message status value indicates the status condition of any message associated with the motion function. See page 1-10.
.STATE	SINT	The execution status value keeps track of the execution state of a function. Many motion functions have several steps and this value tracks these steps. See page 1-10.
.SEGMENT	DINT	A segment is the distance from one point up to but, not including the next point. A .SEGMENT gives the relative position by segment number as the Cam is executing.

Error codes (.ERR)

Error Code:	Error Message	Description:
1	Reserved Error Code 1	Reserved for future use.
2	Reserved Error Code 2	Reserved for future use
3	Execution Collision	The instruction tried to execute while another instance of this instruction was executing. This can occur when the controller executes a messaging instruction without checking the .DN bit of the preceding instruction.
4	Servo On State Error	The instruction tried to execute on an axis with a closed servo loop.
5	Servo Off State Error	The instruction tried to execute on an axis with a servo loop that is not closed.
6	Drive On State Error	The axis drive is enabled.
7	Shutdown State Error	The axis is in the shutdown state.
8	Illegal Axis Type	The configured axis type is not correct.
9	Overtravel Condition	The instruction tried to execute in a direction that aggravates the current overtravel condition.
10	Master Axis Conflict	The master axis reference is the same as the slave axis reference.
11	Axis Not Configured	The axis is not configured.
12	Servo Message Failure	Messaging to the servo module failed.
13	Parameter Out Of Range	The instruction tried to use a parameter that is outside the range limit.
14	Tune Process Error	The instruction cannot apply the tuning parameters because of an error in the run tuning instruction.
15	Test Process Error	The instruction cannot apply the diagnostic parameters because of an error in the run diagnostic test instruction.
16	Home In Process Error	The instruction tried to execute with homing in progress.
17	Axis Mode Not Rotary	The instruction tried to execute a rotary move on an axis that is not configured for rotary operation.
18	Axis Type Unused	The axis type is configured as unused.
19	Group Not Synchronized	The motion group is not in the synchronized state. This could be caused by a missing servo module or a misconfiguration.
20	Axis In Faulted State	The axis is in the faulted state.
21	Group In Faulted State	The group is in the faulted state.
22	Axis In Motion	An MSO (Motion Servo On) or MAH (Motion Axis Home) instruction was attempted while the axis was in motion.
23	Illegal Dynamic Change	An instruction attempted an illegal change of dynamics.
24	Illegal AC Mode Op	The controller attempted to execute an MDO, MSO, MAH, MAJ, MAM, MCD, MAPC, MATC, MAG, MRAT, or MRHD instruction when the controller was in the test mode.
25	Illegal Instruction	You attempted to execute an instruction that is not correct.
26	Illegal Cam Length	The cam array is of an illegal length.
27	Illegal Cam Profile Length	The cam profile array is of an illegal length.
28	Illegal Cam Type	You have an illegal segment type in the cam element.
29	Illegal Cam Order	You have an illegal order of cam elements.
30	Cam Profile Being Calculated	You tried to execute a cam profile while it is being calculated.
31	Cam Profile Being Used	The cam profile array you tried to execute is in use.

Error Code:	Error Message	Description:
32	Cam Profile Not Calculated	The cam profile array you tried to execute has not been calculated.
33	Position Cam Not Enabled	It attempted to execute an MAH instruction without a position cam in process.
34	Registration in Progress	A MAH instruction is trying to start while a registration is already running.
35	Illegal Execution Target	Either the Logix controller or the Output Cam module does not support the specified Output Cam, axis, input or output.
36	Illegal Output Cam	Either the size of the Output Cam array is not supported or the value of one of its members is out of range.
37	Illegal Output Compensation	Either the size of the Output Compensation array is not supported or the value of one of its members is out of range.
38	Illegal Axis Data Type	The axis data type is illegal. It is incorrect for the operation.
39	Process Conflict	You have a conflict in your process. Test and Tune cannot be run at the same time.
40	Drive Locally Disabled	You are trying to run a MSO or MAH instruction when the drive is locally disabled.
41	Illegal Homing Config	The Homing configuration is illegal. You have an absolute homing instruction when the Homing sequence is not immediate.

Message status (.STATUS)

Message Status:	Description:
0x0	The message was successful.
0x1	The module is processing another message.
0x2	The module is waiting for a response to a previous message.
0x3	The response to a message failed.
0x4	The module is not ready for messaging.

Execution status (.STATE)

The execution status is always set to 0 when the controller sets the .EN bit for a motion instruction. Other execution states depend on the motion instruction.

Profile Segment (.SEGMENT)

A segment is the distance from one point up to but, not including the next point. A .SEGMENT instruction gives the relative position by segment number as the Cam is executing.

CAM Structure

The Cam data type consists of slave and master point pairs as well as an interpolation type. Since there is no association with a specific axis position or time, the point values are unit-less. The interpolation type can be specified for each segment as either linear or cubic. The format of the cam array element is shown in the following table.

Mnemonic:	Data Type:	Description:
MASTER	REAL	The x value of the point.
SLAVE	REAL	The y value of the point.
Segment Type	DINT	The type of interpolation. Value: Description 0 linear. 1 cubic.

CAM_PROFILE Structure

The CAM_PROFILE data type is an array of coefficients representing a calculated cam profile that can be used as input to a time cam or position cam instruction. The only element available to the user is Status which is defined in the following table.

Mnemonic:	Data Type:	Description:
Status	DINT	The status parameter is used to indicate that the Cam Profile array element has been calculated. If execution of a camming instruction is attempted using an uncalculated element in a Cam Profile, the instruction produces an error. Value: Description 0 Cam profile element has not been calculated. 1 Cam profile element is being calculated. 2 Cam profile element has been calculated. n Cam profile element has been calculated and is currently being used by (n-2) MAPC and MATC instructions.

OUTPUT_CAM Structure

The OUTPUT_CAM data type is an array that defines the specifics for each Output Cam element. The OUTPUT_CAM contains the following members.

Mnemonic	Data Type:	Description:														
OutputBit	DINT	You must select an output bit within the range of 0 to 31. A selection of less than 0 or greater than 31 results in an Illegal Output Cam error and the cam element is not considered.														
LatchType	DINT	<div>The Latch Type determines how the corresponding output bit is set. A value of less than 0 or greater than 3 results in an Illegal Output Cam error and a latch type of Inactive is used.</div> <table><tr><th>Value:</th><th>Description</th></tr><tr><td>0 = Inactive</td><td>The output bit is not changed.</td></tr><tr><td>1 = Position</td><td>The output bit is set when the axis enters the compensated cam range.</td></tr><tr><td>2 = Enable</td><td>The output bit is set when the enable bit becomes active.</td></tr><tr><td>3 = Position and Enable</td><td>The output bit is set when the axis enters the compensated cam range and the enable bit becomes active.</td></tr></table>	Value:	Description	0 = Inactive	The output bit is not changed.	1 = Position	The output bit is set when the axis enters the compensated cam range.	2 = Enable	The output bit is set when the enable bit becomes active.	3 = Position and Enable	The output bit is set when the axis enters the compensated cam range and the enable bit becomes active.				
Value:	Description															
0 = Inactive	The output bit is not changed.															
1 = Position	The output bit is set when the axis enters the compensated cam range.															
2 = Enable	The output bit is set when the enable bit becomes active.															
3 = Position and Enable	The output bit is set when the axis enters the compensated cam range and the enable bit becomes active.															
UnlatchType	DINT	<div>The Unlatch Type determines how the output bit is reset. Selecting a value less than 0 or greater than 5 results in an Illegal Output Cam error and an unlatch type of Inactive is used.</div> <table><tr><th>Value:</th><th>Description</th></tr><tr><td>0 = Inactive</td><td>The output bit is not changed.</td></tr><tr><td>1 = Position</td><td>The output bit is reset when the axis leaves the compensated cam range.</td></tr><tr><td>2 = Duration</td><td>The output bit is reset when the duration expires.</td></tr><tr><td>3 = Enable</td><td>The output bit is reset when the enable bit becomes inactive.</td></tr><tr><td>4 = Position and Enable</td><td>The output bit is reset when the axis leaves the compensated cam range or the enable bit becomes inactive.</td></tr><tr><td>5 = Duration and Enable</td><td>The output bit is reset when the duration expires or the enable bit becomes inactive.</td></tr></table>	Value:	Description	0 = Inactive	The output bit is not changed.	1 = Position	The output bit is reset when the axis leaves the compensated cam range.	2 = Duration	The output bit is reset when the duration expires.	3 = Enable	The output bit is reset when the enable bit becomes inactive.	4 = Position and Enable	The output bit is reset when the axis leaves the compensated cam range or the enable bit becomes inactive.	5 = Duration and Enable	The output bit is reset when the duration expires or the enable bit becomes inactive.
Value:	Description															
0 = Inactive	The output bit is not changed.															
1 = Position	The output bit is reset when the axis leaves the compensated cam range.															
2 = Duration	The output bit is reset when the duration expires.															
3 = Enable	The output bit is reset when the enable bit becomes inactive.															
4 = Position and Enable	The output bit is reset when the axis leaves the compensated cam range or the enable bit becomes inactive.															
5 = Duration and Enable	The output bit is reset when the duration expires or the enable bit becomes inactive.															
Left	REAL	The left cam position along with the right cam position define the cam range of the Output Cam element. The left and right cam positions specify the latch or unlatch positions of the output bit when the latch or unlatch type is set to Position or Position and Enable with the enable bit active. If the left position is less than the Cam Start position or greater than the Cam End position, an Illegal Output Cam error is returned and the cam element is not considered.														
Right	REAL	The right cam position along with the left cam position define the cam range of the Output Cam element. The right and left cam positions specify the latch or unlatch positions of the output bit when the latch or unlatch type is set to Position or Position and Enable with the enable bit active. If the right position is less than the Cam Start position or greater than the Cam End position, an Illegal Output Cam error is returned and the cam element is not considered.														
Duration	REAL	Duration specifies the time in seconds between latching and unlatching when the UnlatchType is Duration or Duration and Enable with the enable bit active. A value less than or equal to 0 results in an Illegal Output Cam error and the cam element is not considered.														
EnableType	DINT	<div>This defines the source and polarity of the specified EnableBit when LatchType or UnlatchType is Enable, Position and Enable or Duration and Enable. A value of less than 0 or greater than 31 results in an Illegal Output Cam error and the cam element is not considered.</div> <table><tr><th>Value:</th><th>Description</th></tr><tr><td>0 = Input</td><td>The enable bit is in the Input parameter.</td></tr><tr><td>1 = Inverted Input</td><td>The enable bit is in the input parameter and is active low.</td></tr><tr><td>2 = Output</td><td>The enable bit is in the Output parameter.</td></tr><tr><td>3 = Inverted Output</td><td>The enable bit is in the Output parameter and is active low.</td></tr></table>	Value:	Description	0 = Input	The enable bit is in the Input parameter.	1 = Inverted Input	The enable bit is in the input parameter and is active low.	2 = Output	The enable bit is in the Output parameter.	3 = Inverted Output	The enable bit is in the Output parameter and is active low.				
Value:	Description															
0 = Input	The enable bit is in the Input parameter.															
1 = Inverted Input	The enable bit is in the input parameter and is active low.															
2 = Output	The enable bit is in the Output parameter.															
3 = Inverted Output	The enable bit is in the Output parameter and is active low.															
EnableBit	DINT	The value of the Enable Bit selected must be between 0 and 31 when LatchType or UnlatchType is Enable , Position and Enable or Duration and Enable . A value of less than 0 or greater than 31 results in an Illegal Output Cam error and the cam element is not considered.														

OUTPUT_COMPENSATION Structure

The OUTPUT_COMPENSATION data type defines the details for each output bit by setting the characteristics of each actuator. OUTPUT_COMPENSATION contains the following members:

Mnemonic	Data Type:	Description:										
Offset	REAL	Offset provides position compensation for both the latch and unlatch operations.										
LatchDelay	REAL	Latch delay, programmed in seconds, provides time compensation for the latch operation.										
UnlatchDelay	REAL	Unlatch delay, programmed in seconds, provides time compensation for the unlatch operation.										
Mode	DINT	<div>The Mode determines the behavior of the output bit. The following four mode options are available. A value of less than 0 or greater than 3 results in an Illegal Output Compensation error.</div> <table><tr><th>Value:</th><th>Description</th></tr><tr><td>0 = Normal</td><td>The output bit is set for the latch operation and is reset for the unlatch operation.</td></tr><tr><td>1 = Inverted</td><td>The output bit is reset for the latch operation and is set for the unlatch operation.</td></tr><tr><td>2 = Pulsed</td><td>The output bit is set for the latch operation and for the on-duty state of the pulse and is reset for the unlatch operation and for the off-duty state of the pulse.</td></tr><tr><td>3 = Inverted and Pulsed</td><td>The output bit is reset for the latch operation and for the on-duty state of the pulse and is set for the unlatch operation and for the off-duty state of the pulse.</td></tr></table>	Value:	Description	0 = Normal	The output bit is set for the latch operation and is reset for the unlatch operation.	1 = Inverted	The output bit is reset for the latch operation and is set for the unlatch operation.	2 = Pulsed	The output bit is set for the latch operation and for the on-duty state of the pulse and is reset for the unlatch operation and for the off-duty state of the pulse.	3 = Inverted and Pulsed	The output bit is reset for the latch operation and for the on-duty state of the pulse and is set for the unlatch operation and for the off-duty state of the pulse.
Value:	Description											
0 = Normal	The output bit is set for the latch operation and is reset for the unlatch operation.											
1 = Inverted	The output bit is reset for the latch operation and is set for the unlatch operation.											
2 = Pulsed	The output bit is set for the latch operation and for the on-duty state of the pulse and is reset for the unlatch operation and for the off-duty state of the pulse.											
3 = Inverted and Pulsed	The output bit is reset for the latch operation and for the on-duty state of the pulse and is set for the unlatch operation and for the off-duty state of the pulse.											
CycleTime	REAL	Pulse time in seconds. If mode is Pulsed or Inverted and Pulsed , and CycleTime is less than or equal to 0, an Illegal Output Compensation error results.										
DutyCycle	REAL	The percent of CycleTime in which the pulse is to be turned on (on-duty). A value of 50 represents 50% on-duty. A value of less than 0 or greater than 100 returns an Illegal Output Compensation error.										

The Motion Attributes

This appendix lists all of the attributes associated with motion. The motion attributes are parameters that the RSLogix 5000 software uses to define the operational characteristics of a motion module or axis, how the module/axis interacts with the system, and how the conversion of motion commands into actual motion of a device is performed.

Motion Attribute Folders

The motion attributes are divided into three main folders: Interface, Status, and Configuration. These indicate how the attributes are used.

Data Type Groups

The motion attributes are divided into groups and are designated by a G and a number. These groups depend upon the specific DataType and an axis may be associated with many groups.

The following table lists the Group number and the axis DataType it affects.

Group	AXIS_SERVO_DRIVE	AXIS_SERVO	Generic	AXIS_VIRTUAL	AXIS_CONSUMED	Feedback
G1	X	X	X	X	X	X
G2	X	X	X			X
G3					X	
G4	X	X	X	X	X	
G5	X	X	X		X	
G6	X	X	X	X		X
G7	X	X	X			
G8	X	X	X	X		
G9		X				
G10	X					
G11	X	X				
G12	X	X				X

Motion Attributes

The following table lists all of the attributes associated with motion in alphabetical order. The table contains the attribute name, the Data Type, the instruction type, Group, Folder, and a description of the attribute.

Variable	Data Type	Instruction	Group/Folder/Description
AccelerationCommand	REAL	GSV	G11/Status/ It is the current acceleration reference to the output summing junction for the specified axis. It represents the output of the inner velocity control loop.
AccelerationDataScaling	INT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
AccelerationDataScalingExp	INT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
AccelerationDataScalingFactor	DINT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
AccelerationFeedback	REAL	GSV	G11/Status/ It is the actual velocity of the axis as estimated by the servo module. It is calculated by taking the difference in the estimated velocity over the servo update interval. Acceleration Feedback is a signed value. The sign (+ or -) depends on the direction the axis is currently moving.
AccelerationFeedforwardGain	REAL	GSV/SSV	G11/Configuration/ The value used to provide the torque command output to generate the command acceleration. The optimal value is 100%.
AccelerationLimitBipolar	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
AccelerationLimitNegative	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
AccelerationLimitPositive	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
ActualAcceleration	REAL	GSV	G1/Status/ It is the current instantaneously measured acceleration of an axis. It is calculated as the current increment to the actual velocity per coarse update interval. This is a signed value with the sign depending on the direction of the axis.
ActualPosition	REAL	GSV	G1/Status/ The actual position of your axis as of one coarse update period ago.
ActualVelocity	REAL	GSV	G1/Status/ It is the current instantaneously measured speed of an axis calculated as the current increment to the actual position per coarse update interval. It is a signed value to tell in which direction the axis is moving. The internal resolution limit of the actual velocity is 1 encoder count per coarse update.

Variable	Data Type	Instruction	Group/Folder/Description
AssignedGroupInstance	DINT	GSV	G1/Interface/ The instance number of the motion group that contains your axis.
ATConfigurationList	DINT ARRAY		It maps directly to the SERCOS IDN. It is automatically set based on the current ServoLoopConfiguration and is Read-only.
AttributeErrorCode	INT	GSV	G11/Status/ This attribute returns the appropriate ASA Error code when an Axis Configuration fault occurs. It is not reset to zero until the motion module is reconfigured.
AttributeErrorID	INT	GSV	G11/Status/ This retains the identification associated with the error code returned when an Axis Configuration Fault occurred. The module must be reconfigured to reset this attribute to zero.
AuxFeedbackConfiguration	INT	GSV	G10/Configuration/ It maps directly to the SERCOS IDN. It is automatically set based on the current Drive Polarity Settings. All command bits are set according to the current Feedback Type value.
AuxFeedbackRatio	REAL	GSV	G10/Configuration/ This represents the quantitative relationship between the auxiliary feedback device and the motor. It is used in range limit and default value calculations during configuration based on the selected motor's specifications. It is also used by the drive when running the dual feedback loop configuration.
AuxFeedbackResolution	DINT	GSV	G10/Configuration/ This provides the A-B drive with the resolution of the associated feedback device in cycles. It also gives the Logix controller and drive with critical information to compute conversion constants used in converting drive units to feedback counts.
AuxFeedbackType	INT	GSV	G10/Configuration/ It provides the A-B drive with specific device configuration information for the auxiliary feedback device.
AuxPositionFeedback	REAL	GSV	G11/Status/ The current value of the position feedback coming from the auxiliary feedback input.
AverageVelocity	REAL	GSV	G1/Status/ It is the current speed of an axis as calculated by averaging the actual velocity of the axis over the configured Average Velocity Timebase for the axis. It is a signed value to tell in which direction the axis is moving.
AverageVelocityTimebase	REAL	GSV/SSV	G1/Configuration/ It is used to specify the desired time in seconds for use in calculating the Average Velocity of the axis. The value should be large enough to filter out the small changes in velocity which would otherwise result in noisy velocity value yet small enough to track significant changes in axis velocity. A value between 0.25 and 0.5 seconds works for most applications.
AxisConfigurationState	SINT	GSV	G1/Interface/ It is used for debugging purposes to indicate the present location of the axis in the axis configuration state-machine. Consumed and virtual axes use this attribute also.

Variable	Data Type	Instruction	Group/Folder/Description
AxisControlBits	DINT	GSV	<div><div><div><div><div>G11/Status/</div><div>Bit:</div></div><div><div>0</div><div>Abort Process Request</div></div><div><div>1</div><div>Shutdown Request</div></div><div><div>2</div><div>Zero DAC Request (Servo) Reserved (Servo Drive)</div></div><div><div>3</div><div>Abort Home Request</div></div><div><div>4</div><div>Abort Event Request</div></div><div><div>5-14</div><div>Reserved</div></div><div><div>15</div><div>Change Cmd Reference</div></div><div><div>16-31</div><div>Reserved</div></div></div><div><div>Bit Name:</div><div></div></div><div><div>Meaning:</div><div>when set, the servo module /drive disables any active tuning or testing process</div><div>when set, the servo module forces the axis/drive into the shutdown state</div><div>when set, the servo module forces the DAC output for the axis to zero volts.</div><div>when set any Homing procedures are cancelled</div><div>when set, any active watch or registration procedures are cancelled</div><div></div><div>bit is set when the Logix processor switches to a new position coordinate system for command position.</div></div></div></div>
AxisDataType	SINT	GSV	<div><div><div><div><div>G3/Interface/</div><div>This attribute determines which data template, memory format, and set of attributes are created and applied for this axis instance. It can only be set as part of an axis create service.</div></div><div><div>Value:</div><div>0 1 2 3 4 5</div></div><div><div>Meaning:</div><div>Feedback Consumed Virtual Generic Servo Servo Drive</div></div></div></div></div>

Variable	Data Type	Instruction	Group/Folder/Description
AxisInfoSelect1	DINT	GSV/SSV	<p>G11/Configuration/Enables periodic data updates for selected servo/drive status attributes. It is designed to reduce the flow of unnecessary data for the Servo/SERCOS module.</p> <p>Value: Meaning:</p> <ul style="list-style-type: none"> 0 None (default) 1 Position Command 2 Position Feedback 3 Aux. Position Feedback 4 Position Error 5 Position Int. Error 6 Velocity Command 7 Velocity Feedback 8 Velocity Error 9 Velocity Int. Error 10 Accel. Command 11 Accel. Feedback 12 Servo Output Level (Servo) 12 Reserved (Servo Drive) 13 Marker Distance (Servo Drive) 14 Torque Command (Servo Drive) 15 Torque Feedback (Servo Drive) 16 Pos Dynamic Torque Limit (Servo Drive) 17 Neg Dynamic Torque Limit (Servo Drive) 18 Motor Capacity (Servo Drive) 19 Drive Capacity (Servo Drive) 20 Power Capacity (Servo Drive) 21 Bus Regulator Capacity (Servo Drive) 22 Motor Electrical Angle (Servo Drive) 23 Torque Limit Source (Servo Drive) 24 DC Bus Voltage (Servo Drive)
AxisInfoSelect2	DINT	GSV/SSV	<p>G11/Configuration/Enables periodic data updates for selected servo status attributes. It is designed to reduce the flow of unnecessary data for the Servo module.</p> <p>Value: Meaning:</p> <ul style="list-style-type: none"> 0 None (default) 1 Position Command 2 Position Feedback 3 Aux. Position Feedback 4 Position Error 5 Position Int. Error 6 Velocity Command 7 Velocity Feedback 8 Velocity Error 9 Velocity Int. Error 10 Accel. Command 11 Accel. Feedback 12 Servo Output Level 13 Marker Distance
AxisInstance	DINT	GSV	<p>G1/Interface/It returns the instance number of an axis. Major fault records only contain the instance of the offending axis; this attribute is used to determine if the instance number matches that of the offending axis.</p>

Variable	Data Type	Instruction	Group/Folder/Description
AxisResponseBits	DINT	GSV	G11/Status/ Bit: Bit Name: Meaning: 0 Abort Process Acknowledge when set, the servo module accepts that the tuning or test process has been cancelled 1 Shutdown Acknowledge when set, the servo module accepts that the axis has been forced into the shutdown state 2 Zero DAC Acknowledge (Servo)when set, the servo module accepts that the DAC output for the axis has been set to zero volts. Reserved (Servo Drive) 3 Abort Home Acknowledge when set, the servo module accepts that the active Homing procedure is aborted 4 Abort Event Acknowledge when set, the servo module accepts that the active watch or registration procedure is cancelled 5-14 Reserved 15 Change Pos Reference Set when Servo loop switches to a new position coordinate system – Logix processor uses this bit to account for the offset implied by the shift in reference point. 16-31 Reserved
AxisState	SINT	GSV	G1/Interface/ This indicates the operating state of the axis. Value: Meaning: 0 Axis Ready 1 Direct Drive Control 2 Servo Control 3 Axis Faulted 4 Axis Shutdown
AxisStatusBits	DINT	GSV	G1/Status/ The axis status bits for your axis. Bit: Bit Name: Meaning: 0 ServoActionStatus It is set when the associated axis is under servo control. 1 DriveEnableStatus It is set when the Drive Enable output of the associated physical axis is enabled. 2 ShutdownStatus It is set when the associated axis is in a shutdown state. 3 ConfigurationUpdateInProgress It provides a method of monitoring the progress of one or more specific module configuration attribute updates initiated by either a Set Attribute List service or an SSV in the user program. 4-31 Reserved

Variable	Data Type	Instruction	Group/Folder/Description
AxisStructureAddress	DINT		G1/Interface/ It is used to return the actual physical address in memory where the axis instance is located.
AxisType	INT	GSV/SSV	G11/Configuration/ It establishes the intended use for the axis. It also controls the behavior of the servo modules's Axis Status LEDs and the RSLogix5000 uses the current configured type to control the look of its tab dialogs. Value:Meaning: 0 unused 1 feedback only 2 servo
BrakeEngageDelayTime	REAL	GSV/SSV	G10/Configuration/ This attribute controls the amount of time the drive continues to apply torque to the motor after the brake output is changed to engage the brake.
BrakeReleaseDelayTime	REAL	GSV/SSV	G10/Configuration/ This attribute controls the amount of time the drive holds of tracking command reference changes after the brake output is changed to release the brake.
BusRegulatorCapacity	REAL	GSV	G10/Status/ It displays the present utilization of the axis bus regulator as a percent of rated capacity.
BusRegulatorID	INT	GSV	G10/Configuration/ This attribute contains the enumeration of the specific A-B Bus Regulator or System Shunt catalog numbers associated with the axis. If it does not match an error is generated.
C2CConnectionInstance	DINT	GSV	G1/Interface/ This is used with the C2CMapInstance attribute to associate the axis to the consumed data when the AxisDataType is set to Consumed. This attribute is the connection instance under the C2C map instance, which provides the axis data sent to it from another axis via the C2C connection.
C2CMapInstance	DINT	GSV	G1/Interface/ This is used with the C2CConnectionInstance attribute to associate the axis to the consumed data when the AxisDataType is set to Consumed. This attribute For all other axis data types if the axis is to be produced then the attribute is set to 1 to indicate the connection is off the local controller's map instance.
CommandAcceleration	REAL	GSV	G4/Status/ It is the commanded speed of an axis as generated by any previous motion instruction. It is calculated as the current increment to the command velocity per coarse update interval. This is a signed value with the sign depending on the direction of the axis.
CommandPosition	REAL	GSV	G4/Status/ The command position of your axis that is to be acted upon one coarse update period from now.
CommandVelocity	REAL	GSV	G4/Status/ It is the commanded speed of an axis as generated by any previous motion instructions. It is a signed value to indicate the direction of the axis.
ConversionConstant	REAL	GSV/SSV	G1/Configuration/ It must be established for each axis to let axis position to be displayed and motion to be programmed in the position units specified by the PositionUnits attribute. It is also known as the K Constant because K represents the number of feedback counts per position unit.
DampingFactor	REAL	GSV/SSV	G11/Configuration/ This value is used in calculating the maximum position servo bandwidth during the execution of the MRAT instruction. It controls the dynamic response of the servo axis. The default value of 0.8 should work fine for most applications.
DCBusVoltage	DINT	GSV	G10/Status/ The present voltage on the DC Bus of the drive.

Variable	Data Type	Instruction	Group/Folder/Description
DriveAxisID	INT	GSV	G10/Configuration/ It contains the ASA Product Code of the drive amplifier associated with the axis. If the codes don't match and error is returned during the configuration process.
DriveCapacity	REAL	GSV	G10/Status/ This represents the present utilization of drive capacity as a percent of rated capacity.
DriveFaultAction	SINT	GSV/SSV	G9/Configuration/ Sets the type of operation to be performed when a drive fault occurs. Value:Meaning: 0 shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel. 1 disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable output is deactivated 2 stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module's Drive Enable Output. This is the gentlest stopping action for a fault. 3 status only – when set to status only, motion faults must be handled by the application program

Variable	Data Type	Instruction	Group/Folder/Description	
DriveFaultBits	DINT	GSV	G10/Status/	
			Bit:	Bit Name:
			0	PosSoftOvertravelFault
				Meaning:
				sets when the axis travels or attempts to travel beyond the configured value for Maximum Positive Travel
			1	NegSoftOvertravelFault
				sets when the axis travels or attempts to travel beyond the configured value for Maximum Negative Travel
			2	PosHardOvertravelFault
				sets when the axis travels or attempts to travel beyond the maximum position limit set by the hardware limit switch mounted to the machine
			3	NegHardOvertravelFault
				sets when the axis travels or attempts to travel beyond the minimum position limit set by the hardware limit switch mounted to the machine
			4	FeedbackFault
				sets when the differential electrical signal for one or more of the feedback channels are at same level or loss of feedback power or common electrical connection between servo module or drive and the feedback device
			5	FeedbackNoiseFault
				sets when simultaneous transitions of feedback of A and B are detected by the servo module
			6	AuxFeedbackFault
				sets when the differential electrical signal for one or more of the feedback channels are at same level or loss of feedback power or common electrical connection between servo module or drive and the auxiliary feedback device
			7	AuxFeedbackNoiseFault
				sets when simultaneous transitions of feedback of A and B are detected by the servo module
			8-12	Reserved
			13	GroundShortFault
				sets when the drive detects an imbalance in the DC bus supply current – indicating that current is flowing through an improper ground connection.
			14	DriveHardFault
				set when the drive detects a serious hardware fault

Variable	Data Type	Instruction	Group/Folder/Description
			<p>15 OverspeedFault sets when the speed of the axis exceeds the overspeed limit which is typically set to 150% of configured velocity limit for the motor.</p> <p>16 OverloadFault sets if the load limit for the motor/drive persists after the Overload warning bit has been set.</p> <p>17 DriveOvertempFault sets when the drive's temperature exceeds the drive shutdown temperature.</p> <p>18 MotorOvertempFault sets when the motor's temperature exceeds the motor shutdown temperature.</p> <p>19 DriveCoolingFault sets when the ambient temperature surrounding the drive's control circuitry exceeds the ambient shutdown temperature.</p> <p>20 DriveControlVoltageFault sets when the power supply voltages fall outside of acceptable limits</p> <p>21 FeedbackFault sets when one of the feedback sources has a problem that prevents the drive from receiving accurate or reliable position information from the feedback device.</p> <p>22 CommutationFault sets when the commutation feedback source has a problem that prevents the drive from receiving accurate or reliable motor shaft information to perform commutation.</p> <p>23 DriveOvercurrentFault sets when the drive output current exceeds the drive's predefined operating limits</p> <p>24 DriveOvervoltageFault sets when drive DC bus voltage exceeds the bus's predefined operating limits</p> <p>25 DriveUndervoltageFault sets when drive DC bus voltage is below the bus's predefined operating limits</p> <p>26 PowerPhaseLostFault sets when the drive detects that one or more of the three power line phases is lost from the 3 phase power inputs</p> <p>27 PositionErrorFault sets when the axis position error exceeds the value set for Position ErrorTolerance</p>

Variable	Data Type	Instruction	Group/Folder/Description
			28 SERCOSFault sets either when a requested SERCOS procedure fails to execute properly or the drive node detects a SERCOS communication fault 29 OvertravelFault 30-31 Reserved
DriveModelTimeConstant	REAL	GSV/SSV	G11/Configuration/ It is the sum of the drive's current loop time constant, feedback sample period, and the time constant associated with the velocity feedback filter. It is used by the MRAT instruction to calculate the Maximum Velocity and Position Servo bandwidth values when the axis is configured for an External Torque Servo Drive.
DrivePolarity	DINT	GSV/SSV	G10/Configuration/ Bit: Bit Name: 0 CustomPolarity 1 PositivePolarity 2 NegativePolarity Meaning: This is used to let you tailor the polarity configuration using the various polarity parameters defined by the SERCOS interface standard. This is set automatically using the MRHD and MAHD instructions. This is set automatically using the MRHD and MAHD instructions.
DriveScalingBits	DINT	GSV	G10/Configuration/ The custom scaling bit is used to enable custom scaling by the various scaling parameters defined by the SERCOS interface standard. When the bit is clear (default), the scaling parameters are all set based on the preferred Rockwell automation SERCOS drive scaling factors. Value:Meaning: 0 Standard/Custom Scaling 1-31 Reserved

Variable	Data Type	Instruction	Group/Folder/Description
			<div>16 VelocityLockStatus set when the magnitude of the physical axis Velocity Feedback is within the configured Velocity Window of the current velocity command</div> <div>17 VelocityStandstillStatus set when the magnitude of the physical axis Velocity Feedback is within the configured Velocity Standstill Window of zero speed.</div> <div>18 VelocityThresholdStatus set when the magnitude of the physical axis Velocity Feedback is less than the configured Velocity Threshold</div> <div>19 TorqueThresholdStatus Not Available.</div> <div>20 TorqueLimitStatus set when the magnitude of the axis torque command is greater than the configured Torque Limit.</div> <div>21 VelocityLimitStatus set when the magnitude of the commanded velocity to the velocity servo loop input is greater than the configured Velocity Limit.</div> <div>22 PositionLockStatus set when the magnitude of the axis position error becomes less than or equal to the configured Position Lock Tolerance value for the associated physical axis</div> <div>23 PowerLimitStatus Not Available. set when the magnitude of the actual supplied power is greater than the configured Power Threshold.</div> <div>24 Reserved</div> <div>25 LowerVelocityThresholdStatus Not Available.</div> <div>26 HighVelocityThresholdStatus Not Available.</div> <div>27-31 Reserved</div>

Variable	Data Type	Instruction	Group/Folder/Description
DriveThermalFaultAction	SINT	GSV/SSV	<p>G10/Configuration/Sets the type of action performed when a drive thermal fault occurs.</p> <p>Value:Meaning:</p> <ul style="list-style-type: none"> 0 shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel. 1 disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable output is deactivated 2 stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module's Drive Enable Output. This is the gentlest stopping action for a fault. 3 status only – when set to status only, motion faults must be handled by the application program
DriveWarningBits	DINT	GSV	<p>G10/Status/The warning bits are set when a condition exceeds its set limit. The warnings are given prior to a fault bit being set. The fault bit is set if the condition persists.</p> <p>Bit: Bit Name: Meaning:</p> <ul style="list-style-type: none"> 0 DriveOverloadWarning set when motor load limit is exceeded. It gives the control program a chance to reduce motor loading to avoid a shutdown situation. 1 DriveOvertempWarning set when drive's temperature limit is exceeded. It gives the program a chance to increase drive cooling before causing a shutdown situation. 2 MotorOvertempWarning set when the motor's temperature limit is exceeded. It gives the program a chance to increase motor cooling before entering a shutdown situation. 3 CoolingErrorWarning set when ambient temperature limit inside the drive enclosure is exceeded. It gives the program a chance to increase drive cooling to avoid a shutdown situation. 4-31 Reserved
ExternalDriveType	DINT	GSV	<p>G9/Configuration/Set the attribute to velocity servo drive when the servo module axis is interfacing with an external velocity servo drive to disable the servo modules internal digital velocity loop. When configuring as a torque servo drive select torque servo drive to enable the servo module axis' internal digital velocity loop.</p> <p>Value:Meaning:</p> <ul style="list-style-type: none"> 0 torque servo drive 1 velocity servo drive

Variable	Data Type	Instruction	Group/Folder/Description																					
FaultConfigurationBits	DINT	GSV/SSV	G11/Status/ These are the configuration fault bits. <table><thead><tr><th>Bit:</th><th>Bit Name:</th><th>Meaning:</th></tr></thead><tbody><tr><td>0</td><td>SoftOvertravelChecking</td><td>When set, it enables a periodic test that monitors the axis' current position and issues a Positive/Negative Overtravel Fault if it travels beyond the set limits</td></tr><tr><td>1</td><td>DriveFaultChecking (Servo)</td><td>Set this bit if you are using the servo module's drive fault input and specify the drive fault contact configuration of the amplifier's drive fault output.</td></tr><tr><td>1</td><td>HardOvertravelChecking (Servo Drive)</td><td>when set it enables a periodic test to monitor the current state of the positive and negative overtravel limit switch inputs and issues a Positive/Negative Hard Overtravel Fault if the axis position travels activate the limit switches</td></tr><tr><td>2</td><td>DriveFaultNormallyClosed (Servo)</td><td>This attribute controls sense of the Drive Fault input to the servo module.</td></tr><tr><td>3-31</td><td>Reserved (Servo)</td><td></td></tr><tr><td>2-31</td><td>Reserved (Servo Drive)</td><td></td></tr></tbody></table>	Bit:	Bit Name:	Meaning:	0	SoftOvertravelChecking	When set, it enables a periodic test that monitors the axis' current position and issues a Positive/Negative Overtravel Fault if it travels beyond the set limits	1	DriveFaultChecking (Servo)	Set this bit if you are using the servo module's drive fault input and specify the drive fault contact configuration of the amplifier's drive fault output.	1	HardOvertravelChecking (Servo Drive)	when set it enables a periodic test to monitor the current state of the positive and negative overtravel limit switch inputs and issues a Positive/Negative Hard Overtravel Fault if the axis position travels activate the limit switches	2	DriveFaultNormallyClosed (Servo)	This attribute controls sense of the Drive Fault input to the servo module.	3-31	Reserved (Servo)		2-31	Reserved (Servo Drive)	
Bit:	Bit Name:	Meaning:																						
0	SoftOvertravelChecking	When set, it enables a periodic test that monitors the axis' current position and issues a Positive/Negative Overtravel Fault if it travels beyond the set limits																						
1	DriveFaultChecking (Servo)	Set this bit if you are using the servo module's drive fault input and specify the drive fault contact configuration of the amplifier's drive fault output.																						
1	HardOvertravelChecking (Servo Drive)	when set it enables a periodic test to monitor the current state of the positive and negative overtravel limit switch inputs and issues a Positive/Negative Hard Overtravel Fault if the axis position travels activate the limit switches																						
2	DriveFaultNormallyClosed (Servo)	This attribute controls sense of the Drive Fault input to the servo module.																						
3-31	Reserved (Servo)																							
2-31	Reserved (Servo Drive)																							
FeedbackFaultAction	SINT	GSV/SSV	G11/Configuration/ Sets the type of action to be taken when a Feedback Fault is encountered. <table><tbody><tr><td>0</td><td>shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel.</td></tr><tr><td>1</td><td>disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable output is deactivated</td></tr><tr><td>2</td><td>stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module's Drive Enable Output. This is the gentlest stopping action for a fault.</td></tr><tr><td>3</td><td>status only – when set to status only, motion faults must be handled by the application program</td></tr></tbody></table>	0	shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel.	1	disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable output is deactivated	2	stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module's Drive Enable Output. This is the gentlest stopping action for a fault.	3	status only – when set to status only, motion faults must be handled by the application program													
0	shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel.																							
1	disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable output is deactivated																							
2	stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module's Drive Enable Output. This is the gentlest stopping action for a fault.																							
3	status only – when set to status only, motion faults must be handled by the application program																							

Variable	Data Type	Instruction	Group/Folder/Description															
FeedbackNoiseFaultAction	SINT	GSV/SSV	G11/Configuration/ Sets the action to be performed when a Feedback NoiseFault is encountered. 0 shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel. 1 disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable output is deactivated 2 stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module’s Drive Enable Output. This is the gentlest stopping action for a fault. 3 status only – when set to status only, motion faults must be handled by the application program															
FrictionCompensation	REAL	GSV SSV	G11/Configuration/ The fixed output level added or subtracted the Servo Output, based on its current sign, to break static friction (sticktion). The value should be just under the value needed to break the sticktion because a larger value can cause the axis to dither.															
HardOvertravelFaultAction	SINT	GSV/SSV	G11/Configuration/ Sets the type of action performed when a hard overtravel fault occurs. Value:Meaning: 0 shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel. 1 disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable output is deactivated 2 stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module’s Drive Enable Output. This is the gentlest stopping action for a fault. 3 status only – when set to status only, motion faults must be handled by the application program															
HomeConfigurationBits	DINT	GSV/SSV	G6/Configuration/ <table><tr><th>Bit:</th><th>Bit Name:</th><th>Meaning:</th></tr><tr><td>0</td><td>(Reserved)</td><td></td></tr><tr><td>1</td><td>HomeSwitchNormallyClosed</td><td>This determines the normal state of the home limit switch used by the homing sequence. The normal state of the switch is its state prior to being engaged by the axis during the homing sequence.</td></tr><tr><td>2</td><td>(Reserved)</td><td></td></tr><tr><td>3-31</td><td>Reserved</td><td></td></tr></table>	Bit:	Bit Name:	Meaning:	0	(Reserved)		1	HomeSwitchNormallyClosed	This determines the normal state of the home limit switch used by the homing sequence. The normal state of the switch is its state prior to being engaged by the axis during the homing sequence.	2	(Reserved)		3-31	Reserved	
Bit:	Bit Name:	Meaning:																
0	(Reserved)																	
1	HomeSwitchNormallyClosed	This determines the normal state of the home limit switch used by the homing sequence. The normal state of the switch is its state prior to being engaged by the axis during the homing sequence.																
2	(Reserved)																	
3-31	Reserved																	
HomeDirection	SINT	GSV/SSV	G6/Configuration/ The homing direction mode for your axis. Value:Meaning: 0 unidirectional forward 1 bidirectional forward 2 unidirectional reverse 3 bidirectional reverse															

Variable	Data Type	Instruction	Group/Folder/Description
HomeMode	SINT	GSV/SSV	G6/Configuration /The homing mode for your axis. Value:Meaning: 0 passive – This redefines the current absolute position of the axis on the occurrence of a home switch or encoder marker event. It is used to calibrate uncontrolled axes. 1 active (default) – When chosen, the desired homing sequence is selected by specifying whether or not a home limit switch and/or encoder marker is used for this axis. 2 absolute – This establishes the true absolute position of the axis by applying the configured Home Position to the reported position of the absolute feedback device.
HomeOffset	REAL	GSV/SSV	G6/Configuration /When applied to active or passive homing, using a non-immediate sequence, the HomeOffset is the desired position offset of the axis HomePosition from the position at which the home event occurred. Home Offset is applied at the end of the specified homing sequence before the axis moves to the HomePosition.
HomePosition	REAL	GSV/SSV	G6/Configuration /This is the desired absolute position for the axis after the specified homing sequence has been completed.
HomeReturnSpeed	REAL	GSV/SSV	G7/Configuration /This controls the speed of the jog profile used after the first leg of an active bidirectional homing sequence.
HomeSequence	SINT	GSV/SSV	G6/Configuration /The homing sequence type for your axis. Value:Meaning: 0 immediate (default) 1 switch 2 marker 3 switch then marker
HomeSpeed	REAL	GSV/SSV	G7/Configuration /This controls the speed of the jog profile used in the first leg of an active homing sequence.
IntegratorHoldEnable	SINT	GSV/SSV	G11/Configuration /When configured as TRUE, the servo loop temporarily disables any enabled integrators while command position is changing. It is used by point-to-point moves to minimize the integrator wind-up during motion. When FALSE, all active integrators are always on.
InterpolatedActualPosition	REAL	GSV	G1/Status /It is the interpolation of the actual position, based on past axis trajectory history, at the time specified by the InterpolatedTime attribute.
InterpolatedCommandPosition	REAL	GSV	G4/Status /It is the interpolation of the commanded position, based on past axis trajectory history, at the time specified by the InterpolatedTime attribute.
InterpolationTime	DINT	GSV/SSV	G1/Status /It is the 32-bit CST time used to calculate the interpolated positions. When this attribute is updated with a valid CST value, the InterpolatedActual and InterpolatedCommand positions are automatically updated.
MapInstance	DINT	GSV	G2/Interface /The I/O map instance of the motion compatible module. This attribute can only be set if you did not assign the axis to a group or if you assigned it to a group in the group inhibit mode.

Variable	Data Type	Instruction	Group/Folder/Description
MarkerDistance	REAL	GSV	G11/Status/ This is the distance between the axis position where the home switch input was detected and the axis position where the marker event was detected. It is useful in aligning a home limit switch relative to a feedback marker pulse to provide a repeatable homing operation.
MasterOffset	REAL	GSV	G4/Status/ This is the position offset that is applied to the master side of the position cam. It shows the same unwind characteristic as the position of a linear axis.
MaximumAcceleration	REAL	GSV/SSV	G8/Configuration/ This value is used by motion instructions to determine the acceleration rates to apply to the axis. The value is automatically set to ~ 85% of the measured Tuning Acceleration by the MAAT instruction.
MaximumDeceleration	REAL	GSV/SSV	G8/Configuration/ This value is used by motion instructions to determine the deceleration rates to apply to the axis. The value is automatically set to ~ 85% of the measured Tuning Deceleration by the MAAT instruction.
MaximumNegativeTravel	REAL	GSV/SSV	G11/Configuration/ It sets the software travel limit for the negative value. If the axis passes beyond the set limit a Software Overtravel fault is issued. This value must be less than the MaximumPositiveTravel value.
MaximumPositiveTravel	REAL	GSV/SSV	G11/Configuration/ It sets the software travel limit for the positive value. If the axis passes beyond the set limit a Software Overtravel fault is issued. This value must be greater than the MaximumNegativeTravel value.
MaximumSpeed	REAL	GSV/SSV	G8/Configuration/ This is used by various motion instructions to determine the steady-state speed of the axis. This value for the axis is automatically set to the tuning speed by the MAAT instruction. It is usually set to ~90% of the maximum speed rating for the motor.
MDTConfigurationList	DINT ARRAY		It maps directly to the SERCOS IDN. It is automatically set based on the current ServoLoopConfiguration and is Read-only.
MemoryUsage	DINT	GSV	G3/Interface/ It determines the amount of memory the created instance consumes in bytes.
MemoryUse	INT	GSV	G1/Interface/ RSLogix 5000 software uses this attribute to create axis instances in I/O memory for axes that are either produced or consumed. It can only be set as part of an axis create service and it controls in which controller memory the object instance is created.
ModuleChannel	SINT	GSV	G2/Interface/ this is used to associate an axis to a specific channel on a motion compatible module by specifying the ModuleChannel attribute.
ModuleClassCode	DINT	GSV	G12/Interface/ The ASA class code of the object in the motion module which is supporting motion.

Variable	Data Type	Instruction	Group/Folder/Description																											
ModuleFaultBits	DINT	GSV	<p>G11/Status/Module Fault information is passed from a physical module or device to the controller via an 8-bit value contained in the header of the Synchronous Input connection assembly. These fault bits are updated every coarse update period by the Motion Task.</p> <table><thead><tr><th>Bit:</th><th>Bit Name:</th><th>Meaning:</th></tr></thead><tbody><tr><td>0</td><td>ControlSyncFault</td><td>sets when the Logix controller detects that several position update messages in a row have been missed due to failure of the synchronous communications connection</td></tr><tr><td>1</td><td>ModuleSyncFault</td><td>sets when the motion module detects that several position update messages in a row have been missed due to failure of the synchronous communications connection</td></tr><tr><td>1-31</td><td>Reserved (Motion Axis Object)</td><td></td></tr><tr><td>2</td><td>TimerEventFault</td><td>sets when the servo module detects a problem with the module's timer event functionality</td></tr><tr><td>3</td><td>ModuleHardwareFault</td><td>sets when the associated servo module detects a hardware problem that is going to need replacement of the module to correct</td></tr><tr><td>4-31</td><td>Reserved (Servo)</td><td></td></tr><tr><td>4</td><td>SERCOSRingFault (Servo Drive)</td><td>set when SERCOS module detects that a problem has occurred on the SERCOS ring i.e. light has been broken or drive is powered down</td></tr><tr><td>5-31</td><td>Reserved (Servo Drive)</td><td></td></tr></tbody></table>	Bit:	Bit Name:	Meaning:	0	ControlSyncFault	sets when the Logix controller detects that several position update messages in a row have been missed due to failure of the synchronous communications connection	1	ModuleSyncFault	sets when the motion module detects that several position update messages in a row have been missed due to failure of the synchronous communications connection	1-31	Reserved (Motion Axis Object)		2	TimerEventFault	sets when the servo module detects a problem with the module's timer event functionality	3	ModuleHardwareFault	sets when the associated servo module detects a hardware problem that is going to need replacement of the module to correct	4-31	Reserved (Servo)		4	SERCOSRingFault (Servo Drive)	set when SERCOS module detects that a problem has occurred on the SERCOS ring i.e. light has been broken or drive is powered down	5-31	Reserved (Servo Drive)	
Bit:	Bit Name:	Meaning:																												
0	ControlSyncFault	sets when the Logix controller detects that several position update messages in a row have been missed due to failure of the synchronous communications connection																												
1	ModuleSyncFault	sets when the motion module detects that several position update messages in a row have been missed due to failure of the synchronous communications connection																												
1-31	Reserved (Motion Axis Object)																													
2	TimerEventFault	sets when the servo module detects a problem with the module's timer event functionality																												
3	ModuleHardwareFault	sets when the associated servo module detects a hardware problem that is going to need replacement of the module to correct																												
4-31	Reserved (Servo)																													
4	SERCOSRingFault (Servo Drive)	set when SERCOS module detects that a problem has occurred on the SERCOS ring i.e. light has been broken or drive is powered down																												
5-31	Reserved (Servo Drive)																													

Variable	Data Type	Instruction	Group/Folder/Description
MotorCapacity	REAL	GSV	G10/Status/ This displays the present utilization of motor capacity as a percent of rated capacity.
MotorData	SINT ARRAY		It is a structure with a length element and an array of bytes that contain motor configuration information needed by the drive to operate the motor.
MotorElectricalAngle	REAL	GSV	G10/Status/ This shows the present electrical angle of the motor shaft.
MotorFeedbackConfiguration	INT	GSV	G10/Configuration/ It maps directly to the SERCOS IDN. It is automatically set based on the current Drive Polarity Settings. All command bits are set according to the current Feedback Type value.
MotorFeedbackResolution	DINT	GSV	G10/Configuration/ This provides the A-B drive with the resolution of the feedback device in cycles. It also gives the Logix controller and drive with critical information to compute conversion constants used in converting drive units to feedback counts.
MotorFeedbackType	INT	GSV	G10/Configuration/ It provides the A-B drive with specific device configuration information for the mounted motor.
MotorID	DINT	GSV	G10/Configuration/ This contains the specific A-B motor catalog number associated with the axis. If the Motor ID does not match that of the actual motor and error is generated during the drive configuration process.
MotorThermalFaultAction	SINT	GSV/SSV	G10/Configuration/ Sets the type of action performed when a motor thermal fault occurs. Value:Meaning: <ul style="list-style-type: none"> 0 shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel. 1 disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable output is deactivated 2 stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module's Drive Enable Output. This is the gentlest stopping action for a fault. 3 status only – when set to status only, motion faults must be handled by the application program
NegativeDynamicTorqueLimit	REAL	GSV	G10/Status/ This represents the maximum negative torque/current limit magnitude. It should be the lowest value of all torque/current limits in the drive at a given time. It includes the amplifier peak limit, motor peak limit, user current limit, amplifier thermal unit, and the motor thermal limit.
OutputCamExecutionTargets	DINT	GSV	G1/Interface/ This is used to specify the number of output cam nodes attached to the axis. It can only be set as part of an axis create service and dictates the number of output cam nodes created and attached to that axis. The ability to configure the number of Output Execution Targets for a specific axis reduces the memory required per axis for users who do not need Output Cam functionality.

Variable	Data Type	Instruction	Group/Folder/Description
OutputCamLockStatus	DINT	GSV	G1/Status/ It is set when an Output Cam has been armed. It is initiated by an MAOC instruction with Immediate execution selected, when a pending output cam changes to armed, or when the axis approaches or passes through the specified arm position.
OutputCamPendingStatus	DINT	GSV	G1/Status/ It is set if an OutputCam is currently pending completion of another Output Cam initiated by executing an MAOC instruction with Pending execution selected.
OutputCamStatus	DINT	GSV	G1/Status/ It is set when an Output Cam has been initiated. The bit is reset when the cam position moves beyond the cam start or cam end position in Once execution mode with no Output Cam pending or when the Output Cam is terminated by an MDOC instruction.
OutputCamTransitionStatus	DINT	GSV	G1/Status/ This bit is set when a transition between the currently armed and pending Output Cam is in process.
OutputLimit	REAL	GSV/SSV	G9/Configuration/ It provides a method of limiting the maximum servo output voltage of a physical axis to a specified level.
OutputLPFilterBandwidth	REAL	GSV/SSV	G11/Configuration/ It controls the bandwidth of the servo's/ drive's low-pass digital output filter. If set to zero (the default), the programmable low-pass output filter is bypassed. The filter can be used to filter out or reduce high frequency variation of the servo module output to the drive. The lo-pass filter adds lag to the servo loop pushing the system toward instability. Decreasing the OutputLPFilterBandwidth requires lowering the Position or Velocity ProportionalGain to maintain stability.
OutputNotchFilterFrequency	REAL	GSV/SSV	G10/Configuration/ This controls the center frequency of the drive's digital notch filter. It is bypassed if it is configured to the default of zero. It is particularly useful on attenuating mechanical resonance phenomena.
OutputOffset	REAL	GSV/SSV	G9/Configuration/ The fixed value used to offset the drift caused by the cumulative drive offsets of the servo module DAC output and the servo drive input. This value added is to the Servo Output.
PositionCommand	REAL	GSV	G11/Status/ Within the Servo Loop, this attribute is used to control the position of the axis.
PositionDataScaling	INT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
PositionDataScalingExp	INT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
PositionDataScalingFactor	DINT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
PositionError	REAL	GSV	<p>G11/Status/The difference between the actual and command position of a servo axis.</p> <p>You can use this in conjunction with other error terms, to drive the motor to where the actual position equals the command position in an active servo loop.</p>

Variable	Data Type	Instruction	Group/Folder/Description
PositionErrorFaultAction	SINT	GSV/SSV	G11/Configuration/ Sets the type of operation performed when a position error fault occurs. Value:Meaning: 0 shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel. 1 disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable is output is deactivated 2 stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module's Drive Enable Output. This is the gentlest stopping action for a fault. 3 status only – when set to status only, motion faults must be handled by the application program
PositionErrorTolerance	REAL	GSV/SSV	G11/Configuration/ It specifies the amount of position error that the servo/drive tolerates before issuing a position error fault. It is interpreted as a \pm quantity. A value of 0.75 position units means that an error is generated when the position error is greater than 0.75 or less than -0.75.
PositionFeedback	REAL	GSV	G11/Status/ This attribute represents the current position of the axis within the servo loop.
PositionIntegralGain	REAL	GSV/SSV	G11/Configuration/ This attribute improves the steady-state performance of the system. It achieves accurate axis positioning despite disturbances such as static friction and gravity. Increasing the integral gain increases the ultimate positioning accuracy of the system. Increase it too much though and you get system instability.
PositionIntegratorError	REAL	GSV	G11/Status/ The running sum of the Position Error for the specified axis. You can use this in conjunction with other error terms, to drive the motor to where the actual position equals the command position in an active servo loop.
PositionLockTolerance	REAL	GSV/SSV	G11/Configuration/ It specifies how much position error that the servo/SERCOS module tolerates when giving a true position locked status indication. Used in conjunction with the PositionLockedStatus bit it is useful in controlling position accuracy. It is interpreted as a \pm quantity. A value of 0.01 inches means that an error is generated when the position error is greater than 0.01 or less than -0.01.
PositionPolarity	INT	GSV	G10/Configuration/ It maps directly to the SERCOS IDN. It is automatically set based on the current Drive Polarity Settings. All command bits are set according to the Command polarity bit value and all feedback bits are set according to the Feedback Polarity bit setting.
PositionProportionalGain	REAL	GSV/SSV	G11/Configuration/ This value is multiplied by the position error to create a component to the VelocityCommand that attempts to correct for the position error. Increasing the gain value increases the bandwidth of the position servo loop and results in greater static stiffness of the axis which is a measure of the corrective force applied to an axis for a given position error.

Variable	Data Type	Instruction	Group/Folder/Description
PositionServoBandwidth	REAL	GSV/SSV	G11/Configuration/ This value represents the unity gain bandwidth that is used to calculate the gains for a subsequent MAAT instruction. Within the constraints of a stable servo system, the higher the PositionServoBandwidth the better the dynamic performance of the system. A maximum value for this is generated by the MRAT instruction. Computing the gains based on this maximum value by way of the MAAT instruction results in dynamic response in keeping with the current value of the DampingFactor.
PositionUnits	STRING		The Axis Object lets you choose user-defined engineering units rather than feedback counts for measuring and programming all motion related values. It supports an ASCII text string of up to 32 characters. The string is used by the RSLogix 5000 software in the axis configuration dialogs.
PositionUnwind	DINT	GSV/SSV	G1/Configuration/ This is the value used to perform the automatic unwind of the rotary axis. Electronic unwind allows infinite position range for rotary axes by subtracting the unwind value from both the actual and command position every time the axis makes a complete revolution. The unwind value is in units feedback counts per axis revolution and must be an integer.
PositiveDynamicTorqueLimit	REAL	GSV	G10/Status/ This represents the maximum positive torque/current limit magnitude. It should be the lowest value of all torque/current limits in the drive at a given time. It includes the amplifier peak limit, motor peak limit, user current limit, amplifier thermal unit, and the motor thermal limit
PowerCapacity	REAL	GSV	G10/Status/ This displays the present utilization of the axis power supply as a percent of rated capacity.
PowerSupplyID	INT	GSV	G10/Configuration/ This attribute contains the enumeration of the specific A-B Power Supply or System Module catalog numbers associated with the axis. If it does not match an error is generated.
PrimaryOperationMode	INT	GSV	G10/Configuration/ It maps directly to the SERCOS IDN. It is automatically set based on the current ServoLoopConfiguration and is Read-only.

Variable	Data Type	Instruction	Group/Folder/Description
ProgrammedStopMode	SINT	GSV/SSV	<p>G8/Configuration/This determines how a specific axis is to stop when the ControlLogix processor has a critical processor mode change or when an explicit MGS instruction is executed with its stop mode set to programmed.</p> <p>Value:Meaning:</p> <p>0 Fast Stop (default) – the axis decelerates to a stop using the configured value for Maximum Deceleration. Servo action is maintained after the axis motion has stopped.</p> <p>1 Fast Disable – the axis decelerates to a stop using the configured value for Maximum Deceleration. Servo action is maintained after the axis motion has stopped at which time the axis is disabled, i.e. DriveEnable disabled and Servo Action disabled.</p> <p>2 Hard Disable – the axis is immediately disabled, i.e. Drive Enable disabled, Servo Action disabled, but the OK contact is left closed. Unless the drive is configured to provide some form of dynamic braking, the axis coasts to a stop.</p> <p>3 Fast Shutdown – the axis decelerates to a stop using the configured value for Maximum Deceleration. Once the axis motion is stopped the axis is placed in a shutdown state, i.e. Drive Enable disabled, servo action disabled, and the OK contact open. To recover from the shutdown state you must execute either an MASR or MGSR instruction.</p> <p>4 Hard Shutdown – The axis is immediately placed in a shutdown state i.e. Drive Enable disabled, servo action disabled, and the OK contact open. Unless the drive is configured to provide some form of dynamic braking, the axis coasts to a stop. To recover from the shutdown state you must execute either an MASR or MGSR instruction.</p>
Registration1Position	REAL	GSV	<p>G1/Status/This value is the absolute position of a physical or virtual axis at the occurrence of the most recent registration event for that axis.</p> <p>You can use the following equation to determine the maximum registration position error based on your axis speed:</p> $MaximumSpeed\left(\frac{PositionUnits}{Seconds}\right) = \frac{Accuracy(PositionUnits)}{Delay}$
Registration1Time	DINT	GSV	<p>G1/Status/This value contains the lower 32-bits of CST time at which the registration event occurred.</p>
Registration2Position	REAL	GSV	<p>G1/Status/G1/Status/This value is the absolute position of a physical or virtual axis at the occurrence of the most recent registration event for that axis.</p> <p>You can use the following equation to determine the maximum registration position error based on your axis speed:</p> $MaximumSpeed\left(\frac{PositionUnits}{Seconds}\right) = \frac{Accuracy(PositionUnits)}{Delay}$
Registration2Time	DINT	GSV	<p>G1/Status/This value contains the lower 32-bits of CST time at which the registration event occurred.</p>

Variable	Data Type	Instruction	Group/Folder/Description
RotaryAxis	SINT	GSV/SSV	G1/Configuration/ This attribute sets when the axis is Linear or Rotary. When set to true (1) it enables the rotary unwind capability of the axis providing limitless position range. When set to false (0), it indicates linear operation with a maximum total linear position range is 1 billion feedback counts before it rolls over to zero. Value:Meaning: 0 Linear 1 Rotary
RotationalPosResolution	DINT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
SercosErrorCode	INT	GSV	G10/Status/ This value is used to identify the source of the drive parameter update failure that results in the AxisConfigurationFault. The error codes are derived from the IEC-1394 SERCOS Interface standard.

Variable	Data Type	Instruction	Group/Folder/Description	
ServoFaultBits	DINT	GSV	G11/Status/	
			Bit:	Bit Name:
			0	PosSoftOvertravelFault
			1	NegSoftOvertravelFault
			2	PosHardOvertravelFault
			3	NegHardOvertravelFault
			4	FeedbackFault
			5	FeedbackNoiseFault
			6	AuxFeedbackFault
			7	AuxFeedbackNoiseFault
			8	PositionErrorFault
			9	DriveFault
			10-31	Reserved

Meaning:

sets when the axis travels or attempts to travel beyond the configured value for Maximum Positive Travel

sets when the axis travels or attempts to travel beyond the configured value for Maximum Negative Travel

Not Available. sets when the axis travels or attempts to travel beyond the maximum position limit set by the hardware limit switch mounted to the machine

Not Available. sets when the axis travels or attempts to travel beyond the minimum position limit set by the hardware limit switch mounted to the machine

sets when the differential electrical signal for one or more of the feedback channels are at same level or loss of feedback power or common electrical connection between servo module or drive and the feedback device

sets when simultaneous transitions of feedback of A and B are detected by the servo module

Not Available. sets when the differential electrical signal for one or more of the feedback channels are at same level or loss of feedback power or common electrical connection between servo module or drive and the auxiliary feedback device

Not Available. sets when simultaneous transitions of feedback of A and B are detected by the servo module

sets when the axis position error exceeds the value set for Position ErrorTolerance

sets when the external servo drive detects a fault and reports it to the servo module via the Drive Fault input.

Variable	Data Type	Instruction	Group/Folder/Description												
ServoLoopConfiguration	INT	GSV/SSV	G11/Configuration/ This attribute determines the specific configuration of the servo loop topology when the AxisType is set to servo. When AxisType is set to feedback only, it is used to select the feedback port. It also established several advanced drive configuration attributes that are part of the SERCOS interface standard. Value: Meaning: 0 custom 1 feedback only 2 aux. feedback only 3 position servo 4 aux. position servo 5 dual position servo 6 dual command servo 7 aux. dual command servo 8 velocity servo 9 torque servo												
ServoOutputLevel	REAL	GSV	G9/Status/ It is the current voltage level of the servo output of the specified axis. This attribute can be used in a drilling application to detect when the drill bit has engaged the surface of the work piece.												
ServoPolarityBits	DINT	GSV/SSV	G9/Configuration/ <table><tr><th>Bit:</th><th>Bit Name:</th><th>Meaning:</th></tr><tr><td>0</td><td>FeedbackPolarityNegative</td><td>This controls the polarity of the encoder feedback and ensures that when the axis moves in the user defined positive direction that the Actual Position value increases. This bit is configured automatically using the MRHD and MAHD instructions.</td></tr><tr><td>1</td><td>ServoPolarityNegative</td><td>This controls the polarity servo output to the drive. It ensures that the axis servo loop is closed as a negative feedback system and not an unstable positive feedback system. It is configured automatically using the MRHD and MAHD instructions.</td></tr><tr><td>2-31</td><td>Reserved</td><td></td></tr></table>	Bit:	Bit Name:	Meaning:	0	FeedbackPolarityNegative	This controls the polarity of the encoder feedback and ensures that when the axis moves in the user defined positive direction that the Actual Position value increases. This bit is configured automatically using the MRHD and MAHD instructions.	1	ServoPolarityNegative	This controls the polarity servo output to the drive. It ensures that the axis servo loop is closed as a negative feedback system and not an unstable positive feedback system. It is configured automatically using the MRHD and MAHD instructions.	2-31	Reserved	
Bit:	Bit Name:	Meaning:													
0	FeedbackPolarityNegative	This controls the polarity of the encoder feedback and ensures that when the axis moves in the user defined positive direction that the Actual Position value increases. This bit is configured automatically using the MRHD and MAHD instructions.													
1	ServoPolarityNegative	This controls the polarity servo output to the drive. It ensures that the axis servo loop is closed as a negative feedback system and not an unstable positive feedback system. It is configured automatically using the MRHD and MAHD instructions.													
2-31	Reserved														

Variable	Data Type	Instruction	Group/Folder/Description																																										
ServoStatusBits	DINT	GSV	G9/Status/ The status bits for your servo loop. <table><thead><tr><th>Bit:</th><th>Bit Name:</th><th>Meaning:</th></tr></thead><tbody><tr><td>0</td><td>ServoActionStatus</td><td>set when servo action is enabled</td></tr><tr><td>1</td><td>DriveEnableStatus</td><td>set when drive is enabled</td></tr><tr><td>2</td><td>AxisShutdownStatus</td><td>set when axis is in shutdown state</td></tr><tr><td>3</td><td>ProcessStatus</td><td>set when axis tuning or hookup diagnostic operation is in progress</td></tr><tr><td>4</td><td>OutputLimitStatus</td><td>set when magnitude of the output has reached or exceeded configured output limit value</td></tr><tr><td>5</td><td>PositionLockStatus</td><td>set when magnitude of axis position error has become less or equal to the Position Lock Tolerance value of the axis</td></tr><tr><td>6</td><td>HomeInputStatus</td><td>set when Home input is active</td></tr><tr><td>7</td><td>Registration1InputStatus</td><td>set when registration 1 input is active</td></tr><tr><td>8</td><td>Registration2InputStatus</td><td>not available</td></tr><tr><td>9</td><td>PositiveOvertravelInputStatus</td><td>not available</td></tr><tr><td>10</td><td>NegativeOvertravelInputStatus</td><td>not available</td></tr><tr><td>11-15</td><td>Reserved</td><td></td></tr><tr><td>16-31</td><td>Reserved</td><td></td></tr></tbody></table>	Bit:	Bit Name:	Meaning:	0	ServoActionStatus	set when servo action is enabled	1	DriveEnableStatus	set when drive is enabled	2	AxisShutdownStatus	set when axis is in shutdown state	3	ProcessStatus	set when axis tuning or hookup diagnostic operation is in progress	4	OutputLimitStatus	set when magnitude of the output has reached or exceeded configured output limit value	5	PositionLockStatus	set when magnitude of axis position error has become less or equal to the Position Lock Tolerance value of the axis	6	HomeInputStatus	set when Home input is active	7	Registration1InputStatus	set when registration 1 input is active	8	Registration2InputStatus	not available	9	PositiveOvertravelInputStatus	not available	10	NegativeOvertravelInputStatus	not available	11-15	Reserved		16-31	Reserved	
Bit:	Bit Name:	Meaning:																																											
0	ServoActionStatus	set when servo action is enabled																																											
1	DriveEnableStatus	set when drive is enabled																																											
2	AxisShutdownStatus	set when axis is in shutdown state																																											
3	ProcessStatus	set when axis tuning or hookup diagnostic operation is in progress																																											
4	OutputLimitStatus	set when magnitude of the output has reached or exceeded configured output limit value																																											
5	PositionLockStatus	set when magnitude of axis position error has become less or equal to the Position Lock Tolerance value of the axis																																											
6	HomeInputStatus	set when Home input is active																																											
7	Registration1InputStatus	set when registration 1 input is active																																											
8	Registration2InputStatus	not available																																											
9	PositiveOvertravelInputStatus	not available																																											
10	NegativeOvertravelInputStatus	not available																																											
11-15	Reserved																																												
16-31	Reserved																																												
SoftOvertravelFaultAction	SINT	GSV/SSV	G11/Configuration/ Sets the type of action performed when a soft overtravel fault occurs. Value:Meaning: <table><tbody><tr><td>0</td><td>shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel.</td></tr><tr><td>1</td><td>disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable output is deactivated</td></tr><tr><td>2</td><td>stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module’s Drive Enable Output. This is the gentlest stopping action for a fault.</td></tr><tr><td>3</td><td>status only – when set to status only, motion faults must be handled by the application program</td></tr></tbody></table>	0	shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel.	1	disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable output is deactivated	2	stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module’s Drive Enable Output. This is the gentlest stopping action for a fault.	3	status only – when set to status only, motion faults must be handled by the application program																																		
0	shutdown – most severe action to a fault and is reserved for faults that could endanger machinery or personnel.																																												
1	disabled drive – when the fault occurs the drive is immediately disabled, the servo output zeroed, and drive enable output is deactivated																																												
2	stop command – when fault occurs the axis immediately begins decelerating the axis command position to a stop at the configured Maximum Deceleration Rate without disabling servo action or the servo module’s Drive Enable Output. This is the gentlest stopping action for a fault.																																												
3	status only – when set to status only, motion faults must be handled by the application program																																												
StartActualPosition	REAL	GSV	G1/Status/ This stores the actual position of your axis at precisely the instant motion begins when a new motion planner instruction starts for the axis. You can use this value to correct for any motion occurring between the detection of an event and the action initiated by the event.																																										
StartCommandPosition	REAL	GSV	G4/Status/ This stores the command position of your axis at precisely the instant motion begins when a new motion planner instruction starts for the axis. You can use this value to correct for any motion occurring between the detection of an event and the action initiated by the event.																																										

Variable	Data Type	Instruction	Group/Folder/Description
StartMasterOffset	REAL	GSV	G4/Status/ This is the position offset that is applied to the master side of the position cam when the last MAM instruction with the move type set to either Absolute Master Offset or Incremental Master Offset was executed. It shows the same unwind characteristic as the position of a linear axis.
StoppingTimeLimit	REAL	GSV/SSV	G10/Configuration/ This attribute maps directly to the SERCOS IDNs and is automatically configured based on the current Drive Configuration.
StoppingTorque	REAL	GSV/SSV	G10/Configuration/ This attribute maps directly to the SERCOS IDNs and is automatically configured based on the current Drive Configuration.
StrobeActualPosition	REAL	GSV	G1/Status/ This stores a snapshot of the actual position of an axis when the MGSP instruction executes. Because it stores the strobe positions for all axes in a specified group the values for different axes can be used to perform real time calculations.
StrobeCommandPosition	REAL	GSV	G4/Status/ This stores a snapshot of the commanded position of an axis when the MGSP instruction executes. Because it stores the strobe positions for all axes in a specified group the values for different axes can be used to perform real time calculations.
StrobeMasterOffset	REAL	GSV	G4/Status/ This is the position offset that is applied to the master side of the position cam when the last MGSP instruction was executed. It shows the same unwind characteristic as the position of a linear axis.
TelegramType	INT	GSV	G10/Configuration/ It maps directly to the SERCOS IDN. It is automatically set based on the current ServoLoopConfiguration and is Read-only.
TestDirectionForward	SINT	GSV	G11/Status/ It reports the direction of axis travel during hookup test as seen by the servo module/SERCOS drive when the MRHD instruction is run. Value:Meaning: 0 negative (reverse) direction 1 True – positive (forward) direction
TestIncrement	REAL	GSV/SSV	G11/Configuration/ A commissioning configuration attribute used with the MRHD instruction to determine the amount of motion needed to satisfy the test process. Because this value is used by the MRHD instruction it must be set before the instruction is run.
TestStatus	INT	GSV	G11/Status/ This attribute provides information on the last run MRHD instruction. It reports the status of the instruction using the following values: Value:Meaning: 0 test process successful 1 test in progress 2 test process aborted by the user 3 test exceeded 2-second time-out 4 test failed – servo fault 5 test failed – insufficient test increment (Servo Drive) 6 test failed – wrong polarity (Servo Drive) 7 test failed – missing signal (Servo Drive) 8 test failed – device comm error (Servo Drive) 9 test failed – feedback config error (Servo Drive) 10 test failed – motor wiring error (Servo Drive)

Variable	Data Type	Instruction	Group/Folder/Description
TorqueCommand	REAL	GSV	G10/Status/ This is the command value when operating in torque mode.
TorqueDataScaling	INT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
TorqueDataScalingExp	INT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
TorqueDataScalingFactor	DINT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
TorqueFeedback	REAL	GSV	G10/Status/ This is the torque feedback value when operating in torque mode.
TorqueLimitBipolar	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
TorqueLimitNegative	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
TorqueLimitPositive	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
TorqueLimitSource	DINT	GSV	G10/Status/ It displays the present source (if any) of any torque limiting the axis. The values are: Value:Meaning: 0 Not Limited 1 Neg. Torque Limit 2 Pos. Torque Limit 3 Amp Peak Limit 4 Amp I(t) Limit 5 Bus Regulator Limit 6 Bipolar Torque Limit 7 Motor Peak Limit 8 Motor I(t) Limit 9 Voltage Limit
TorqueOffset	REAL	GSV/SSV	G11/Configuration/ It is used to provide a dynamic torque command correction to the output of the velocity servo loop. It can be tied into custom outer control loop algorithms using Function Block programming.
TorquePolarity	INT	GSV	G10/Configuration/ It maps directly to the SERCOS IDN. It is automatically set based on the current Drive Polarity Settings. All command bits are set according to the Command polarity bit value and all feedback bits are set according to the Feedback Polarity bit setting.

Variable	Data Type	Instruction	Group/Folder/Description
TorqueScaling	REAL	GSV/SSV	G11/Configuration/ This attribute is used to convert the acceleration of the servo loop into equivalent % rated torque to the motor. It has the effect of normalizing the units of the servo loop gain parameters so their values are not affected by variations in feedback resolution, drive scaling, motor and load inertia, and mechanical gear ratios. The TorqueScaling value represents the inertia of the system and is related to the TuneInertia attribute value by a factor of the Conversion Constant. It is normally established by the MAAT instruction as part of the controller's automatic tuning procedure but it can be manually calculated: $\text{TorqueScaling} = 100 \% \text{ Rated Torque} / (\text{Acceleration @ } 100 \% \text{ Rated Torque})$
TorqueThreshold	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
TuneAcceleration	REAL	GSV	G11/Status/ It returns the measured acceleration value from the last run MRAT instruction. This value is used to calculate the Tune Inertia value of the axis and are used by a subsequent MAAT instruction for the tune value for the MaximimAcceleration attribute.
TuneAccelerationTime	REAL	GSV	G11/Status/ The acceleration time in seconds measured during the last run MRAT instruction. This value is used in calculating the TuneAcceleration attribute.
TuneDeceleration	REAL	GSV	G11/Status/ It returns the measured deceleration value from the last run MRAT instruction. This value is used to calculate the Tune Inertia value of the axis and are used by a subsequent MAAT instruction for the tune value for the MaximimDeceleration attribute.
TuneDecelerationTime	REAL	GSV	G11/Status/ The deceleration time in seconds measured during the last run MRAT instruction. This value is used in calculating the TuneDeceleration attribute.
TuneInertia	REAL	GSV	G11/Status/ The TuneInertia value represents the total inertia of the axis as calculated from the measurements made during the last MRAT instruction. The value is shown in terms of percent of full-scale servo output per MegaCounts/Sec^2 of feedback input.
TuneRiseTime	REAL	GSV	G9/Status/ The axis rise time in seconds measured during the last run MRAT instruction. This value only applies to axes that you configure to work with an external velocity servo drive. This value is used to calculate the TuneVelocityBandwidth.
TuneSpeedScaling	REAL	GSV	G9/Status/ The axis drive scaling factor measured during the last executed MRAT instruction. It applies only to axes configured to interface with an external velocity servo drive. This value is applied to the VelocityScaling attribute by a subsequent MAAT instruction.

Variable	Data Type	Instruction	Group/Folder/Description
TuneStatus	INT	GSV	G11/Status/ It returns the status of the last run MRAT instruction that initiates a tuning process on the targeted servo/SERCOS module axis. The following values apply to the status of the MRAT instruction: Value:Meaning: 0 tune process successful 1 tuning in progress 2 tune process aborted by user 3 tune exceeded 2-second time-out 4 tune process failed due to servo/drive fault 5 axis reached Tuning Travel Limit 6 axis polarity set incorrectly 7 tune measurement fault (ServoDrive) 7 tune configuration fault (ServoDrive)
TuningConfigurationBits	DINT	GSV/SSV	G11/Configuration/ The tuning configuration bits for your axis. Bit: Bit Name: Meaning: 0 TuningDirectionReverse It determines the direction of the tuning motion profile initiated by the MRAT instruction. If set (true), goes in reverse or negative direction. 1 TunePositionErrorIntegrator It determines whether or not the MAAT instruction calculates a Position Integral Gain value. If set to clear (false), Position Integral Gain is set to zero. 2 TuneVelocityErrorIntegrator It determines whether or not the MAAT instruction calculates a Velocity Integral Gain value. If set to clear (false), Velocity Integral Gain is set to zero. 3 TuneVelocityFeedforward It determines whether or not the MAAT instruction calculates a Velocity Feedforward Gain value. If set to clear (false), Velocity Feedforward Gain is set to zero. 4 AccelerationFeedforward It determines whether or not the MAAT instruction calculates an Acceleration Feedforward Gain value. If set to clear (false), Acceleration Feedforward Gain is set to zero. 5 TuneVelocityLow-PassFilter It determines whether or not the MAAT instruction calculates an Output Filter Bandwidth value. If set to clear (false), Output Filter Bandwidth is set to zero disabling the filter. . 6 Reserved

Variable	Data Type	Instruction	Group/Folder/Description
TuningSpeed	REAL	GSV/SSV	G11/Configuration/ It determines the maximum speed of the MRAT instruction initiated tuning motion profile. It should be set to the desired maximum operating speed of the motor prior to running the MRAT instruction.
TuningTorque	REAL	GSV/SSV	G11/Configuration/ It determines the maximum torque of the MRAT initiated tuning motion profile. Set it to the desired maximum safe torque level prior to running the MRAT instruction to ensure the most accurate measure of the acceleration and deceleration capabilities of the system.
TuningTravelLimit	REAL	GSV/SSV	G11/Configuration/ This attribute is used by the MRAT instruction to limit the travel of the axis during tuning.
VelocityCommand	REAL	GSV	G11/Status/ The current velocity reference to the velocity servo loop for a specified axis. It represents the output of the outer position control loop.
VelocityDataScaling	INT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
VelocityDataScalingExp	INT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
VelocityDataScalingFactor	DINT	GSV	G10/Configuration/ This advanced scaling attribute maps directly to the SERCOS IDNs. It is automatically configured to the appropriate default. It is read-only.
VelocityDroop	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
VelocityError	REAL	GSV	G11/Status/ The difference between the commanded and actual velocity of a servo axis. You can use this value to drive the motor to where the velocity feedback equals the velocity command for an axis with an active velocity loop.
VelocityFeedback	REAL	GSV	G11/Status/ The actual velocity of your axis as estimated by the servo/SERCOS module. It is computed by applying a 1 KHz low-pass filter to the change in actual position over the servo update interval. VelocityFeedback is a signed value. The sign (+ or -) depends on the direction the axis is currently moving.
VelocityFeedforwardGain	REAL	GSV/SSV	G11/Configuration/ The value used to provide the velocity command output to generate the command velocity. The optimal value is 100%.
VelocityIntegralGain	REAL	GSV/SSV	G11/Configuration/ When configured for a torque loop servo drive, at every servo update the current Velocity Error is accumulated in a variable called Velocity integral Error. This value is multiplied by the VelocityIntegralGain to produce a component to the Servo Output or Torque Command that tries to correct the velocity error. The characteristic of the VelocityIntegralGain is that any non-zero Velocity Error accumulates in time to generate enough force to make the correction. VelocityIntegralGain makes it invaluable in applications where velocity accuracy is critical. The higher the value the faster the axis is driven to the zero Velocity Error condition.

Variable	Data Type	Instruction	Group/Folder/Description
VelocityIntegratorError	REAL	GSV	G11/Status/ The running sum of the Velocity Error for a specified axis. You can use this value to drive the motor to where the velocity feedback equals the velocity command for an axis with an active velocity loop.
VelocityLimitBipolar	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
VelocityLimitNegative	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
VelocityLimitPositive	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
VelocityOffset	REAL	GSV/SSV	G11/Configuration/ It is used to provide a dynamic velocity correction to the output of the position servo loop. It can be tied into custom outer control loop algorithms using Function Block programming.
VelocityPolarity	INT	GSV	G10/Configuration/ It maps directly to the SERCOS IDN. It is automatically set based on the current Drive Polarity Settings. All command bits are set according to the Command polarity bit value and all feedback bits are set according to the Feedback Polarity bit setting.
VelocityProportionalGain	REAL	GSV/SSV	G11/Configuration/ This value is multiplied by the velocity error to create a component to the Servo Output or Torque Command that attempts to correct for the velocity error, creating the damping effect. Increasing the gain value results in smoother motion, enhanced acceleration, reduced overshoot, and greater system stability. Too great of an increase can cause frequency instability and resonance effects.
VelocityScaling	REAL	GSV/SSV	G9/Configuration/ This attribute is used to convert the output of the servo loop into equivalent voltage to an external velocity servo drive. It has the effect of normalizing the units of the servo loop gain parameters so their values are not affected by variations in feedback resolution, drive scaling, or mechanical gear ratios. The VelocityScaling value is normally established by the servo's automatic tuning procedure but it can be manually calculated: $\text{VelocityScaling} = 100 \% / (\text{Speed @ } 100 \%)$
VelocityServoBandwidth	REAL	GSV/SSV	G11/Configuration/ This value represents the unity gain bandwidth that is used to calculate the gains for subsequent MAAT instruction. Within the constraints of a stable servo system, the higher the VelocityServoBandwidth the better the dynamic performance of the system. A maximum value for this is generated by the MRAT instruction. Computing the gains based on this maximum value by way of the MAAT instruction results in dynamic response in keeping with the current value of the DampingFactor.

Variable	Data Type	Instruction	Group/Folder/Description
VelocityStandstillWindow	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
VelocityThreshold	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
VelocityWindow	REAL	GSV/SSV	G10/Configuration/ This maps directly to the SERCOS IDNs and is automatically configured to reasonable default values. Manipulation is not needed unless motivated by a specific application requirement.
WatchPosition	REAL	GSV	G1/Status/ It is the current set-point of an axis as set up in the last, most recently executed, MAW instruction for that axis.

Instruction Timing

This appendix describes motion instruction timing types.

Motion instructions use three types of timing sequences

Timing type	Description
Immediate	The instruction completes in one scan.
Message	The instruction completes over several scans because the instruction sends messages to the servo module.
Process	The instruction could take an indefinite amount of time to complete.

Immediate Type Instructions

Immediate type motion instructions execute to completion in one scan. If the controller detects an error during the execution of these instructions, the error status bit sets and the operation ends.

Examples of immediate type instructions include the:


- Motion Change Dynamics (MCD) instruction
- Motion Group Strobe Position (MGSP) instruction

Immediate instructions work as follows:

1. When the rung that contains the motion instruction becomes true, the controller:
 - Sets the enable (EN) bit.
 - Clears the done (DN) bit.
 - Clears the error (ER) bit.
2. The controller executes the instruction completely.
- 3.

If the controller	Then
Does not detect an error when the instruction executes	The controller sets the .DN bit.
Detects an error when the instruction executes	The controller sets the .ER bit and stores an error code in the control structure.

4. The next time the rung becomes false after either the .DN or .ER bit sets, the controller clears the .EN bit.
5. The controller can execute the instruction again when the rung becomes true.



Message Type Instructions

Message type motion instructions send one or more messages to the servo module.

Examples of message type instructions include the:

- Motion Direct Drive On (MDO) instruction
- Motion Redefine Position (MRP) instruction

Message type instructions work as follows:

1. When the rung that contains the motion instruction becomes true, the controller:
 - Sets the enable (EN) bit.
 - Clears the done (DN) bit.
 - Clears the error (ER) bit.
2. The controller begins to execute the instruction by setting up a message request to the servo module.

The remainder of the instruction executes in parallel to the program scan.

3. The controller checks if the servo module is ready to receive a new message.
4. The controller places the results of the check in the message status word of the control structure.


5. When the module is ready, the controller constructs and transmits the message to the module.

This process may repeat several times if the instruction requires multiple messages.

6.

If the controller	Then
Does not detect an error when the instruction executes	The controller sets the .DN bit.
Detects an error when the instruction executes	The controller sets the .ER bit and stores an error code in the control structure.

7. The next time the rung becomes false after either the .DN or .ER bit sets, the controller clears the .EN bit.
8. When the rung becomes true, the controller can execute the instruction again.



Process Type Instructions

Process type motion instructions initiate motion processes that can take an indefinite amount of time to complete.

Examples of process type instructions include the:

- Motion Arm Watch Position (MAW) instruction
- Motion Axis Move (MAM) instruction

Process type instructions work as follows:

1. When the rung that contains the motion instruction becomes true, the controller:

- Sets the enable (.EN) bit.
- Clears the done (.DN) bit.
- Clears the error (.ER) bit.
- Clears the process complete (.PC) bit.

2. The controller initiates the motion process.


3.

If	Then the controller
The controller does not detect an error when the instruction executes	<ul style="list-style-type: none"> • Sets the .DN bit. • Sets the in process (.IP) bit.
The controller detects an error when the instruction executes	<ul style="list-style-type: none"> • Sets the .ER bit. • Stores an error code in the control structure. • Does not change the .IP and .PC bits.
The controller detects another instance of the motion instruction	Clears the .IP bit for that instance.
The motion process reaches the point where the instruction can be executed again	Sets the .DN bit. For some process type instructions, like MAM, this will occur on the first scan. For others, like MAH, the .DN bit will not be set until the entire homing process is complete.
One of the following occurs during the motion process: <ul style="list-style-type: none"> • The motion process completes • Another instance of the instruction executes • Another instruction stops the motion process • A motion fault stops the motion process 	<ul style="list-style-type: none"> • Sets the .DN bit. • Sets the .PC bit. • Clears the .IP bit.

4. Once the initiation of the motion process completes, the program scan can continue.

The remainder of the instruction and the control process continue in parallel with the program scan.

5. The next time the rung becomes false after either the .DN bit or the .ER bit sets, the controller clears the .EN bit.
6. When the rung becomes true, the instruction can execute again.



Fault Handling

This appendix describes motion errors and faults.

Handling Motion Faults

Two types of motion faults exist.

Type	Description	Example
Errors	<ul style="list-style-type: none">Do not impact controller operationShould be corrected to optimize execution time and ensure program accuracy	A Motion Axis Move (MAM) instruction with a parameter out of range
Minor/ Major	<ul style="list-style-type: none">Caused by a problem with the servo loopCan shutdown the controller if you do not correct the fault condition	The application exceeded the PositionErrorTolerance value

Errors

Executing a motion instruction within an application program can generate errors. The MOTION_INSTRUCTION tag has a field that contains the error code. For more information on error codes for individual instructions, refer to the motion instruction chapters in the Logix5550 Controller Instruction Set Reference Manual.

Minor/Major Faults

Several faults can occur that are not caused by motion instructions. For example, a loss of encoder feedback or actual position exceeding an overtravel limit will cause faults. The motion faults are considered Type 11 faults with error codes from 1 to 32. For more information about motion error codes, refer to *Handling Controller Faults* in the Logix5550 Controller User Manual.

TIP

You can configure a fault as either minor (non major) or major by using the Axis Wizard-Group window.



For more information about handling faults, see *Handling Controller Faults* in the Logix5550 Controller User Manual, publication 1756-6.5.12.

Symbols

.ERR C-29
 .SEGMENT C-30
 .STATE C-30
 .STATUS C-30

Numerics

1394C Drive module
 Associated Axes Tab 7-10
 New Axis button 7-11
 Node X0 7-10
 Node X1 7-10
 Node X2 7-10
 Node X3 7-11
 Connection Tab 7-7
 Inhibit Module checkbox 7-8
 Major Fault on Controller if Connection Fails checkbox 7-9
 Module Fault 7-9
 Connection Request Error 7-9
 Electronic Keying Mismatch 7-9
 Module Configuration Invalid 7-9
 Service Request Error 7-9
 Requested packet Interval 7-7
 General Tab 7-4
 Base Node 7-5
 Description 7-5
 Electronic Keying 7-6
 Compatible Module 7-6
 Disable Keying 7-6
 Exact Match 7-6
 Name 7-5
 Revision 7-5
 Type 7-5
 Vendor 7-5
 Module Info tab 7-12
 (16#xxxx) unknown 7-14
 Configured 7-14
 Internal State Status 7-14
 Major/Minor Fault Status 7-13
 Module Identity 7-15
 Owned 7-14
 Product Name 7-13
 Refresh 7-15
 Reset Module 7-15
 Power Tab 7-11
 Bus Regulator ID 7-11
 1394-CFLAExx Cable

Pinouts B-9
 Wiring Diagram B-9
 1394C-SJT05/10/22-D Digital Servo Drive Overview 7-3
 1398-CFLAExx
 Cable Diagram B-7
 Pinouts B-7
 1756-M02AE Module Properties
 Associated Axes Tab 3-12
 Channel 0 3-13
 Channel 1 3-13
 New Axis button 3-13
 Servo Update Period 3-13
 Backplane Tab 3-17
 ControlBus Parameters 3-17
 ControlBus Status 3-17
 Multicast CRC Error Threshold 3-18
 Receive Error Counters 3-18
 Refresh 3-18
 Set Limit Button 3-18
 Transmit Error Counters 3-18
 Transmit Retry Limit 3-18
 Connection Tab 3-9
 Inhibit Module checkbox 3-10
 Major Fault on Controller if Connection Fails checkbox 3-11
 Module Fault 3-11
 Requested Packet Interval 3-10
 General Tab 3-8
 Description 3-8
 Electronic Keying 3-9
 Name 3-8
 Revision 3-9
 Slot 3-8
 Type 3-8
 Vendor 3-8
 Module Info Tab 3-13
 Configured 3-15
 Internal State Status 3-15
 Major/Minor Fault Status 3-15
 Module Identity 3-16
 Owned 3-16
 Refresh 3-16
 Reset Module 3-16
 1756-M02AE servo module 1-1
 Adding to a program 3-1, 6-1
 Additional modules and axes 3-19
 Block diagrams
 Torque servo drive B-2
 Velocity servo drive B-3

- Coarse update rate calculations A-4
- Configuring a motion axis 3-1
- Features 1-2
- Loop and interconnect diagrams B-1
- Specifications A-1
- Troubleshooting 10-1
- Wiring diagrams
 - 1394 drive B-8
 - 24V registration sensor B-10
 - 5V registration sensor B-10
 - Home limit switch B-11
 - OK contacts B-11
 - Servo module RTB B-4
 - Ultra 100 drive B-5
 - Ultra 200 drive B-6
- 1756-M08SE 4-1
 - Adding the module 4-1
 - configuring module 4-1
 - Motion Module Overview 4-4
- 1756-M08SE Properties
 - Backplane Tab 4-17
 - ControlBus Parameters 4-17
 - ControlBus Status 4-17
 - Multicast CRC Error Threshold 4-18
 - Receive Error Counters 4-18
 - Refresh 4-18
 - Set Limit Button 4-18
 - Transmit Error Counters 4-18
 - Transmit Retry Limit 4-18
 - Connection Tab 4-7
 - Inhibit Module checkbox 4-8
 - Major Fault 4-9
 - Module Fault 4-9
 - Requested Packet Interval 4-8
 - General Tab 4-5
 - Name 4-6
 - Description 4-6
 - Electronic Keying 4-6
 - Compatible Module 4-7
 - Disable Keying 4-7
 - Exact Match 4-6
 - Revision 4-6
 - Slot 4-6
 - Type 4-5
 - Vendor 4-6
 - Module Info Tab 4-13
 - Configured 4-15
 - Identification 4-14

- Internal State Status 4-15
- Major/Minor Fault Status 4-15
- Module Identity 4-16
- Owned 4-16
- Refresh 4-16
- Reset Module 4-16
- SERCOS Interface Info Tab 4-11
 - Fault Type 4-12
 - Refresh 4-12
 - Ring Comm. Phase 4-12
- SERCOS Interface Tab 4-10
 - Cycle Time 4-11
 - Data Rate 4-11
 - Transmit Power 4-11
- 1756-M08SE SERCOS interface module 1-1
- 8 Axis SERCOS interface Module 1-3

A

- Adding the 1756-M02AE Module 3-1
 - New Module 3-3
- Adding to a program
 - A motion module ??-6-71
- Application program
 - Developing 1-4, ??-3-1, 6-70-??
 - Example 6-71
- Assigning Additional Motion Axes 6-70
- Assigning in an application program
 - Additional modules 3-19
- Axis Properties
 - Conversion Tab 6-13
 - Conversion Constant 6-14
 - Position Unwind 6-14
 - Positioning Mode 6-13
 - Drive Tab - (AXIS_SERVO_DRIVE) 6-17
 - Amplifier Catalog Number 6-17
 - Attribute 1/Attribute 2 6-18
 - Drive Resolution 6-18
 - Loop Configuration 6-17
 - Real Time Axis Information 6-18
 - Set Custom Scaling...button 6-18
 - Dynamics Tab 6-32
 - Manual Tune 6-35
 - Maximum Acceleration 6-34
 - Maximum Deceleration 6-34
 - Maximum Velocity 6-33
 - Program Stop Action 6-35
 - Fault Actions Tab - AXIS_SERVO 6-61
 - Drive Fault 6-63
 - Feedback Loss 6-63

- Feedback Noise 6-63
- Position Error 6-64
- Soft Overtravel 6-64
- Fault Actions Tab - AXIS_SERVO_DRIVE 6-64
 - Drive Thermal 6-66
 - Feedback 6-67
 - Feedback Noise 6-67
 - Hard Overtravel 6-67
 - Motor Thermal 6-67
 - Position Error 6-67
 - Set Custom Stop Action 6-67
 - Soft Overtravel 6-67
- Gains Tab - AXIS_SERVO
 - Integral (Position) Gain 6-38
 - Integrator Hold 6-39
 - Manual Tune 6-40
 - Proportional (Position) Gain 6-37
 - Proportional (Velocity) Gain 6-39
- Gains Tab - AXIS_SERVO_DRIVE 6-35, 6-40
 - Acceleration Feedforward 6-37, 6-42
 - Integral (Position) Gain 6-43
 - Integral (Velocity) Gain 6-39, 6-44
 - Integrator Hold 6-45
 - Manual Tune 6-45
 - Proportional (Position) Gain 6-42
 - Proportional (Velocity) Gain 6-39, 6-43
 - Set Custom Gains 6-45
 - Velocity Feedforward 6-37, 6-41
- Homing Tab - AXIS_VIRTUAL 6-25
 - Mode 6-25
 - Position 6-25
 - Sequence 6-26
- Homing Tab - SERVO_AXIS and SERVO_AXIS_DRIVE 6-21
 - Direction 6-24
 - Homing Configurations 6-25
 - Limit Switch 6-23
 - Mode 6-22
 - Offset 6-23
 - Position 6-22
 - Return Speed 6-24
 - Sequence 6-23
 - Speed 6-24
- Hookup Tab - AXIS_SERVO 6-26
 - Feedback Polarity 6-27
 - Output Polarity 6-27
 - Test Feedback 6-28
 - Test Increment 6-26
 - Test Marker 6-27
 - Test Output & Feedback 6-28
- Hookup Tab Overview - AXIS_SERVO_DRIVE 6-28
 - Drive Polarity 6-28
 - Test Feedback 6-29
 - Test Increment 6-28
 - Test Marker 6-29
 - Test Output & Feedback 6-29
- Limits Tab - AXIS_SERVO 6-51
 - Manual Tune 6-54
 - Maximum Negative 6-53
 - Maximum Positive 6-53
 - Output Limit 6-54
 - Position Error Tolerance 6-53
 - Soft Travel Limits 6-52
- Limits Tab - AXIS_SERVO_DRIVE 6-54
 - Hard Travel Limits 6-55
 - Manual Tune 6-56
 - Maximum Negative 6-56
 - Maximum Positive 6-55
 - Position Error Tolerance 6-56
 - Position Lock Tolerance 6-56
 - Set Custom Limits 6-56
 - Soft Travel Limits 6-55
- Motor/Feedback Tab (AXIS_SERVO_DRIVE) 6-19
 - (Aux) Cycles 6-21
 - (Aux) Interp Factor 6-21
 - (Aux) Ratio 6-21
 - (Auxiliary Feedback) Type 6-20
 - (Motor) Catalog Number 6-19
 - (Motor) Cycles 6-20
 - (Motor) Feedback Type 6-20
 - (Motor) Interpolation Factor 6-20
- Offset Tab - AXIS_SERVO 6-57
 - Friction Compensation 6-58
 - Manual Tune 6-59
 - Output Offset 6-59
 - Torque Offset 6-58
 - Velocity Offset 6-58
- Offset Tab - AXIS_SERVO_DRIVE 6-59
 - Friction Compensation 6-60
 - Manual Tune 6-61
 - Torque Offset 6-60
 - Velocity Offset 6-60
- Output Tab - SERVO_AXIS 6-45
 - Enable Low-pass Output Filter 6-47
 - Low-pass Output Filter Bandwidth 6-48
 - Manual Tune 6-48
 - Torque Scaling 6-47
 - Velocity Scaling 6-46

Output Tab Overview - AXIS_SERVO_DRIVE 6-48

Enable Low-pass Output Filter 6-50

Enable Notch Filter 6-50

Low-pass Output Filter Bandwidth 6-51

Manual Tune 6-51

Notch Filter 6-50

Torque Scaling 6-49

Servo Tab - AXIS_SERVO 6-15

Drive Fault Input 6-16

Enable Drive Fault Input 6-16

External Drive Configuration 6-15

Loop Configuration 6-16

Real Time Axis Information 6-16

Tag Tab 6-68

Base Tag 6-69

Description 6-68

Manual Tune 6-69

Name 6-68

Produce this tag for up to 6-69

Scope 6-69

Style 6-69

Tag Type 6-68

Tune Tab - AXIS_SERVO, AXIS_SERVO_DRIVE 6-30

Damping Factor 6-31

Direction 6-31

Speed 6-30

Start Tuning 6-32

Torque 6-30

Travel Limit 6-30

Tune 6-31

AXIS Structures C-1

AXIS_CONSUMED C-1

AXIS_SERVO C-5

AXIS_SERVO_DRIVE C-12

AXIS_VIRTUAL C-21

Axis Tag types

alias tag 6-2

base tag 6-2

produced tag 6-2

B

Block diagrams for a 1756-M02AE module B-1

With a torque servo drive B-2

With a velocity servo drive B-3

C

Change Controller Type 2-7

Select a processor 2-8

Configuring a 1394C-SJT05/10/22-D Digital Servo Drive 7-1

consumed tag 6-2

Control structures C-1

MOTION_GROUP C-26

MOTION_INSTRUCTION C-27

ControlLogix motion control 1-1

Components 1-2

Features 1-2

Course update rate calculations A-4

Action timing A-4

Calculation worksheet A-6

Sample calculation A-7

Creating A Motion Group 5-1

D

Diagrams

Block B-1

Wiring B-4

DRIVE LED indicator 10-2

E

Editing 1756-M08SE Module Properties 4-5

Editing Axis Properties

General Tab - AXIS_SERVO_DRIVE 6-8

Assigned Motion Group 6-9

Axis Configuration 6-9

Ellipsis (...) button 6-9

Module 6-9

Module Type 6-9

New Group button 6-9

Node 6-10

Output Cam Execution Targets 6-10

General Tab - SERVO_AXIS 6-6

Assigned Motion Group 6-7

Axis Configuration 6-7

Channel 6-8

Ellipsis (...) button 6-7

Module 6-7

Module Type 6-7

New Group button 6-7

Output Cam Execution Targets 6-8

Units Tab 6-12

Average Velocity Timebase 6-12

Position Units 6-12

Editing Controller Properties 2-5

Advanced Tab 2-21

Controller Fault Handler 2-22

Memory Total 2-21

- Memory Unused 2-21
- Memory Used 2-21
- Power-Up Handler 2-22
- System Overhead Time Slice 2-22
- Date/Time Tab 2-19
 - Coordinated System Time master 2-20
 - Date 2-20
 - Set 2-20
 - Status 2-20
 - Time 2-20
- File Tab 2-22
 - Created 2-23
 - Edited 2-23
 - Name 2-23
 - Path 2-23
- General Tab 2-6
 - Change Type 2-7
 - Chassis Type 2-7
 - Description 2-7
 - Name 2-6
 - Revision 2-7
 - Slot 2-7
 - Type 2-6
 - Vendor 2-6
- Major Faults Tab 2-17
 - Clear Majors 2-18
 - Number of Major Faults Since Last Cleared 2-18
 - Recent Faults 2-18
- Minor Faults Tab 2-18
 - Clear Minors 2-19
 - Fault Bits 2-19
 - Number of Minor Faults Since Last Cleared 2-18
 - Recent Faults 2-19
- Serial Port Tab 2-8
 - Baud Rate 2-9
 - Continuous Carrier 2-10
 - Control Line 2-10
 - Data Bits 2-9
 - Mode 2-9
 - Parity 2-9
 - RTS Off Delay 2-10
 - RTS Send Delay 2-10
 - Stop Bits 2-9
- System Protocol Tab 2-10
 - Active Station Tag 2-14
 - Common Parameters 2-11
 - ACK Timeout 2-12
 - Enable Duplicate Detection 2-12
 - Error Detection 2-12
 - Protocol 2-11
 - Station Address 2-11
 - DF1 Master Parameters 2-13
 - Master Transmit 2-14
 - Polling Mode 2-13
 - Reply Message Wait 2-13
 - Transmit Retries 2-13
 - DF1 Point to Point Parameters 2-12
 - Embedded Responses 2-12
 - ENQ Transmit Limit 2-12
 - NAK Receive Limit 2-12
 - DF1 Slave Parameters 2-13
 - EOT Suppression 2-13
 - Slave Poll Timeout 2-13
 - Transmit Retries 2-13
 - Normal Poll Group Size 2-14
 - Normal Poll Node Tag 2-14
 - Priority Poll Node Tag 2-14
- User Protocol Tab 2-15
 - Append Character 1 and 2 2-16
 - Buffer Size 2-15
 - Delete Mode 2-17
 - Echo Mode 2-16
 - Protocol 2-15
 - Termination Character 1 and 2 2-15
 - XON/OFF 2-16
- Editing Motion Axis Properties 6-4
- Editing the Motion Group Properties 5-4
 - Attribute Tab 5-5
 - Auto Tag Update 5-6
 - Base Tag 5-8
 - Coarse Update Period 5-5
 - Data Type 5-8
 - Description 5-7
 - General Fault Type 5-6
 - Name 5-7
 - Produce 5-8
 - Reset Max 5-6
 - Scan Times 5-6
 - Scope 5-8
 - Style 5-8
 - Tag Type 5-8
 - Axis Assignment Tab 5-4
 - Add 5-4
 - Assigned 5-4
 - Remove 5-5
 - Unassigned 5-4
 - Tag Tab 5-7
- Editing the Ultra Drive Properties 8-7

Associated Axes Tab (Ultra3000 Drives) 8-14

Ellipsis (...) 8-14

New Axis 8-14

Node 8-14

Connection Tab 8-10

Inhibit Module 8-12

Major Fault 8-13

Module Fault 8-13

Requested Packet Interval 8-11

General Tab 8-8

Description 8-8

Electronic Keying 8-9

Name 8-8

Node 8-8

Revision 8-8

Slot 8-9

Status 8-10

Type 8-8

Vendor 8-8

Module Info 8-14

Configured 8-16

Identification 8-15

Internal State Status 8-16

Major/Minor Fault Status 8-16

Module Identity 8-17

Refresh 8-17

Power Tab - Ultra Drive 8-14

Bus Regulator ID 8-14

Editing Your1756-M02AE Motion Module Settings 3-6

Error codes C-29

Errors F-1

Execution status C-30

F

Fault handling F-1

Errors F-1

Minor/major faults F-1

Motion faults F-1

Faults F-1

Types 1-5

FDBK LED indicator 10-2

G

General Tab - AXIS_VIRTUAL 6-10

Assigned Motion Group 6-10

Ellipsis (...) button 6-11

New Group button 6-11

Output Cam Execution Targets 6-11

GSV instruction

Reading status and configuration parameters 1-5

I

Immediate instruction timing E-1

L

Logix5550 controller 1-1

Features 1-2

M

Major faults F-1

Message instruction timing E-2

Message status C-30

Minor faults F-1

Motion attributes D-1, D-2

Changing configuration parameters 1-5

Data Type Groups D-1

Motion Attribute Folders D-1

Understanding status and configuration parameters 1-5

Motion configuration instructions 9-4

Motion Apply Axis Tuning (MAAT) 9-4

Motion Apply Hookup Diagnostic (MAHD) 9-5

Motion Run Axis Tuning (MRAT) 9-4

Motion Run Hookup Diagnostic (MRHD) 9-5

Motion event instructions 9-3

Motion Arm Output Cam (MAOC) 9-4

Motion Arm Registration (MAR) 9-4

Motion Arm Watch Position (MAW) 9-4

Motion Disarm Output Cam (MDOC) 9-4

Motion Disarm Registration (MDR) 9-4

Motion Disarm Watch Position (MDW) 9-4

Motion group instructions 9-3

Motion Group Programmed Stop (MGPS) 9-3

Motion Group Shutdown (MGSD) 9-3

Motion Group Shutdown Reset (MGSR) 9-3

Motion Group Stop (MGS) 9-3

Motion Group Strobe Position (MGSP) 9-3

Motion instructions 9-1

Motion Apply Axis Tuning (MAAT) 9-4

Motion Apply Hookup Diagnostic (MAHD) 9-5

Motion Arm Output Cam (MAOC) 9-4

Motion Arm Registration (MAR) 9-4

Motion Arm Watch Position (MAW) 9-4

Motion Axis Fault Reset (MAFR) 9-2

Motion Axis Gear (MAG) 9-2

Motion Axis Home (MAH) 9-2

Motion Axis Jog (MAJ) 9-2

- Motion Axis Move (MAM) 9-2
- Motion Axis Position Cam (MAPC) 9-3
- Motion Axis Shutdown (MASD) 9-2
- Motion Axis Shutdown Reset (MASR) 9-2
- Motion Axis Stop (MAS) 9-2
- Motion Axis Time Cam (MATC) 9-3
- Motion Calculate Cam Profile (MCCP) 9-3
- Motion Change Dynamics (MCD) 9-2
- Motion configuration instructions 9-4
- Motion Direct Drive Off (MDF) 9-2
- Motion Direct Drive On (MDO) 9-2
- Motion Disarm Output Cam (MDOC) 9-4
- Motion Disarm Registration (MDR) 9-4
- Motion Disarm Watch Position (MDW) 9-4
- Motion event instructions 9-3
- Motion group instructions 9-3
- Motion Group Programmed Stop (MGPS) 9-3
- Motion Group Shutdown (MGSD) 9-3
- Motion Group Shutdown Reset (MGSR) 9-3
- Motion Group Stop (MGS) 9-3
- Motion Group Strobe Position (MGSP) 9-3
- Motion move instructions 9-2
- Motion Redefine Position (MRP) 9-2
- Motion Run Axis Tuning (MRAT) 9-4
- Motion Run Hookup Diagnostic (MRHD) 9-5
- Motion Servo Off (MSF) 9-1
- Motion Servo On (MSO) 9-1
- Motion state instructions 9-1
- Timing E-1
 - Immediate E-1
 - Message E-2
 - Process E-3
- Motion move instructions 9-2
 - Motion Axis Gear (MAG) 9-2
 - Motion Axis Home (MAH) 9-2
 - Motion Axis Jog (MAJ) 9-2
 - Motion Axis Move (MAM) 9-2
 - Motion Axis Stop (MAS) 9-2
 - Motion Axis Time Cam (MATC) 9-3
 - Motion Calculate Cam Profile (MCCP) 9-3
 - Motion Change Dynamics (MCD) 9-2
 - Motion Redefine Position (MAPC) 9-3
 - Motion Redefine Position (MRP) 9-2
- Motion state instructions 9-1
 - Motion Axis Fault Reset (MAFR) 9-2
 - Motion Axis Shutdown (MASD) 9-2
 - Motion Axis Shutdown Reset (MASR) 9-2
 - Motion Direct Drive Off (MDF) 9-2
 - Motion Direct Drive On (MDO) 9-2

- Motion Servo Off (MSF) 9-1
- Motion Servo On (MSO) 9-1
- MOTION_GROUP control structure C-26
- MOTION_INSTRUCTION control structure C-27
- Motion Instruction tag 1-4

N

- Naming an Axis 6-1
 - Entering Tag Information 6-2
 - Common Parameters 6-3
 - Data Type 6-3
 - Description 6-3
 - Name 6-3
 - Tag Type 6-3
 - Alias 6-3
 - Base 6-3
 - Consumed 6-3
 - Produced 6-3
- New Module window 3-4

O

- OEediting the Ultra Drive Properties
 - Module Info
 - owned 8-16
- OK LED indicator 10-1
- Output Cam Timing A-9
 - 1756-L50 Controller A-10

P

- Performance guidelines A-1
- Process instruction timing E-3
- product support, local
 - telephone number P-4
- Profile Segment C-30

R

- Rockwell Automation support
 - Technical product assistance P-3
- RSLogix 5000 programming software 1-1
 - Application program
 - Developing 6-70
 - Example 6-71
 - Control structures C-1
 - Fault handling F-1
 - Features 1-3
 - Instruction timing E-1
 - Motion attributes D-1

Motion instructions 9-1
Running Hookup Diagnostics and Auto Tuning 6-70

S

Select Module Type window 3-2
Servo Configuration Update Status Bits attributes C-25
Specifications A-1
SSV instruction
 Changing configuration parameters 1-5
structures
 AXIS C-1
 CAM C-31
 CAM_PROFILE C-31
support
 On the Web P-4

T

Termination 2-15
Troubleshooting 10-1
 DRIVE LED indicator 10-2

FDBK LED indicator 10-2
OK LED indicator 10-1

U

Ultra 3000 Drive 8-1

W

Windows
 New module 3-4
 Select module type 3-2
Wiring diagrams B-4
 1394 drive B-8
 24V registration sensor B-10
 5V registration sensor B-10
 Home limit switch B-11
 OK contacts B-11
 Servo module RTB B-4
 Ultra 100 drive B-5
 Ultra 200 drive B-6
World Wide Web site P-4

For more information refer to our web site: www.ab.com/motion

www.rockwellautomation.com

www.ab.com

Corporate Headquarters

Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36-BP 3A/B, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Headquarters for Dodge and Reliance Electric Products

Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4800, Fax: (1) 864.281.2433

Europe: Rockwell Automation, Brühlstraße 22, D-74834 Elztal-Dallau, Germany, Tel: (49) 6261 9410, Fax: (49) 6261 1774

Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 351 6723, Fax: (65) 355 1733

Allen-Bradley Industrial Motion Control Technical Support

Ultra, Servo Motors (MP, F, H, Y and N-Series) and Electro-Craft products: Tel: (1) 952.914.3990, Fax: (1) 952.942.3756, E-mail: RAEPTechSupport@ra.rockwell.com

ControlLogix Motion, GMC, GML, S-Class, 1746, IMC and Creonix products: Tel: (1) 603.443.5419, Fax: (1) 603.448-5969, E-mail: RALebTechSupport@ra.rockwell.com

CNC products: (1) 440.646.6800

1394, Servo Motors (1326), 8720, and other products: Tel: (1) 262.512.8176, Fax: (1) 262.512.8450, E-mail: Support@drives.ra.rockwell.com

For Europe: Tel: 44 1270 580142, Fax: 44 1270 580141, E-mail: Ctechnicalsupport@ra.rockwell.com