



Operating manual Palletizing PowerPac

Trace back information:
Workspace Main version a205
Checked in 2017-02-27
Skribenta version 4.6.334

Operating manual

Palletizing PowerPac

RobotStudio 6.04

Document ID: 3HAC042340-001

Revision: K

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damages to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2012-2017 ABB. All rights reserved.

ABB AB, Robotics
Robotics and Motion
Se-721 68 Västerås
Sweden

Table of contents

Overview of the manual	9
1 Safety	13
2 Introduction	15
2.1 Overview	15
2.2 About Palletizing PowerPac	16
2.3 The palletizing process	18
2.4 Terms and concepts	22
2.5 Using a robot with 6 axes	25
3 Installation	31
3.1 System requirements	31
4 Workflow	35
4.1 Introduction	35
4.2 Preparing your controller for PickMaster	36
4.3 How to add tool	37
4.4 How to add feeders	38
4.5 How to create or modify product data	39
4.6 How to set pick setting	40
4.7 How to add job	41
4.8 How to do simulation	42
4.9 How to adjust cell layout to achieve reachability	43
4.10 How to transfer the project	44
4.11 How to start production	45
4.12 How to Pack Palletizing Project Data to Controller	46
4.13 How to UnPack Palletizing Project Data from Controller	47
4.14 How to Import PickMaster5 Projects into Palletizing PowerPac	48
5 User interface	49
5.1 Introduction	49
5.2 General	50
5.3 Ribbon	52
5.3.1 Overview	52
5.3.2 Add tool	55
5.3.3 Add feeder	57
5.3.4 Product/Pallet/Sheet	59
5.3.5 Pallet pattern	71
5.3.6 Pick setting	77
5.3.7 Add job	81
5.3.8 Check reach	86
5.3.9 Preview Palletizing	88
5.3.10 Simulation	91
5.3.11 Operator interface	92
5.3.12 Record as viewer File	97
5.3.13 Speed mode	98
5.3.14 Add controller	99
5.3.15 Download	100
5.3.16 Upload	102
5.3.17 Project overview	104
5.3.18 I/O interface	105
5.3.19 Project report	108
5.3.20 Pack data	109
5.3.21 UnPack data	112
5.3.22 Delete projects	114

5.3.23	Import PM5	115
5.3.24	Library	117
5.3.25	Models	118
5.3.26	IOPanel	140
5.3.27	Change viewpoint	141
5.3.28	Adjust position of object	142
5.3.29	Help	143
5.4	Layout browser	144
5.4.1	Introduction	144
5.4.2	Station	145
5.4.3	Robot	146
5.4.4	Tool SmartComponent	147
5.4.5	Feeder SmartComponent	148
5.4.6	Part	149
5.5	Programming browser	150
5.5.1	Introduction	150
5.5.2	Project	152
5.5.3	Controller	156
5.5.3.1	Controller	156
5.5.3.2	Robot	162
5.5.4	Tool	165
5.5.5	Feeders	167
5.5.5.1	Context Menus from the Feeders Node	167
5.5.5.2	Feeder	168
5.5.5.3	Operation set	177
5.5.6	Flows	195
5.5.6.1	Flows	195
5.5.6.2	Flow	197
5.5.7	Job	198
6	RAPID program	199
6.1	Introduction	199
6.2	Overview	200
6.2.1	Relationship between RAPID execution and PickMaster project	200
6.2.2	RAPID modules overview	202
6.3	Program module templates	203
6.3.1	PmMain module	203
6.3.2	PmUtility module	208
6.3.3	PmProjMgr module	214
6.3.4	PmProjServer module	217
6.4	System modules	222
6.4.1	System modules, overview	222
6.4.2	Public system module pmrcUser	223
6.4.3	Public system module pmrcSys	224
7	Runtime operation	229
7.1	Introduction	229
7.2	FlexPendant interface	230
7.2.1	Introduction to PickMaster FlexPendant interface	230
7.2.2	Opening a project	232
7.2.3	Starting and stopping production	233
7.2.4	Flow recovery	240
7.2.5	Process Signals	246
7.2.6	Tuning	249
7.3	I/O interface	253
7.3.1	Overview	253
7.3.2	Default signals	254
7.3.3	Basic I/O interface	256
7.3.4	Extended I/O interface	265

7.3.5	Timing diagrams for PLC communication	275
8	RAPID reference information	281
8.1	Introduction to RAPID reference information	281
8.2	Instructions	282
8.2.1	PmAckTarget - Acknowledge a target	282
8.2.2	PmCalcArmConf - Calculates the arm configuration	284
8.2.3	PmGetFlow - Get flow to execute	287
8.2.4	PmGetFlowInfo - Get information about a specific flow	289
8.2.5	PmGetLastWa - Get last used work area	291
8.2.6	PmGetOperation - Get operation from a work area	292
8.2.7	PmGetProjectInfo - Get information about a specific project	294
8.2.8	PmGetWaByWobj - Get a reference to a work area using a work object data	296
8.2.9	PmGetWalInfo - Get information about a specific work area	297
8.2.10	PmSearchAdjust - Adjust number of remaining layers	299
8.2.11	PmSetLastWa - Set last used work area	301
8.2.12	PmSetRecoverAction - Set flow recover action	302
8.2.13	PmStartFlow - Starts a specific flow	306
8.2.14	PmStartProj - Start a PickMaster project	308
8.2.15	PmStopFlow - Stop a specific flow	309
8.2.16	PmStopProj - Stop current project	311
8.2.17	PmWaitProjStart - Wait for any active project	312
8.3	Functions	313
8.3.1	PmCalcIntermid - Calculate intermediate position	313
8.3.2	PmGetEvent - Get events for an action	317
8.3.3	PmGetPathHeight - Get a safe path height for an intermediate movement	319
8.3.4	PmSetDefaultHeight - Set the default height	322
8.3.5	PmGetTarget - Get target	324
8.3.6	PmGetTgtAction - Get target action	326
8.3.7	PmGetWaHeight - Get the height of a work area	328
8.3.8	PmGetWaName - Get the name of a work area	329
8.4	Data types	330
8.4.1	pm_accdata - PickMaster acceleration/deceleration data	330
8.4.2	pm_acktype - PickMaster target acknowledge type	332
8.4.3	pm_actiondata - PickMaster action data	333
8.4.4	pm_actionhandle - PickMaster action handle	336
8.4.5	pm_actiontype - PickMaster action type	337
8.4.6	pm_eventdata - PickMaster event data	338
8.4.7	pm_eventtype - PickMaster event type	340
8.4.8	pm_flowinfo - PickMaster flow information	341
8.4.9	pm_moduleinfo - PickMaster module information	343
8.4.10	pm_movetype - PickMaster movement type	345
8.4.11	pm_offsetdata - Offset data	346
8.4.12	pm_operationdata - PickMaster operation data	348
8.4.13	pm_ophandle - PickMaster operation handle	350
8.4.14	pm_projectinfo - PickMaster project information	351
8.4.15	pm_robotinfo - PickMaster robot information	353
8.4.16	pm_searchdata - PickMaster search data	355
8.4.17	pm_searchtype - PickMaster stack search type	357
8.4.18	pm_singareatype - PickMaster interpolation type around singular points	358
8.4.19	pm_slavewainfo - PickMaster slave work area information	359
8.4.20	pm_stoptype - PickMaster stop type	361
8.4.21	pm_targetdata - PickMaster target data	362
8.4.22	pm_targethandle - PickMaster target handle	365
8.4.23	pm_wadescr - PickMaster work area reference	366
8.4.24	pm_wainfo - PickMaster Work Area information	367
9	Relationships between PickMaster frames	371
9.1	Structure of this chapter	371

Table of contents

9.2	Shape frame	372
9.3	Format frame versus shape frame	373
9.4	Pallet pattern frame versus shape frame	378
9.5	Format frame versus tool frame	379
9.6	Pallet pattern item versus tool frame	381
9.7	Format frame versus work object in format operation set	382
9.8	Pallet pattern frame versus work object in pallet pattern operation set	384
9.9	Tune frame versus work area frame	386
9.10	Tune frame versus work area frame versus displacement frame	389
Index		391

Overview of the manual

About this manual

This manual contains information and instructions for installing, configuring, and running Palletizing PowerPac.

Usage

This manual should be used during installation and configuration of Palletizing PowerPac. It describes Palletizing PowerPac and includes step-by-step instructions on how to perform the tasks from there.

Who should read this manual?

This manual is mainly intended for:

- System integrators
- ABB engineers
- End customers

Prerequisites

The reader should:

- Have experience with RobotStudio
- Have experience of installation and configuration work
- Good skills in the IRC5 robot controller and RAPID programming

References

References	Document ID
<i>Operating manual - IRC5 with FlexPendant</i>	3HAC050941-001
<i>Operating manual - RobotStudio</i>	3HAC032104-001
<i>Operating manual - Trouble shooting IRC5</i>	3HAC020738-001
<i>Technical reference manual - RAPID Instructions, Functions and Data types</i>	3HAC050917-001
<i>Technical reference manual - RAPID overview</i>	3HAC050947-001
<i>Technical reference manual - RAPID kernel</i>	3HAC050946-001
<i>Technical reference manual - System parameters</i>	3HAC050948-001
<i>Product manual - IRC5</i>	3HAC021313-001
<i>Product manual - IRC5 Panel Mounted Controller</i>	3HAC027707-001
<i>Product manual - IRB 260</i>	3HAC026048-001
<i>Product manual - IRB 460</i>	3HAC039842-001
<i>Product manual - IRB 660</i>	3HAC025755-001
<i>Product manual - IRB 760</i>	3HAC039838-001
<i>Product specification - Palletizing PowerPac</i>	3HAC041431-001

Continues on next page

Other references

References	Description
http://www.robotstudio.com/forum/	PickMaster Support Forum

Revisions

Revision	Description
-	First edition
A	Released with RobotStudio 5.14.03 The following updates are made: <ul style="list-style-type: none">• Updated the section Pack data on page 109.• Updated the section UnPack data on page 112.• Updated the section Import PM5 on page 115.
B	Released with RobotStudio 5.15 The following updates are made: <ul style="list-style-type: none">• Updated the section Import PM5 on page 115.• Added <code>pmSystem_doMotorOnState</code> and updated <code>pmSystem_doMotorOn</code>, see System outputs on page 265• Updated new Operator interface on page 92 dialog box• Updated Flow recovery on page 240• Updated instruction PmSetRecoverAction - Set flow recover action on page 302• Updated timing diagrams in Timing diagrams for PLC communication on page 275.• Updated Approach/Depart, see Group operation set on page 178.
C	Released with RobotStudio 5.15.01 The following updates are made: <ul style="list-style-type: none">• Updated the section PmMain module on page 203.• Updated the section PmUtility module on page 208.• Updated the section Public system module pmrcSys on page 224.• Updated the section Delete projects on page 114.• Updated the program code in the section PmProjMgr module on page 214.
D	Released with RobotStudio 5.60 The following updates are made: <ul style="list-style-type: none">• Updated the section IOPanel on page 140.• Updated the section Product flow sequence on page 21.• Updated the section Extended I/O interface on page 265.
E	Released with RobotStudio 5.61 The following updates are made: <ul style="list-style-type: none">• Updated the section Versions of Palletizing PowerPac on page 32.• Updated the section General tab on page 119.

Continues on next page

Revision	Description
F	Released with RobotStudio 6.0 The following updates are made: <ul style="list-style-type: none">• Updated the section Add tool on page 55.• Updated the section Pallet pattern on page 71.• Updated the section Download on page 100.
G	Released with RobotStudio 6.01 The following updates are made: <ul style="list-style-type: none">• Updated the section Operation set on page 177.
H	Released with RobotStudio 6.02 The following updates are made: <ul style="list-style-type: none">• Updated the section Using a robot with 6 axes on page 25.• Updated the section Tune Limitation on page 154.• Updated the section Group operation set on page 178.• Updated the section Operation editor on page 193.
J	Released with RobotStudio 6.03 The following updates are made: <ul style="list-style-type: none">• Updated the section Feeder on page 168.• Updated the section Operation set on page 177.
K	Released with RobotStudio 6.04 The following updates are made: <ul style="list-style-type: none">• Updated the section PmCalcIntermid - Calculate intermediate position on page 313.• Updated the section Preview Palletizing on page 88.

This page is intentionally left blank

1 Safety

Safety of personnel

When working inside the robot controller it is necessary to be aware of voltage-related risks.

A danger of high voltage is associated with the following parts:

- Units inside the controller, for example I/O units, can be supplied with power from an external source.
- The mains supply/mains switch.
- The power unit.
- The power supply unit for the computer system (230 VAC).
- The rectifier unit (400-480 VAC and 700 VDC). Capacitors!
- The drive unit (700 VDC).
- The service outlets (115/230 VAC).
- The power supply unit for tools, or special power supply units for the machining process.
- The external voltage connected to the controller remains live even when the robot is disconnected from the mains.
- Additional connections.

Therefore, it is important that all safety regulations are followed when doing mechanical and electrical installation work.

Safety regulations

Before beginning mechanical and/or electrical installations, ensure you are familiar with the safety regulations described in *Product manual - IRC5*.

This page is intentionally left blank

2 Introduction

2.1 Overview

This chapter gives an overview of the Palletizing PowerPac software, and includes the following:

- The Palletizing cell concept.
- A description of the palletizing process.
- A list of terms relating to PickMaster and terms which are specific to palletizing.

2 Introduction

2.2 About Palletizing PowerPac

2.2 About Palletizing PowerPac

Overview

The Palletizing PowerPac (PzPP) is a RobotStudio solution for offline programming and simulation of Palletizing application. The PowerPac replaces the ABB's PickMaster 5 application.

PickMaster is designed to handle one or more cells in the production. It is a modular product, which can be customized to your needs:

- PickMaster RC is a stand-alone robot kernel, running the process in production. It communicates through the RAPID program, I/O interface, and FlexPendant interface.
- PzPP allows you to make the configuration and simulation for a palletizing application and process.

Prerequisites

The Palletizing PowerPac can be installed on a computer running Windows XP, Windows Vista, or Windows 7. RobotStudio should also be installed.

To work with real controllers, the computer must be connected to a controller over an Ethernet network.

For minimum system requirements, see *Product specification - Palletizing PowerPac*. The Prepared for PickMaster option, together with the PickMaster 5 sub-option, are the required RobotWare software options to use PickMaster on the IRC5 controller.

Palletizing PowerPac functionality

The PowerPac contains:

- The Build Tool Function and Tool Events Configuration for configuring a robot tool model. See [Create Tool on page 118](#).
- The Tool I/O Configuration for configuring the I/O connection between robot tool and controller. See [Edit Tool Signals on page 166](#).
- The Build Feeder Configuration for configuring the feeder model properties, including hotspots. See [Create Feeder on page 137](#).
- The Feeder Configuration for configuring the feeder properties, including signals, work objects, feeder CAD models, and so on. See [Feeder on page 168](#).
- The Product/Pallet/Sheet Configuration for configuring the product/pallet/sheet that will be picked and placed by the robot. See [Product/Pallet/Sheet on page 59](#).
- The Pallet Pattern Configuration for configuring the stack of products organized in different layouts. See [Pallet pattern on page 71](#).
- The Layout Editor for creating new or modifying existing layouts. See [Layout Editor on page 73](#).
- The Pick Setting Configuration for configuring the products and tool orientation, as well as the tool functions to activate when gripping the products. See [Pick setting on page 77](#).

Continues on next page

- The Operation Set Configuration for configuring the format operation set and pattern operation set. See [Operation set on page 177](#).
- The Job Wizard Configuration for configuring a new job including pattern operation sets and/or format operation sets. See [Add job on page 81](#).
- The Flow configuration for defining accessible feeders in runtime. See [Flow on page 197](#).
- The Tuning for changing parameter values online from the FlexPendant. See [Tuning on page 249](#).
- The Project Settings for defining project name, descriptions, restart options and tune limitations. See [Project Settings on page 152](#).
- The Feeder Order Settings for defining feeder order in the cell layout. See the Feeder Order Settings page in [Controller Settings on page 156](#).
- The Event Settings for defining signals that can report events from external devices. See The Event Settings page in [Controller Settings on page 156](#).
- The Message Settings for defining messages that can be reported from external devices. See The Message Settings page in [Controller Settings on page 156](#).
- The Robot Settings for modifying motion limits and RAPID programs for each robot. See [Robot Settings on page 163](#).
- The I/O Interface editor for assigning I/O values to products, product groups, pattern operation sets, feeders, flows, and projects. See [I/O interface on page 105](#).
- The Pack Data for storing the Project in controller. See [Pack data on page 109](#).
- The UnPack Data for retrieving the stored project. See [UnPack data on page 112](#).
- The Palletizing Library for saving products, layouts, I/O connections and messages. See [Library on page 117](#).
- The Preview Palletizing function to go through each palletizing robot targets for user validation. See [Preview Palletizing on page 88](#).
- The Simulation function to simulate the palletizing application. See [Simulation on page 91](#).
- The Download and Upload function to synchronize programs between RobotStudio and robot controllers. See [Download on page 100](#) and [Upload on page 102](#).

2 Introduction

2.3 The palletizing process

2.3 The palletizing process

Overview

The palletizing application aims at picking larger size objects from a fixed position and stacking them tightly together in another fixed position. An important parameter in the palletizing process is the speed of the process, that is, the throughput of products in time and the efficiency in stacking the products in a stable configuration without taking up too much space.

After the palletizing process, the stacks are loaded into containers or trucks. The lesser the space products require, lesser will be the transportation cost.

The palletizing cell

The following figure illustrates an example of a palletizing cell.



xx110000001

In a palletizing cell, the robot is used for the following tasks:

- Picking and placing one or more products.
- Picking and placing slip sheets from a slip sheet stack station to pallet stations. This task is optional.
- Picking and placing pallets from a pallet stack station to pallet stations. This task is optional.

When working with the optional tasks described above, the robot has to be able to pick the objects off a varying and initially unknown stack size. This is solved by automatically searching the height of the stack, usually with a sensing device in the robot gripper for the first approach and then keeping track of the stack height. For more information, see [Stack search on page 189](#).

If the robot is not handling the pallets, they are moved into position by a feeder working in two directions, by AGVs or manually by fork lifts.

All the goods produced in a factory pass through the palletizing cells before shipping to the customers. This means that there is a large number of different products, which have to be guided to the right destination for accumulation. The most common shapes of products are a variety of carton boxes followed by bag types, but increasing numbers of open recycling crates are shaped for tight stacking.

Continues on next page

Packing the products

The way the products are packed is solved by using optimal layer layouts, and a variety of layouts to build stability in the complete stack. The various layouts can be achieved by using different layouts every second layer or by simply rotating or mirroring the same layout for every second layer.

Further common practice to stabilize the stack and protect the products is to use slip sheets between the layers. The slip sheets are thin cardboard sheets and they can be placed anywhere between the layers, but mostly they are evenly distributed. Slip sheets can also be placed at the bottom and on the top.

Speeding up the process

Introduction

For the fast palletizing process, the robot itself has to be fast and it has to be able to take more than one product at a time. The simplest way is to take boxes in groups and to place them in the same configuration in one drop. However, this reduces the universal flexibility of the robot. It is usually used for half and full layer palletizing, where the layouts are simple and very high throughput is required, often also in retrofits of older hard automated palletizers.

To plan each layout

A more flexible and efficient way is to plan each layout to be processed as efficiently as possible, which usually means as few operations as possible with a limited number of boxes at a time. If a specific format requested by the pallet stack is not possible to place in one target, the placing operation has to be split into a number of separate placing targets, releasing one box at a time, with the possibility to rotate each box separately if needed. This is referred to as single pick, multiple placing.

Infeeders, outfeeders, and logical devices

To handle many products and pallet loads simultaneously, the installations use multiple infeeders and outfeeders gathered around the robot and logical devices to order the correct products to the robots. Different products have different production cycle durations and any order can be stopped and switched to another at any time, while other orders continue to operate without being affected.

The robot can move between different stacks

During the palletizing process the robot has to be informed about the next format to pick and where to get it. When an operation is completed, another station can request the robot. In this way the robot has to move constantly and dynamically between different combinations of stacks.

The flow concept

Introduction

PickMaster introduces the unique concept of *Flow* which is a built-in and automated intelligent order sequence distribution for the robot to act upon. Thereby, no advanced PLC program is required to control the logics of the application.

Continues on next page

2 Introduction

2.3 The palletizing process

Continued

Execution of a palletizing job

A palletizing job with the flow concept can be described in the following steps:

- 1 A PLC requests a palletizing job to be done by a robot on a palletizing station. For example build a pallet consisting of seven layers of boxes on outfeeder 1.
- 2 While executing the job, the robot will step by step request the PLC to feed pallets, products, and slipsheets . For example, the robot requests a box to be fed on infeeder 1, or a new stack of slipsheets to be placed at the slip sheet station.
- 3 When a palletizing job is ready, the robot communicates to the PLC that the job has been completed. For example a full pallet is ready on outfeeder 1.
- 4 The palletizing station is prepared for a new job to be started. For example the PLC sends the pallet away. A new palletizing job can now be requested by the PLC to be started on the palletizing station.

Sequence of palletizing jobs

Palletizing jobs are configured using the graphical user interface in the PickMaster 5 PC application. Many different jobs can be executed by the robot in a sequence that does not have to be decided in advance. A palletizing job can be modified while executing, for example finishing a job before it has been completed.

Parallel palletizing jobs

The flow concept allows a robot running multiple palletizing jobs in parallel, using one palletizing station for each job. The jobs run independently of each other but can share common resources, for example one infeeder can feed products to several parallel jobs.

The robot can switch between different jobs after each pick-place cycle. If a job not is ready to run after a pick-place cycle (for example, the next box to be picked cannot be fed since an error has occurred on the infeeder) the robot continues to work with the other jobs until the error has been resolved. In this way, the productivity of the robot can be maximized.


Running parallel jobs does not add any complexity to programming or operator interaction.

Continues on next page

Product flow sequence


Following are the product flow sequence chart and the signal chart which are helpful while simulation.

Product flow sequence chart, 1 in -1 out



xx1300002144

Signal chart



xx1300002145

Related information

[Terms and concepts on page 22](#)

2 Introduction

2.4 Terms and concepts

2.4 Terms and concepts

About these terms

Some words have a specific meaning when used in this manual. This manual's definitions of these words are listed below. Some of the terms are put in their context when describing a palletizing process. See [The palletizing process on page 18](#)

Words that have italic font style in the definition column are included in the term list and have their own definitions.

Term list

Term	Definition
Action	Description of one robot movement to get to/on/from a <i>target</i> . Every action can have a number of <i>events</i> . For more information, see Relationship between RAPID execution and PickMaster project on page 200 .
Activator	An I/O controlled part of a robot tool, normally a vacuum cup. For more information, see Create Tool on page 118
Event	A description of an event on the robot path, for example setting an I/O signal. For more information, see Relationship between RAPID execution and PickMaster project on page 200 .
Facing	Possibility to select one or more sides of an <i>item</i> that should be facing outwards in a <i>pallet pattern</i> .
Feeder	A PickMaster's representation of pick and place areas. Often referred to as station, infeeders, or outfeeders. It defines the signals needed to control the in- and outfeeding of groups and pallet patterns on the feeder. Palletizing jobs can only be started on master feeders, see Flow on page 197 . The feeding on a slave feeder is dictated by one or more master feeders. A feeder also holds all group operation sets and all pallet pattern operation sets. It also contains general robot movement data for the feeder, for example, safe positions. For more information, see the Feeder on page 168 Configuration.
Flow	Logical directions of <i>items</i> being moved between pick and place stations when performing a palletizing/depalletizing job. A flow: <ul style="list-style-type: none">• Contains one master station on which palletizing/depalletizing jobs can be started. The master station dictates the operation sequence for itself and its slave stations.• Contains one or more slave stations. The slave stations execute operations requested by the master station. For more information, see Flow on page 197 .
Group	Describes a group of products that can be picked/placed by a robot tool in one operation
Group operation set	One operation that describes how to pick/place a group on a specific feeder. For more information, see the Operation set on page 177 Configuration.

Continues on next page

Term	Definition
Hotspot	A special frame on feeder model that can be used to attach a work object. It also describes the position relationship between an item and the work object.
Item	<p>The generic term for a specific object to be picked or placed. An item can be a product (i.e. box or bag), pallet, or slip sheet. An item is based on the geometric definition of a shape. For more information, see the Product/Pallet/Sheet on page 59 Configuration .</p> <p>Box: A rigid box with rectangle shape</p> <p>Bag: Same as box, but the bag has margins on length and width sides, specifying how much distance the bags can be overlapped with each other in a layout.</p> <p>Sheet: A thin sheet that is placed on a pallet before palletizing of products and between two layers to increase stability in the stack.</p> <p>Pallet: The actual wooden or plastic structure that the products are placed on.</p>
Job	A job is a supported program (i.e. Operation Set) on a flow's master feeder.
Layout	Defines the arranged two dimensional pattern of the <i>shapes</i> in a layer.
Master Feeder	The master station of a flow
Operation	<p>An operation describes what a robot shall do when entering a <i>work area</i> for a new pick or place. What to do is described as a list of <i>targets</i>.</p> <p>For more information, see Relationship between RAPID execution and PickMaster project on page 200.</p>
Pallet pattern	Defines a stack of <i>shapes</i> organized in different <i>layouts</i> . A layer in the stack can either be of <i>pallet</i> , <i>slip sheet</i> , or <i>product</i> type.
Pallet pattern operation set	A sequence of <i>operations</i> that describe how to pick/place a <i>pallet pattern</i> on a specific feeder.
Pick Setting, i.e. Format	<p>Defines one item or a group of items that can be picked/placed by a robot tool in one operation.</p> <p>In PickMaster 5, it was called Format.</p> <p>For more information, see the Pick setting on page 77 Configuration .</p>
Project	<p>Description of a PickMaster palletizing process applied on a specific <i>line</i>. Several projects can be defined for each <i>line</i>.</p> <p>For more information, see Project overview on page 104 .</p>
Robot Target	A single robot target that robot goes to during picking and placing. An action contains one robot target.
Safe Target	A position that the robot always has to pass through when going to or leaving a feeder
Slave Feeder	A slave station of a flow
Stack	An arranged pile of items consisting of a number of layers.
Target	A target describes a robot position used when performing an operation on a feeder. A target has a list of products carried by the robot tool and a list of actions that shall be executed. Note the difference with robot target: a target can have a list of actions, and each action has one robot target.

Continues on next page

2 Introduction

2.4 Terms and concepts

Continued

Term	Definition
Tool Function	A single function of a tool that requires input signals to control and will generate results as output signals.
Tool Scenario	One grouping of tool functions to use in all actions of a target during picking or placing.
Work area	The original term used in PickMaster 5 PC to describe feeders, now it is only used in RAPID functions and variables.
Zone	A vacuum tool function is divided into a number of zones. Each zone has one or more activators.

2.5 Using a robot with 6 axes

Overview

Even though running PickMaster 5 applications on a robot with 6 axes is possible, some manual modifications might be required depending on the robot configuration that is used.

The configuration of **SingArea** determines if you have to do manual modifications before running PickMaster 5 on a robot with six axes. This section describes the required modifications depending on the robot configuration.

The following scenarios are described for a bending backwards robot with 6 axes:

- Axis 6 is pointing down. See [Axis 6 points down on page 26](#).
- The wrist is tilted. See [Wrist is tilted on page 27](#).
- The robot is bending backwards. See [Robot is bending backwards on page 28](#).

For using a parallel rod robot with 6 axes together with PickMaster 5, see [Parallel rod robot on page 29](#).

Configuration of SingArea

Linear movements are by default configured to use **SingArea \Wrist** path interpolation mode. This setting is configured in the **Operation Set** dialog boxes. See [Group operation set on page 178](#) and [Pattern/Stack operation set on page 181](#).

Continues on next page

2 Introduction

2.5 Using a robot with 6 axes


Continued

Bending backwards robot

This section illustrates the different scenarios for a bending backwards robot, and describes the required manual modifications.

Axis 6 points down

The figure illustrates axis 6 pointing down. In this position the robot works in a similar way as a floor mounted palletizer robot with 4 axes, always having the mounting interface (and the tool) directed downwards in a horizontal orientation. No bending backward positions are used.




xx0700000354

Configuration	Description
Using SingArea \Wrist	Long linear movements causes varying tool orientation. Tool orientation deviates between targets when using SingArea /Wrist interpolation. The deviation is small for short movements but increases with longer distance between robot targets.
Using SingArea \LockAx4	While using a 6 axis robot, using this instruction locks the fourth axis during the motion between the targets.
Using SingArea \Off	See Manual modifications on page 28 .

Continues on next page

Wrist is tilted

The figure illustrates the tilted wrist. In this position the robot uses other tool orientations than a robot with 4 axes for some work areas, for example wall mounted work areas. No bending backward positions are used.



xx0700000355

Configuration	Description
Using SingArea \Wrist	Not recommended.
Using SingArea \LockAx4	Not recommended.
Using SingArea \Off	See Manual modifications on page 28 .

Continues on next page


2 Introduction

2.5 Using a robot with 6 axes

Continued

Robot is bending backwards

The figure illustrates the robot bending backwards. In this case the robot uses bending backward movements to reach some work areas. The tool can have various orientations.



xx0700000356

Configuration	Description
Using SingArea \Wrist	Not recommended.
Using SingArea \LockAx4	Not recommended.
Using SingArea \Off	See Manual modifications on page 28 .

Manual modifications

When the robot configuration is set to **SingArea \Off**, the following modifications are required for robot to run properly:

	Action	Note
1.	Use ConfL \Off. Update the system module <i>pmrcUser</i> , with the procedure <i>PmDoAction</i> from system module <i>pmrcSys</i> and rename the procedure to <i>DoAction</i> . Modify <i>DoAction</i> according to description in section System module pmrcUser on page 29 .	Linear motion supervision must be turned off to allow movements with large axis reorientations (> 90°).
2.	Use a robot position for each work area with MoveJ. In PzPP browser, record a safe position for each feeder, and use MoveJ for each position. See Safe Targets Set WorkObject position on page 175 .	First ensure the angles of axis 4 and 6 do <i>not</i> reach the physical limitation. Then ensure the robot has the correct arm configuration when operating on the work area.

Continues on next page

	Action	Note
3.	<p>Use ConfJ \On. Turn on the configuration control for joint movements.</p> <p>Update the system module <i>pmrcUser</i>, with the procedure <code>PmDoAction</code> from system module <i>pmrcSys</i>, and rename the procedure to <code>DoAction</code>. Modify <code>DoAction</code> according to description in section System module <i>pmrcUser</i> on page 29.</p>	First ensure the angles of axis 4 and 6 do <i>not</i> reach the physical limitation. Then ensure the robot has the correct arm configuration when operating on the work area.

System module *pmrcUser*

Modify the system module *pmrcUser*, with the procedure `DoAction` copied from procedure `PmDoAction` in system module *pmrcSys*.

```
...
IF Act.ArmConfMon = TRUE THEN
  ConfL\Off;
  ConfJ\On;
ELSE
  ConfL\Off;
  ConfJ\On;
ENDIF
...
```

You find the complete program code for the system modules *pmrcUser* and *pmrcSys* in section [Program code on page 225](#).



Note

The following modifications must be done in the program code:

- `ConfL\Off`
- `ConfJ\On`



Note

The procedure `Operate` in program module `PmMain` must be updated with a call to `DoAction` instead of `PmDoAction`.

Parallel rod robot

RAPID calls to `PMCalcArmConf`

When using a parallel rod robot, the same modifications need to be done as described for the bending backwards robot. For a parallel robot only the scenarios [Axis 6 points down on page 26](#) and [Wrist is tilted on page 27](#) are possible.

Following modification needs to be done in addition to what is described for bending backwards robots:

All RAPID calls to the routine `PmCalcArmConf` must use the optional argument `\TypeB1` instead of `\cf6`.

Continues on next page

2 Introduction

2.5 Using a robot with 6 axes

Continued

pmMain.mod

Modify the program module pmMain.mod, procedure Operate:

```
...  
PmCalcArmConf  
    Act.RobTgt,Tgt.TargetTool,Tgt.TargetWobj\TypeB1\MaxAngle:=  
    MaxToolAngle\MinAngle:=MinToolAngle\SingAreaType:=Act.SingAreaType;  
...
```

Related information

Group operation set on page 178.

Pattern/Stack operation set on page 181.

Public system module pmrcUser on page 223.

3 Installation

3.1 System requirements

Hardware and software Requirements

The following are the prerequisites for installing Palletizing PowerPac:

- A computer that meets or exceeds the system requirements as specified by RobotStudio.
- A log on account with administrator rights on the computer.

Hardware Requirements	Software Requirements
CPU: 2.0 GHz or faster processor, recommended is multicore processor	Microsoft Windows 7 (32 Bit or 64 bit)
Memory: 1 GB RAM or more (More is recommended).	RobotStudio 5.60 or above
Available disk space: 5+ GB on the system disk, 250+ MB on the installation disk	RobotWare 5.60 or above
Graphics card: High performance OpenGL-compatible graphics card with the corresponding up-to-date drivers installed	.NET 4.5 Framework
Screen resolution: 1280 x 1024 pixels (Recommended)	
Colors: 256 or higher	
DPI: Normal size (96 dpi)	
Mouse: Three-button mouse	

Installing Palletizing PowerPac

Use this procedure to install the Palletizing PowerPac:

- 1 Browse to Palletizing PowerPac installation package and double-click Setup.exe.
The installation starts.
- 2 Read the License Agreement and accept the terms.
- 3 Click Install.
- 4 When the installation is finished, complete the installation wizard by clicking Finish.



Note

Ensure that you have RobotStudio installed on your computer before installing Palletizing PowerPac.

Installing a license

To install a license of RobotStudio and PowerPac, see *Operating manual - RobotStudio*.

Continues on next page

3 Installation

3.1 System requirements

Continued

Versions of Palletizing PowerPac

The Palletizing PowerPac is available in the following two versions:

- **Basic:** The Basic version has limited features and is available free of cost.
- **Premium:** The Premium version has advanced features and is available on paying a subscription fee.



Note

The Basic version requires a Station or Pack&Go file.

Following are the details of the features available in the two versions of Palletizing PowerPac.

Feature	Basic	Premium
Build Cell - Add Tool	Yes	Yes
Build Cell - Add Feeder	No	Yes
Product Data - Product/Pallet/Sheet - Pallet Patterns	Yes	Yes
Programming - Pick Setting - Add Job	Yes	Yes
Validation - Check Reachability - Preview Palletizing	Yes	Yes
Simulation - Start - Pause/Stop - Reset	No	Yes
Transfer - Add Controller - Download - Upload	Yes	Yes
Project Properties - Overview - IO Interface - Unpack data - Report	Yes	Yes
Project Properties - Pack Data - Delete Projects - Import PM5	No	Yes
Advanced - Library - Models	No	Yes

Continues on next page

Feature	Basic	Premium
Advanced - IOPanel	Yes	Yes
3D Tools and Help	Yes	Yes

The support for the different versions of Palletizing PowerPac depends on the RobotStudio version installed on your system as displayed in the following table:

RobotStudio version	Palletizing PowerPac Basic	Palletizing PowerPac Premium
RobotStudio Basic	Limited features	Not available
RobotStudio Premium	Limited features	Full features



Note

Graphics is disabled in the Basic version of RobotStudio and Palletizing PowerPac.

This page is intentionally left blank

4 Workflow

4.1 Introduction

The following is the recommended working procedure for Palletizing PowerPac with PickMaster.

4 Workflow

4.2 Preparing your controller for PickMaster

4.2 Preparing your controller for PickMaster

Prerequisites

To run a PickMaster application you must prepare your robot controller for PickMaster. You create and install a system for the robot controller using RobotStudio.

The option Prepared for PickMaster, with the sub-option PickMaster 5, is needed to run PickMaster on an IRC5 robot controller.

Preparing your controller for PickMaster

Use this procedure to prepare the controller for PickMaster:

	Action	Note/See
1	Create and install a system for the robot controller using RobotStudio.	Operating manual - RobotStudio.
2	Setup RAPID tool data for the robot tool. Use RobotStudio or the FlexPendant.	The tool data will be created and downloaded in PzPP when certain tool is attached to the virtual robot. It is often convenient to define one tool data for picking/placing and another one to be used when calibrating work objects. If the robot tool supports stack search a separate tool data is created for that purpose. Technical reference manual - RAPID Instructions, Functions and Data types, section tooldata - Tool data.
3	Calibrate the work object for each feeder. Use the FlexPendant.	Technical reference manual - RAPID Instructions, Functions and Data types, section wobjdata - Work object data. Operating manual - IRC5 with FlexPendant.
4	Add tool related signals. Use RobotStudio or the FlexPendant.	See Edit Tool Signals on page 166 for information about the signals. Operating manual - RobotStudio. Operating manual - IRC5 with FlexPendant.
5	Add feeder related signals. Use RobotStudio or the FlexPendant.	See Edit detailed signals for feeder on page 171 for information about the signals. Operating manual - RobotStudio. Operating manual - IRC5 with FlexPendant.
6	Add event related signals if you want an external equipment to report errors and/or messages to the PickMaster application. Use RobotStudio or the FlexPendant.	The Controller Settings window. Operating manual - RobotStudio. Operating manual - IRC5 with FlexPendant.

4.3 How to add tool

On the **Palletizing** tab, click **Add Tool** to import a tool for the palletizing process.
See [Add tool on page 55](#) for detailed description.

4 Workflow

4.4 How to add feeders

4.4 How to add feeders

On the **Palletizing** tab, click **Add Feeder** to import a feeder and add to a robot for the palletizing process. Continue to add other feeders. At least two feeders are required for each robot. See [Add feeder on page 57](#) for detailed description.

4.5 How to create or modify product data

On the **Palletizing** ribbon tab, click **Product/Pallet/Sheet** to create or modify items for the palletizing process.

See [Product/Pallet/Sheet on page 59](#) for detailed description.

On the **Palletizing** ribbon-tab, click **Pallet Patterns** to create or modify patterns for the palletizing process.

See [Pallet pattern on page 71](#) for detailed description.

4 Workflow

4.6 How to set pick setting

4.6 How to set pick setting

On the **Palletizing** tab, click **Pick Setting** to define how products from an group or a stack are picked by a robot tool.

See [Pick setting on page 77](#) for detailed description.



Note

This function is only available when at least one item is created, and one tool is attached to at least one robot.

4.7 How to add job

On the **Palletizing** tab, click **Add a Job** to create a job for palletizing process.
See [Add job on page 81](#) for detailed description.

4 Workflow

4.8 How to do simulation

4.8 How to do simulation

On the **Palletizing** tab, click **Start button** to start simulation, **Stop button** to stop simulation and **Reset button** to clean the temporary objects generated in the previous simulation.


See [Simulation on page 91](#) for detailed description.

4.9 How to adjust cell layout to achieve reachability

If Check Reach or Simulation has reported unreachable targets, you usually have following ways to adjust the cell:


- **Move feeders:** you can enable the Freehand Move, click on the feeder model in the station, and drag it to an appropriate position. You can also use the Set WorkObject Position to change the feeder location.
- **Move robot:** you can also move the robot by Freehand Move or by Set Position of the corresponding robot model.

After you have changed robot position, a message box will show up to ask you whether to update the Task Frame:



xx110000180

Choose **Yes** to update Task Frame, otherwise, the controller needs to be restarted. Then a further message box will ask you to keep the positioning of all stationary RAPID variables (for example, work object):



xx110000181

Choose **Yes** to keep all work object values unchanged, otherwise the work objects will move together with the robot.

4 Workflow

4.10 How to transfer the project

4.10 How to transfer the project

On the **Palletizing** ribbon-tab, click **Add Controller** to connect to online controllers, and **Download** to check the destinations and transfer the project onto the online controllers.

See [Add controller on page 99](#) and [Download on page 100](#) for detailed description.

4.11 How to start production

Introduction

To run a PickMaster project in production you can use the PickMaster FlexPendant interface.

Starting production

Use this procedure to start a PickMaster project.

	Action	See
1	Start the PickMaster FlexPendant interface.	
2	Select the project you want to run.	Opening a project on page 232.
3	Start the project.	Starting a project on page 233.
4	Start flows.	Starting a specific flow on page 234 and Starting and stopping all flows on page 236.

Related information

[FlexPendant interface on page 230.](#)

[Opening a project on page 232.](#)

[Starting and stopping production on page 233.](#)

4 Workflow

4.12 How to Pack Palletizing Project Data to Controller

4.12 How to Pack Palletizing Project Data to Controller

On the **Palletizing** tab, in the **Project** group, click **Add Controller** to connect to online controllers. Click on **Pack Data** in **Project** group to transfer the palletizing project configured in RobotStudio Station to online or offline controllers.

For more information, see [Add controller on page 99](#) and [Pack data on page 109](#).

4.13 How to UnPack Palletizing Project Data from Controller

On the **Palletizing** tab, in the **Project** group, click **Add Controller** to connect to online controllers. Click on **UnPack Data** in **Project** group to transfer the palletizing project configured in RobotStudio Station from online or offline controller.

For more information, see [Add controller on page 99](#) and [UnPack data on page 112](#).

4.14 How to Import PickMaster5 Projects into Palletizing PowerPac

Palletizing tab, in the Project group, click on Import PM5 to convert PickMaster5 project to palletizing project.

For more information, see [Import PM5 on page 115](#).

5 User interface

5.1 Introduction

This chapter describes how to navigate in Palletizing PowerPac. Windows and other parts of the user interface are described in respect of their content and how they are accessed. The description of the main layout provides an overview of the menus, ribbon commands, and windows in Palletizing PowerPac.

5 User interface

5.2 General

5.2 General

Overview

Before starting Palletizing PowerPac, you must load a RobotStudio station.

In a station without system and robot, you are able to edit products, pallet patterns, create custom grippers and feeders, and edit libraries.

In a station with a system and at least one robot, you can continue to add tools and feeders to the robots, to configure flows and pick/place operation sets on feeders. The virtual controller (VC) associated with the robot must be loaded with Prepare for PickMaster option and PickMaster 5 sub-option.

Loading a Station

You can go through following steps to create a station and a system, and start using Palletizing PowerPac:

- 1 Open **RobotStudio** and create an empty station.
- 2 Select a palletizing robot and create a system from layout.
- 3 In the Systems option list, check **Prepare for PickMaster – PickMaster 5**. Finish system building and wait until system is ready.
- 4 On the **Add-Ins** tab in the ribbon, select **Palletizing** from the **PowerPacs** group.
- 5 A dedicated tab for Palletizing is added to the ribbon.
- 6 The Palletizing ribbon and tree structure browser opens.
- 7 Start from ribbon left to right: add tool, add feeder, add products, add patterns, add job, simulate, add real controllers and download.




Note

For other ways to create a station and a system, refer to Operating manual - RobotStudio.

Continues on next page

The User Interface

The panes and windows of the user interface, described in the following figure, help you create a well-structured palletizing program.



xx110000002

	Item	Description
1	Palletizing ribbon tab	Contains the general functions for palletizing application. When creating a new project, the work flow is usually from left to right. See Ribbon on page 52 for detailed description.
2	Palletizing browser	Organizes the components of the station and project in a tree structure. See Layout browser on page 144 for detailed description.
3	Tool window	Dialog boxes to edit certain project elements in browser and ribbon.
4	Graphics window	The graphics window is coordinated with the selection in browser elements and edited object in the tool window, showing context related temporary graphic objects.

5 User interface

5.3.1 Overview

5.3 Ribbon

5.3.1 Overview

The Palletizing PowerPac ribbon contains the following controls

- Building cell
- Creating pick and place programs
- Operating virtual controller
- Modifying Palletizing PowerPac data
- Modeling tools and feeders
- Help information



xx11000003

Elements on the Palletizing ribbon-tab

Group	Button	Description
Build Cell	Add Tool	Add a tool to robot for palletizing/depalletizing. See Add tool on page 55 for detailed description.
	Add Feeder	Add feeders to the cell for palletizing/depalletizing. At least two feeders are needed for a robot. See Add feeder on page 57 for detailed description.
Product Data	Product/Pallet/Sheet	Create products, pallets or sheets to be palletized/depalletized. See Product/Pallet/Sheet on page 59 for detailed description.
	Pallet Patterns	Create pattern related to the products to be palletized/depalletized. See Pallet pattern on page 71 for detailed description.
Programming	Pick Setting	Define how robot tool picks the products, pallets or sheets. See Pick setting on page 77 for detailed description.
	Add Job	Open Job Wizard to build a new palletizing/de-palletizing job. See Add job on page 81 for detailed description.
Validate	Check Reach	Check whether all of the picking robot targets and placing robot targets are reachable.
	Settings on Check Reachability	Check whether the specified picking robot targets and placing robot targets are reachable. See Check reach on page 86 for detailed description.
	Preview Palletizing	Preview all pick and place targets for all operation sets on feeders, by jumping tool or robot to the robot targets accordingly. See Preview Palletizing on page 88 for detailed description.

Continues on next page

Group	Button	Description
Simulation	Quick Start	Transfer program to virtual controller, open operator interface and start the simulation with the default jobs in one click. See Operator interface on page 92 for detailed description.
	Operator Interface	Transfer program to virtual controller, open operator interface. Then start the simulation for the specified jobs manually. See Operator interface on page 92 for detailed description.
	Record Simulation as Viewer	Select this option to save the simulation as viewer file after the simulation is stopped. See Record as viewer File on page 97 for detailed description.
	Speed Mode	Set simulation speed and there are three modes for it, such as Full, Customized and Low. See Speed mode on page 98 for detailed description.
Transfer	Add Controller	Connect a controller with this station using RobotStudio Online functionality.
	Download	Download the program to connected controllers. See Download on page 100 to Controllers for detailed description.
	Upload	Upload the program from the connected controller. See Upload on page 102 from Controllers for detailed description.
Project	Overview	Displays the overview information for all operation sets in the project. See Project overview on page 104 for detailed description.
	I/O Interface	Displays the I/O information for this project. See I/O interface on page 105 for detailed description.
	Report	Generate a report for this project. See Project report on page 108 for detailed description.
	Pack Data	Stores the Palletizing PowerPac project in the controller (Virtual or Real controller). See Pack data on page 109 for detailed description.
	UnPack Data	Unpacks the stored Palletizing PowerPac project to the controller (Virtual or Real controller). See UnPack data on page 112 for detailed description.
	Delete Projects	Deletes the saved projects from the Virtual or Online Controller. See Delete projects on page 114 for more details.
Advanced	Library	Edit the default libraries for reuse. See Library on page 117 for detailed description.
	Models	Guide user to design customized tool and feeder. See Create Tool on page 118 and Create Feeder on page 137 for detailed description.

Continues on next page

5 User interface


5.3.1 Overview

Continued

Group	Button	Description
	IOPanel	Monitors and sets the signals used during palletizing process. See IOPanel on page 140 .
3D Tools	View angles	Adjust the view point for the station from top, left, and front.
	Freehand move	Enable to adjust the position/orientation for the selected objects by manual dragging in 3D view.
Help	Help	Provides the user manual of Palletizing PowerPac.
	About	Provides the general information about Palletizing PowerPac.

5.3.2 Add tool

- 1 On the **Palletizing** ribbon Tab, in the **Build Cell** group, click **Add Tool**.




xx110000004

- 2 Under **Add Tool** select the tool from **ABB Grippers**, **User Grippers**, or **Browse Library** to select a gripper. The **Add Tool** dialog appears.



Note

One robot can only hold one tool for palletizing/depalletizing.



xx110000005

Item	Description
Controller	Select a controller in which the robot to attach the tool belongs to.
Robot	Select a robot which will hold the tool.
Signal Configuration	Provide the match information about signals connection between the tool and the virtual controller. If the signal connection is not valid, the status light will be red, and you can check and modify with button Edit Signals . See Edit detailed signals for feeder on page 171 for detailed description.

- 3 Do one of the following:
- Click **OK** to add the selected tool to the robot. The robot will hold the tool and the signals will be connected between the tool and the virtual controller automatically.

Continues on next page

5 User interface

5.3.2 Add tool

Continued

- Click **Add to Station Only** to only add the selected tool into the station only. The robot will not hold the tool and there is no signal connection between the tool and the virtual controller.
- 4 After the tool is added to the robot, a new **Tool** node will be added under the robot node in the programming browser, and also a tool node will be added in the layout browser.



Note

When a custom tool is added the signals are mapped automatically to the free available signals based on their type.

5.3.3 Add feeder

- 1 On the **Palletizing** ribbon tab, in the **Build Cell** group, click **Add Feeder**.



xx110000006


- 2 Under **Add Feeder** select the Feeder from **ABB Feeders**, **User Feeders**, or **Browse Library** to select a feeder.



Note

There should be at least two feeders for a robot for palletizing/depalletizing.

- 3 After a feeder library is selected, the following dialog box pops up.



xx110000007

Item	Description
Controller	Select a controller in which the robot to work with the feeder belongs to.
Robot	Select a robot in which the feeder is added.
Signal Configuration	Provide the match information about signals connection between the feeder and the virtual controller. If the signal connection is not valid, the status light is red, and you can check and modify with button Edit Signals . See Edit detailed signals for feeder on page 171 for detailed description.

Continues on next page

5 User interface

5.3.3 Add feeder

Continued

- 4 Do one of the following:
 - Click **OK** to add the selected feeder to the robot. The signals are connected between the feeder and the virtual controller automatically.
 - Click **Add to Station Only** to add the selected feeder into the station only. There is no signal connection between the feeder and the virtual controller.
- 5 After the feeder is added, a new feeder node is added under the **Feeders** node of the robot in the programming browser, and also a new feed node is added in the layout browser.

5.3.4 Product/Pallet/Sheet

- 1 On the **Palletizing** ribbon tab, in the **Product Data** group, click **Product/Pallet/Sheet**.



xx110000008

- 2 In the **Product/Pallet/Sheet** dialog box, click on any of the four item types: **Box**, **Bag**, **Pallet**, or **Sheet**.




Note

In a project, one box or one bag should be created at least.



Note

After one object is selected in the item list, its properties will be shown on the right UI.



xx110000009

For each type of item, there are two types for its collection:

- **Group:** a row by column grouping of several items, to describe how many items are handled by the robot at one pick. Usually for boxes and bags that comes with several rows.
- **Stack:** stacking of items by several layers. Usually for pallets and sheets, which are stacked together with several layers.

Click	To
Box	Create a new box as item with default values, and a default box group will be created simultaneously.

Continues on next page

5 User interface


5.3.4 Product/Pallet/Sheet

Continued

Click	To
Bag	Create a new bag as item with default values, and a default bag group will be created simultaneously.
Pallet	Create a new pallet as item with default values, and a default pallet stack will be created simultaneously.
Sheet	Create a new sheet as item with default values, and a default sheet stack will be created simultaneously.
Group	Create a new group for the selected item.
Stack	Create a new stack for the selected item.
Delete	Delete the selected object (product, group or stack) in the item list.
Export	Export the existing items to an XML file for reusing.
Import	Import and create items from an XML file.

Box Properties

This section describes how to edit the box properties.



To...	Do this
Rename a Box	In the Name text box, type a new name for the box. In default, a unique name can be generated automatically when a new box is created.
Set I/O value	In the I/O value number box, type a value to identify different products. Or click the button besides it, a new I/O value can be found automatically.
Select Box from Library	In the Library drop-down combo box, select an existing box to read in its values.
View the Item Type	In the Type combo box, the item type is shown. Its type cannot be changed after the item is created.

Continues on next page

To...	Do this
Set Box Size	In the Size boxes, type the dimensions for x, y and z.
Set Box Weight	In the Weight number box, type the weight (in kg).
Set Box Facing	Select the check boxes in Facing group to define which sides of the box to attach a label. See below 'Note' for detailed description.
Save the Box	Click <i>Save As Library</i> button, current box will be saved into the library for reusing.
Edit Advanced Settings for Box	Click <i>Show Advanced Settings</i> button, the advanced settings of the box will be shown in the right window and can be modified manually. See Advanced setting for Item on page 65 .
Show a Box	With the specified size and facing setting, the box can be shown in the 3D View.

**Note**

The facing defines the sides of a product that are of specific importance. A facing side could be a label or a carton opening (See [Advanced setting for Item on page 65](#) to know how to change the label picture). If the product is to be used in a pallet pattern, the products can be placed in a way that will maximize labels on the outside or openings in a specific direction.

Bag Properties

This section describes how to edit the bag properties.

xx110000011

To...	Do this
Rename a Bag	Same as Box
Set I/O value	Same as Box

Continues on next page

5 User interface


5.3.4 Product/Pallet/Sheet

Continued

To...	Do this
Select Bag from Library	Same as Box
View the Item Type	Same as Box
Set Bag Size	Same as Box
Set Bag Weight	Same as Box
Set Bag Margin	In the Margin number boxes, type the margin distance which is allowed for overlapping between multiple bags in a pallet pattern.
Set Bag Facing	Same as Box
Save the Bag	Same as Box
Edit Advanced Settings for Bag	Same as Box
Show a Bag	Same as Box

Pallet Properties

This section describes how to edit the pallet properties.




To...	Do this
Rename a Pallet	Same as Box
Set I/O value	Same as Box
Select Pallet from Library	Same as Box
View the Item Type	Same as Box
Set Pallet Size	Same as Box
Set Pallet Weight	Same as Box
Set Pallet Facing	Same as Box

Continues on next page

To...	Do this
Save the Pallet	Same as Box
Edit Advanced Settings for Pallet	Same as Box
Show a Pallet	Same as Box

Sheet Properties

This section describes how to edit the Sheet properties.



xx110000013

To...	Do this
Rename a Sheet	Same as Box
Set I/O value	Same as Box
Select Sheet from Library	Same as Box
View the Item Type	Same as Box
Set Sheet Size	Same as Box
Set Sheet Weight	Same as Box
Set Sheet Facing	Same as Box
Save the Sheet	Same as Box
Edit Advanced Settings for Sheet	Same as Box
Show a Sheet	Same as Box

Continues on next page


5 User interface

5.3.4 Product/Pallet/Sheet

Continued

Group Properties

This section describes how to edit the Group properties.




xx110000014

To...	Do this
Rename a Group	In the Group Name text box, type a new name for the group. In default, a unique name can be generated automatically when a new group is created.
View Used Item	In the Used Item combo box, this used item name will be shown. Its value cannot be changed after the group is created.
Set Group Orientation	In the Orientation combo box, select the group orientation to use. The selection defines the side of the group to place in negative y direction. A green marker shows the origin of each item.
Set Group Row	In the Row Count number box, type a value to define the rows of the group.
Set Group Column	In the Column Count number box, type a value to define the columns of the group.
Set I/O value	The I/O value is a combined value and is calculated from the orientation of the group and the number of rows and columns of occurrences of the item in the group. The I/O value represents the different ways a group can arrive on a conveyor. Also it is possible to type a value to identify different products in the I/O value number box. Click the button on the right, a new valid I/O value will be assigned.
Show a Group	With the specified row and column, the group can be shown in the 3D View.

Continues on next page

Stack Properties

This section describes how to edit the stack properties.



xx110000015

To...	Do this
Rename a Stack	In the Stack Name text box, type a new name for the stack. In default, a unique name can be generated automatically when a new stack is created.
View Used Item	In the Used Item combo box, this used item name will be shown. Its value cannot be changed after the stack is created.
Set Stack Orientation	In the Orientation combo box, select the stack orientation to use. The selection defines the side of the stack to place in negative y direction. A green marker shows the origin of each item.
Set Stack Height	In the Height Count number box, type a value to define the layers of the stack.
Show a Stack	With the specified row and column, the group can be shown in the 3D View.

Advanced setting for Item

After one item is created, its advanced settings can be edited as well. There are 3 pages for its settings: General, Pick/Place and Motion Limits.

Continues on next page

5 User interface

5.3.4 Product/Pallet/Sheet

Continued

General

In this section the general settings about the CAD of the item can be adjusted.

Advanced

Name Box1

General Pick/Place Motion Limits

CAD

Label Picture

C:\Program Files (x86)\ABB Industrial IT\Robotics IT Browse...

☐ Use Texture

Browse...

☐ Use Customized Model

Browse...

Offset (mm)

0.00 0.00 0.00

Orientation (deg)

0.00 0.00 0.00

☒ Show Outline in CAD model Color

☒ Show Origin in CAD model

Apply Tune Values

Tune Info


Tune Size (mm) (240.0, 200.0, 190.0)

Apply Close

xx110000016

To...	Do this
Set Label Picture	Click the Browse button to select a custom picture as the product label.
Set Texture	Select the Use Texture check box to use the selected picture as texture.
Set Customized Model	Select the Use Customized Model check box, and then click the Browse button to select a customized CAD model for the item, to replace the default box-like CAD model. If customized model is used changing the size of the item will not affect the model itself.
Show Outline	Select the Show Outline check box to display the outline of the CAD item as thin lines along the product edges.
Show Origin	Select the Show Origin check box to display the origin of the CAD item as green markers on the top and bottom surfaces.


Continues on next page

To...	Do this
Set Color	Click Color to select the color of the CAD item.  Note The color is hidden if texture is used.
Apply Tune Values	Click Apply Tune Values to set the tuned values as the default values for individual products.

Pick/Place

In this section the timing of tool events can be set, in order to pick and place the item as efficient as possible. You can define the pick time, that is, the time the robot is standing still in the pick position when picking up the item. Similarly the place time can also be defined, that is, the time the robot is standing still in the place position when placing the item.

The drop offset for the item in a pattern operation set can be set as well. This is usually used for bag when being released with an offset above the already finished stack. If a pattern operation set is created using this item, the value will be used as each layer's drop offset. See [Offsets for each layer on page 183](#) for detailed information.



Advanced

Name Box1

General Pick/Place Motion Limits

Vacuum Pick/Place Settings

	Default	Tuned	
Pick Time	0.010	0.010	s
Place Time	0.010	0.010	s
Vacuum Activation Time	0.100	0.100	s
Vacuum Deactivation Time	0.000	0.000	s

Drop Offset (Usually for bag) 0.000 mm

xx110000017

Continues on next page


5 User interface

5.3.4 Product/Pallet/Sheet

Continued

To...	Do this
Set Time Values for Vacuum Activation and Deactivation.	In the Vacuum Activation Time and Vacuum Deactivation Time number boxes, type the values.
Adjust Time that Robot Stays at the Robot Target Position When Picking or Placing an Item.	In the Pick Time and Place Time number boxes, type the time in seconds.
Set Drop Offset	In the Drop Offset number box, type the offset (in mm). It is useful for releasing bag from a certain height

You can adjust the location, where the tool zone gets activated when picking the item. The time when the zone should activate, Vacuum Activation Time, is specified in seconds before reaching the pick position. If a negative time is specified, activation will take place after reaching the pick position. If the time is set to zero, activation will occur after half the pick time has passed.




xx110000018

You can also adjust the location, where the tool zone gets deactivated when placing the item. The time when the zone should deactivate, Vacuum deactivation time, is specified in seconds before reaching the place position. If a negative time is

Continues on next page

specified, deactivation will take place after reaching the place position. If the time is set to zero, deactivation will occur after half the place time has passed.



xx110000019

Continues on next page

5 User interface

5.3.4 Product/Pallet/Sheet

Continued

Motion Limits

In this section the default speed and acceleration limits for the item can be defined. Also the tuned speed and acceleration of the item can be viewed. To edit separate motion configurations for the actions (Pick Approach, Pick Depart, Place Approach and Place Depart), select the Use * check box of the action to edit. If the Use * check box is cleared, the default settings will be used for this action.

Advanced

Name Box1

General Pick/Place Motion Limits

General Motion Limits

	Default	Tuned	
Speed	5000.0	5000.0	mm/s
Acc/Dec	10.0	10.0	m/s²
Rot Speed	500.0	500.0	deg/s

☒ Use Pick Approach

Pick Approach

Speed	5000.0
Acc/Dec	10.0
Rot Speed	500.0

☒ Use Pick Depart

Pick Depart

Speed	5000.0
Acc/Dec	10.0
Rot Speed	500.0

☒ Use Place Approach

Place Approach

Speed	5000.0
Acc/Dec	10.0
Rot Speed	500.0

☒ Use Place Depart

Place Depart

Speed	5000.0
Acc/Dec	10.0
Rot Speed	500.0

xx110000020

To...	Do this
Set Maximum Speed	In the Speed number box, type the maximum allowed speed.
Set Acceleration/Deceleration	In the Acc/Dec number box, type the acceleration value (in mm/s).The same value will be used for both acceleration and deceleration.
Set Maximum Rotation Speed	In the Rot Speed number box, type the maximum allowed rotation speed (in deg/s).



Note

There is NO need to set approach or depart speed because these will be limited by the acceleration and deceleration limits.

5.3.5 Pallet pattern


Introduction

- 1 On the **Palletizing** ribbon tab, in the **Product Data** group, click **Pallet Patterns**.



xx110000021

- 2 The **Pallet Patterns** dialog box opens and you can create or import pallet pattern to be used in the station. The item(s) that are defined before (using **Product/Pallet/Sheet**) are listed in the pattern. In a project, atleast one pallet pattern should be created. After one pallet pattern is selected in the pattern list, its corresponding properties are displayed on the right side.



xx110000022

Item	Description
Add Pattern	Create a new pallet pattern with items created before. For more information, see Pallet Pattern Layout on page 72 .
Delete	Delete the selected pallet pattern in the pattern list.
Export	Export the existing pallet patterns into XML file.
Import	Import and create pallet patterns from XML file. The used items in the XML file will also be created in station.

The following table describes the details of the **Pallet Patterns** dialog box:

Item	Description
1. Generate and Select Layouts	Based on the selected pallet, product, sheet and inputted pallet margin, the possible layouts will be calculated. Or you can also select layouts saved in the library. You can choose a layout and click the right arrow button to select into Selected Layouts.

Continues on next page

5 User interface

5.3.5 Pallet pattern

Continued

Item	Description
2. Selected Layouts	The selected layouts can be modified, and/or used directly to create layers. The specified layout can also be saved to reuse. You can choose a selected layout and click the right arrow button to add into pattern layers.
3. Pattern Layers	Shows the whole layers in a pallet pattern. For each layer you can also see the layout name, and adjust the mirror type.
Layout View	Shows the 2D view of any selected layout in the above 3 lists of layouts.

Pallet Pattern Layout

This section describes defining the pallet pattern layout. A pallet pattern is built as a stack of item layouts. Layout contains only one type of item.

To...	Do this
Select Pallet Area	In the selection box Pallet Area , select the pallet to use. If there are no pallets defined before, a default pallet area (1200 mm* 800mm) will be used for calculating the layout, which can be modified. The layout will be generated based on the selected pallet or input pallet size, and the margin.
Set Pallet Margin	In the Pallet Margin text box, type the minimum allowed margin (in mm). This will limit the maximum layout size by including a safety margin to the size of the palletizing area.
Select Product	Select the Product to be used, that is, a box or a bag.
Select Sheet	Select the Sheet to use. That is optional for the pallet pattern.



Note

You must always select a pallet, even if it will not be included in the pallet pattern. The pallet defines the maximum size of each layout. The pallet can NOT be changed once a layout based on the pallet is selected but sheet and product can be changed to build a pallet pattern with different items.

When the appropriate items are selected, the **Layout Source** list will be populated with the generated layouts. The layouts are generated for the selected product using different algorithms. Information, such as **Item**, **Count**, and **Coverage**, is shown for each layout.

The layouts that are saved in the library are selected by choosing **From Library** in **Layout Source**. After you have selected a new sheet, product, or given a new margin, new layouts are generated based on the new information. The new layouts are listed in the **Layout Source** list. All layouts in the **Selected Layouts** list are not affected and still use the old product and margin.






To...	Do this
Access Library Layouts	In the Layout Source drop-down list, select From Library . This will show all layouts from the library converted to use the selected items.
Select Layouts to Use in the Pallet Pattern	In the Layout Source list, select the layouts of interest and click right arrow button to bring it to the Selected Layouts list.

Continues on next page

To...	Do this
Edit Layout	In the Selected Layouts list, select the layout and click Edit Layout button. This opens up the Layout Editor. See Layout Editor on page 73 for detailed description.
Export to Library	In the Selected Layouts list, select the layout and click Export to Library
Show a Layout	In either the Layout Source or the Selected Layouts list, select the layout and it is displayed in the Layout View .
Remove Layout from Selected List	In the Selected Layouts list, select the layout to remove and click the Delete button.

Pallet Pattern Layers

This section describes how to proceed with the pallet pattern layer. When the layouts to use in the pallet pattern are defined, continue with setting the order and number of layers. The resulting pallet pattern is always shown in the Pattern Layers together with the stack details.

To...	Do this
Add Layers	In the Selected Layouts list, select the layout you want to use and click the right arrow button to add to the Pattern Layers list.  xx_120000012
Remove Layers	In the Pattern Layers list, select the layer and click  . Click  to remove every layer in the Pattern Layers list.
Reorder Layers	In the Pattern Layers list, select the layer and click   to reorder the layers in the list.
Show a Layer	In the Pattern Layers list, select the layer and it will be shown in the Layout View
Show Pallet Pattern	All of the layers in the Pattern Layers list will be shown in the Pattern Layers View .

Layout Editor

Introduction

Layout Editor is to create new or modify existing layouts. The purpose of modifying layouts is to make them fit the operator's specific requirements. A layout can be saved to the Library and/or to a pallet pattern configuration for a project.

Continues on next page

5 User interface


5.3.5 Pallet pattern

Continued

Depending on which layout to edit, you can start the Layout Editor in two ways:

- 1 From the Library, if you want to edit a layout that is included in the library.
 - In the library tree view, select a layout item to edit. For more information, see [Library on page 117](#).
 - Click **Edit**.
 - The **Layout Editor** window appears and you can edit the layout.
- 2 From a **Pallet Pattern** dialog box, if you want to edit a layout that is included in a **Pallet Pattern**.
 - Select the pallet pattern that includes the layout to edit.
 - In the **Selected Layouts** list, select the layout to edit.
 - Click **Edit Layout**
 - The Layout Editor window appears and you can edit the layout.

Illustration, Layout Editor



xx11000023

Item	Description
Layout	Shows the name of the layout and the size of the area where to palletize. The Layout area is mostly the area of a pallet. The Layout margin is the free distance from the edge of the palletizing area to the actual layout. The values for Layout area and Layout margin are only editable when there are no items in the layout.
Item	The drop-down combo box shows the selected item. If you add a new item, it will be added to the layout. If there are no items in the layout, you select which item to add. When you edit a library layout you can change the selected item to any of the available items in the library. When you edit a layout in a pallet pattern, you cannot change the item.

Continues on next page

Item	Description
Display	Shows the layout of a layer. Here you modify the layout by using a drag-and-drop operation or the buttons on the right side. The Show Overlap check box provides an option to show the overlapping boxes in red.
Selection	Shows the position and orientation of the selected item. You can adjust the position by editing the values in the text boxes, or by using CTRL + arrow keys.
Layout information	Shows the number of items in the layout and its coverage ratio. If there are any overlapping shapes, this will be noted here as well.

Proceed with the item

To...	Do this
Select multiple items	Press and hold the CTRL key while you click the items to select. Or use Press Left mouse key + Drag to multi select items
Select all items	Click Select All, or perform a select all operation (CTRL+A).
Add a new item	Click Add.
Copy an item	Click the item to copy and perform a copy-and-paste operation (CTRL+C for copy, CTRL+V for paste).
Delete the selected item/items	Click Delete, or press the Delete button on the keyboard.
Rotate the selected item/items	Click Rotate.

Proceed with the layout

To...	Do this
Mirror the layout in x direction	Click Flip Horizontal.
Mirror the layout in y direction	Click Flip Vertical.
Rotate the entire layout 180°	Click Rotate.
Center the layout	Click Center.

Align and distribute

The selected items can be aligned relative to each other by their edges. When you align items, the marked item always remains stationary. For example, clicking Align Left aligns the left edges of all selected objects with the left edge of the marked item. The selected items can also be distributed relative to the marked item. When items are distributed, all selected items are moved adjacent to the marked item in a horizontal or vertical direction. The marked item always remains stationary. Distribution of items is normally followed by an alignment operation.



Tip

All the commands are also accessible from the menu that appears when you select an item and right-click.

Continues on next page

5 User interface

5.3.5 Pallet pattern

Continued

Related information

[*Library on page 117*](#)

[*Pallet pattern on page 71*](#)

[*Terms and concepts on page 22*](#)

5.3.6 Pick setting


Procedure

- 1 On the **Palletizing** ribbon tab, in the **Programming** group, click **Pick Setting** to define how the item group or a stack is held by a robot tool.



xx110000024

- 2 The item and tool orientations can be configured, along with the tool functions (and zones if vacuum function is used) to activate when gripping the items. Furthermore, tool I/O signal events can be defined to control specific tool functionality.



xx110000025

3	Item	Description
	Add	Create a new pick setting for an item group or a stack.
	Delete	Delete the selected pick setting.
	Show Pick Setting	In the Pick Setting list, select the pick setting and the tool with the items will be shown in the 3D View. Weight information is shown, including product weight, and tool weight. If the product weight is more than the max payload of the tool's used tool data, a warning icon will be shown. Additionally, format ID is shown.

After one object is selected in the pick setting list, its preview and corresponding properties will be shown in the right.



Note

It is possible to define more than one pick settings for a same item group or stack.

Continues on next page

5 User interface

5.3.6 Pick setting

Continued

Tool Location

This section describes how to adjust the tool location relative to the group or the stack.

The screenshot shows a software window titled 'Name' with the text 'Box1Group1Format1'. Below the title bar are three tabs: 'Tool Location' (selected), 'Item - Tool Function Match', and 'Additional Events'. The 'Tool Location' tab contains the following elements:

- A label 'Specify the relative position between tool and products'.
- Two dropdown menus: 'Align position of' with 'Clamp1' selected, and 'With' with 'Item1' selected.
- A 'Tool Alignment' dropdown menu with 'Front' selected.
- Two sets of input fields for 'Offset (mm)' and 'Rotation (deg)'. Each set has three input boxes (all showing '0.00') and three small directional arrow buttons.
- Two small square icons with circular arrows, one green and one orange.
- A text field at the bottom showing 'TCP (in product frame): tGripper: (120.0, 0.0, -10.0)'.

xx110000026

To...	Do this
Align Position between tool functions (and/or zones) with products	Select the tool functions (and zones if the tool contains vacuum function) from the left selection list, and select the product in the right selection list. The tool will then be put to a location where the tool function position is at the center top of the product. Note that this is only used to change tool location, and does not necessarily mean that the selected tool function will be used to pick the product. To set which tool function to use for picking each product, see Item - Tool Function Match on page 79 .
Tool Alignment	Tool alignment allows you to position the tool based on the selection relative to the object which is being picked. This is valid only in the case of clamp gripper. For the rest of the grippers the default position is center.
Adjust Offset and Rotation	Input the translation offset and rotation angles (or click the rotation buttons) to adjust detailed offsets. The offset is relative to the aligned tool function and the selected product.
View TCP location	The TCP name and location is shown. The location is relative to the item group or stack's origin.

Continues on next page

Item - Tool Function Match

This section describes how to adjust the match relationship between item and tool function, i.e., which tool function is used to pick or place each item.

Item	Tool Function
Item1	Vacuum 1/Config1(Default)
Item2	Vacuum 1/Config1(Default)
Item3	Vacuum 1/Config1(Default)

☐ Auto Calculate

	Zone1	Zone2	Zone3	Zone4	Zone5	Zone6	Zone7	Zone8	Zone9	Zone10
Item1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Item2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Item3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

xx110000027

To...	Do this
Select Tool Scenario	In the Tool Scenario list, select the tool scenario you want to use. The tool scenario defines a group of tool functions that will be used in the pick setting, and tool functions not included in a tool scenario will not be activated. See Tool events and scenarios on page 133 for detailed information.
Adjust Relationship between Tool Function and Items	For each item, select a tool function to match with this item. If vacuum is selected for one item, it should also be used for other items.
Adjust Relationship between Tool Zone and Items (if vacuum is used)	If vacuum is used, you need to check the match between zones and items, i.e., using which zones to pick/place which items. Select Auto Calculate to automatically calculate the default item-zone matches.

When simulation is running, robot is at a pick position, and tool open signals are activated, the picking sensor of the tool functions will also be activated and any items that intersect with the sensor area will be picked up. Thus to make simulation of picking work, the picking location of the tool, relative to the items, should make the picking sensor areas of the tool function intersect with the matched item.

Continues on next page

5 User interface

5.3.6 Pick setting

Continued

See [Create Tool on page 118](#) for detailed information on picking sensor of different type of tool functions.



Note

The position of the tool, as well as the match between tool function and item, are important for simulation of picking to work.

Additional Events

This section describes how to edit the additional events for the tool.

For some pick settings, the items cannot be picked or placed by only using the defined tool functions and/or zones - for example, when picking a pallet using a specific I/O driven tool that cannot be modeled by standard tool functions. In such cases it is possible to set digital or group output signals and wait for digital input signals at various positions when picking or placing the products. These I/O events can be set for each pick or place operation at first approach action, last approach action, target action and first depart action, and last depart action. You must also define the value to set for output signals and the value to check for digital input signals. See an example in the following illustration.

Type	Signal Name	Value	Preset Time	Movement
Set	GO_Gripper	2	0	PickFirstApproach
Wait	GI_GripperOpen	1	0	PickFirstApproach
Set	GO_Gripper	1	0	Pick
Wait	GI_GripperClosed	1	0	Pick
Set	GO_Gripper	1	0	PickLastDepart
Wait	GI_GripperClosed	1	0	PickLastDepart


xx110000028

Type	Type of the event: <ul style="list-style-type: none">Set: set an output signal to a value at a specific movement.Wait: check the value of an input signal that indicates the actual status of the tool. In this example used for checking that the desired action indicated by the group output signal has been achieved.
Signal Name	The signal that is used in the event
Preset Time	The time in advance for the out signal to set to a value (only used for Set output type)
Movement	Describes when event occurs, i.e., first approach action, last approach action, target action and first depart action, or last depart action.

5.3.7 Add job

After the cell is built, the product data is created and the pick setting is ready, a new job for palletizing/depalletizing can be created with a wizard.


- 1 On the **Palletizing** ribbon tab, in the **Programming** group, click **Add Job** to open a wizard to create a new job for palletizing/depalletizing in three steps.



xx110000029

	Page	Action
1	Match Feeders with Products/Pattern for Picking/Placing	Select a controller, robot, job type, specify a pallet pattern on a master feeder and select necessary groups/stacks on the other feeders.
2	Configure Operation Set for Group or Stack	Configure the operation set for selected groups/stacks in detail.
3	Configure Operation Set for Pallet Pattern	Configure the operation set for selected pallet pattern in detail.

- 2 Distribute the roles of each feeders as described in the following table:



xx110000030

To...	Do this
Set Job Type	There are two types for the job, Palletizing and Depalletizing. It should be defined for the job at first. In the Job Type group, select the radio box to define the job type.
Select Controller and Robot	In the Robot group, select a controller and a robot in which the job is added.

Continues on next page

5 User interface

5.3.7 Add job

Continued

To...	Do this
Select Feeder as Master	<p>Master feeder is usually the feeder where the palletizing/de-palletizing jobs will be started. See Flow on page 197 for detailed information.</p> <p>In the Feeder selection box, select one feeder as the master. Note that feeders that are not valid to be a master (for example, those being slave feeders for existing flows) are not listed in the selection box.</p> <p>Once the master feeder is selected, the other feeders of the robot valid as slave will be listed in the tree view.</p> <p>If this feeder is not used as master by any existing flow, when the job creation is finished, a new flow will be created as well, including the newly generated job.</p> <p>If this feeder is a master of an existing flow, when the job is created, the existing flow will include the newly created job.</p>
Select Pallet Pattern for the Job	<p>In the Pattern selection box, select one pallet pattern. This pattern will be implemented in this job. In the main 3D view, the selected pallet pattern will be shown on the master feeder. Once the pallet pattern is selected, the necessary groups or stacks to build the pallet pattern will be listed in the list view (i.e. Groups and Stacks list).</p>
Adjust Orientation for Selected Pallet Pattern	<p>Click Flip button, the orientation of selected pallet pattern will be flipped 90 degrees on the master feeder.</p>
Select Feeder to Feed in Products	<p>Select one candidate feeder in the right list, select one group or stack in the left list, click Right Arrow button, the selected group or stack will be added under the selected candidate feeder. It means that this feeder will feed in (or out) products in this palletizing (or de-palletizing) job.</p> <p>Groups or stacks provided by existing operation sets on the feeder will also be listed.</p>
Remove Feeder from Feeding in Products	<p>In the right list, select one group or stack under a candidate feeder, click Delete button, the selected group or stack will be removed from the candidate feeder. It means that this selected group on this feeder will not play a role in this job.</p>
Adjust Orientation for Selected Group or Stack	<p>In the right list, select one group or stack under a candidate feeder, click Flip button, the orientation of selected group or stack will be flipped 90 degrees on this feeder.</p>

- 3 Click **Next** button to continue to the next step.



Tip

In the main 3D View, the products can be moved directly to adjust their position and orientation.


- 4 **Configure Operation Set for Group or Stack** and then **Configure Operation Set for Pallet Pattern** is described in the following sections.

Continues on next page

Configure operation set for group or stack

After the group or stack is selected, the operation set is configured. In general, if this job type is palletizing, the action for the operation set in this page is Picking, otherwise the action is Placing.

Each group or stack on each feeder will have its own operation set. The operation set will define how to pick or place the group or stack based on the pick setting related to the corresponding group or stack.



xx110000031

To...	Do this
Rename the Operation Set	In the Name text box, type a new name for the operation set. In default, a unique name can be generated automatically when a new operation set is created.
Select Pick Setting	Each group or stack should have at least one pick setting defined before. Based on the selected group or stack, one appropriate pick setting can be selected in the Pick Setting selection box for this operation set.
Set Stack Search	In some cases before picking the items (usually for pallet or sheet), the position of the items should be searched. Select Stack Search check box, the robot will search the height of pallet or sheet before picking it.
Check Reach	<p>Click Check Reach button to validate the reachability of all robot targets related to picking/placing the group/stack.</p> <p>The color of the icon next to the Check Reach button will show the check result:</p> <ul style="list-style-type: none"> Green: all robot targets can be reached Red: some of robot targets cannot be reached. <p>If it is red, then move mouse cursor over the icon and a tool tip will be shown, indicating which operation sets are not reachable.</p> <p>Select the corresponding operation set, and the unreachable items will turn red in main 3D view. For more information, see Check reach on page 86.</p> <p>You can adjust feeder position, flip group/stack position, or move robot to make all targets reachable.</p>

Continues on next page

5 User interface

5.3.7 Add job

Continued


To...	Do this
Preview Palletizing	Click Preview Palletizing button, a preview dialog will pop out to visualize all the robot targets in the main 3D view, which you can go through step-by-step. For more information, see Preview Palletizing on page 88 .

Click **Next** button to continue to the next page.

Configure operation set for pallet pattern

After the pallet pattern and corresponding group or stack are selected, and pick settings are selected for slave feeders, the operation set for the master feeder is configured. In general, if this job type is palletizing, the action for the operation set is Placing, otherwise the action is Picking.

A new pallet pattern operation set will be created, that defines the sequence and positions of picking/placing operations, using the pick settings selected for the related groups/stacks.



xx110100032

To...	Do this
Rename the Operation Set	In the Name text box, type a new name for the operation set. In default, a unique name is generated automatically when a new operation set is created.
Edit the Pallet Pattern	Select one layer in the Pattern Layers list, this layer layout will be shown in Layer Properties view. Click Edit button, a dialog box will be shown to edit the selected layer. See Layout Editor on page 73 for detailed description. Select Start Corner combo box, this layer will change its start corner according to the selection.

Continues on next page

To...	Do this
Check Reach	<p>Click Check Reach button, to validate the reachability of all robot targets related to picking/placing the pattern.</p> <p>The color of the icon next to the Check Reach button will show the check result:</p> <ul style="list-style-type: none"> • Green: all robot targets can be reached • Red: some of robot targets cannot be reached. <p>If it is red, the unreachable items in the selected pattern will turn red in main 3D view. For more information, see Check reach on page 86.</p> <p>You can adjust feeder position, flip group/stack position, or move robot to make all targets reachable.</p>
Preview Palletizing	<p>Click Preview Palletizing button, a preview dialog will pop out to visualize all the robot targets in the main 3D view, which you can go through step-by-step. See Preview Palletizing on page 88 for detailed description.</p>
Show Selected Layer in 3D View	<p>Select Show Selected Layer in 3D View check box and select one layer in the Pattern Layers list, the selected layer will be shown in 3D View and layers above it will be invisible.</p>

Click **Finish** button to complete the wizard.

After a job is created, the corresponding program nodes will be added into the browser, including new operation sets, flow and new jobs under the flow.


5 User interface

5.3.8 Check reach

5.3.8 Check reach

When any robot targets are generated in the station, it is possible to validate whether they are reachable.

- 1 On the **Palletizing** ribbon tab, in the **Validate** group, click **Check Reach** button, to validate the reachability of all robot targets related to picking/placing the pattern. If all robot targets are reachable, the icon displays green. Otherwise it turns red.



xx110000032

- 2 If there are unreachable targets, a warning dialog box pops up with the message '*Do you want to see details*'. If you click **Yes**, a list appears on the right side with the reach status of all the items.



Note

It is recommended that before downloading program and running simulation, all targets should be checked to be reachable.



xx110000033

To...	Do this
Check Selected Object	Select an object in the check list and click Check button, or double click the object, the robot targets contained by the object will be checked. The light status will change its color according to the check result. Green means that the robot targets can be reached while red means that some of robot targets cannot be reached.

Continues on next page

To...	Do this
Check All Robot Targets	Click Check All button, all objects in the list will be checked.
Show Unreachable Products	If some objects contain unreachable targets after checking, click on the object and the unreachable items in the selected object will turn red in main 3D view. Information of unreachable targets will also be shown in RobotStudio output window.

5 User interface

5.3.9 Preview Palletizing


5.3.9 Preview Palletizing

Previewing the Palletizing operation

For any operation set, the operation process can be previewed. That is, each pick or place robot target can be checked. The preview helps you to check the sequence of picking and placing, and check on the possible collisions.

To preview the Palletizing operation:

- 1 On the **Palletizing** ribbon tab, in the **Validate** group, click **Preview Palletizing**. The preview interface is displayed in the right window. All existing operation sets are listed in the **Palletizing Programs** group.




xx1600001365






- 2 Select an operation set in the list, and select preview preview palletizing options according to your requirement.

Continues on next page

The following figure and table provides information regarding the preview palletizing options.



xx110000036





Field	Description
Play Control- Speed	You can drag the button in the speed track bar and adjust the preview play speed from the slowest to the fastest.
Play Control - Step	Type a step number in the box and press ENTER. The preview goes to the specified step.
Play controls	<p>Click  to play all preview steps one by one from the current step.</p> <p>Click  to pause the preview step at the current step.</p> <p>Click  to stop the preview step the first step.</p> <p>Click  or the up arrow in Steps number box to navigate the previous step.</p> <p>Click  or the down arrow in Steps number box to navigate to the next step.</p>
Show with Tool	Select the Tool check box to display the tool during the preview process.
Show with Robot	Select Robot check box, the robot holding the tool jumps to each robot target during the preview process. If the robot target is not reachable, the robot will not move to this robot target.

Continues on next page

5 User interface

5.3.9 Preview Palletizing

Continued

Field	Description
Arm Configuration	<p>The Arm Configuration list displays all the possible arm configurations for a selected target in the operation set. You can define Safe targets and Search targets with their respective configuration. Click Apply Config to apply the selected configuration to the current target.</p> <p>Following are the known limitations of Arm Configuration option:</p> <ul style="list-style-type: none">• Arm configurations for General Offset targets, Horizontal Approach/Depart targets, and Extra Z targets have by default the same configuration as the item placement target and cannot be edited.• If a Pallet pattern has the same layout pattern in all the layers, then the Arm configurations are same through all the layers. The arm configurations within a layer can be changed but cannot be changed layer to layer. <p> Note</p> <p>When defining search targets you can select the reachable Arm configurations for Search targets and subsequent Box pick targets.</p> <p> Note</p> <p>The configurations are retained for small displacements in Feeder positions and Operation set displacements. For larger displacements Arm configurations may have to be redefined.</p>
Reset Configuration	<p>The Rest Configuration list allows you to reset the configurations. Configurations could be reset for each target as well as for the entire operation set by selecting Reset All Layers.</p> <p> Note</p> <p>To reset the configuration of an individual operation, first select the operation set in the browser tree.</p> <p> Note</p> <p>When a target is reset, the configurations for the all the offset targets surrounding the target are reset.</p>
Show Robot Targets	Select Show Robot Targets check box, the robot targets related to the operation set will be shown in main 3D view.
Show Target Description	Select Show Target Description check box, the description about the robot targets will be shown in main 3D view.

5.3.10 Simulation



xx11000042


1	<p>Click Start button, the following three simulation steps will be executed automatically and the operator interface will be displayed in the right window.</p> <ol style="list-style-type: none"> 1 Download the project file to virtual controller. 2 Load project file into PickWare and start project. 3 Start flows and jobs.
2	<p>The Pause is to Pause the simulation. On Pausing the button changes to Step. The step allows you to advance the simulation step by step.</p>
3	<p>If the simulation is started, the Stop button will be enabled. Click Stop button, the simulation will be stopped.</p>
4	<p>The Reset button is enabled when simulation is not started. Click Reset button, the simulation environment will be reset, the products created during the simulation will be cleaned, and the station is ready for next simulation.</p>

5 User interface

5.3.11 Operator interface





5.3.11 Operator interface

Click **Operator Interface**, the first two simulation steps will be executed. You can then start the flows and jobs with the buttons in this interface.



xx_120000014

The project status is shown on top of the interface:


Project status	Description	Status Light
Started	The project has been started successfully.	 xx110000044
Starting	The project is in the starting process.	 xx110000045
Stopped	The project has been stopped.	 xx110000046
Error	Error occurs during the project execution.	 xx110000047

Below the project status, there are two pages in the operator interface:

Continues on next page




Control page

Control the starting and stopping of flows, and the job sequences for each flow



xx110000048

All available flows are listed in the Controllers and Flows group. After the project is started, the status light will show different color to indicate flow status.


Project status	Description	Status Light
Running	The flow is running.	 xx110000044
Stopping	The flow is in the stopping process.	 xx110000045
Stopped	The flow has been stopped.	 xx110000046

Continues on next page

5 User interface





5.3.11 Operator interface

Continued

Project status	Description	Status Light
Error	Error occurs during the flow execution.	 xx110000047



Flow control

For the flows in the Controller and Flows group, their execution status can be controlled by the right buttons.

To...	Do this
Start a Flow	Select one flow in the Controllers and Flows group whose status is Stopped, click  to start the selected flow. If the selected flow is to be restarted, a flow recover option can be selected to specify how and when the flow must be restarted. If the status of the selected flow is not Stopped, this button will be disabled.
Stop a Flow	Select one flow in the Controllers and Flows group whose status is Running, click  to stop the selected flow. A flow stop option can be selected to specify how and when the flow must be stopped. If the status of the selected flow is not Running, this button will be disabled.
Start All Flow(s)	Click  to start all flows. If some of flows are to be restarted, a flow recover option can be selected to specify how and when these flows must be restarted. This button is enabled when the status of some of the flows are Stopped.
Stop All Flow(s)	Click  to stop all flows. A flow stop option can be selected to specify how and when the flow must be stopped. This button is enabled when the status of some of the flows are Running.

Scheduled Jobs

When one flow is selected, the scheduled jobs belonging to this flow will be refreshed in Scheduled Jobs group as well.


To...	Do this
Add Job	In the Scheduled Jobs group, click  button and a dialog will pop up. The dialog shows all supported jobs of the flow. Select one job and click OK button, the selected job will be added into the list.
Delete a Job	In the Scheduled Jobs group, select one job and click  to delete the selected job from the list.
Reorder Jobs	In the Scheduled Jobs group, select one job and click the Up or Down button to reorder the job in the list.

Continues on next page

To...	Do this
Repeat the Jobs	Select Run Continuously check box, the jobs in the list will be executed repeatedly.

Statistics Tab

Statistics Tab displays the statistics information for the palletizing process, including cycle time, throughputs, and certain event logs.



xx110000055

When the simulation is started, the statistics information is continuously updated to display the palletizing process data.

Item	Description
Simulation Time	Display the simulation time in second.

Continues on next page

5 User interface

5.3.11 Operator interface

Continued

Item	Description
Product Data	Display how many products are inputted and outputted and the calculated data of throughput (based on outputted products and cycle time).
Simulation Event Log	Display the main event log for palletizing process.

5.3.12 Record as viewer File

Check this option, to save the whole simulation as RobotStudio Viewer file after the simulation is stopped.


5.3.13 Speed mode

There are three speed modes for the simulation process: Full, Customized and Low.

You can check and change the speed mode, before the simulation is started. Default mode is Low.

Note that the specified speed is effective when robot is moving without products. If robot is moving with products, the speed is limited by the motion limits of the product itself.

5.3.14 Add controller



xx110000058

On the **Palletizing** ribbon tab, in the **Transfer** group, under **Add Controller** click one of the following:

- **Add Controller** - For adding available controllers to the network
- **One Click Connect** - For connecting to the service port of the controller

For more information on Online functionality, See *Operating manual - RobotStudio*.

5 User interface

5.3.15 Download

5.3.15 Download




xx110000059

On the **Palletizing** ribbon tab, in the **Transfer** group, click **Download**, the download interface will be displayed. The available virtual controllers and online controllers will be listed in the table.


The download includes:

- Synchronizing work object and tool data values, if downloading to virtual controller(s)
- Checking the completeness of project setups
- Generating and transferring the configuration files
- Generating and transferring the tune file to Pickware



xx110000060

Continues on next page

To...	Do this
Download Program to Online Controller	<p>Clear the Download to Virtual Controller check box. After the online controller(s) is added as described above, the available online controller(s) will be available to select in the table's Online Controller column. Match each virtual controller with an online controller, and click Download button to download the program to the available online controller(s).</p> <p> Note</p> <p>The download to online controllers is task based. You can select any particular task in the online controller to download from the station.</p>
Download Program to Virtual Controller	<p>Select Download to Virtual Controller check box, and click Download button to download the program to virtual controller(s).</p>

Before transferring the project, it is checked for errors to ensure that the configuration is valid.

**Note**

The project verification when transferred to the controller does not include verification of the RAPID program.

**Note**

It is not possible to transfer a project to a controller that is running the very same project. To update a project on a controller, the project must first be stopped.

**Note**

If the same project already exists on the controller, the tuning will be overwritten. To preserve the tuning use function before the downloading.

5 User interface

5.3.16 Upload

5.3.16 Upload




xx110000061

On the **Palletizing** ribbon tab, in the **Transfer** group, click **Upload** button in ribbon, the upload interface gets displayed. The available virtual controllers and online controllers will be listed in the table.

The upload includes:

- Reading the work object and tool data values from controller: feeder positions and tool function positions in the project will be updated accordingly.
- Reading the tune value from Pickware: the product sizes (the graphical model), feeder tune offsets (thus operation set positions on the feeders) will be updated accordingly.



xx110000062

Continues on next page

To...	Do this
Upload Program from Online Controller	Unselect Upload from Virtual Controller check box. After the online controller(s) is added as described above, the available online controller(s) will be available to select in the table's Online Controller column. Match each virtual controller with an online controller, and click Upload button to upload data from the available online controller(s).
Upload Program from Virtual Controller	Select Upload from Virtual Controller check box, and click Upload button to upload the program from virtual controller(s).

5 User interface


5.3.17 Project overview

5.3.17 Project overview



xx110000063


On the **Palletizing** ribbon tab, in the **Project** group, click **Overview** button in ribbon to display the overview information for the project.



xx110000064

The dialog shows each configured operation set and its corresponding product and format I/O values. You can also save this information into .txt file by clicking the “Save As Report” button.

5.3.18 I/O interface



xx110000065

On the **Palletizing** ribbon tab, in the **Project** group, click **I/O Interface** button in ribbon to display the I/O information for the project.

The interface is a one-stop place to view all information related with PLC for synchronizing with robot for palletizing process.

This includes all I/O values used in the projects (items and item groups, pattern operation sets, feeders, flows and projects), and all I/O signal names used in controllers, feeders, tools, and flows.

To save all the information into .txt file, click “Save As Report” button, input file name and click Save.

I/O values

To view and edit all I/O values used in the project.

For Products, Pattern operation sets, and Flows, you can also view and edit their I/O values in their editing interface respectively.

You can click “Generate Default” to generate default values for interested objects.

The screenshot shows the 'I/O Values' window with tabs for 'Project I/O' and 'Signals'. The 'Project I/O' tab is active, displaying a list of robot controller signals. The window is divided into four main sections, each with a 'Generate Default' button:

- Products:** Contains a table for 'Products/Pallets/Sheets' and a table for 'Groups'.
- Pattern Operations:** Contains a table for 'Pattern Operations'.
- Flows:** Contains a table for 'Flows'.
- Feeders:** Contains a table for 'Feeders'.

Each table lists I/O values and their associated controllers. The 'Generate Default' button is located at the top right of each table.

Name	I/O Value
Box1	0
Pallet1	1

Name	I/O Value	Parent Product
Box1Group1	10	Box1
Box1Group2	20	Box1

Name	I/O Value	Robot	Controller
Flow1	0	T_ROB1	SystemPalletizingMultiPickPlace

Name	I/O Value	Feeder	Robot	Controller
Pick PPforPick	0	InFeeder1	T_ROB1	SystemPalletizingMultiPickPlace
Place PalletPattern1	0	OutFeeder1	T_ROB1	SystemPalletizingMultiPickPlace

Name	I/O Value	Robot	Controller
InFeeder1	1	T_ROB1	SystemPalletizingMultiPickPlace
OutFeeder1	2	T_ROB1	SystemPalletizingMultiPickPlace

xx110000066

Continues on next page

5 User interface


5.3.18 I/O interface

Continued

Project Manager

If you want to start the projects using a PLC instead of the FlexPendant, then you must assign unique I/O value to each project.

The project I/O values are stored on the controller in the folder HOME:/Pickmaster/RC-Mode/ProjectMapping. A dedicated GI signal, pmProject_giSelection, specifies which project to start.



xx110000067

The projects exist in the controller will be listed on the list view. And their I/O values will be also read from the project mapping file and shown together.

Projects with I/O value of -1 means these projects are not assigned in the mapping file and cannot be remotely started by PLC.


To change an I/O value for a project, you can click on the I/O value number and input a different value.

Item	Description
Generate Default	Generate default valid I/O values for project with unassigned values.
Export...	Export the project I/O value setup to an xml file.
Import	Import a project I/O value setup from an xml file. The current setup will be replaced.
Remove	Remove the project from the list. The removed project I/O value can now be used by another project.

Continues on next page

Signals

You can view all the signals used in the project, including the signal name, related object and its type, and the signal's usage/purpose.



Object	Type	Usage/Purpose	Signal Name
SystemPalletizingMultiPickPlace	Controller	Error Trigger	pmEvent_d1Trigger
SystemPalletizingMultiPickPlace	Controller	Error Source	pmEvent_d1ErrorSource
SystemPalletizingMultiPickPlace	Controller	Error Message	pmEvent_d1ErrorMessage
VacuumGripper	Tool	gSCToolActivators	pmGripper1_goActivators
VacuumGripper	Tool	gOpenClaw	pmGripper1_goToolEvent1
VacuumGripper	Tool	gClawOpened	pmGripper1_goToolEvent1
VacuumGripper	Tool	gOpenSearcher	pmGripper1_goToolEvent2
VacuumGripper	Tool	doSearcherOpened	pmGripper1_dActivator1Opened
VacuumGripper	Tool	doSearcherClosed	pmGripper1_dActivator1Closed
Flow1	Flow	Status	pmFlow1_goSStatus
InFeeder1	InFeeder	Position Request Trigger (DO)	pmInFeeder1_dgPosReqTrig
InFeeder1	InFeeder	Product Selection (GO)	pmInFeeder1_goProdSel
InFeeder1	InFeeder	Format Selection (GO)	pmInFeeder1_goFormSel
InFeeder1	InFeeder	Requesting Master (GO)	pmInFeeder1_goReqMaster
InFeeder1	InFeeder	Target Generation Trigger (DI)	pmInFeeder1_d1gGenTrig
InFeeder1	InFeeder	Product Selection (GI)	pmInFeeder1_giProdSel
InFeeder1	InFeeder	Format Selection (GI)	pmInFeeder1_giFormSel
InFeeder1	InFeeder	Start Layer Count (GI)	pmInFeeder1_giStartLayerCount
InFeeder1	InFeeder	Start Product Count (GI)	pmInFeeder1_giStartProdCount
InFeeder1	InFeeder	Position Available (DO)	pmInFeeder1_dgPosAvail
InFeeder1	InFeeder	Operation Set Complete (DO)	pmInFeeder1_dgOpSetCompl
InFeeder1	InFeeder	Queue Empty (DO)	pmInFeeder1_dgQueueEmpty
InFeeder1	InFeeder	Execution State (GO)	pmInFeeder1_goExecState
InFeeder1	InFeeder	Height State (GO)	pmInFeeder1_goHeightState
InFeeder1	InFeeder	Layer Count (GO)	pmInFeeder1_goLayerCount
InFeeder1	InFeeder	Product Count (GO)	pmInFeeder1_goProductCount
InFeeder1	InFeeder	Stop Job (DI)	pmInFeeder1_d1StopJob
InFeeder1	InFeeder	Redo Search (DI)	pmInFeeder1_d1RedoSearch
InFeeder1	InFeeder	Robot Execution (DI)	N/A
OutFeeder1	OutFeeder	Position Request Trigger (DO)	pmOutFeeder1_dgPosReqTrig
OutFeeder1	OutFeeder	Product Selection (GO)	pmOutFeeder1_goProdSel
OutFeeder1	OutFeeder	Format Selection (GO)	pmOutFeeder1_goFormSel
OutFeeder1	OutFeeder	Requesting Master (GO)	pmOutFeeder1_goReqMaster
OutFeeder1	OutFeeder	Target Generation Trigger (DI)	pmOutFeeder1_d1gGenTrig
OutFeeder1	OutFeeder	Product Selection (GI)	pmOutFeeder1_giProdSel

xx110000068

5 User interface

5.3.19 Project report

5.3.19 Project report




xx110000069

On the **Palletizing** ribbon tab, in the **Project** group, click **Report** button in ribbon to display the process report for the project.

The report function generates a report for all project objects, including item properties, pattern designs, operation sets, and flows.


You can save the report as a PDF or Excel file.



xx110000070

5.3.20 Pack data

- 1 In the **Project** group, click **Pack Data** , the **Pack Data** interface is displayed in the right window.



xx1200000122

The available virtual controllers and online controllers are listed in the drop down menu.

- 2 Click **Pack Data To**.


Continues on next page

5 User interface

5.3.20 Pack data

Continued

The **Pack Data** creates a Pack and Go file of the RobotStudio Station in *.rspag* format and transfers it to the online/virtual controllers.



xx_120000013

To	Do this
Pack Data to Online Controller	After the online controller(s) is added, the available online controller(s) is available for selection in the drop down menu Online Controller . Click Pack Data To in tool window and select Online Controller(s).
Pack Data to Virtual Controller	Click Pack Data To in tool window and select Virtual Controller(s).

Continues on next page

To	Do this
Include Libraries	Select Include Libraries present in the dialog to include them while packing data.



Note


If a similar palletizing project data exists in the controller, the data would be overwritten.

5 User interface

5.3.21 UnPack data

5.3.21 UnPack data

- 1 In the **Project** group, click **UnPack Data** .



xx1200000123

The **UnPack Data** interface is displayed in the right window.

A screenshot of the 'UnPack Data from Controller(s)' dialog box. The dialog has a title bar with a minimize button, a maximize button, and a close button. Inside, there is a 'Select' section with the following controls: 'Controller Type' with two radio buttons, 'Virtual' (selected) and 'Online'; 'Controller Name' with a dropdown menu showing 'SystemPalletizing660_VacuumWithPalletPicker'; 'Project Name' with a dropdown menu showing 'Palletizing 660 Vacuum with Pallet Picker'; and 'Pack and Go file' with a dropdown menu showing 'Click here to select'. At the bottom left is a help icon (a question mark in a circle). At the bottom right are two buttons: 'UnPack' and 'Close'.

xx_120000013

Controller Name: Corresponds to the selected controller

Project Name: Corresponds to the Palletizing Project name

Continues on next page

Pack and Go file: Corresponds to the Pack and Go file created

- 2 Select either **Virtual** or **Online** as the controller type.



Note

Based on the selection the Virtual or Online controllers would be populated along with the available pack and go files.


- 3 Click and select the **Pack and Go file**.
- 4 Click **UnPack Data**.



Note

- 1 The **Pack and Go** file can also be accessed from the controller system folder.
- 2 The system that is unpacked will not have the project information in the form of **Pack and Go** (.rspag). Pack data needs to be done inorder to have the same.

5.3.22 Delete projects




en1300000344

The controller (Virtual or Online Controller) contains reference of projects. The **Delete Projects** option allows you to delete the saved projects from the selected Controller.

To delete a project:

- 1 Click the **Delete Projects** button.

The **Delete project from controller** window is displayed.




en1300000343


- 2 Select the controller type from the **Select Controller Type** section.
The saved projects in the selected controller are displayed.
- 3 Select the project(s) that you want to delete.
- 4 Click the **Delete** button.
The selected projects are removed from the selected controller.

5.3.23 Import PM5

- 1 In the **Project** group, click **Import PM5** ,



xx1200000124



xx1200000125

The **Import PM5** interface is displayed in the right window.

- 2 Browse and select the PickMaster5 project to be imported (.pmproj).
- 3 Map the controllers in RobotStudio with the controllers in PickMaster5 project.
- 4 Map the tasks in RobotStudio with the tasks in PickMaster5 project.
- 5 Click **Import**.

Continues on next page

- 6 The PickMaster5 project is converted to Palletizing PowerPac project structure.



Note

- 1 The Import function will check for *.pmlne* file before reading the PickMaster project.
- 2 Default feeders are used which are provided as part of Palletizing PowerPac.
- 3 Supports addition of Vacuum gripper tool only
- 4 The values of **Format offset**, **Format rotation** and **operation sets** are read from the *.pmproj* file, the values are updated during to Palletizing PowerPac **AutoCorrect**.
- 5 User needs to update the workobject and tooldata values from the controller.
- 6 If ItemZoneMap is not manual, the zone mapping is re-calculated automatically and overwritten.

5.3.24 Library



xx110000071


In the **Advanced** group, click **Library** to display the libraries used in the project. Library contains template products, pattern layouts, controller messages and tool I/O connections.

In Palletizing PowerPac, there are two places where library files are saved:

- Installation directory: for example: “C:\Program Files\ABB Industrial IT\Robotics IT\PzPP 5.14\Library”
- User directory: “...My Documents\RobotStudio\Palletizing\Library\”

Library files from each location are retrieved and shown in the UI.

New libraries added are stored in the user library and only the library files from the user directory can be edited and saved.



xx110000072

Command	Description
Add an library item	Right click on a group node (i.e., Items, Layouts, Messages, Connections), and click Add context menu
Edit	Click on the node and edit on the right UI. Note only library items from user directory can be edited and saved. Otherwise, a message will be shown to user for warning.
Delete	Right click on a library item node, and click Delete context menu.
Copy an existing item	Right click on a library item node, and click Copy context menu.

5.3.25 Models

Create Tool



xx110000073

The **Create Tool** interface is used to create a Palletizing PowerPac compatible tool SmartComponent model. The SmartComponent model can then be attached to the robot, or saved as RobotStudio library (.rslib) file, and be imported and reused in other palletizing projects.


Tool Functions

Introduction

A Palletizing PowerPac compatible tool includes properties of:

- Tool weight, center of gravity, and inertia.
- I/O connection template name: the I/O template that can be used as default for the tool. This information is used when the tool is attached to a robot. See [Edit Tool Signals on page 166](#) for detailed information.
- Tool function: A tool should contain at least one tool function. A tool function is a modular function of the tool that is controlled by certain I/O and optionally containing certain behaviors.

For example, the ABB Vacuum Tool in Palletizing PowerPac contains the following three tool functions:



xx110000074

- 1 Pallet pick function: a type of claw that is controlled by 2 DI signals for opening and closing, and contains 2 DO signals to tell the opened and closed status. It is usually used to pick up a pallet.
- 2 Vacuum function: the vacuum is usually controlled by a GI signal to open certain groups of suction cups and close other groups of suction cups. It is usually used to pick boxes.
- 3 Searcher: the searcher is usually controlled by 2 DI signals for opening and closing, and contains 2 DO signals to tell the opened and closed status. It is usually used to detect the actual height of a pallet stack. When the searcher is totally opened, and during the downward movement touches the

Continues on next page

pallet, one of the DO signal value is changed so robot will know the actually height of the pallet.

- Tool data: each tool function usually uses one tool data. Thus a tool may contain one or more tool data. These tool data, when the tool is attached to a robot, will be created in station.

The following sections describe:

- How to edit tool weight, I/O template, tool data
- How to add/edit/remove different types of tool functions, and the related tool data

General tab

Build Tool SmartComponent

General | Tool Functions

Tool Name: ClawGripper

I/O Connection Template: ClawGripper Connection

Tool Height And Weight

☒ Use Tool Height: 800

Tool Weight: 60.0

Center of Gravity (mm)

0.00 0.00 10.00

Inertia Ix, Iy, Iz (kgm²)

1.11~ 0.33~ 0.81~

Tooldata List

Name	Max Payload (Kg)	TCP (Relative to Tool Origin)
tClaw	50.0	Position (mm): 0.00 0.00 495.00 Orientation (deg): 0.00 0.00 0.00

OK Cancel

xx110000075

Continues on next page

5 User interface

5.3.25 Models

Continued


	Description
I/O Connection Template	Choose a default I/O template for this tool. The chosen template will be used as default when the tool is attached to a robot. The available templates are read from library.
Use Tool Height	The height of the tool. This value is considered as the default tool height. If this option is not selected, default height of the tool based on the tool functions is considered as the tool height.
Tool Weight	The weight of the tool. This value is applied to the related tool data in station when this tool is attached to a robot.
Center of Gravity (mm)	Center of gravity of the tool. This value is applied to the related tool data in station when this tool is attached to a robot.
Inertia Ix,Iy,Iz (kgm²)	Inertia of the tool. This value is applied to the related tool data in station when this tool is attached to a robot.
Tooldata List	A list of tool data that are contained by this tool. Some tool functions of this tool may use one of the tool data. The tool data will be created or overridden accordingly in station when this tool is attached to a robot.
Name	Name of the tool data.
Max Payload (Kg)	Maximum payload for this tool data. In Pick Setting dialog, if the tool function using this tool data is specified to pick products more than this payload, a warning appears.
TCP (Relative to Tool Origin)	The position and orientation of the tool data.

To add/edit/remove tool functions

There are currently 6 types of tool functions defined in Palletizing PowerPac. Click



the button, and the following window is displayed:



xx110000077

Following sections describe each tool function, and their related UI interfaces

Continues on next page


Vacuum



xx110000078

A Vacuum function contains one or more Activators, and several activators can be grouped into one zone and opened and closed together. It also contains one or more zone configurations that specify different way of grouping activators into zones.

The editing UI for Vacuum is as following:



Properties	Description
General	<div><p>You can change the tool function name, choose the tool data, and input a control signal name for tool SmartComponent.</p><div><div>Vacuum1</div><div>Tooldata</div><div>tVacuum</div></div><div><div>Control Signal (GI)</div><div>giSCToolActivators</div></div></div> <div><div>xx110000080</div><div><div></div><div>Note</div></div><div>The control signal is for the tool SmartComponent, and is not a robot controller signal.</div></div>

Continues on next page




5 User interface

5.3.25 Models

Continued

Properties	Description																																												
Activators	<p>An activator is a physical correspondent to the control signal, and controls one part of the tool, for example a vacuum cup. The figure shows a configuration example</p> <div><div>Vacuum ActivatorsZones</div><div>Activators</div><table><tr><th>Name</th><th>Start Bit</th><th>Bit Length</th><th>A/D/(I)</th></tr><tr><td>Act1</td><td>0</td><td>1</td><td>0/1</td></tr><tr><td>Act2</td><td>1</td><td>1</td><td>0/1</td></tr><tr><td>Act3</td><td>2</td><td>1</td><td>0/1</td></tr><tr><td>Act4</td><td>3</td><td>1</td><td>0/1</td></tr><tr><td>Act5</td><td>4</td><td>1</td><td>0/1</td></tr><tr><td>Act6</td><td>5</td><td>1</td><td>0/1</td></tr><tr><td>Act7</td><td>6</td><td>1</td><td>0/1</td></tr><tr><td>Act8</td><td>7</td><td>1</td><td>0/1</td></tr><tr><td>Act9</td><td>8</td><td>1</td><td>0/1</td></tr><tr><td>Act10</td><td>9</td><td>1</td><td>0/1</td></tr></table><div><div>+</div><div>×</div></div><div>Act1</div><div>Act1</div><div>Position (Relative to TCP) (mm)</div><div>0.000-540.0000.000</div><div>Orientation (deg)</div><div>0.0000.0000.000</div><div>Size (x,y,z) (mm)</div><div>280.000100.00020.000</div></div> <p>xx110000081</p> <p>To add a new activator, click .</p> <p>To remove an activator, click .</p> <p>To edit an activator setting, select the activator from the list and edit the value in the lower UI.</p> <p>For descriptions of the activator settings, see Activators properties on page 123.</p>	Name	Start Bit	Bit Length	A/D/(I)	Act1	0	1	0/1	Act2	1	1	0/1	Act3	2	1	0/1	Act4	3	1	0/1	Act5	4	1	0/1	Act6	5	1	0/1	Act7	6	1	0/1	Act8	7	1	0/1	Act9	8	1	0/1	Act10	9	1	0/1
Name	Start Bit	Bit Length	A/D/(I)																																										
Act1	0	1	0/1																																										
Act2	1	1	0/1																																										
Act3	2	1	0/1																																										
Act4	3	1	0/1																																										
Act5	4	1	0/1																																										
Act6	5	1	0/1																																										
Act7	6	1	0/1																																										
Act8	7	1	0/1																																										
Act9	8	1	0/1																																										
Act10	9	1	0/1																																										

Continues on next page

Properties	Description
Zones	<p>Here you define the configurations of the zones.</p> <p>A zone is a collection of activators with the same state, while a configuration is a setup of zones that a tool can have. A tool can have several configurations but only one at a time can be active. The figure shows a configuration example</p>  <p>xx110000084</p> <p>To add or remove a configuration, click  or .</p> <p>In the Configurations group; To set a configuration as default, right click on a configuration and select Set as Default Configuration;</p> <p>To add or remove a zone, click “Add Zone” and “Delete Zone” button.</p> <p>To include an activator into a zone, select the check box at the activator row and the zone column.</p> <p>The activators are defined at the Vacuum Activators page.</p>

Activators properties

The following table describes the settings of the activators:

Setting	Description
Name	The activator's name
Position	The center position of the activator related to the TCP. It is recommended to set the same z-value to all activators within one zone.
Orientation	The center orientation of the activator related to the TCP.
Size	The size of the activator.
Start bit	Defines the first bit field where the activator is connected to the Activators control signal.
Bit Length	The number of bit fields used for the activator.

Continues on next page

5 User interface

5.3.25 Models

Continued

Setting	Description
A/D/I	<p>Defines the Active (A), Deactivated (D), and Idle (I) states for the activator. The state for the activator is set by the values of the bits defined by the fields of the Start Bit and No. Bits. The different states:</p> <ul style="list-style-type: none">• Active state, which is set for an activator when it holds an item.• Deactivated state, which is set for an activator when it releases an item.• Idle state, which is set when no item is held by the activator. <p>The values for the different states are given in the format A/D/I, that is Active/Deactivated/Idle. To set a value, click the value of an activator and select the desired value from the drop-down combo box.</p> <p>If Bit Length is set to the value 1, the Idle state is not used since only two states can be given with one bit.</p>

Clamp







xx110000086

A Clamp function contains a clamp and a hook. They are usually independently controlled by different DI/GI signals.

Continues on next page


The editing UI of Clamp is as following:

Properties	Description
Open/Close Clamp	<p>Opening and closing of clamp can be controlled by DI or GI signals, and when the open or close state is reached, it can set DO or GO signals to certain values. Also a mechanical movement in 3D view may be included to visualize the opening and closing.</p>  <p>xx110000087</p> <p>Take the above setting for Open Clamp as example: To add/edit/remove a signal to trigger the open movement, click , , or .</p> <p>In the Control Signals (Input) group. You can specify the signal type (DI/DO/GI/GO), the signal set value, the pulse value and length. See Edit signal control on page 132 for detailed information.</p> <p>To add/edit/remove a signal to be triggered when open movement is finished, click add/edit/remove in the Status Signals (Output) group.</p> <p>See Edit signal control on page 132 for detailed information of setting signal and value.</p> <p>To add a joint movement for opening of clamp, select the corresponding joint and move the slider bar to the opened position. You can also click the slider bar and input the joint position directly.</p> <p>To edit the time that the joint takes to move to the open position, input a time value (s) in Move Duration number box.</p> <p>The above example specifies that:</p> <ul style="list-style-type: none"> When the input tool signal “giOpenClamp” goes to 1, the clamp will start to open. The open movement will take 0.2 seconds to move joint J2 to position 0. When the open movement is finished and the joint is at position 0, the output tool signal “goClampOpened” will be set to 1
Open/Close Hook	Same as Clamp

Continues on next page

5 User interface

5.3.25 Models
Continued

Properties	Description
Picking Sensor (Simulation)	<p>The picking sensor is mainly for simulation use. It defines an area (usually within the clamp tool) that will intersect with the products when robot moves to the picking position.</p> <p>In simulation, the products that intersect with this area during the closing of the clamp will be picked up by the clamp.</p> <p>Thus users need to set the position and size of this area with appropriate values so that this area will intersect with the products that are “intended” to be picked when the tool is at picking positions.</p> <div><div>Open Hook</div><div>Close Hook</div><div>Picking Sensor (Simulation)</div></div> <div><div>- Clamp Sensor (SmartComponent)</div><div>Position (Relative to TCP) (mm)</div><div>0.0000.000-210.000</div><div>Orientation (deg)</div><div>0.0000.0000.000</div><div>Size (x,y,z) (mm)</div><div>300.00050.000400.000</div><div>Pick Mode</div><div>CenterBottom</div><div>The gripper will pick the products from product center bottom as default (e.g. claw, clamp type)</div></div> <div>xx110000091</div> <p>During editing, the picking sensor area will also be shown in 3D view as a gray box:</p> <div></div> <div>xx110000092</div>

Continues on next page

Properties	Description
	<p>Pick Mode: Pick mode defines whether the tool function should pick the products from top or bottom. This affects the default position of the tool relative to the products, defined in Pick Setting.</p> <p>Currently only Center Top and Center Bottom are supported:</p> <ul style="list-style-type: none"> Center top: in default position, the center of the picking sensor area will be aligned with the center top of the product Center bottom: in default position, the center bottom of the picking sensor area will be aligned with the center bottom of the product


Claw



xx110000093

Simpler than clamp, a Claw function contains only a claw.

The editing UI of Claw is as following:


Properties	Description
Open/Close Claw	<p>Opening and closing of claw is similar to that of clamp. See Open/Close Clamp to see how to edit control signals and status signals, and joint movements.</p>  <p>xx110000094</p>

Continues on next page

5 User interface

5.3.25 Models

Continued

Properties	Description
Picking Sensor (Simulation)	<p>The picking sensor for claw is the same as that of Clamp. See Picking Sensor (Simulation) for clamp for detailed information.</p>  <p>xx110000095</p>


Search




xx110000096

A search function contains a searcher movement, and search sensor. The movement contains the opening, the loosening, and the closing of searcher. And the search sensor describes in simulation where on the tool to detect product's height (such as pallet stack).

The editing UI of Search is as following:

Properties	Description
General	<p>The search stop trigger describes which tool signal to trigger when a product is detected by search sensor, and the flank type of the signal that is triggered.</p>  <p>xx110000097</p> <p>The trigger flank type describes what kind of signal value change indicates a search stop:</p> <ul style="list-style-type: none">• Both Flanks: Trigger for any signal change• Negative Flank: Trigger when signal changes from high to low• Positive Flank: Trigger when signal change from low to high

Continues on next page



Properties	Description
Open/Loosen/Close Searcher	<p>A typical sequence of search process includes: open searcher, loosen search, wait until search sensor touches product and stop signal triggers, close searcher.</p> <p>The steps related to joint movements are described as Open Seacher, Loosen Searcher, and Close Searcher.</p>  <p>xx110000098</p> <p>The editing each movement is same as Open/Close Clamp. See Open/Close Clamp for detailed information.</p>

Continues on next page

5 User interface

5.3.25 Models

Continued

Properties	Description
Search Sensor (Simulation)	<p>The editing of search sensor is the same as that of Clamp, except that for search, Pick Mode information is not needed, since search is not used for picking.</p> <p>Note that the position of the sensor should be set carefully so that the height of the lowest position of the sensor area is the same as the height of the search TCP position. Otherwise, during simulation, the sensor SmartComponent may touch the pallet/sheet stack earlier than the TCP, and robot can not calculate the height value correctly, thus missing the product picking afterwards.</p>  <p>xx110000099</p> <p>During editing, the search sensor area will also be shown in 3D view as a gray box:</p>  <p>xx110000100</p>

Sensor



xx110000101

Continues on next page

A sensor function is a simple function to add a product sensor and triggers certain DO when a product is detected.

The editing UI of Sensor is as following:


Properties	Description
General	<div><p>A DI signal can be specified to activate the sensor, and a DO signal should be specified to be triggered when product is detected.</p><div><div>Activate Sensor (DI)</div><div>Signal<div>diStartPartCheck</div><div>1</div></div></div><div><div>Sensor Out (DO)</div><div>Signal<div>doPartChecked</div></div></div><div><div>Sensor (Simulation)</div><div>Position (Relative to TCP) (mm)<div><div>0.000</div><div>0.000</div><div>0.000</div></div></div><div><div>Orientation (deg)</div><div><div>0.000</div><div>0.000</div><div>0.000</div></div></div><div><div>Size [x,y,z] (mm)</div><div><div>10.000</div><div>10.000</div><div>20.000</div></div></div></div><div>xx110000102</div></div>

Unit mover



xx110000103

A unit mover function is a function to move some part of the tool which is not picking related. For example, a bag flatter/fixer in a claw tool is typical unit mover:




xx110000104

Continues on next page

5 User interface

5.3.25 Models
Continued


The editing UI of unit mover is as following:

Properties	Description
Open/Close Setting	<p>Opening and closing of a Unit Mover is similar to that of clamp. See Open/Close Clamp to see how to edit control signals and status signals, and joint movements.</p>  <p>xx110000105</p>

Edit signal control

A signal control describes a signal configuration that can be used to trigger certain behavior (e.g. opening a clamp) or to show certain status (e.g. clamp is totally opened). It includes the information of the signal and the value for this signal to set to.

In Signal Control interface, you can specify such a value control for a signal.



xx110000106

Continues on next page

Properties	Description
Signal	<p>To add a signal control on a new SmartComponent signal, click on the “Signal” list box to change it to input mode, and type the name for the new signal. Then choose the signal type at “Type” list box. The new signal can then be used other signal controls.</p> <p>To add a signal control on an already created signal, click on the arrow besides the “Signal” list box, and choose one. In this case you will not be able to change the signal type by the “Type” list box.</p>
Type	Choose the type of the new signal. This is disabled if an already existing signal is selected.
Set or Pulse	This group specifies the value change property of the signal for set or pulse. If the Set option button is selected, the set value is sent at Preset Time before the robot reaches a certain target. If the Pulse option button is selected, the Reset Value is sent after Pulse Length.

Tool events and scenarios

The tool events describe how the tool functions are controlled during picking and placing. It includes a list of events to control certain tool functions to open and close during different movement of picking and placing.

The tool scenarios describe which group of tool functions to use to pick different type of products. For example, the ABB Vacuum tool contains two picking tool functions: vacuum and pallet picker. When the tool is picking boxes, only vacuum is used; and when it is picking pallets, only pallet picker is used. Thus two scenarios can be created, each only including the vacuum function and the pallet picker function respectively. See [Pick setting on page 77](#) on how tool scenarios are used.

When the tool is attached to the robot, a controller I/O signal will be specified to connect to each tool I/O signal (see [Edit Tool Signals on page 166](#)). Thus during picking/places of group and pattern operation sets, the controller signal and its value will be set or waited, according to what is specified for its connected tool I/O and value, in the tool event settings.


Continues on next page

5 User interface


5.3.25 Models

Continued

You can open the Edit Tool Events interface by right clicking on the tool node from browser's Layout tab or Programming tab.



Continues on next page



xx110000107




Properties	Description
Contained Tool Functions	List of contained tool functions. Each contained tool function should have a sequence of control events.
Event Sequence	The list of events for the selected tool function, in picking and placing
Type	Set or Wait. Set means the event is to set a signal to a certain value; Wait means the event is to start waiting until a signal value equals to a specified value.
Signal Name	The signal to be used in the event
Value	The set or wait value for the signal
Preset Time	The time to preset a signal to a certain value. Only valid for Set type of event.

Continues on next page


5 User interface

5.3.25 Models

Continued

Properties	Description
Movement	<p>The movement phase (i.e. action) of a pick/place target where this event is used.</p> <p>Each pick/place target contains at least 1 Approach point, 1 pick/place point, and 1 Depart point. Depending on the approach/depart setting in operation sets, one pick/place target may contain more than 1 Approach points and 1 Depart points. (See Operation set on page 177 for detailed information on operation, target, and actions)</p> <p>Accordingly, in picking and placing, there are 6 movements defined respectively:</p> <p>Pick First Approach ->Pick Last Approach->Pick-> Pick First Depart ->Pick Last Depart</p> <p>Place First Approach ->Place Last Approach->Pick-> Place First Depart ->Place Last Depart</p> <p>First Approach means the first approach point of a pick (or place) operation.</p> <p>Last Approach means the last approach point of a pick (or place) operation. If only 1 approach point was specified originally, an extra point will be added at the same location as the last approach.</p> <p>Pick (or Place) means the actual point where pick (or place) happens.</p> <p>First Depart means the first depart point of a pick (or place) operation. If only 1 depart point was specified originally, an extra point will be added at the same location as the first depart.</p> <p>Last Depart means the last depart point of a pick (or place) operation.</p>
Add, edit, or delete an event	<p>To add/edit/remove an event, click , , or  under the event list.</p>

Continues on next page



xx110000108

Properties	Description
Scenario List	List of contained tool scenarios. A tool should at least have one tool scenario.
Pick/Place Scenario	For each scenario, two tree views will be shown for Picking and Placing, including all the movements. The tool functions that contain events for the movement will be listed under the movement node. To include a tool function into a scenario at a specific movement, select the check box before the tool function node under the movement node.

Create Feeder



xx110000109


Continues on next page

5 User interface

5.3.25 Models

Continued

The Create Feeder interface is used to create a Palletizing PowerPac compatible feeder SmartComponent model. The SmartComponent model can then be added to the robot, or saved as RobotStudio library (.rslib) file, and be imported and reused in other palletizing projects.




xx110000110

A Palletizing PowerPac compatible feeder includes properties of:

- Default feeder type: the default type that this feeder will be used.
- Hotspots of this feeder: a hotspot is a special frame attached with the feeder model that can be directly used to position a work object. A hotspot also describes how does the product will be shown up at this position.

Properties	Description
Default Type	The default type is used when this SmartComponent model is added for a robot, and a feeder is to be created. The default feeder type (i.e., InFeeder, OutFeeder, PalletFeeder, or SheetFeeder) will use the type defined here, but user can still choose to use another type. See Add feeder on page 57 for detailed information.
Hotspots	The list of hotspots contained by this feeder.
General	General information: name, position, and orientation of the hotspot frame.

Continues on next page

Properties	Description
WorkObject/Product alignment	<p>The group specifies the location of the work object and which quadrant the items are picked from or placed to. Adjust the Alignment and Rotation parameters to select a location suitable for calibration of the work object.</p> <p>Alignment: Specifies if the work object origin is located to the right or to the left of the items.</p> <p>Rotation: Specifies the orientation of the work object coordinate system.</p> <p>When you change the values for Alignment and Rotation, a dummy box and three coordinate arrows will be shown at the hotpot in 3D view, visualizing the relationship between item and work object. Note that the item's front is attached with label.</p> 

**Note**

The work object should be calibrated with its origin where items are fixed, that is along any guide and stop rails. For an infeder or other feeders used for picking, the work object calibration is especially important. If the picking location of the tool must be adjusted, then update the tool location in Pick Setting. Avoid adjusting the displacement frame or tuning the location of the feeder, since this might reduce the accuracy when items are placed. For a palletizing feeder or other feeders where products are placed, the work object calibration can be adjusted with the displacement frame or by tuning the location of the feeder to modify the place location of items.

5 User interface

5.3.26 IOPanel


5.3.26 IOPanel

Overview

IOPanel helps to monitor and set the signals used during a palletizing process. This can be used both for VC and RC. It helps to understand the problems during commission and it works as a tool for training classes. It also helps to understand the handshake between the PLC and the controller and also how to control the system using the flow and job signals.

User interface

In the **Advanced** group, click **IOPanel**. The **IOPanel** window is displayed.



xx1300002143




The **IOPanel** window has the following four tabs:

- The **Common** tab allows you to monitor the project signals, gripper signals, event message signals, default height signals, flow signals, and system signals.
- The **Infeeder** tab allows you to monitor the infeeder signals.
- The **Outfeeder** tab allows you to monitor the outfeeder signals.
- The **Stack Sheets** tab allows you to monitor the pallet and stack sheet signals.

By default, the appropriate signals are selected for each type. If required, the signal can be changed and monitored. Set the signal by clicking on the LED. The LED color changes to red. If it is a group signal then type the numeric value corresponding to the signal.

5.3.27 Change viewpoint

A viewpoint stores the location and direction of a virtual camera in the 3D environment. It stores points of interest in a station and to create camera movements during simulation.



Icon	Description
 xx110000112	To view the objects in the Top orientation.
 xx110000113	To view the objects in the Front orientation.
 xx110000114	To view the objects in the Right orientation.

5 User interface


5.3.28 Adjust position of object

5.3.28 Adjust position of object

The selected object in main 3D view can be adjusted with freehand.

Icon	Description
 xx110000115	To adjust the position of selected object in main 3D view.
 xx110000116	To adjust the orientation of selected object in main 3D view.

5.3.29 Help



xx110000117

This group is related to displaying help documentation and the basic software information.

To...	Do this
Show Help File	Click Help button, a help file with chm format will display to give detailed information about this PowerPac.
Show Basic Information	Click About button, a dialog will display to show basic information about this PowerPac, such as version number, status of license, etc.


5 User interface

5.4.1 Introduction






5.4 Layout browser

5.4.1 Introduction

The layout browser is a hierarchical display of physical items, such as robots and tools.



xx110000118

Icon	Node	Description
 xx110100119	Station	The station node
 xx110100120	Robot	The robot in the station.
 xx110000119	Tool	A tool SmartComponent in the station. This may or may not be attached to a robot
 xx110000120	Feeder	A feeder SmartComponent in the station. This may or may not be added into a robot.
 xx110100121	Part	A physical object in RobotStudio. Parts with geometric information are made up of one or more 2D or 3D entities. Parts without geometric information are empty.

5.4.2 Station

You can access the context menus for the station node in the layout browser by right-clicking the station node.

Context Menus from the Station Node

Context Menu	Description
Import Model...	Import one model into this station, which should be a library component file for RobotStudio.

5 User interface

5.4.3 Robot

5.4.3 Robot

You can access the context menus for the robot node in the layout browser by right-clicking the robot node.

Context Menus from the Robot Node

Context Menu	Description
Jump Home	Jump the robot to the home position.
Mechanism Joint Jog	Jog the robot's joint.
Set Position...	Set robot's position.
Examine	Adjust an appropriate viewpoint for the robot.
Rename	Change the robot's name.
Visible	Show or hide the robot.

5.4.4 Tool SmartComponent

You can access the context menus for the tool node in the layout browser by right-clicking the tool node.

Context Menus from the Tool Node

Context Menu	Description
Edit Tool Functions...	Edit tool functions for this tool. See Tool Functions on page 118 for detailed description
Edit Tool Events...	Edit tool events for this tool. See Tool events and scenarios on page 133 for detailed description
Joint Jog	Jog the tool's joint. Only available when a mechanism is used.
Disconnect Library	Disconnect the library
Save As Library	Save the library as rslib file
Attach to / Detach from	If the tool has not been attached to the robot, click Attach to menu and select the right robot, this tool will attach to the selected robot. If the tool has been attached to a robot, click Detach from menu, this tool will detach from the robot.
Examine	Adjust an appropriate viewpoint for the tool.
Rename	Change the tool's name.
Visible	Show or hide the tool.
Delete	Delete the tool from station.

5 User interface

5.4.5 Feeder SmartComponent

5.4.5 Feeder SmartComponent

You can access the context menus for the feeder node in the layout browser by right-clicking the feeder node.

Context Menus from the Feeder Node

Context Menu	Description
Edit Feeder Hotspots...	Edit hotspots for this feeder. See Create Feeder on page 137 for detailed description
Disconnect Library	Disconnect the library
Save As Library	
Attach to / Attached Status	If the feeder has not been attached to the robot, click Attach to menu and select the right robot, this feeder will attach to the selected robot. If the tool has been attached to a robot, which robot is attached to will display in this context menu.
Set Position...	Set feeder's position.
Examine	Adjust an appropriate viewpoint for the feeder.
Rename	Change the feeder's name.
Visible	Show or hide the feeder.
Delete	Delete the feeder from station.

5.4.6 Part

You can access the context menus for the part node in the layout browser by right-clicking the part node.

Context Menus from the Part Node

Context Menu	Description
Build into a Tool...	Build this part as a tool Smart Component, which can be used by the robot. See Create Tool on page 118 for detailed description
Build into a Feeder...	Build this part as a feeder Smart Component, which can be used by the robot. See Create Feeder on page 137 for detailed description.
Set Position...	Set part's position.
Examine	Adjust an appropriate viewpoint for the part.
Rename	Change the part's name.
Visible	Show or hide the part.
Delete	Delete the part from station.

5 User interface


5.5.1 Introduction

5.5 Programming browser







5.5.1 Introduction

The programming browser is a hierarchical display of program elements for each controller and robot.






Each virtual controller can subsequently run up to four robot nodes, here named T_ROB1.



xx110000121

Icon	Node	Description
 xx110000122	Project	The project node
 xx110000123	Controller	A controller that exists in the station
 xx110000124	Robot	A robot (motion task) that exists in the parent controller
 xx110000125	Tool	The tool used by the parent robot. It references a tool SmartComponent.
 xx110000126	Feeders	The collection of feeders for the parent robot
 xx110000127	Feeder	A feeder that is used by the robot. It references a feeder SmartComponent.

Continues on next page

Icon	Node	Description
 xx110000128	Operation Set	An Operation Set program that picks(places) from(to) the parent feeder. Depending on the type of item it handles (box, bag, pallet, or sheet), and whether it is picking or placing, the icon is different.
 xx110000129	Flows	The collection of flows for the parent robot
 xx110000130	Flow	A flow that exists for the parent robot
 xx110000131	Job (Master Operation Set)	A supported job for the parent flow. It actually references to an Operation Set of the flow's master feeder.
 xx110000132	Slave Operation Set	Reference to an Operation Set on the slave feeders that are related to the master job.

5 User interface

5.5.2 Project

5.5.2 Project

Context Menus from the Project Node

You can access the context menus for the project node in the programming browser by right-clicking the project node.


Context Menu	Description
Settings	Edit settings for the project. The following section gives you a more detailed description on Project Settings.
Rename	Change the Project's name.

Project Settings

Introduction

This dialog is shared with project, controller and robot settings. The left tree view is a hierarchical display of project elements for each controller and robot. Select the project node and its settings will display in the right three pages.

General




xx110000133

The project name and description can be edited in this page.

Continues on next page

Restart Options



xx110000134

Select which restart options should be visible on the FlexPendant when recovering after an error. All options are selected as default. To hide a restart option on the FlexPendant, clear the option's check box. See [Flow on page 197](#).

Continue Pick-Place is always available.


Continues on next page

5 User interface

5.5.2 Project

Continued

Tune Limitation



xx110000135

It is used to set the minimum and maximum limits for how much each parameter can be tuned online. For more information about how to tune the parameters online, see [Runtime operation on page 229](#).

Feeder WorkObject Group

Click **Reset Tune Value** to reset all the tuned values.

Click **Apply Tune Value** to assign the tuned values as the default values.

In the Feeder WorkObject group the limits are specified using the same unit as the parameter. The x, y, z, and z angle defines the displacement of the feeder relative to the default value. The Lower tune limits define the maximum displacement from the default values in the negative direction. The Upper tune limits define the maximum displacement from the default values in the positive direction.

Example

- Assume the default value of Z angle in the Group Operation Set Configuration window is 25 degrees. See [Group operation set on page 178](#).
- The Lower tune limit in the Tune Limitations window is set to 6 degrees. This means you can tune the z-angle to maximum 6 degrees less than the default value, that is, you can tune the Angle (z) to a minimum of 19 degrees.
- The Upper tune limit in the Tune Limitations window is set to 6 degrees. This means you can tune the z-angle to maximum 6 degrees more than the default value, that is, you can tune the Angle (z) to a maximum of 31 degrees.

Continues on next page

The following table describes the parameters of the Feeder WorkObject group

Item	Description
X	Displacement of the feeder in x-direction relative the work object.
Y	Displacement of the feeder in y-direction relative the work object.
Z	Displacement of the feeder in z-direction relative the work object.
Angle(Z)	Displacement angle of the feeder in the z-direction.

Item Group

In the Item group all limits are specified in percent (%) relative the default value, which is referred to as 100%.

Example

- Assume the default speed in the Motion Limits window is 1000 mm/s. This is referred to as 100%. See [Advanced setting for Item on page 65](#).
- The Lower tune limit in the Tune Limitations window is 10% of the default speed. Hence, you can tune the speed to a minimum of 100 mm/s.
- The Upper tune limit in the Tune Limitations window is 110% of the default speed. Hence, you can tune the speed to a maximum of 1100 mm/s.

The following table describes the parameters of the Item group:

Item	Description
Speed	Specifies maximum speed for an item.
Rot Speed	Specifies maximum orientation speed for an item.
Acc/Dec	Specifies maximum acceleration/deceleration for an item.
Pick Time	Specifies the time that the robot stays at the target position when picking an item.
Place Time	Specifies the time that the robot stays at the target position when placing an item.
Vacuum Activation Time	Specifies the time for vacuum activation.
Vacuum Deactivation Time	Specifies the time for vacuum deactivation.
Size (z)	Specifies the height of an item.

5 User interface

5.5.3.1 Controller

5.5.3 Controller

5.5.3.1 Controller

Context Menus from the Controller Node

You can access the context menus for the controller node in the programming browser by right-clicking the controller node.

Context Menu	Description
Settings	Edit settings for the controller. The following section gives you a more detailed description on Controller Settings.


Controller Settings

Introduction

This dialog is shared with project, controller and robot settings. The left tree view is a hierarchical display of project elements for each controller and robot.

Select the controller node and its settings will display in the right four pages.

General




xx110000136

Continues on next page

Item	Description
Pulse Feeder DO Signals	If selected, the Position request trigger signals and the Operation set complete signals will be pulsed instead of set by the controller. It is not recommended to use "Pulse Feeder DO Signals" since a pulse may be missed out to be detected by the PLC.
Pulse Length	Here you specify the general pulse length that will be used, if the controller pulses an output signal . The pulse length can be set in the range of 50 ms to 2000 ms.

Events



xx110000137

Item	Description
Event Signals	This group contains the signals that are used by an external equipment to report a message or error to the PickMaster process.
Source Settings	This group contains the information on which source (feeder, robot and/or robot controller) is affected by a reported error.

Event Signals Group

Item	Description
Trigger (DI)	Specifies which digital input signal will be used to trigger an event. When this signal goes high, the event will be reported to the PickMaster process. This signal must be used together with the Error Source (GI) and/or Messages (GI) signal.

Continues on next page

5 User interface

5.5.3.1 Controller

Continued

Item	Description
Error Source (GI)	A group input signal representing the source of an error. If the signal is defined it indicates where the error has occurred (feeder, robot and/or controller) when the Trigger (DI) signal is set, and thus where a flow recovery action should be performed to handle the error. For information about the source setting, see below <i>Source Settings Group</i> .
Messages (GI)	A group input signal representing an event message. If the signal is defined it specifies which message will appear on the FlexPendant when the Trigger (DI) signal is set. You define the messages in the line view of PickMaster, see Messages on page 160 .

Source Settings Group

The Source Settings group needs to be configured if the Error Source (GI) signal in the Signals group is used. See [Flow recovery on page 240](#).

Item	Description
Source	Specifies the feeder, robot and/or controller that can be affected by the reported error.
Bit	Specifies which bit of the Error Source (GI) signal to use for the specific source. One or several bits can be set when triggering an event. Value 0 indicates no action.

If the source points out a feeder, then the feeder will be set in error state when the Trigger (DI) peaks. The current state of a feeder is indicated by the FlexPendant interface, see [Viewing flow status on page 236](#). It is also indicated by the feeder I/O signal Execution state (GO), see [Feeder on page 168](#).

A feeder in error state cannot be used in any pick or place operations.

A flow can continue to operate if there are alternative feeders to operate on. If there is no alternative feeder the flow will continue to operate until the feeder in error state is needed. The RAPID execution stops if there is only one flow.

If one feeder is shared between several flows all flows will stop when the feeder goes to error state. Setting one feeder in error state can result in error state on other feeders as well. The PickMaster process automatically sets affected feeders in error state.


If you plan to use Redo last pick then we recommend that you set the place feeder in error state rather than the pick feeder. Setting the pick feeder in error state after the pick operation is completed will not stop the robot movement. In this case the robot will continue to deliver the faulty products.

Flow recovery can be used from the FlexPendant interface or the I/O interface to recover from errors.

For examples, see [Event and error reporting on page 272](#).

Continues on next page

Feeder order



xx110000138

The feeder order settings define the physical order of the feeders, that is, in which order the robot will pass the feeders when making long movements through its working range.

The feeder order settings are used to define which feeders that will be considered when planning the path height of an intermediate movement between two feeders. Also, when moving to or from the home position, the feeder order settings will affect the path height. Each feeder and the home position are given an order number. When planning an intermediate movement, the order number of the start feeder and the end feeder (where none, one or both of them may be the home position) will set the upper and lower order limits of order numbers for other feeders to be considered when planning the path height. The order numbers can be freely chosen and two feeders can have the same order.

PM_HOME is a default installed feeder with work object pm_homeWObj. The order number for this feeder should be where the home position is located.


Continues on next page

5 User interface





5.5.3.1 Controller

Continued

Messages



xx110000139

Item	Description
Max Title Length	Displays the title length. There can be maximum 60 characters in the message title.
Max Message Length	Displays the total message length. Each message can contain maximum 195 characters, including the title.
Import	Click Import to import messages from PickMaster library.
Export Selected	Click Export Selected to export a message to PickMaster library.
Export All	Click Export All to export all messages to PickMaster library.
Add	 Click  to add a new message. If the controller is connected, the first available value will be given to the new message.
Delete	 Click  to delete a message.
Category	Click the Category column and select a category in the drop-down list. The category controls how the message is presented on the FlexPendant.
Value	Click the Value column and select a value or type a value in the drop-down list. The value is mandatory.
Title	Click the Title column and type the title.

Continues on next page

Item	Description
Description	Click the Message text group and type the description for the selected message.

5 User interface

5.5.3.2 Robot

5.5.3.2 Robot

Context Menus from the Robot Node

You can access the context menus for the robot node in the programming browser by right-clicking the robot node.


Context Menu	Description
Attach Tool...	If there is no tool attached to the robot, this context menu will display. It is to add a tool to the robot. See Add tool on page 55 for detailed description.
Settings	Edit settings for the robot. The following section gives you a more detailed description on Robot Settings.
Jump Home	Jump the robot to the home position.
Set Position...	Set robot's position.
Examine	Adjust an appropriate viewpoint for the robot.
Visible	Show or hide the robot.

Continues on next page

Robot Settings

This dialog is shared with project, controller, and robot settings. The left tree view is a hierarchical display of project elements for each controller and robot.

Select the robot node and its settings will display in the right page.



xx110000140


Item	Description
Controller	The name of the controller which the robot belong to.
Robot	The name of the robot.
Speed	The speed of the robot.
Acceleration/Deceleration	The speed can be set to full or low with the right button. The acceleration/deceleration speed of the robot.
Rotation Speed	The rotation speed of the robot.
Load and Start RAPID	If you select this check box, you can press the start button on the FlexPendant and the RAPID module will be loaded to the robot controller. The check box is selected by default.
Activate PickWare Log	If you select this check box, the log files for system debug purpose are generated in the Home folder of the robot system.

Continues on next page

5 User interface

5.5.3.2 Robot

Continued

Item	Description
Add	To add a RAPID module to the project: 1 Click Add. 2 The Load RAPID dialog box appears, and you can select which RAPID module to add. 3 In the Load RAPID dialog box, click OK.
Delete	To remove a RAPID module from the project, select a module and click  .
Edit	To edit a RAPID module, select a module and click Edit.
Export	To save a module with a new name, select a module and click Export.
Browse	Select software to edit the RAPID. In default, the software is notepad.

5.5.4 Tool

Context Menus from the Tool Node

You can access the context menus for the tool node in the programming browser by right-clicking the tool node.

Context Menu	Description
Edit Tool Signals	Edit signals for this tool. See Edit Tool Signals on page 166 Error! Reference source not found. for detailed description
Edit Tool Functions...	Edit tool functions for this tool. See Tool Functions on page 118 for detailed description
Edit Tool Events...	Edit tool events for this tool. See Tool events and scenarios on page 133 for detailed description
Joint Jog	Jog the tool's joint.
Detach from	If the tool has been attached to a robot, click Detach from menu, this tool will detach from the robot. And this node will be deleted either.
Examine	Adjust an appropriate viewpoint for the tool.
Rename	Change the tool's name.
Visible	Show or hide the tool.

Continues on next page

5 User interface


5.5.4 Tool

Continued

Edit Tool Signals

In Edit Tool Signals interface, you can view and edit the I/O connection between tool and controller.

A tool SmartComponent contains a set of input and output signals. In order for simulation to run, they should be connected with certain virtual controller I/O.



xx110000141

	Description
I/O Template List	A list of I/O connection templates. An I/O template contains a mapping between tool I/O signals and controller I/O signals.
Tool I/O	The list of tool input and output signals.
Controller I/O	The list of controller input and output signals. You can click on any controller signal name to select another signal. If you have made changes, the I/O template will change to "Customized", indicating that the mapping is modified by you.
Save as Library	If the current template is "Customized", you are then able to save the current mapping into Library, for future reuse.

5.5.5 Feeders**5.5.5.1 Context Menus from the Feeders Node**

You can access the context menus for the feeders node in the programming browser by right-clicking the feeders node.

Context Menu	Description
Add Feeder...	It is to add a feeder into the station. See Add feeder on page 57 for detailed description.

5 User interface

5.5.5.2 Feeder

5.5.5.2 Feeder

Context Menus from the Feeder Node

You can access the context menus for the feeder node in the programming browser by right-clicking the feeder node.

Context Menu	Description
Edit...	Edit general settings for this feeder. See Edit feeder on page 169 for detailed description
Edit Feeder Hotspots...	Edit hotspots for this feeder. See Create Feeder on page 137 for detailed description
Add Operation Set - Group	Add a group operation set. See Operation set on page 177 for detailed description. Available when the feeder does not have any operation set or already has group operation sets.
Add Operation Set – Pattern/Stack	Add a pattern or stack operation set. See Operation set on page 177 for detailed description Available when the feeder does not have any operation set or already has pattern/stack operation sets.
Safe Targets...	Define the safe positions that the robot will pass before entering and after leaving the selected feeder. You can define several safe positions to let the robot follow a path when entering and leaving the feeder. Please note the order of the selected safe positions! The last safe position in the list is the last that the robot will pass before reaching the feeder and the first that the robot will pass when leaving the feeder. The last safe position in the list will also define the reference arm and wrist configuration of the robot when operating the feeder. See Safe targets on page 173 for detailed description
Robot Path Height...	Define some height attributes that are considered when the robot is moving to, from or over the feeder. The Robot path height settings affect the height of intermediate movements, which means the settings affect the output of the RAPID instruction PmGetPathHeight that is used by MoveInterMid in the PmUtility module. See Robot path height on page 174 for detailed description
Set WorkObject Position...	Set WorkObject position for the feeder. See Set WorkObject position on page 175 for detailed description
Examine	Adjust an appropriate viewpoint for the feeder.
Rename	Change the feeder's name.
Visible	Show or hide the feeder.
Delete	Delete the feeder from station.

Continues on next page

Edit feeder

There are two pages to edit general settings for feeder.

Edit Feeder: InFeeder1

Name: InFeeder1 Type: InFeeder

Work Object to Attach: pmlnfeeder1_WObj Signal Index: 1

Tuned Offset: (0, 0, 0) mm, (0) deg

Feeder Model: Conveyor_400 Feeder I/O: Hotspot_Right

Stop Job Timeout (ms): 5000

Buttons: [Help] [Apply] [Close]

xx110000142

Item	Description
Name	The name of the feeder.
Type	The feeder type and the following types are available: <ul style="list-style-type: none"> • Infeeder • Outfeeder • PalletFeeder • SheetFeeder
Work Object to Attach	Specify to which work object this feeder is connected. To change work object, select a work object from the drop-down box. Ten predefined work objects are listed in the work object drop-down box. The work object can be selected also in offline mode.
Signal Index	Specify which default signals that shall be suggested for the feeder when selecting Use Default I/O checkbox. It is combined with the feeder type.
Stop Job Timeout	Define the maximum time a pending position request will be active after a stop job has been started. It is used only by the slave feeders. Should be set to a time that is longer than the time it takes to generate new targets on the feeder. For example, longer than the maximum product infeed time.


Continues on next page

5 User interface

5.5.5.2 Feeder

Continued

Item	Description
Model (SmartComponent)	Select which model (SmartComponent) is the source of the feeder.
Hotspot to Attach Workobject	Select which hotspot is attached with the work object.



xx110000143

Item	Description
Use Default I/O	See Edit detailed signals for feeder on page 171 for detailed description.
Edit Signals...	Edit detailed signals for the feeder. Click this button, a dialog will popup. In this dialog, the signal configuration can be adjusted. See Edit detailed signals for feeder on page 171 for detailed description.
Simulated	See Edit detailed signals for feeder on page 171 for a detailed description.
Feeder Used as Master	See Edit detailed signals for feeder on page 171 for a detailed description.
Feeder Used as Slave	See Edit detailed signals for feeder on page 171 for a detailed description.

Continues on next page

Item	Description
Feeder Used neither as Master nor as Slave	When the feeder is not used in any job this check box is selected by default.
Signal Status	Provides the match information about signals connection between the feeder and the virtual controller. If the signal connection is not valid, the status light is red, otherwise it is green.

Edit detailed signals for feeder

xx110000144

Item	Description
Use Default I/O	When selected, PickMaster will, depending on the selection of Master or Slave, suggest default signals in Position request, Target generation, and Status. The names of the default signals will be based on the selection in feeder type and default signal index. Clear the checkbox if you want to edit the signal selection manually. See Default signals .
Feeder Used as Master	Specify this feeder is used as master. Filter that simplifies setting up a master feeder. When selected, only signals and parameters that can be used by a master feeder are enabled for updates.
Feeder Used as Slave	Specify this feeder is used as slave. Filter that simplifies setting up a slave feeder. When selected, only signals and parameters that can be used by a slave feeder are enabled for updates.
Feeder Used neither as Master nor as Slave	Specify this feeder is used neither as master nor as slave. When selected, signals and parameters are not enabled.

Continues on next page

5 User interface

5.5.5.2 Feeder

Continued

Item	Description
Position Request Group	Define the signals used by the PickMaster process when requesting new operation sets. For a detailed description of the signals, see Basic I/O interface on page 256 .
Target Generation Group	Define the signals used by a PLC to indicate that new targets are available for picking or placing. For a detailed description of the signals, see Basic I/O interface on page 256 .
Simulated	<p>When the check box is selected, the configured target generation signals are not used on the robot controller. Instead, Target generation will be directly cross connected to the output of the Position request signals.</p> <p>Use simulation on all slave feeders to test run a palletizing project without having implemented the communication with a PLC.</p> <p>Palletizing jobs can be started from the FlexPendant or the I/O interface. If only one job, that is, operation set, has been defined for a master feeder, simulation can be used to auto start the job in a continuous mode when the flow has been started.</p>
Status Group	Define different signals to monitor the status of the PickMaster process. For a detailed description of the signals, see Basic I/O interface on page 256 .
Robot Control Group	Define different signals to affect the PickMaster process. For a detailed description of the signals, see Basic I/O interface on page 256 .



Note

All the above-mentioned signals and their corresponding values are available in the Process signal view on the FlexPendant interface for PickMaster.







Note

When the Target Generation Selection signal is not set on the selected feeder, there can only be one operation set in the feeder. See the [Operation set on page 177](#) Configuration for more information.

Continues on next page

Safe targets

xx110000145


Item	Description
Add a Safe Target	Click  to add a new safe target in the list.
Delete a Safe Target	Select the safe target and click  to delete it from the list.
Reorder Safe Targets	Select the safe target and click  or  to reorder the target s in the list.
Change Move Type for a Safe Target	Select the safe position in the list and click the move type value. Select move type in the drop-down list.
Rename a Safe Target	In the Name text box, type a new name for the safe target. In default, a unique name can be generated automatically when a new safe target is created.
Select Axis Configuration	Select one axis configuration for the selected safe target in the combo box. Also click the right button, the available configurations for the safe target can be calculated automatically.
Show the Reference WorkObject	The referenced workobject of the safe target is shown in the Location page.

Continues on next page

5 User interface

5.5.5.2 Feeder

Continued

Item	Description
Edit Safe Target Position	Click in one of Position boxes, and then click the position in the graphics window to transfer the values to the Position boxes. Or type a new value in the Position boxes to specify the position of the safe target.
Edit Safe Target Orientation	Type a new value in the Orientation boxes to specify the orientation of the safe target.
Modify Safe Target Position and Orientation based on Current Robot Pose and Selected TCP	Select one available TCP in the combo box and click Read Robot Pos button, the selected safe target will be updated based on current robot pose.
Check Reach for the Safe Target	Select one safe target in the list and click  to check the robot can reach the safe target based on the selected TCP.
Edit External Axis for the Safe Target	If the robot system has external axis, in the External Axis page, the external axis value can be edited for the selected safe target.


Robot path height

The default robot path height is the expected height of the feeder after an operation set has been completed. For an outfeeder the default height is normally set to **Full height** or **Height of latest finished operation set**. For an infeeder, the default height is normally set to **Full height**, **Empty height**, or **Height of latest finished operation set** depending on how the products are fed into the working range of the robot.



xx110000149

Continues on next page

Item	Description
Height of latest finished operation set	<p>Height of latest finished operation set is the final height of the latest run operation set. The default height can be temporarily updated in runtime, for example, set to Empty after unloading a completed stack from the working range of the robot, by using predefined signals in the extended I/O interface or the RAPID function <code>PmSetDefaultHeight</code>.</p> <p> Note</p> <p>It is possible to update the default height in runtime to save cycle time without decreasing the margins for collisions, especially if the project consists of many feeders and flows.</p>
Empty height	Define the empty height of the feeder in the work object frame (mm).
Full height	Defines the full height of the feeder in the work object frame (mm). Select the Auto generate full height check box to generate the value as the maximum value between height of the configured operation sets and the safe targets defined (if any).
Safety Offset	An offset that is always added to the expected height of the feeder.

Set WorkObject position



xx110000150




To...	Do this
Change the Reference Coordinate System	Select the Reference coordinate system you want to use to position the WorkObject used for the feeder.
Edit WorkObject Position	Click in one of Position boxes, and then click the position in the graphics window to transfer the values to the Position boxes. Or type a new value in the Position boxes to specify the position of the WorkObject.

Continues on next page

5 User interface

5.5.5.2 Feeder

Continued

To...	Do this
Edit WorkObject Orientation	Type a new value in the Orientation boxes to specify the orientation of the WorkObject. Or click  and  to adjust the orientation for the WorkObject.
Check Reach for the WorkObject	Click  check whether the robot can reach the WorkObject based on the active TCP. If it is reachable, the status light will be red, otherwise its color is green.

5.5.5.3 Operation set

Overview

An operation set defines how positions are generated for a specific feeder. There are two types of operation sets, the Group Operation Set defining how to pick or place a item group and the Pallet Pattern/Stack Operation Set defining how to pick or place a complete pallet pattern.

Operation sets are created from a feeder and consequently locked to the feeder and the robot with its tool.

Operation sets defined for master feeders are equivalent with palletizing jobs that can be started from a PLC or the FlexPendant interface.

Operation sets defined for slave feeders specify how product groups are to be picked or placed.

Start the operation set configuration

Operation sets are owned by feeders and are accessed from there. For more information about how to add operation sets, see the [Feeder on page 168](#) Configuration.

You can access the context menus for the operation set node in the programming browser by right-clicking the operation set node.

Context Menus from the operation Set

Context Menu	Description
Edit...	Open the editing dialog for the operation set. See Group operation set on page 178 and Pattern/Stack operation set on page 181 for detailed information
Locate Pick Setting	Locate the referenced Pick Setting. The Pick Setting interface will be opened and the referenced pick setting will be selected. Available for group and stack operation set.
Locate Pallet Pattern	Locate the referenced pattern. The pattern interface will be opened and the referenced pallet pattern will be selected. Available for pattern operation set.
Locate Stack	Locate the referenced item stack. The Product/Pallet/Sheet interface will be opened and the referenced item stack will be selected. Available for stack operation set.
Preview Palletizing...	Preview each pick (place) target in the operation set. See Preview Palletizing on page 88 for detailed description.
Rename	Change the operation set's name.
Delete	Delete the Operation Set from the parent feeder.


Continues on next page

5 User interface


5.5.5.3 Operation set

Continued


Group operation set



xx110000153

Item	Description
Pick Setting Selection	Select the item, item group and the pick setting for that item group to use. Click  to see item count, weight, Pick setting ID, and related input signals from the online PLC when the targets have been generated.
Validation	Use Preview Palletizing function to view each target of the operation set. See Preview Palletizing on page 88 for detailed information. Use Check Reach to quickly check reach-ability of all the targets, which will be indicated by the status light.
General	<p>Pick or Place: indicates how does the robot access the item group</p> <p>Preparation Time (Simulation): if picking, it describes the time it takes for the item group to show up on the in-feeder before robot goes to pick; if placing, it describes the time it takes for the item group to be moved away on the out-feeder after robot has placed it. A robot can only continue to work on the feeder after the previous items are moved away.</p> <p>Displacement: describes the displacement between the item group and the feeder's work object. To rotate the frame 90 degrees, click the Flip button, and offsets and angle will be updated to keep chosen alignment. Or you can also click "Drag in 3D View" and use Freehand Move to move the item CAD models directly.</p>

Continues on next page


Item	Description
Approach/Depart	<p>Define the robot path to follow when picking or placing the item group. It enables configuration of Approach and Depart movements which are necessary for specific grippers like Jaw Gripper. It will be useful where the gripper has to make horizontal movements to avoid collisions to neighboring equipment/components inside the cell. It is basically an improvement to the movement of robots as well as the pick and place directions. You can pick and place the items (Bag,Box,Pallet,Sheet and so on) based on the selection of Approach and Depart.</p> <p>1 Select the Add Horizontal Approach and Add Horizontal Depart, then add the approach and depart value.</p>  <p>xx110000155</p>

Continues on next page

5 User interface

5.5.5.3 Operation set

Continued

Item	Description
Search	<p>You can enable stack search only if the operation set is Pick. To enable the stack search, select the Activate Stack Search check box.</p>  <p>xx110000156</p> <p>For more information, see Stack search on page 189.</p>


The following table describes the configuration parameters for the group operation set's stack search

Item	Description
Speed	Defines the TCP speed of the robot when it searches for the format.
Offset	Defines an offset of the distance between the expected position of the format, and the starting position of the robot's search movement. The total search offset will also include the product height of the format.
Stop height	Defines the TCP height above the work object where the robot will stop the search movement (if search stop never occurs).
Search Tool Function	Defines which search tool function to use for searching. See Tool Functions on page 118 on description on search tool function


Continues on next page

Pattern/Stack operation set

Introduction



xx110000157



Item	Description
Pattern/Stack	<p>Set the name of the Operation Set.</p> <p>Select the pallet pattern or item stack to use.</p> <p>Click  to see item count, weight, total height, and the related product selection signal from the online PLC when the targets have been generated.</p>
Validation	<p>Use Preview Palletizing function to view each target of the operation set. See Preview Palletizing on page 88 for detailed information.</p> <p>Use Check Reach to quickly check reach-ability of all the targets, which will be indicated by the status light beside the check button and before each layer. Also see Check reach on page 86 for detailed information.</p>

Continues on next page


5 User interface

5.5.5.3 Operation set

Continued

Item	Description
Pattern tab	<p>This section lists and shows information about all layers in the pallet pattern and the pick settings to be used for this pallet pattern.</p> <p>In the Pick Settings to use list box, check the ones that you want to include in the operation set. It is important to select them in such a way that it is possible to complete each layer.</p> <div> Note</div> <p>When a pick setting for an item group with more than one column is used, the algorithm to calculate the operations and target positions may be wrong. Warning information will be shown in 2D layout view and user should manually check the sequence and use Preview Palletizing to validate.</p> <p>To edit layer offsets, select the layer and edit the values. To edit the operations for a layer, double-click on the layer, or click on the layer and then click Edit. Manually edited layers operations will be specifically marked as “Manual”, otherwise, they will be marked as “Auto”. See Operation editor on page 193 for more information. The display shows how the items are grouped together in different operations. For more information, see Display information.</p>
General tab	<div></div> <p>xx110000158</p> <p>I/O Value: Set the I/O value of the Operation Set. Also see I/O interface on page 105 for detailed information.</p> <p>Pick or Place: Indicates how does the robot access the item group</p> <p>Preparation Time (Simulation): If picking, it describes the time it takes for the pattern/stack group to show up on the in-feeder before robot goes to pick; if placing, it describes the time it takes for the pattern/stack to be moved away on the out-feeder after robot has placed it. A robot can only continue to work on the feeder after the previous pattern/stack is moved away.</p> <p>Start Corner: Defines the corner of the pallet pattern where the robot should start.</p> <p>Displacement: Describes the displacement between the item group and the feeder's work object. To rotate the frame 90 degrees, click the Flip button, and offsets and angle will be updated to keep chosen alignment. Or you can also click “Drag in 3D View” and use Freehand Move to move the item CAD models directly.</p>

Continues on next page

Item	Description
Approach/Depart tab	Define the robot path to follow when picking or placing the item group. It enables configuration of Approach and Depart movements
Stack search	<p>You can select the stack search if you have clicked the Pick button in the General tab. To select the stack search, select the Activate check box. For descriptions of the configuration parameters for the stack search, see later in this section. For more information, see Stack search on page 189.</p> <p>You can enable stack search only if the operation set is Pick. To enable the stack search, select the Activate Stack Search check box.</p> 

Display information

The two-dimensional display shows how the items are grouped together in different operations. Each operation for a layer is given a number and every target within an operation is given a letter. As an example, 2A identifies the first target in the second operation and 4B identifies the second target in the fourth operation. Every item is marked with a tag notifying the operation and target number. Every target is also marked with an arrow showing the direction the robot will move in when picking or placing that target. For format operation sets there will only be one operation with one target, but for pallet patterns the items will be automatically grouped into several operations.

In 3D view, it also show an overview of the resulting operation set, including the facing of all the items.

Offsets for each layer

You can configure adjustments of the general offsets, drop offset and the search offset for individual layers in the Layers Properties section.



Note

This functionality is enabled in RobotWare 5.11. When using older RobotWare releases, then the configured layer offset values will have no effect.

Two offsets are available to adjust the general offset for each layer:

Layer offset	Used when
Item offset	Items are attached to the tool.
Tool offset	No items are attached to the tool.

Continues on next page

5 User interface

5.5.5.3 Operation set

Continued

Use positive values to approach/depart to/from the layer with increased height than defined by the general offset. Use negative values to approach/depart the layer with decreased height. There are no limitations on offsets but the product layer height defines a lower limit in runtime.



Note

If the Item offset is set to a lower negative value than the general offset, there is a risk that carried items will collide with other items already situated in the top layer. Such an offset may however be useful if space or robot reach is limited in specific layers. To avoid collisions, the layout operations may be modified to achieve an optimal pick/place order and item orientations.

Drop offset describes the offset in Z direction above original targets. Usually used for bag palletizing where bags are dropped off from a certain height above the unfinished pallet pattern.

Continues on next page

Approach and depart

In this section you define how the robot should move when accessing formats in the operation set. The movement will consist of 3 to 7 positions, depending on the selected settings. The position in which the robot actually picks or places the format is known as the target. Positions preceding the target are called approach and positions following the target are called depart.

The screenshot shows a software window titled 'Edit: Place PalletPattern11'. At the top, there's a dropdown menu for 'Pattern/Stack' set to 'PalletPattern1'. Below it is a 'Validation' section with 'Preview Palletizing...' and 'Check Reach' buttons. The 'Approach/Depart' tab is active, showing various configuration fields. 'General Offset' is set to 100 mm. There are checkboxes for 'End Approach in z Only' and 'Start Depart in z Only', both set to 100 mm. 'Add Horizontal Approach' is checked, with 'Horizontal Approach' set to 'Front' and 50 mm. 'Add Horizontal Depart' is also checked, with 'Horizontal Depart' set to 'Right' and 50 mm. Other options include 'Use Concurrency' (unchecked), 'Use Arm Config Monitoring' (checked), and 'Use SingArea' set to 'SingArea Off'. 'Apply' and 'Close' buttons are at the bottom right.

xx110000159


Item	Description
General offset	Defines the general pick and place approach/depart height. It also defines the movement safety distance to keep between robot held items and their nearby items in a pallet pattern. See the robot movement tables on the following pages for a detailed approach and depart movement description when picking and placing items.
End approach in z only	Select this check box when you want the robot to move straight down just before it reaches the target. In the Offset box, type the extra approach distance.
Start depart in z only	Select this check box when you want the robot to move straight up when it leaves the target. In the Offset box, type the extra depart distance.

Continues on next page

5 User interface

5.5.5.3 Operation set

Continued

Item	Description
Add Horizontal Approach	Select this check box when you want to add an additional approach point before the pick target, so that the tool will move to the pick target from side instead of above. In Direction selection box, select the horizontal direction; and in the Offset box, type the horizontal offset.
Add Horizontal Depart	To move the gripper horizontally away from the object of interest with the specified horizontal depart value. Directions of movements can also be configured.
Use Concurrency	When the check box is selected, the <code>\Conc</code> instruction is added to the RAPID move instruction. It allows the subsequent instructions to be executed while the robot is moving to avoid unwanted stop.
Use Arm Config Monitoring	Select this check box to enable the <code>Act.ArmConfMon</code> Boolean variable.
Use SingArea	<p>You can select one of the following 3 options for SingArea.</p> <ul style="list-style-type: none"> <code>SingArea Off</code> - The tool orientation is not allowed to differ. <code>SingArea Wrist</code> - The tool orientation is allowed to differ somewhat to avoid wrist singularity. <code>SingArea LockAx4</code> - The orientation is such that the 4th axis is locked, that is, 6 axis robot behaves like a 4 axis robot. <p>By default the SingArea is set to <code>SingArea Off</code>.</p> <div style="display: flex; align-items: center;">  <div style="margin-left: 10px;"> <p>Note</p> <p>The orientation of the tool will deviate between target positions during linear movements when approaching or departing from a work area. The orientation of the tool will never deviate during movements where products are picked or placed.</p> </div> </div>




Note






For more information about the concurrency and SingArea settings, see *Technical reference manual - RAPID Instructions, Functions and Data types*.

The following table illustrates the resulting robot movement for group operation sets using various settings. Use the following assumptions:

- General offset is offs.
- End approach in z is appr.
- Start depart in z is dept.

Type	Direction	End approach	Start depart in Z only	Position count in Z only	Movement
any	none	no	no	3	 <p>xx110000161</p>

Continues on next page

Type	Direction	End approach	Start depart in Z only	Position count in Z only	Movement
pick	any	no	no	3	 xx110000162
place	any	no	no	3	 xx110000163
pick	any	no	yes	4	 xx110000164
place	any	yes	no	4	 xx110000165
pick	any	yes	yes	5	 xx110000166

For pallet pattern operation sets the movements are generated a little bit differently. Since multiple picking or placing is supported, the height of the current item must be taken into account. The special cases, when the last item is placed as well as when the first item is picked, are handled separately. The table below illustrates the resulting movement for a pallet pattern operation set with different settings.

Use the following assumptions:

- General offset is offs.
- End approach in z is appr.
- Start depart in z is dept.
- Layer item offset is item offs.

Continues on next page

5 User interface

5.5.5.3 Operation set

Continued

- Layer tool offset is tool offs.
- Item height is h.

End approach in Z only	Start depart in Z only	Special case	Position count	Movement
no	no	no *	5	<p>xx110000167</p>
no	no	last place	4	<p>xx110000168</p>
no	no	first pick	4	<p>xx110000169</p>
yes	no	no *	6	<p>xx110000170</p>
no	yes	no *	6	<p>xx110000171</p>
yes	yes	no *	7	<p>xx110000172</p>

Continues on next page

*) Any pick or place except the first pick or the last place in the operation.



Note

If using Vacuum tool function to pick the items, the statuses of the tool zones are changed during each operation. When picking items, the zones that are configured for those items are set to activate at the target position. When placing items, the corresponding tool zones are set to deactivate at the target position and then to idle at its last depart position.

For more information about tool events, see [Tool events and scenarios on page 133](#), [Advanced setting for Item on page 65](#), and the [Pick setting on page 77](#) Advanced Events.

I/O interface

Whenever the target generation signal is set for a feeder, the positions in an operation set are sent to that feeder. If different operation sets are required in a feeder, the target generation selection signal must be set for corresponding feeder and all operation sets must be given unique I/O values. To select a specific operation set, you first set the correct I/O value for the target generation selection and then set the target generation trigger.

If the target generation selection signal is not configured for the corresponding feeder, only one operation set is allowed for the feeder. When using several operation sets in the same feeder, all operation sets must have unique I/O values. For more information about the target generation signals, see the [Edit detailed signals for feeder on page 171](#).

Stack search

The following table describes the configuration parameters for the pattern/stack operation set's stack search.

Item	Description
Activate stack search	Select the Activate check box. When stack search is activated, you can enter values in the text boxes.
Speed	Defines the TCP speed of the robot when it searches for the next layer. To set speed, in the Speed text box, type the value the robot should use when searching.
Offset	Defines an offset of the distance between the next layer and the starting position of the robot's search movement. The total search offset will also include the product height of the next layer and the current layer's layer search offset (defined in the Layers section). Total search offset = offset + product height + layer search offset. To set offset, in the Offset text box, type the offset value from the assumed to most layer where the robot should start the search procedure.
Stop height	Defines the TCP height above the work object where the robot will stop the search movement (if search stop never occurs). To set stop height, in the Stop height text box, type the offset value from the work area where the robot should stop searching.

Continues on next page

5 User interface

5.5.5.3 Operation set

Continued

Item	Description
Frequency	Defines the frequency to use stack search. The value 1 means every layer, 2 means every second layer, 3 means every third layer, and so on. Set the frequency, in the Frequency box, type or select the layer frequency for which the stack search will be done. 1 means every layer, 2 means every second layer, and so on.
Search Tool Function	Defines which search tool function to use for searching. See on Tool Functions on page 118 for details.

With the stack search function it is possible to configure runtime calibrations of the stack height for a pallet pattern or format. The function is useful to:

- Handle picking from pallet patterns where the initial number of layers varies from time to time - for example, pallet stations or slip sheet stations.
- Handle picking from pallet patterns or formats where the height of the layer/layers varies a lot from the configured height.

Search tool

With stack search activated, a special search tool is activated and a search movement is started before the first item in the first layer is picked. The search movement starts an offset from the expected height of the pallet pattern/format and continues until a sensor input indicates that the top layer is reached. If there is no indication from the sensor input, the search movement continues until a stop height is reached. At search stop, the height of the pallet pattern (or format) is updated with the current height of the search tool. Then, movement is started to the approach position of the next pick position. The search tool is deactivated before the movement to the pick position is started.

Pallet pattern

If a pallet pattern is used, picking will continue with lower layers until the pallet is empty. It is also possible to configure new searches for lower layers to improve the picking accuracy. Further it is possible to order a new search from the top of the pallet pattern at any time before the next layer is picked by using an input signal. See Redo search signal in the illustration, in section [Edit detailed signals for feeder on page 171](#).

Configuration of stack search


You do the configuration of the stack search in the Pallet Pattern Operation Set Configuration and Group Operation Set configuration dialog boxes.

Configuration of search tool

You do the configuration of the search tool function in the [Search tool on page 190](#) window.

Continues on next page

The following illustration shows an example of a stack search target sequence.



Check reach




In current version, intermediate positions are NOT checked.

Operating manual - Palletizing PowerPac
3HAC042340-001 Revision: K

5 User interface

5.5.5.3 Operation set
Continued


The result of the reachability check function is displayed in different ways

Result	Description
Status light	<p>The status light will be Gray, Green, and Red, indicating reach status of unknown, all reachable, and containing unreachable targets.</p> <p>Each layer also has a status light indicating its containing targets.</p>  <p>xx110000174</p>
3D graphical display	<p>In 3D view, if a layer contains unreachable positions, the related items with these positions are drawn with red color.</p>  <p>xx110000175</p>
Graphic display in Layer, layout display	<p>When selecting a layer containing unreachable positions from the layers list, all items containing unreachable positions will be drawn in red</p>  <p>xx110000176</p>

Continues on next page


Operation editor

When configuring a pattern operation set, it is automatically given operations, which means that which formats to use and how to access them is defined for each layer. In some situations there might be requirements not fulfilled by the generated operations. In such cases you can adjust the operations using the **Operation Editor**.



xx110000177_

A layer normally requires several operations, each using a specific format. The order of the operations is important since this is the order the robot will use to access the formats.

To...	Do this
Remove an operation	Click Remove to remove the last existing operation. <div> Note You can remove only the last operation, and new operations can only be added last. This means that to change operations, you may have to remove existing operations first.</div>
Remove all operations	Click Remove All to remove all existing operations.
Add an operation	Click New to add a new operation. The selected format to use for the operation is shown in the Display area.
Select format	Select the format to use for the new operation in the Format list.

Continues on next page

5 User interface

5.5.5.3 Operation set

Continued

To...	Do this
Define format location	Move and rotate the format using the mouse. To define that an item in the format should be placed at a specific location in the layer, make the areas overlap and double-click on the intersection. To define if an item should be placed separately or together with its neighbor, right-click and select Group item or Separate item .
Auto generate operations	Click Fill to auto generate the operations for the rest of the layer.
Show the tool	Select this check box to display the location of the tool while dragging a format in the display area.
Approach direction	To change the general approach direction of a placed target, right-click and select Approach or select the target and use the mouse wheel to change the direction. The horizontal depart direction is indicated by grey arrows.
Horizontal Approach direction	This is enabled only when the Add Horizontal Approach check box is selected in the Approach/Depart tab, and the direction is set to User Defined . If the check box is selected and the appropriate direction is chosen in this tab, then all the targets follow this direction. If the check box is not selected, the option is disabled. To change the horizontal approach direction of an individual target, right-click on the target and select Horizontal Approach direction and choose the appropriate direction. The horizontal approach direction is indicated by red arrows.
Horizontal Depart direction	This is enabled only when the Add Horizontal Depart check box is selected in the Approach/Depart tab, and the direction is set to User Defined . If the check box is selected and the appropriate direction is chosen in this tab, then all the targets follow this direction. If the check box is not selected, the option is disabled. To change the horizontal depart direction of an individual target, right-click on the target and select Horizontal Depart direction and choose the appropriate direction. The horizontal depart direction is indicated by green arrows.
Retain Manual Changes	Select this check box to retain the manual changes made to the pallet pattern even if you change the layout from the pallet pattern editor.



Note

It is recommended that you use a mouse with a wheel when working with the **Operation Editor**. The mouse wheel can be used to rotate the format and change the access directions.



Note

Layers with edited operations is not updated in the operation set configuration when input such as start corner is changed. Remove all operations and click **Fill** to make the layer un-edited.

5.5.6 Flows

5.5.6.1 Flows

Context Menus from the Flows

You can access the context menus for the flows node in the programming browser by right-clicking the flows node.

Context Menu	Description
Add Flow...	It is to add a new flow into the robot. See Add Flow on page 195 for detailed description.

Add Flow

Add Flow: Flow1*

General

Name: Flow1 I/O Value: 0

Description: Input your description here

Priority: 1 ☐ Auto Start ☒ Early Request

Status Signal: pmFlow1_goStatus

Feeder

Master Feeder: PalletFeeder1

Slave Feeder:

- ☒ OutFeeder1
- ☒ InFeeder1
- ☒ SheetFeeder1

OK Close



xx110000178

Continues on next page

5 User interface

5.5.6.1 Flows

Continued

Item	Description
Name	<p>The name of the flow as it will be shown.</p> <div> Note</div> <p>The name of the flow will also appear on the PickMaster Flex-Pendant interface.</p>
I/O Value	<p>A unique I/O value for each flow. The I/O value is used when starting, stopping, or performing recovery of a flow from a PLC instead of using the FlexPendant. The I/O value of the GI signal, pmFlow_giSelection, specifies which flow to be started/stopped/recovered.</p>
Description	<p>A brief description of the flow.</p>
Priority	<p>Set individual priority between different flows, used to decide which flow to execute if several are ready to be executed. Valid values are between 0 and 32767(0 is the highest priority).</p>
Auto Start	<p>Select Auto Start check box if the flow should start when the project starts.</p>
Early Request	<p>Select Early request check box if the next request for new products to the slave feeder (used as a slave) is made before the operation is executed on the master feeder (used as a master). If this option is not selected, the next request for new products to the slave feeders is made after the operation is executed on the master feeder.</p> <div> Note</div> <p>In practice, when palletizing and the outfeeder feeder is the master, the next operation is requested on the infeeder right after the last products are picked up from it. The consequence can be that if something fails on the way to the feeder in which to place the products, it might not be possible to redo the interrupted operation since the next product is already requested in the infeeder, which may not be the same as the interrupted one.</p>
Status Signal	<p>A unique GO status signal for each flow. The status signal is used to monitor the runtime status of the flow.</p>
Master Feeder	<p>Select the feeder on which palletizing jobs are started. Often the feeder where the pallet pattern is built is used as a master. A feeder used as a master in a flow cannot be involved in any other flows.</p>
Slave Feeders	<p>Select the feeder s used as slaves (slave feeders). These are the feeder s that will serve the master feeder with products. The slave feeder s are often pallet stacks, slipsheet stacks, and conveyor feeders. Slave feeders can be shared by multiple flows.</p>

5.5.6.2 Flow

Context Menus from the Flow

You can access the context menus for the flow node in the programming browser by right-clicking the flow node.

Context Menu	Description
Edit...	Edit the selected flow configuration. See Add Flow on page 195 for detailed description.
Add Job...	Starts the Add Job wizard. See Add job on page 81 for detailed description.
Locate Master Feeder	Locate the master feeder of this flow. The feeder node will be selected in the Programming browser.
Rename	Change the flow's name.
Delete	Delete the flow from the robot.

5 User interface

5.5.7 Job

5.5.7 Job

Context Menus from the Job

You can access the context menus for the job node in the programming browser by right-clicking the job node.

Context Menu	Description
Locate Original Operation set	Locate the referenced operation set node in Programming browser.
Simulate Job	Starts simulation but only running the selected job.
Delete	Delete the referenced operation set of the master feeder.

6 RAPID program

6.1 Introduction

Structure of this chapter

This chapter describes the RAPID program module templates and system modules. Program examples with detailed descriptions are also included. Windows and other parts of the user interface are described with regard to their content and how they are accessed.

6 RAPID program

6.2.1 Relationship between RAPID execution and PickMaster project

6.2 Overview

6.2.1 Relationship between RAPID execution and PickMaster project

Overview

The RAPID program templates for a robot executes a pick-and-place cycle for one of the configured flows in every loop. The selection of flow is made in priority order among the flows which currently are ready to execute, that is, having targets generated for the next operation on both the infeeders and the outfeeder. The robot movements and the I/O events on the infeeders and outfeeder are performed according to the configured operation sets and formats.

Intermediate positions

The RAPID program templates includes functionality to generate safe intermediate positions for the movements between infeeders, outfeeders and the home position.

Operation, target, action, event and product

Introduction

To describe all movements in an Operation Set, their properties are divided into Operations, Targets and Actions, which are retrieved by the instructions `PmGetOperation`, `PmGetTarget` and `PmGetTgtAction`.

Operation

Everything that is done by the robot in one visit to work area. This includes multi-pick or multi-place of several products.

One Operation contains one or more Targets.

For details, see [pm_operationdata - PickMaster operation data on page 348](#).

Target

The final position of every pick or place of one or more products. Also contains the work object and tool used for the whole path to and from the target positions.

One Target contains one or more Actions and product data.

For details, see [pm_targetdata - PickMaster target data on page 362](#).

Action

One path segment on the way to and from a target. Every action is realized as a move instruction (`TriggL/MoveL`) in RAPID.

One Action contains one or more Events.

For details, see [pm_actiondata - PickMaster action data on page 333](#).

Event

An event that occurs on the path. It can be a change of a signal value or an acknowledgement that a certain task has been performed and is realized through trigg data using `TriggL` in RAPID.

Continues on next page


6.2.1 Relationship between RAPID execution and PickMaster project *Continued*

Product

One or more Product(s) that is/are handled (picked/placed) by the robot at each Target.

Illustration

A typical place operation of two products at two different angles will be realized as:



xx0600003002

A	Operation
B	Targets
C	Actions
D	Event (in this case <i>Turn off the vacuum</i>)
E	Products
F	To next InterMid position

6.2.2 RAPID modules overview

Overview

To run a PickMaster project you need RAPID program modules and system modules, which are described in this section.

RAPID template modules

The PickMaster installation includes the following two RAPID template modules:

- `PmMain`, which is a program module that contains basic code to execute the operations in different work areas.
- `PmUtility`, which is a program module that contains home positions and intermediate positions.

The RobotWare option **Prepared for PickMaster**, together with the sub-option *PickMaster 5*, includes the following two RAPID template modules:

- `PmProjMgr`, which is a program module that contains basic code to execute the commands from PickMaster I/O interface.
- `PmProjServer`, which is a program module that contains basic code to execute the commands from PickMaster I/O interface, executed in a semi-static RAPID task.

System modules

The RobotWare option *Prepared for PickMaster*, together with the sub-option *PickMaster 5*, includes the following three installed system modules:

- `pmrcUser`, which is a system module that contains tool and work object declarations and traps for checking I/O values.
- `pmrcSys`, which is a system module that contains open non-view procedures mainly used to set all modal data used in the moves.
- `pmrcBase`, which is a system module that contains encrypted non-view procedures and variables used in the process.

6.3 Program module templates

6.3.1 PmMain module

Overview

This section describes the routines and variables in the *PmMain* module. The module contains the main procedure for the PickMaster RAPID execution, and it is where the program starts the execution.

This section describes the following procedures:

- Main
- OperateSequence
- Operate

Procedure Main

Usage

This is the main procedure of the template and where the execution starts.

Description

The routine is re-executed for every new pick and place cycle. The error handler is used to recover an error when running a pick and place cycle including a stack search on the master work area.

To recover `PM_ERR_JOB_EMPTY`, follow these directions:

- 1 Move back the robot in the negative search direction.
- 2 Eliminate the cause of the error, for example, fill up with new pallets.
- 3 The position request DO signal is set on the master work area after an empty stack is detected.
Generate a new job on the master work area.
- 4 Recover the error in the error handler using `RETRY`. As a result the robot will start the new job and a new pick and place cycle is started.

Program code

```
PROC Main()
  IF FirstMainLoop THEN
    MoveHomePos;
    FirstMainLoop:=FALSE;
  ENDIF
  PmWaitProjStart;
  OperateSequence;
  ERROR
  IF ERRNO = PM_ERR_JOB_EMPTY THEN
    RETRY;
  ENDIF
ENDPROC
```

Related information

Main routine in *Technical reference manual - RAPID kernel*.

Continues on next page

6 RAPID program

6.3.1 PmMain module

Continued

Procedure OperateSequence on page 204.

PmWaitProjStart - Wait for any active project on page 312.

PmGetWaByWobj - Get a reference to a work area using a work object data on page 296.

Procedure OperateSequence

Usage

This routine performs one cycle sequence.

Description

OperateSequence executes one cycle beginning with fetching a flow that is ready to be executed. Then the robot operates first on the infeeders and then on the outfeeder.

The error handler is used to handle some errors when running an operation including a stack search.

Error code	Description
PM_ERR_PALLET_REDUCED	The detected stack height was lower than expected. The error is recovered by fetching next operation using RETRY.
PM_ERR_PALLET_EMPTY	The detected stack height was zero on a slave work area.
PM_ERR_JOB_EMPTY	The detected stack height was zero on a master work area. The error is raised and recovered in the Main routine.

To recover PM_ERR_PALLET_EMPTY:

- 1 Move back the robot in the negative search direction.
- 2 Eliminate the cause of the error, for example, fill up with new pallets.
- 3 The position request DO signal is set after an empty stack is detected. Generate a new stack by setting the target generation signals according to the position request.
- 4 Set variable MultiOperation to TRUE to avoid an intermediate movement before starting a new search.
- 5 Recover the error in the error handler using RETRY. As a result the robot will search the new stack from the top.

Program code

```
PROC OperateSequence()  
PmGetFlow waInFeeder,waOutFeeder;  
Operate waInFeeder;  
Operate waOutFeeder;  
ERROR  
TEST ERRNO  
CASE PM_ERR_PALLET_REDUCED:  
! Number of remaining layers on pallet was updated after stack  
  search.  
! Operate the same work area again to access the new current layer.  
MultiOperation:=TRUE;  
RETRY;  
CASE PM_ERR_PALLET_EMPTY:
```

Continues on next page

```

! The pallet stack was found empty during stack search.
MultiOperation:=TRUE;
RETRY;
CASE PM_ERR_JOB_EMPTY:
! The pallet stack was found empty during stack search on master.
MultiOperation:=FALSE;
RAISE;
ENDTEST
ENDPROC

```

Related information

Procedure Operate on page 205.

Procedure Operate

Usage

This procedure is used to execute an operation.

Description

The procedure loops through all targets in an operation and through all actions in every target. It calls the `PmCalcArmConf`, which helps setting the arm configuration on every target. Before the very first target in the operation is executed, the robot will move to an intermediate position.

The default error handler handles raise errors from `PmSearchAdjust` when running stack search. The errors are raised to the calling routine, `OperateSequence`.

Arguments

WorkArea

Datatype: pm_wadescr

Contains a reference to a work area.

Program code

```

PROC Operate(VAR pm_wadescr WorkArea)
VAR pm_operationdata Op;
VAR pm_targetdata Tgt;
VAR pm_actiondata Act;
VAR bool FirstTgtInOp:=TRUE;
PmGetOperation WorkArea, Op;
WHILE PmGetTarget(WorkArea \OpHandle:=Op.OpHandle, Tgt) DO
  WHILE PmGetTgtAction(WorkArea, Tgt.TargetHandle, Act) DO
    PmCalcArmConf Act.RobTgt,Tgt.TargetTool,Tgt.TargetWobj
      \cf6\MaxAngle:=MaxToolAngle\MinAngle:=
      MinToolAngle\SingAreaType:=Act.SingAreaType;
    IF FirstTgtInOp AND (NOT MultiOperation)THEN
      MoveInterMid WorkArea,Tgt,Act,PmSafetyOffsetZ
      \MaxAngle:=MaxToolAngle\MinAngle:=MinToolAngle;
    ENDIF
    DoAction WorkArea,Tgt,Act;
    SetLastPos WorkArea,Tgt,Act;
  ENDWHILE
ENDWHILE

```

Continues on next page

6 RAPID program

6.3.1 PmMain module

Continued

```
ENDWHILE
MultiOperation:=FALSE;
ERROR
TEST ERRNO
CASE PM_ERR_PALLET_REDUCED:
RAISE;
CASE PM_ERR_PALLET_EMPTY:
RAISE;
ENDTEST
ENDPROC
```

Related information

[Procedure *PmDoAction* on page 224](#)

[Procedure *SetLastPos* on page 209.](#)

[Procedure *MoveInterMid* on page 210.](#)

[pm_wadescr - *PickMaster* work area reference on page 366.](#)

[pm_operationdata - *PickMaster* operation data on page 348.](#)

[pm_targetdata - *PickMaster* target data on page 362.](#)

[pm_actiondata - *PickMaster* action data on page 333.](#)

[PmGetOperation - Get operation from a work area on page 292.](#)

[PmCalcArmConf - Calculates the arm configuration on page 284.](#)

[PmGetTarget - Get target on page 324.](#)

[PmGetTgtAction - Get target action on page 326.](#)

[PmSearchAdjust - Adjust number of remaining layers on page 299](#)

Variables **waInFeeder1** and **waOutFeeder1**

Usage

The variables are used as work area descriptors for one infeeders and one outfeeder.

Description

The descriptors are handled to access the work areas when retrieving operations, targets and actions.

Program code

```
VAR pm_wadescr waInFeeder1;
VAR pm_wadescr waOutFeeder1;
PmGetFlow waInFeeder, waOutFeeder;
Operate waInFeeder1;
Operate waOutFeeder1;
```

Related information

[pm_wadescr - *PickMaster* work area reference on page 366.](#)

Constants **MaxToolAngle** and **MinToolAngle**

Usage

The constants are used to set the maximum and minimum allowed angles for the tool.

Continues on next page

Description

The angle limitation is used to set the maximum and minimum angle on the tool axis 6. This may be changed because of the limitations in hoses and wires.

Program code

```
PmCalcArmConf Tgt.RobTgtPoint, Tgt.TargetTool, Tgt.TargetWobj \cf6
               \MaxAngle:=MaxToolAngle \MinAngle:=MinToolAngle
               \SingAreaType:=Act.SingAreaType;
```

Related information

[*pm_wadescr - PickMaster work area reference on page 366.*](#)

[*PmCalcArmConf - Calculates the arm configuration on page 284.*](#)

6 RAPID program

6.3.2 PmUtility module

6.3.2 PmUtility module

Overview

This section describes the routines and variables in the *PmUtility* module. The module contains support for the home and intermediate position.

Procedure MoveHomePos

Usage

This procedure is used to move the robot to the home position.

Description

This routine uses `MoveInterMid` to move the robot to a well-defined home position with a safe path height when passing intermediate work areas on the way. The routine will wait for the project to be started before the movement is executed. The default installed work area `PM_HOME` is used as the work area to go to. Finally, the home position is set as the last work area, thus making it the starting point for the next intermediate movement which also will get a safe path height.

Program code

```
PROC MoveHomePos()  
  CONST num RetractDist:=50;  
  VAR pm_targetdata Tgt;  
  VAR pm_actiondata Act;  
  VAR pm_wadescr HomeWorkArea;  
  ! Get the weight from current tool and frame from tool0  
  PmLastTool:=CTool();  
  PmLastTool.tframe:=tool0.tframe;  
  PmLastWobj:=CWobj();  
  PmLastRobTgt:=CRobT(\Tool:=PmLastTool\Wobj:=PmLastWobj);  
  Act.Speed:=v500;  
  Act.Accel.AccLim:=FALSE;  
  Act.Accel.AccMax:=100;  
  Act.Accel.DecelLim:=FALSE;  
  Act.Accel.DecelMax:=100;  
  Act.Accel.Acc:=100;  
  Act.Accel.Ramp:=100;  
  Act.RobTgt:=CalcRobT(HomePos,tool0);  
  Tgt.TargetTool:=PmLastTool;  
  Tgt.TargetWobj:=pm_home_Wobj;  
  PmLastRobTgt.trans.z:=PmLastRobTgt.trans.z+RetractDist;  
  MoveLPmLastRobTgt,Act.Speed,fine,PmLastTool\Wobj:=PmLastWobj;  
  PmWaitProjStart;  
  PmGetWaByWobj pm_home_Wobj,HomeWorkArea;  
  MoveInterMid HomeWorkArea,Tgt,Act, PmSafetyHeight\MoveToEndPoint;  
  PmLastRobTgt:=Act.RobTgt;  
  PmLastWobj:=Tgt.TargetWobj;  
  PmLastTool:=Tgt.TargetTool;  
  PmSetLastWa HomeWorkArea;
```

Continues on next page

ENDPROC

Related information

[PmWaitProjStart](#) - Wait for any active project on page 312.

[PmGetWaByWobj](#) - Get a reference to a work area using a work object data on page 296.

[PmSetLastWa](#) - Set last used work area on page 301.

Procedure SetLastPos

Usage

This procedure is used to store the last position, tool, work object, and work area.

Description

The stored position, tool, work object, and work area are used when calculating the intermediate position.

Arguments

WorkArea

Datatype: pm_wadescr

Last work area that was used.

Tgt

Datatype: pm_targetdata

Last target data that was used.

Act

Datatype: pm_actiondata

Last action data that was used.

Program code

```
PROC SetLastPos(VAR pm_wadescr WorkArea, VAR pm_targetdata Tgt,
  VAR pm_actiondata Act)
  VAR robtarget temp;
  temp:=LastRobTgt;
  LastRobTgt:=Act.RobTgt;
  LastWobj:=Tgt.TargetWobj;
  LastTool:=Tgt.TargetTool;
  PmSetLastWa WorkArea;
  IF Act.ArmConfMon = FALSE THEN
    LastRobTgt.robconf:=temp.robconf;
  ENDIF
ENDPROC
```

Related information

[pm_actiondata](#) - PickMaster action data on page 333.

[pm_targetdata](#) - PickMaster target data on page 362.

[pm_wadescr](#) - PickMaster work area reference on page 366.

[PmSetLastWa](#) - Set last used work area on page 301.

Continues on next page

6 RAPID program

6.3.2 PmUtility module

Continued

Procedure MoveInterMid

Usage

This procedure is used to move the robot from a starting point (for example another work area or the home position) towards a new operation on the next work area with a safe path height when passing intermediate work areas on the way from the starting point.

Description

This procedure uses the last stored position (from the `SetLastPos` procedure) and a new operation on the next work area to calculate three consecutive intermediate positions by using the `PmCalcIntermid` routine. `PmGetPathHeight` is used to find the minimum height for a safe travel towards the work area.

Arguments

WorkArea

Datatype: pm_wadescr

Work area to go to.

Tgt

Datatype: pm_targetdata

The next target to go to.

Act

Datatype: pm_actiondata

The next action to perform.

SafetyOffsetZ

Datatype: num

An additional safety offset that is added to the minimum path height.

MaxAngle

Datatype: num

The maximum allowed tool angle.

MinAngle

Datatype: num

The minimum allowed tool angle.

MoveToEndPoint

Datatype: switch

Finish with zone or fine point.

Program code

```
PROC MoveInterMid(VAR pm_wadescr WorkArea, VAR pm_targetdata Tgt,  
  VAR pm_actiondata Act,num SafetyOffsetZ,\num MaxAngle,\num  
  MinAngle,\switch MoveToEndPoint)  
CONST num IntermidPart1:=0.1;  
CONST num IntermidPart2:=0.5;  
CONST num IntermidPart3:=0.9;  
VAR robtarget InterMid1;
```

Continues on next page

```

VAR robtarget InterMid2;
VAR robtarget InterMid3;
VAR jointtarget FromJointTgt;
VAR jointtarget ToJointTgt;
VAR robtarget FromRobTgt;
VAR robtarget ToRobTgt;
VAR num MinZ;
VAR pm_wadescr LastWorkArea;

PmGetLastWa LastWorkArea;

! Calculate MinZ. The z value of the tool and product is not
! considered in the calculation of min z in PmCalcIntermid.
IF Tgt.NumOfAppProds=0 THEN
! MinZ without product in tool
MinZ:=PmGetPathHeight(LastWorkArea,WorkArea\UseSafePosition)+
Tgt.GripLenEmptyZ+SafetyOffsetZ;
ELSE
! MinZ with product in tool
MinZ:=PmGetPathHeight(LastWorkArea,WorkArea\UseSafePosition)+
Tgt.GripLenLoadedZ+SafetyOffsetZ;
ENDIF

! Check z value also for the start and end target.
! Use tool and workobject from target tool.
TempTool:=Tgt.TargetTool;
TempWobj:=Tgt.TargetWobj;
! Set start and end target values.
FromJointTgt:=CalcJointT(PmLastRobTgt,PmLastTool\Wobj:=PmLastWobj);
ToJointTgt:=CalcJointT(Act.RobTgt,TempTool\Wobj:=TempWobj);
FromRobTgt:=CalcRobT(FromJointTgt,tool0);
ToRobTgt:=CalcRobT(ToJointTgt,tool0);
! Compare z value for start and end targets, set a new higher value
! for z if needed.
IF (FromRobTgt.trans.z<ToRobTgt.trans.z) AND
(MinZ<ToRobTgt.trans.z) THEN
MinZ:=ToRobTgt.trans.z;
ELSEIF (ToRobTgt.trans.z<FromRobTgt.trans.z) AND
(MinZ<FromRobTgt.trans.z) THEN
MinZ:=FromRobTgt.trans.z;
ENDIF
ConfJ\On;

! Use the frame from tool0 and the load from target tool
TempTool:=Tgt.TargetTool;
TempTool.tframe:=tool0.tframe;

! Set Acceleration
PathAccLim Act.Accel.AccLim\AccMax:=Act.Accel.AccMax,
Act.Accel.DecelLim\DecelMax:=Act.Accel.DecelMax;
AccSet Act.Accel.Acc, Act.Accel.Ramp;

```

Continues on next page

6 RAPID program

6.3.2 PmUtility module

Continued

```
! Using PmDoMove3 instead of MoveJ.
! PmDoMove3 will automatically avoid using too many consecutive
  concurrent (\Conc) movements.
! Travel distance: 10%
InterMid1:=PmCalcIntermid(PmLastRobTgt,PmLastTool,PmLastWobj,
  Act.RobTgt,Tgt.TargetTool,Tgt.TargetWobj,IntermidPart1\
  MaxAngle?MaxAngle\MinAngle?MinAngle\AngleLimAx6\
  MinZ:=MinZ\FromWa:=LastWorkArea\ToWa:=WorkArea);
PmDoMove3
  PM_MOVE_JOINT\Conc,InterMid1,Act.Speed,z200,TempTool,wobj0;

! Calculate intermediate targets two and three
InterMid2:=PmCalcIntermid(PmLastRobTgt,PmLastTool,
  PmLastWobj,Act.RobTgt,Tgt.TargetTool,Tgt.TargetWobj,
  IntermidPart2\MaxAngle?MaxAngle\MinAngle?MinAngle\
  AngleLimAx6\MinZ:=MinZ\FromWa:=LastWorkArea\ToWa:=WorkArea);
InterMid3:=PmCalcIntermid(PmLastRobTgt,PmLastTool,
  PmLastWobj,Act.RobTgt,Tgt.TargetTool,Tgt.TargetWobj,
  IntermidPart3\MaxAngle?MaxAngle\MinAngle?MinAngle\
  AngleLimAx6\MinZ:=MinZ\FromWa:=LastWorkArea\ToWa:=WorkArea);

! Travel distance: 50%
PmDoMove3
  PM_MOVE_JOINT\Conc,InterMid2,Act.Speed,z200,TempTool,wobj0;

! Travel distance: 90%
IF Present(MoveToEndPoint) THEN
PmDoMove3
  PM_MOVE_JOINT\Conc,Act.RobTgt,Act.Speed,fine,TempTool,wobj0;
ELSE
PmDoMove3
  PM_MOVE_JOINT\Conc,InterMid3,Act.Speed,z200,TempTool,wobj0;
ENDIF
ENDPROC
```

Related information

[*pm_actiondata - PickMaster action data on page 333.*](#)

[*pm_targetdata - PickMaster target data on page 362.*](#)

[*pm_wadescr - PickMaster work area reference on page 366.*](#)

[*PmGetLastWa - Get last used work area on page 291.*](#)

[*PmGetPathHeight - Get a safe path height for an intermediate movement on page 319.*](#)

[*PmCalcArmConf - Calculates the arm configuration on page 284.*](#)

Variable HomePos

Usage

The variable is used to set the home position of the robot.

Continues on next page

Description

The home position must be modified for custom purposes.

Program code

```
LOCAL PERS jointtarget  
    HomePos:=[[0,0,0,0,90,0],[9E+09,9E+09,9E+09,9E+09,9E+09,9E+09]];  
    ...  
MoveAbsJ HomePos,HomeSpeed,fine,TempTool;
```

Related information

Technical reference manual - RAPID Instructions, Functions and Data types, section robtargt - Position data.

6 RAPID program

6.3.3 PmProjMgr module

6.3.3 PmProjMgr module

Overview

The `PmProjMgr` module can be used if needed. It is prepared to be used in PickMaster I/O interface for starting a project and loading the modules needed for the main palletizing loop. The I/O signals used in this module are the same as in the configuration that comes with the installation of PickMaster. This module is compatible with the modules `PmMain` and `PmUtility`.

This section describes:

- Procedure `Main`
- Trap `TrapProjectStopped`

Procedure `Main`

This section describes the main routine in the *PmProjMgr* module.

Usage

This is where the program starts the execution if the PickMaster I/O interface is used.

The error handler is simple but it is prepared so it can easily be complemented with more sophisticated error handling depending on your needs.

Description

`PmProjMgr` executes the following:

- Setting up a TRAP that supervises the stop project signal. The RAPID execution is interrupted and continues from `Main`.
- Waiting for project start signal.
- Reading project selection signal. The mapping between project and its signal value must have been transferred.
- Starting selected project.
- Setting current project signal to the value of the selected project.
- Loading the modules in the project. The modules are only loaded if it is specified in the configuration and if they are not already loaded.
- Executing the main loop until the project is stopped. The main routine that is called is the same as if the project is started without the I/O interface.

Program code

```
PROC main()  
  VAR pm_projectinfo ProjInfo;  
  IF FirstProjMgrLoop THEN  
    FirstProjMgrLoop:=FALSE;  
    ! Project is stopping  
    IDelete pmIntProjectStopping;  
    CONNECT pmIntProjectStopping WITH TrapProjectStopped;  
    ISignalDI\SingleSafe,pmProject_diStop,1, pmIntProjectStopping;  
  ENDIF  
  ! Activate the main loop  
  StartLoadRun:=TRUE;
```

Continues on next page

```

IF PM_PROJECT_STATUS=PM_PROJECT_STOPPED OR
   PM_PROJECT_STATUS=PM_PROJECT_STOPPING OR
   PM_PROJECT_STATUS=PM_PROJECT_ERROR THEN
  IF PM_PROJECT_STATUS=PM_PROJECT_STOPPING THEN
    WaitUntil PM_PROJECT_STATUS=PM_PROJECT_STOPPED OR
      PM_PROJECT_STATUS=PM_PROJECT_ERROR;
  ENDIF
  ! Wait for start project order from PLC
  WaitDI pmProject_diStart,1;
  ! Check which project to be started
  ProjectSelection:=pmProject_giSelection;
  ! Get info from select project
  PmGetProjectInfo ProjectSelection,ProjInfo;
  ProjectInfo:=ProjInfo;
  ! Start the selected project
  IF StartLoadRun THEN
    WaitTestAndSet ProjectStart;
    IF PM_PROJECT_STATUS<>PM_PROJECT_RUNNING THEN
      PmStartProj ProjectInfo.Name\Signal:=pmProject_goStatus;
    ENDIF
    ProjectStart:=FALSE;
    SetGO pmProject_goCurrent, ProjectSelection;
  ENDIF
ELSE ! STARTING OR RUNNING
  ! Wait for project to be running
  PmWaitProjStart;
ENDIF
! Load all program modules for the task
IF StartLoadRun THEN
  LoadAllModulesInTask ProjectInfo;
ENDIF
WHILE StartLoadRun DO
  ! Execute the main routine in the selected project
  %"PmMain:Main"%;
  IF PM_PROJECT_STATUS=PM_PROJECT_STOPPED OR
     PM_PROJECT_STATUS=PM_PROJECT_STOPPING OR
     PM_PROJECT_STATUS=PM_PROJECT_ERROR THEN
    StartLoadRun:=FALSE;
  ENDIF
ENDWHILE
ERROR
IF ERRNO=PM_ERR_NO_TASK THEN
  ! ProjectInfo has no task configured for current task
  StartLoadRun:=FALSE;
ELSEIF ERRNO=PM_ERR_PROJ_NOT_FOUND THEN
  ! There is no project mapped to the selection value
  StartLoadRun:=FALSE;
  WaitDI pmProject_diStart,0;
  TRYNEXT;
ELSEIF ERRNO=ERR_REFUNKPRC THEN
  ! There is no main routine in the loaded modules

```

Continues on next page

6 RAPID program

6.3.3 PmProjMgr module

Continued

```
        StartLoadRun:=FALSE;  
    ENDIF  
ENDPROC
```

Related information

Main routine in *Technical reference manual - RAPID kernel*.

Late binding in *Technical reference manual - RAPID kernel*.

[PmWaitProjStart - Wait for any active project on page 312.](#)

[PmStartProj - Start a PickMaster project on page 308.](#)

Trap TrapProjectStopped

This section describes the trap that is called when the project stopped signal is pulsed.

Usage

The trap will prevent that RAPID execution continues after an ordered stop of project. The execution continues at main but the loaded modules are not unloaded. Starting a new project will fail to load the new modules. This trap is not executed if the recommended stop sequence is followed.

Description

TrapProjectStoped executes the following:

- Stopping robot movement.
- Clearing the robot path.
- Resetting stop move state.
- Continuing execution from main.

Program code

```
TRAP TrapProjectStopped  
    StopMove\Quick;  
    ClearPath;  
    StartMove;  
    FirstProjMgrLoop:=TRUE;  
    WaitTime 2;  
    ExitCycle;  
ENDTRAP
```

Related information

Technical reference manual - RAPID kernel.

6.3.4 PmProjServer module

Overview

The *PmProjServer* module is used in the semi-static RAPID task `PM_PROJ_SUPERV`. It is prepared to be used in PickMaster I/O interface for starting and stopping flows. The I/O signals used in this module are the same as in the configuration that comes with the installation of PickMaster.

The I/O signals are mapped to alias signals to prevent errors if the signals are not configured in the controller. A warning is generated in the error log at each restart of the controller if the signals are not found.

Procedure Main

This section describes the main routine in the *PmProjServer* module.

Usage

This is where the program starts the execution.

Description

Main routine executes the following:

- Connecting all alias signals with the configured signals.
- Waiting for a project to start.
- Connecting traps to project stop, flow start, and flow stop traps.
- Waiting for the project to stop.
- Disconnecting all traps.

Program code

```
PROC main()
  VAR bool SignalsExist:=TRUE;
  ! Connect all alias signals with the configured signals
  SignalsExist:=ConnectAliasSignals();
  WHILE SignalsExist=FALSE DO
    ! Loop forever
    WaitTime 1000;
  ENDWHILE
  WHILE TRUE DO
    ! Wait for project to be running.
    PmWaitProjStart;
    ! Connect all traps with its interrupts
    ConnectTraps;
    ! Wait for stop project order
    WaitUntil PM_PROJECT_STATUS=PM_PROJECT_STOPPED;
    SetGO alias_goCurrentProject, 0;
    ! Disconnect all traps from its interrupts
    DeleteTraps;
  ENDWHILE
ENDPROC
```

Continues on next page

6 RAPID program

6.3.4 PmProjServer module

Continued

Trap TrapSetRecoverAction

This section describes the trap that executes when the set recover action signal has been pulsed.

Description

Before a flow that is in error state can be started a recover action has to be set. If using the I/O interface a flow, work area, and a recover action must have been set before the set recover action is pulsed. An event log messages is generated with information about conditions for a successful flow restart.

Program code

```
TRAP TrapSetRecoverAction
  VAR pm_flowinfo FlowInfo;
  VAR num FlowSelection;
  VAR pm_wainfo WaInfo;
  VAR num RecoverAction;
  VAR num WaSelection;
  VAR num EvtId;
  VAR errstr Arg1;
  VAR errstr Arg2;
  VAR errstr Arg3;
  VAR errstr Arg4;
  VAR bool UseMasterWa:=FALSE;
  FlowSelection:=alias_giSelectionFlow;
  RecoverAction:=alias_giRecoverAction;
  WaSelection:=alias_giWaRecoverSelection;
  ! Get info from selected flow
  PmGetFlowInfo FlowSelection,FlowInfo;
  IF RecoverAction=PM_RECOVER_REDO_LAST_PICK THEN
    ! Set recover action
    PmSetRecoverAction FlowInfo.Name,RecoverAction\EventId:=EvtId
      \Argument1:=Arg1\Argument2:=Arg2\Argument3:=Arg3
      \Argument4:=Arg4;
  ELSE
    ! Get info from selected Work Area
    PmGetWaInfo WaSelection,WaInfo;
    IF UseMasterWa = TRUE THEN
      ! Set recover action - If no workarea, use the master workarea
      for the flow
      PmSetRecoverAction FlowInfo.Name\Workarea:=FlowInfo.MasterWa,
        RecoverAction\EventId:=EvtId
        \Argument1:=Arg1\Argument2:=Arg2\Argument3:=Arg3\Argument4:=Arg4;
      UseMasterWa:=FALSE;
    ELSE
      ! Set recover action
      PmSetRecoverAction
        FlowInfo.Name\Workarea:=WaInfo.Workarea,RecoverAction
        \EventId:=EvtId\Argument1:=Arg1\Argument2:=Arg2
        \Argument3:=Arg3\Argument4:=Arg4;
    ENDIF
  ENDIF
```

Continues on next page

```

IF (EvtId<2398) AND (EvtId>2392) THEN
    PmErrorLog EvtId,FlowInfo.Name,Arg1,Arg2,Arg3,Arg4
    \EventType:=TYPE_WARN;
ENDIF
ERROR
    ! Continue supervision on recoverable errors
IF ERRNO=PM_ERR_FLOW_NOT_FOUND THEN
    IF RecoverAction = PM_RECOVER_CONTINUE_OPERATION THEN
        UseMasterWa:=TRUE;
        TRYNEXT;
    ELSE
        RETURN;
    ENDIF
ELSEIF ERRNO=PM_ERR_WA_NOT_FOUND THEN
    RETURN;
ELSEIF ERRNO=PM_ERR_NO_RUNNING_PROJECT THEN
    RETURN;
ELSEIF ERRNO=PM_ERR_REDO_LAST_PICK_REJECTED THEN
    RETURN;
ELSEIF ERRNO=PM_ERR_WORKAREA_EXPECTED THEN
    RETURN;
ELSEIF ERRNO=PM_ERR_NOT_VALID_RECOVER_ACTION THEN
    RETURN;
ELSE
    RETURN;
ENDIF
ENDTRAP

```

Trap TrapStartFlow

This section describes the trap that executes when the start flow signal has been pulsed.

Description

A GI signal defines which flow should be started. The flow name received from *PmGetFlowInfo* is used to start the flow.

Program code

```

TRAP TrapStartFlow
VAR pm_flowinfo FlowInfo;
VAR num FlowSelection;
FlowSelection:=alias_giSelectionFlow;
! Get info from selected flow
PmGetFlowInfo FlowSelection,FlowInfo;
! Start the selected flow
PmStartFlow FlowInfo.Name;
ERROR
    ! Continue supervision on recoverable errors
IF ERRNO=PM_ERR_FLOW_NOT_FOUND THEN
    RETURN;
ELSEIF ERRNO=PM_ERR_NO_RUNNING_PROJECT THEN
    RETURN;

```

Continues on next page

6 RAPID program

6.3.4 PmProjServer module

Continued

```
ELSEIF ERRNO=PM_ERR_WRONG_FLOW_STATE THEN
    RETURN;
ELSE
    RETURN;
ENDIF
ENDTRAP
```

Trap TrapStopFlow

This section describes the trap that executes when the stop flow signal has been pulsed.

Description

A GI signal defines which flow should be stopped and another GI signal defines the stop behavior. The flow name received from *PmGetFlowInfo* is used to stop the flow.

Program code

```
TRAP TrapStopFlow
VAR pm_flowinfo FlowInfo;
VAR num FlowSelection;
VAR num StopOption;
FlowSelection:=alias_giSelectionFlow;
StopOption:=alias_giStopOptionFlow;
! Get info from selected flow
PmGetFlowInfo FlowSelection,FlowInfo;
! Stop the selected flow
PmStopFlow FlowInfo.Name,StopOption;
ERROR
! Continue supervision on recoverable errors
IF ERRNO=PM_ERR_FLOW_NOT_FOUND THEN
    RETURN;
ELSEIF ERRNO=PM_ERR_NO_RUNNING_PROJECT THEN
    RETURN;
ELSE
    RETURN;
ENDIF
ENDTRAP
```

Trap TrapProjectStopped

This section describes the trap that executes if the stop project signal has been pulsed.

Description

PmStopProj is called to stop the current project. This trap will normally not be executed since the traps are disconnected at the same time as the stop project signal has been pulsed.

Program code

```
TRAP TrapProjectStopped
PmStopProj;
ENDTRAP
```

Continues on next page

Related information

[PmGetFlowInfo](#) - Get information about a specific flow on page 289.

[PmStartFlow](#) - Starts a specific flow on page 306.

[PmStopFlow](#) - Stop a specific flow on page 309.

[PmStopProj](#) - Stop current project on page 311.

6 RAPID program

6.4.1 System modules, overview

6.4 System modules

6.4.1 System modules, overview

Description

An ABB IRC5 robot controller installed with the RobotWare option *Prepared for PickMaster*, together with the sub-option *PickMaster 5*, will always contain the following loaded system modules:

- pmrcUser (open)
- pmrcSys (open)
- pmrcBase (encrypted).

6.4.2 Public system module pmrcUser

Description

The *pmrcUser* module contains declarations of work object data and tool data that can be used when setting up the line. Additional work objects and tools can be added here.

Trap TrapDIToolEvents

Usage

This trap is called if one DI signal is not set to the desired value at a specific robot position. The RAPID execution and robot movement is interrupted until all the specified DI and GI signal values for the robot position are set to their desired values.

WarningTime defines how long time the robot will wait for the signals to be set before a warning is logged.

PollTime defines how often the signals will be checked while waiting.

Program code

```
TRAP TrapDIToolEvents
  VAR num warningTime := 5;VAR num pollRate := 0.1;
  PmCheckToolEventInputSignals warningTime, pollRate;
ENDTRAP
```

Trap TrapGIToolEvents

Usage

This trap works in the same way as `TrapDIToolEvents` but is executed for GI signals.

6 RAPID program

6.4.3 Public system module pmrcSys

6.4.3 Public system module pmrcSys

Description

The *pmrcSys* module contains instructions and data that are a part of the PickMaster base functionality. This module is declared as NOSTEPIN, which means that the code is open and editable but it is not possible to step into the routines. The NOSTEPIN statement can be removed for debug purposes.

This module is not saved in a backup. If modifications are needed in this module, then rename the instructions and move them to *pmrcUser*.

Procedure PmDoAction

Usage

Execute an action, that is, a single robot movement having preconfigured path events and motion settings.

Basic examples

A basic example of the procedure `PmDoAction` is seen in the program code for the [Procedure Operate on page 205](#), in the `PmMain` module.

Arguments

WorkArea

Datatype: `pm_wadescr`

Contains a reference to the work area to use.

Tgt

Datatype: `pm_targetdata`

The target data used for the move.

Act

Datatype: `pm_actiondata`

The action data used for the move.

Error handling

The following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable `ERRNO` will be set to:

Error code	Des
PM_ERR_PALLET_REDUCED	The detected stack height was lower than expected.
PM_ERR_PALLET_EMPTY	The detected stack height was zero on a slave work area.
PM_ERR_JOB_EMPTY	The detected height was zero on a master work area.

Syntax

```
PmDoAction
[ Wa ':= ' ] < expression (IN) of pm_wadescr > ', '
[ Tgt ':= ' ] < expression (IN) of pm_targetdata > ', '
[ Act ':= ' ] < expression (IN) of pm_actiondata > ';'
```

Continues on next page

Program code

See the program code by browsing the `pmrcSys` module on the robot.

Procedure `PmDoMove3`

Usage

This procedure calls the selected move Instruction (`MoveL`, `MoveJ`, `TriggL` or `TriggJ`) using the selected parameters.

Basic examples

A basic example of the procedure `PmDoMove3` is seen in the program code for the [Procedure `MoveInterMid` on page 210](#), in the `PmUtility` module.

Arguments

Move

Datatype: `pm_movetype`

The type of movement that is used. Supported types are `MoveJ`, `MoveL`, `TriggL` and `TriggJ`.

Conc

Datatype: `bool`

Tells if a concurrent move instruction is used.

ToPoint

Datatype: `robtarget`

The destination point of the movement.

Speed

Datatype: `speeddata`

The speed data that applies to movements. Speed data defines the velocity of the tool center point, the external axes and of the tool reorientation.

T1

Datatype: `triggdata`

Variable that refers to trigger conditions and trigger activity.

T2

Datatype: `triggdata`

Variable that refers to trigger conditions and trigger activity.

T3

Datatype: `triggdata`

Variable that refers to trigger conditions and trigger activity.

T4

Datatype: `triggdata`

Variable that refers to trigger conditions and trigger activity.

T5

Datatype: `triggdata`

Variable that refers to trigger conditions and trigger activity.

Continues on next page

6 RAPID program

6.4.3 Public system module pmrcSys

Continued

T6

Datatype: `triggdata`

Variable that refers to trigger conditions and trigger activity.

T7

Datatype: `triggdata`

Variable that refers to trigger conditions and trigger activity.

T8

Datatype: `triggdata`

Variable that refers to trigger conditions and trigger activity.

Zone

Datatype: `zonedata`

Zone data for the movement. Zone data describes the size of the generated corner path.

Inpos

Datatype: `stoppointdata`

The setting of the dwell in the motion.

Tool

Datatype: `tooldata`

The tool in use when the robot moves. The tool center point is the point that is moved to the specified destination position.

WObj

Datatype: `wobjdata`

The work object (coordinate system) to which the robot position in the instruction is related.

Program code

See the program code by browsing the `pmrcSys` module on the robot.

Variable `pm_home_Wobj`

Usage

This variable is used for the default installed work area `PM_HOME` to connect to an always existing work object.

Description

The variable is only used to get `PM_HOME` work area. It is a copy of the installed work object `wobj0`.

Variables `LastRobTgt`, `LastWobj` and `LastTool`

Usage

These variables are used to store the last position, work object, and tool.

Description

The variables are used to store the last position's properties, to be able to calculate an intermediate position.

Continues on next page

Program code

See usage of the variables in the program code by browsing the `pmUtility` module.

This page is intentionally left blank

7 Runtime operation

7.1 Introduction

Structure of this chapter

This chapter describes the runtime operating interface to PickMaster.

The runtime operating interface consists of three parts:

- PickMaster FlexPendant interface. A graphic operator's interface.
- PickMaster I/O interface. Used by a PLC.
- PickMaster RAPID interface. The RAPID interface can be customized to receive and handle requests not covered by the FlexPendant or the I/O interface. For a complete description of program modules, functions, procedures, and data specific for palletizing see [RAPID program on page 199](#), and [RAPID reference information on page 281](#).

Prerequisites

The runtime operating interface is only available with the option *Prepared for PickMaster*, with the sub-option *PickMaster 5*.

7 Runtime operation

7.2.1 Introduction to PickMaster FlexPendant interface

7.2 FlexPendant interface

7.2.1 Introduction to PickMaster FlexPendant interface

PickMaster FlexPendant interface

The PickMaster FlexPendant interface is available from the ABB menu on the FlexPendant. It is a graphical user interface designed to control and/or supervise the palletizing process.

The PickMaster FlexPendant interface covers the following four areas:

- Open Project
- Production
- Process Signals
- Tune

Illustration

The illustration shows the PickMaster main menu.



xx0600002995

Open Project

Open Project displays a list of all the PickMaster projects that have been downloaded to the robot controller. A project must be opened before it can be started from the production window. The status bar always contains information about the loaded project as well as the current location within the window hierarchy. See [Opening a project on page 232](#).

Production

Production is used by the operator to start and stop and monitor the palletizing process.

Continues on next page

See [Starting and stopping production on page 233](#).

Process Signals

Process Signals presents a list of all the work areas, items, events, and the I/O signals that are connected to each work area. It is possible not only to view but also to set new signal values. This window also presents all the tool configurations that build up the tool together with the zones and the activators. For a detailed description of the tool configuration, see [Zone frame on page 379](#), and [Activators properties on page 123](#).

See also [Process Signals on page 246](#).

Tune

Tune is used to change the parameter values online while running the PickMaster application.

See [Tuning on page 249](#).

7 Runtime operation


7.2.2 Opening a project

7.2.2 Opening a project

This section describes how to open a PickMaster project from the Open Project window. A list of all the available projects on the controller appears together with a description, if provided. For more information, see [Project on page 152](#).

	Action	Note
1.	On the PickMaster main menu, tap Open Project .	The Open Project button is only accessible if the current PickMaster project is stopped.
2.	Tap a project.	When a project is selected, the OK button appears. To update the list of projects, tap Refresh .
3.	To open the project and return to the main menu, tap OK .	
4.	To view information about the project, tap View project info .	The window shows information about line path, transfer data, PickMaster version, user, computer, and a description of the project.
5.	To close the window, tap Cancel .	

The following figure shows the **Open Project** window.



xx0600002996

Related information

[Starting and stopping production on page 233.](#)

[Process Signals on page 246.](#)


7.2.3 Starting and stopping production

Overview

This section describes how to start and stop the palletizing process from the Production window.

Illustration, Production window

The illustration shows an example of the Production window when three flows are defined in the PickMaster project.



xx0700000229

Flow	The name of the flow as specified in the PickMaster project.
Status	The status of the flow, which can be Stopped , Running , or Error . The status can also indicate type of stop in progress, for example, Stopping after cycle , Stopping after layer , and Stopping after pallet .
Active job	The currently running job on the flow, that is, the name of the active master operation set.
Job status	The current job status of the flow, which can be Idle (no job is running), Running or Stopping (a job has been ordered to stop).

Starting a project

	Action	Note
1.	On the Production menu, tap Project .	
2.	Tap Start .	A warning appears if the system is in motors off state.

Continues on next page

7 Runtime operation

7.2.3 Starting and stopping production

Continued

Stopping a project

	Action	Note
1.	On the Production menu, tap Project .	
2.	Tap Stop . To proceed, tap Yes . To cancel, tap No .	A warning appears.

Restarting RAPID

The following procedure describes how to restart the program execution. This is the same function as pushing the hardware button *Start* on the IRC5 FlexPendant.

	Action	Note
1.	On the Production menu, tap Project .	
2.	Tap Restart RAPID .	The Restart RAPID button is only available when program is paused.

Starting a specific flow

Starting the flow will enable the starting and execution of a palletizing job.



Note

The PickMaster project must be started before a flow can be started.

	Action
1.	In the list of defined flows, tap on the flow to start. The Start Flow button becomes available.
2.	Tap Start Flow .

Stopping a specific flow

Stopping the flow pause the execution of a running palletizing job. When the flow is restarted, the execution of the job will continue. A flow stop option can be selected to specify how and when the flow shall be stopped.

	Action
1.	In the list of defined flows, tap on the flow to stop. The Stop Flow button becomes available.
2.	Tap Stop Flow .

Starting a specific job




Note

The flow must be running before a job can be started.

	Action
1.	In the list of defined flows, tap on the flow to start a job on. The Start Job button appears.
2.	Tap Start Job . The Start Job window appears.
3.	Select job and press start.

Continues on next page

The following illustration shows an example of the Start job window.



en100000858

Job selection	A list of palletizing jobs defined for the master work area to select from.
Restart conditions	A list of parameters that needs to be specified when an unfinished job shall be restarted, for example, a half finished pallet pattern. When starting a new job, do not update these parameters. NOTE: A restart is not possible if the last operation was a partially completed multi drop operation. In that case, some products has to be manually removed from the stack before starting, for example, a removal of the top layer.
Layer count	Specifies number of available full layers, including defined pallet and slip sheets.
Product count	Specifies number of available products in the top layer. If the top layer is full, product count shall be set to zero.

Editing restart conditions

	Action
1.	Select restart condition .
2.	Press Edit restart condition menu.
3.	Enter appropriate value on the displayed numerical pad and press OK .

Stopping a specific job

If stopping a job, it will be finished without being completed. The job will stop as soon as any currently ongoing or pending pick-places cycle has been completed or cancelled. Pending position requests on slaves will be cancelled if no targets are generated before the slave's stop job timeout has passed.

Continues on next page

7 Runtime operation

7.2.3 Starting and stopping production

Continued

If the job is waiting on a slave that has been running out of products, stop job can be used to finish the job without running any further pick-place cycles. The job will become stopped after the stop job timeout has passed.



Note

The flow must be running before a job can be stopped.

	Action
1.	In the list of defined flows, tap on the flow to stop the job on. The Stop Job button becomes available.
2.	Tap Stop Job . A pop-up window appears.
3.	In the pop-up window, confirm that the job shall be stopped.

Starting and stopping all flows


To...	Do this
Start all flows	Tap Start All Flows .
Stop all flows	Stop All Flows .

Viewing flow status

	Action
1.	In the list of flows, tap on a specific flow. In the Production window, the Status command on the View menu becomes available.
2.	On the View menu, tap Status and select a work area.
3.	To close the Status Information window, tap Status on the View menu.

Continues on next page

The following illustration shows an example of the **Production** window when the flow status information appears. In this example the project *Medium Coffee* includes the work areas *Medium Outfeed* and *Medium Infeed*.



xx0700000228

Work Area	The name of the work area as specified in the PickMaster software. For further details, see Feeder on page 168 .
Status	Provides status information about the work area, which can be Running or Error .
Operation Set	Specifies the last accessed operation set on the work area.
Item Count	A counter for the accumulated number of items that has been picked or placed on the work area since the project start.

Viewing messages

	Action
1.	On the View menu, tap Messages .
2.	In the list of messages, tap a specific message. A message window appears.

Continues on next page

7 Runtime operation

7.2.3 Starting and stopping production

Continued

The following illustration shows an example of the message window where only messages concerning flow recovery are shown.



xx0700000482

Code	The code of the message.
Title	The title of the message.
Date	The date and time of the generated message.
Clear	Clears the list of messages. Note that the messages are <i>not</i> deleted. If the production window is closed and then reopened, the cleared messages appear again.
OK	Closes the window.

For details about message configuration, see [Messages on page 160](#).

Changing or viewing flow stop options

	Action
1.	In the list of flows, tap on the flow to change the stop option for. The Flow Stop Options button on the Production menu becomes available.
2.	Tap Flow Stop Options and select a stop option. The currently selected stop option is checked.

There are four different ways to stop each product flow from the FlexPendant. Each stop option is described according to what will happen when a flow is stopped with the specific stop option and after tapping **StopFlow**.

Flow stop option	Description
Finish cycle	The robot will continue palletizing until the current pick/place cycle of the job is finished.
Finish layer	The robot will continue palletizing until the current layer of the job is finished.
Finish job	The robot will continue palletizing until the current job is finished.

Continues on next page

Flow stop option	Description
Stop immediately	<p>The flow is stopped and a flow recovery action must be selected when restarting.</p> <p>If the flow is the current active flow, the robot will stop immediately, without finishing a started cycle. A warning symbol appears next to the flow, indicating that a flow recovery action must be selected, and the status changes to Error.</p> <p>If another flow shares one of the slave work areas, a warning symbol will appear also next to that flow when this slave is requested, but the flow status does not change.</p> <p>If the stopped flow is not the current active flow, the robot will continue palletizing using the remaining running flows.</p>

A StopFlow command can be cancelled using Undo. However, this is not possible with flow stop option "Stop Immediately". To cancel a requested stop action:

- On the **Stop Options** menu, tap **Undo**.

Related information

[Opening a project on page 232.](#)

[Process Signals on page 246.](#)

[Feeder on page 168.](#)

[Events on page 157.](#)

[Robot Settings on page 163.](#)

7 Runtime operation

7.2.4 Flow recovery

7.2.4 Flow recovery

Overview

If a work area is in error state, (for example, as a result of using event signals **Error Source** and **Trigger**), a warning symbol appears next to the flows that are affected. If a flow is stopped in the error state, a warning symbol appears on the **Start Flow** button. For example, this occurs if the flow is stopped immediately or if the flow needs to access a work area in the error state. The warning symbol indicates that the flow must be recovered when started. The following section describes how to recover the flow in such a case.

Recovering a specific flow


Overview

	Action	Note
1	In the Production window, tap Start Flow .	See Illustration, Production window with a flow to recover on page 241 .
2	The Restart options window appears. Select one of the displayed recovery options and tap OK .	You get three options to continue. See Illustration, Restart options window on page 242 .
3	The Production window appears and there is a note symbol on the Start Flow button. Tap Start Flow .	See Illustration, Production window after selecting a recovery option on page 243 .
4	A dialog box containing information about the selected option appears. Verify the status as specified in the message, and then tap OK .	After tapping OK , the flow is in production again. If the RAPID program has stopped, it will restart. See Illustration, Confirm restart information on page 244

Continues on next page

Illustration, Production window with a flow to recover

The following figure illustrates the **Production** window when a flow has been forced to stop due to an error.



xx1300000753

Start Flow

The warning symbol indicates that a flow has been forced to stop by an error in a work area or with the stop option **Stop immediately**. When the **Start Flow** button is pressed, the **Restart options** window appears.


Continues on next page

7 Runtime operation

7.2.4 Flow recovery

Continued

Illustration, Restart options window



xx1300000754

The work areas in error state are marked with a warning symbol. Select a suitable recover action and press OK to confirm.

Recover action	Description
Continue Pick-Place	The flow continues from where it was stopped.
Redo last pick	The flow repeats the last pick operation. Redo last pick is enabled in the gap only after the first product is picked and before the first product is placed.
Restart layer	The flow restarts the job from the beginning of the current layer, starting with the picking.
Terminate job	The flow terminates the current job, cancel the remaining operations, and enable the starting of the next job.




Note

The robot moves directly to the pick work area after a restart with flow recovery when using **Redo last pick**, **Restart layer**, or **Terminate job**. Any passed safe position is not considered in the planned path. Ensure that the robot is jogged to a secured position.

Continues on next page

Illustration, Production window after selecting a recovery option

The following figure illustrates the **Production** window after selecting a recovery option for a flow.



xx1300000758

Start Flow

The info symbol indicates that a flow recovery action has been selected for the flow. Tap **Start** to display more information about the selected action, expected number of products in robot tool and on work areas, and so on.

Continues on next page


7 Runtime operation

7.2.4 Flow recovery

Continued

Illustration, Confirm restart information

The following figure illustrates the information window to confirm while starting the flow after selecting a flow recovery action. Tap **OK** to immediately run the flow start. The error state for the flow and the work areas are reset. Tap **Cancel** to open the **Restart options** window from where you can select a new restart action.



xx1300000759

Restarting other flows after error event

If a flow is stopped by an error event (or "Stop immediately") while the robot is executing the flow, the RAPID program will also stop.

In order to restart execution of the other flows without first resolving the error:

- 1 Verify that the robot tool is prepared for the next pick/place cycle, for example, empty
- 2 Jog the robot to a safe position from where execution of the next pick/place cycle can be started
- 3 Move PP to Main
- 4 Restart RAPID
- 5 Confirm a warning message on the flex pendant




WARNING

If the PP is not moved to Main in step 3, the robot may start moving to an already fetched but not yet executed target. Execution will then stop on the next of the following functions: `PmGetEvent`, `PmGetTarget`, or `PmGetTgtAction`.

Continues on next page

Illustration, Restart other flows after error event

The following figure illustrates the **warning** message which must be confirmed if RAPID is restarted after an error event of the executing flow.



xx0700000503

Related information

[Starting and stopping production on page 233](#)

7 Runtime operation

7.2.5 Process Signals

7.2.5 Process Signals

Introduction


This section describes how to use the **Process Signals** window to manually control and view:

- The I/O signals that are connected to a work area.
- The zones and the activators that build up the tool configuration.
- The event signals.

Viewing the work area signals

	Action	Note
1.	On the PickMaster main menu, tap Process Signals .	
2.	Tap View and select Work Areas .	See Feeder on page 168 .
3.	From the Work Areas list, tap one work area.	

The following illustration shows an example of the **Process Signals** window when one work area is selected.




xx0700000226

Viewing the tool configuration

	Action
1.	On the PickMaster main menu, tap Process Signals .
2.	Tap View and select Tool .
3.	From the Tool list, tap one tool configuration.

Continues on next page

The following illustration shows an example of the **Process Signals** window when one tool configuration is selected.



xx0700000225

Viewing events

	Action	Note
1.	On the PickMaster main menu, tap Process Signals .	
2.	Tap View and select Events .	See Events on page 157 .
3.	From the Events list, tap one controller.	


Continues on next page

7 Runtime operation

7.2.5 Process Signals

Continued

The following illustration shows an example of the **Process Signals** window when one controller is selected.



xx0700000407

Related information

[Opening a project on page 232.](#)

[Starting and stopping production on page 233.](#)

7.2.6 Tuning

Introduction


This section describes how to tune the parameter values online in the **Tune** window. A parameter can be tuned at any time for a selected project, for example while the project is running. Parameter tune updates affects the received data of the next calls to Pickmaster RAPID instructions (for example `PmGetTarget`).

Illustrations, Tune window

Below the FlexPendant interface illustrating tuning of an item and a work area.

Item

The illustration shows an example of the Tune window when five products are defined, and the properties that can be tuned for each product.



xx0700000408

- Item** The name of an item as specified in the PickMaster project. See [Product/Pallet/Sheet on page 59](#).
- Property** The property of an item. For description of the parameters, see table below.
- Current** Specifies the actual current value of the property.
- Default** Specifies the default value of the property as it was in the PickMaster project when it was downloaded to the controller.
- Reset All** All items and work areas are set to their respective default value.

The following table describes the **Property** parameters:

Parameter	Description
Speed	Specifies the maximum speed for an item.
Ori speed	Specifies the maximum orientation speed for an item.

Continues on next page

7 Runtime operation


7.2.6 Tuning

Continued

Parameter	Description
Acceleration	Specifies the maximum acceleration/deceleration for an item.
Pick time	Specifies the time the robot stays at the target position when picking an item.
Place time	Specifies the time the robot stays at the target position when placing an item.
Size Z	<p>Specifies the height of the item. When updating the item height, the height of pick and place positions for next items to be handled will be affected accordingly.</p> <p>Always when updating the item height, the operator is asked if the new value shall be applied also to previously placed layers. If the answer is yes, product place positions will be affected by height updates of all previously placed items in lower layers. If the answer is no, place positions will only be affected by the height updates of new items to be placed. Pick positions will never be affected.</p>
Pick Activation	Specifies the time for pick activation.
Place Activation	Specifies the time for place activation.

Work Area

The illustration shows an example of the Tune window when six work areas are defined, and the properties that can be tuned for each work area.



xx0700000409

Work area	The name of a work area specified in the PickMaster project. See Feeder on page 168 .
Property	The property of a work area. For description of the parameters, see table below.
Value	Specifies the actual current value of the property.
Default	Specifies the default value of the property as it was in the PickMaster project when it was downloaded to the controller.

Continues on next page

The following table describes the **Property** parameters:

Parameter	Description
Disp offs x	Displacement of the work area in x-direction relative the work object.
Disp offs y	Displacement of the work area in y-direction relative the work object.
Disp offs z	Displacement of the work area in z-direction relative the work object.
Disprotz	Displacement angle of the work area in the z-direction.


How to proceed

This section describes how to proceed with tuning of an item and a work area.

Tuning an item

	Action	Note
1.	On the Tune menu, tap View .	
2.	Tap Item .	
3.	In the Item list, tap the item to tune.	
4.	In the Property list, tap the item property to tune.	
5.	On the Tune menu, tap Tune Value .	The Item Tune Value window appears. See illustration below this procedure.
6.	In the Increment drop-down combo box, select the size of increment.	The increment specifies the value that will be added to/subtracted from the item property for each time you tap the + or - button.
7.	Tap Apply .	

The following figure illustrates tuning of an item.



xx0700000411

Continues on next page

7 Runtime operation


7.2.6 Tuning

Continued

Tuning a work area

	Action	Note
1.	On the Tune menu, tap View.	
2.	Tap Work Area.	
3.	In the Work Area list, tap the work area to tune.	
4.	In the Property list, tap the work area property to tune.	
5.	On the Tune menu, tap Tune Value.	The Work Area Value window appears. See illustration below this procedure.
6.	In the Increment drop-down combo box, select the size of increment.	The increment specifies the value that will be added to/subtracted from the item property for each time you tap the plus or minus button.
7.	Tap Apply.	

The following figure illustrates tuning of a work area.



xx0700000410

7.3 I/O interface

7.3.1 Overview

PickMaster I/O interface

The PickMaster I/O interface is used by external equipment, such as a PLC, to control and supervise the palletizing process. It consists of two parts:

- The basic I/O interface defines work area specific signals. It covers the minimum I/O configuration needed to run a PickMaster project.
- The extended I/O interface adds optional functionality, for example reporting error events, starting projects and flows, and so on. You can use the extended I/O interface if needed.

7 Runtime operation

7.3.2 Default signals

7.3.2 Default signals

Introduction to default signals

More than one hundred (100) default signals are installed on every controller with the option *Prepared for PickMaster*. The signals can be used when setting up PickMaster lines and projects.

Configuration and setup

The signals can be selected in the configuration dialogs. As default, the signals are mapped to simulated I/O units, *Pickmaster_Sim1*, *Pickmaster_Sim2*, and *Pickmaster_Sim3*. During commissioning, the signals can be mapped to physical I/O units.

Additional signals are required if you use more than:

- 8 work areas
- 1 robots
- 1 controllers
- 4 flows

Use RobotStudio for:

- Renaming, reconfiguring, or removing default signals.
- Adding additional signals.

Description of default signals

The following default signals are installed.

Work areas

Default signals are defined for eight work areas. Signal name prefixes:

- *pmlInfeeder1*
- *pmlInfeeder2*
- *pmlInfeeder3*
- *pmlInfeeder4*
- *pmOutfeeder1*
- *pmOutfeeder2*
- *pmOutfeeder3*
- *pmOutfeeder4*
- *pmSlipsheet1*
- *pmPallet1*

Controller system actions

Default signals are defined for controller system actions. Signal name prefix:

- *pmSystem*

Project handling

Default signals are defined for project handling. Signal name prefix:

- *pmProject*

Continues on next page

Flows

Default signals are defined for flows. Signal name prefixes:

- *pmFlow*
- *pmFlow1*
- *pmFlow2*
- *pmFlow3*
- *pmFlow4*

Grippers

Default signals are defined for a gripper. Signal name prefix:

- *pmGripper1*

Event reporting

Default signals are defined for event reporting. Signal name prefix:

- *pmEvent*

7 Runtime operation

7.3.3 Basic I/O interface

7.3.3 Basic I/O interface

General

The I/O signals are used by a PLC to:

- Start and stop jobs on master work areas.
- Control and supervise the flow of products on work areas.
- Control and supervise the robot execution on work areas.
- Control and supervise the status and height of work areas.

I/O signals must be setup for each work area. Some of the signals must be used and others can be used if needed.

How to use the work area signals depends on if the work area will be used as a master or slave.

Master work areas

Overview

The following signals must be configured:

- Target generation trigger signal (DI)
- Target generation product selection (GI)¹
- Position request trigger signal (DO)¹

The following signals must be setup if simulated target generation is selected for the work area. See [Feeder on page 168](#).

- Position request trigger signal (DO)



Note

The signal is mandatory only if there is more than one operation set in the feeder.

Target generation trigger signal (DI)

The signal is mandatory unless simulated target generation is used.

The signal can also be skipped if palletizing jobs always are to be started using the FlexPendant interface.

A trigger pulse generates the start of a new palletizing/depalletizing job on that work area. A palletizing/depalletizing job is equivalent to one of the operation sets configured for the feeder. Before the signal is pulsed, the flow must be running, the position request trigger signal must be set and the work area must be prepared for the job to be started. For example:

- Work area is empty and ready to receive products to build a new pallet.
- Work area is loaded with a pallet to be depalletized.

Default signal, example: *pmOutfeeder1_diTgtGenTrig*.

Target generation product selection (GI)

The signal is mandatory if there is more than one operation set for the work area.

Continues on next page

It is used to select among all palletizing jobs (that is, operation sets) configured for the work area. The signal is set to the product I/O value for the selected operation set. It must be set before the target generation trigger signal is pulsed.

Default signal, example: *pmOutfeeder1_giProdSel*.

Target generation format selection (GI)

The signal has no function and is not required.

Target generation start layer count (GI)

The signal is optional. It is used when restarting an unfinished job. The signal is set to the number of full layers on the stack, including the pallet (if defined in the pallet pattern) and slip sheets. It must be set before the target generation trigger signal is pulsed.

Default signal, example: *pmOutfeeder1_giStartLayerCount*.

Target generation start product count (GI)

The signal is optional. It is used when restarting an unfinished job. The signal is set to the number of products on the top layer off the stack. If the top layer is full, the signal is set to zero. It must be set before the target generation trigger signal is pulsed.

Default signal, example: *pmOutfeeder1_giStartProdCount*.

Position request trigger signal (DO)

The signal is mandatory if simulated target generation is used and highly recommended otherwise.

The signal is set by the controller when it is ready to start a new palletizing job (that is, operation set) on that work area. This will happen:

- When the corresponding flow is started.
- When a job is completed.
- When a job is stopped before completing.
- When an operation set is finished using the robot execution signal.
- As a result of a flow recovery action.

A new job/operation set cannot be started until the signal is set and the work area is prepared for palletizing (the work area is empty and ready to receive new products from the slave infeeders) or depalletizing (the work area is loaded with a new pallet of products). The signal is reset when the target generation trigger signal is pulsed or if the flow is stopped.

Default signal, example: *pmOutfeeder1_doPosReqTrig*.

Position request product selection (GO)

The signal has no function and is not required.

Position request format selection (GO)

The signal has no function and is not required.

Position request requesting master (GO)

The signal has no function and is not required.

Continues on next page

7 Runtime operation

7.3.3 Basic I/O interface

Continued

Position available (DO)

The signal is optional.

The signal indicates if target positions can be received in RAPID to be executed by the robot. Using the *Robot execution* signal affects the output of the *Position available* signal.

If the robot execution signal is not defined, *Position available* is set after:

- A new operation set is generated by the PLC.
- Any operation, except the last one of an operation set, is performed by the robot.

If the robot execution signal is not defined, the *Position available* signal is reset after any operation is received in RAPID.

If the robot execution signal is defined, the *Position available* signal is set after:

- A new operation set is generated and the robot execution signal is set by the PLC.
- Any operation, except the last one of an operation set, is performed by the robot, the robot execution signal is reset and then set again by the PLC.

If the robot execution signal is defined, the *Position available* signal is reset after

- Any operation is received in RAPID.
- The robot execution signal is reset to finish an uncompleted operation set.

Default signal, example: *pmOutfeeder1_doPosAvail*.

Queue empty (DO)

The signal is optional.

The signal indicates if there are targets generated that yet has not been received in RAPID.

After the last target is received for an operation set, the signal goes to one. Note, the signal will go high before the movements is finished, that is the last products might not have been placed/picked.

Default signal, example: *pmOutfeeder1_doQueueEmpty*.

Operation set complete (DO)

The signal is optional.

The signal is set:

- After all products in an operation set have been placed/picked and the robot has departed from the work area after the last place/pick operation.
- If the job is stopped (e.g. before being completed)
- If the current job is finished before being completed by resetting the robot execution signal.

The signal is reset when the target generation trigger signal is pulsed. If the target generation signal is set very early, that is, just before or just after operation set is complete, the signal will be reset after a time corresponding to the configured pulse length. For more information on pulse length configuration, see [Controller Settings on page 156](#).

Default signal, example: *pmOutfeeder1_doOpSetCompl*.

Continues on next page

Execution state (GO)

The signal is optional.

The signal indicates the runtime state of the work area.

I/O value	Description
0	A project using this work area is not running.
1	Work area is running.
2	Work area has an error. Flow recovery is required to recover from the error.
3	Work area has a response error, that is, the PLC has generated wrong targets. A generation of correct targets is required to recover from the error.

Default signal, example: *pmOutfeeder1_goExecState*.

Height state (GO)

The signal is optional.

The signal indicates the current height of the work area. The signal must have a bit length of at least three to represent the five possible states.

I/O value	Description
0	Full height. The height is equal to the setting of Full height , see Robot path height on page 174 .
1	Active height. An operation set is executed and the height is updated after each pick or place until the operation set is completed.
2	Latest height. The height is equal to the final height of the latest run operation set.
3	Empty height. The height is equal to the setting of Empty height , see Robot path height on page 174 .
4	Value. The height is set to a value with the RAPID function <code>PmSetDefaultHeight</code> .

Default signal, example: *pmOutfeeder1_goHeightState*.

Layer count (GO)

The signal is optional.

The signal value indicates the number of full layers on the work area.

Default signal, example: *pmOutfeeder1_goLayerCount*.

Product count (GO)

The signal is optional.

The signal value indicates the number of products in the top layer. If the top layer is full, the signal is set to zero.

Default signal, example: *pmOutfeeder1_goProductCount*.

Stop job (DI)

The signal is optional.

Continues on next page

7 Runtime operation

7.3.3 Basic I/O interface

Continued

The signal is used to stop the currently ongoing job before it is completed. The flow must be running before a job can be stopped. The job is stopped by pulsing the signal.

The job will stop as soon as any currently ongoing or pending pick-places cycle is completed or cancelled. Pending position requests on slaves will be cancelled if no targets are generated before the slave's stop job timeout has passed. For more information on stop job timeout, see [Feeder on page 168](#).

If the job is waiting on a slave that is running out of products, stop job can be used to finish the job without running any further pick-place cycles. The job will become stopped after the stop job timeout has passed.

Default signal, example: `pmOutfeeder1_diStopJob`.

Robot execution (DI)

The signal is optional.

The signal is used to control whether the robot is allowed to approach the work area or not. If the signal is reset, the RAPID execution will not pass the instruction `PmGetTarget` until the signal is set. After an operation is performed by the robot, the signal must be reset and then set again to allow the robot to approach the work area the next time.

The signal can also be used to finish the current operation set before all operations have been completed. If the signal is reset, the remaining targets will be removed.

Default signal, example: `pmOutfeeder1_diRobotExec`.

Redo search (DI)

The signal is optional.

The signal is used with operation sets having stack search activated.

Stack search is normally not used for a master work area.

If the signal is pulsed, the next operation will start with a search movement from the top of the stack. The signal can be used after adding new items on a stack. To affect the next approach to the work area, the signal must be pulsed before the robot receives the operation in RAPID.

Default signal, example: `pmOutfeeder1_diRedoSearch`.

Slave work areas

The following signals must be setup:

- Target generation trigger signal (DI)
- Target generation product selection (GI)²
- Target generation format selection (GI)³
- Position request trigger signal (DO)
- Position request product selection (GO)²
- Position request format selection (GO)³

The following signals must be setup if simulated target generation is selected for the work area. See [Feeder on page 168](#).

- Position request trigger signal (DO)

Continues on next page

- Position request product selection (GO)²
- Position request format selection (GO)³

2) Only mandatory if there is more than one item.

3) Only mandatory if there is more than one format for the same item.

Position request trigger signal (DO)

The signal is mandatory.

The signal is set by the controller when one of the corresponding master work areas requests a format on this slave work area from the PLC. The requested format must be defined as an operation set in the feeder. The request occurs after the previous pick and place cycle for that flow has finished.

If the flow uses early request, then the request will occur in advance, before the robot has finished the previous cycle. Early request will decrease cycle times if the same flow is run in consecutive pick place cycles. The signal is reset when the target generation trigger signal is pulsed.

Default signal, example: *pmlInfeeder1_doPosReqTrig*.

Position request product selection (GO)

The signal is mandatory if there is more than one item.

The signal I/O value specifies the requested product when the position request trigger signal is set.

Default signal, example: *pmlInfeeder1_goProdSel*.

Position request format selection (GO)

The signal is mandatory if there is more than one format for the same item.

The signal I/O value specifies the requested format when the position request trigger signal is set.

Default signal, example: *pmlInfeeder1_goFormSel*.

Position request requesting master (GO)

The signal is optional.

The signal value indicates the requesting master work area. The I/O value of the work area is configured in the Work Area I/O Settings editor. For more information on the Work Area I/O Settings, see [Edit detailed signals for feeder on page 171](#).

Default signal, example: *pmlInfeeder1_goReqMaster*.

Target generation trigger signal (DI)

The signal is mandatory unless simulated target generation is used.

A trigger pulse indicates that a previously requested format is now available for the work area to be handled by the robot.

Default signal, example: *pmlInfeeder1_diTgtGenTrig*.

Target generation product selection (GI)

The signal is mandatory if there is more than one item.

The signal specifies the product I/O value of the available format when the target generation trigger signal is pulsed.

Continues on next page

7 Runtime operation

7.3.3 Basic I/O interface

Continued

Default signal, example: *pmlInfeeder1_giProdSel*.

Target generation format selection (GI)

The signal is mandatory if there is more than one format for the same item.

The signal specifies the format I/O value of the available format when the target generation trigger signal is pulsed.

Default signal, example: *pmlInfeeder1_giFormSel*.

Target generation start layer count (GI)

The signal has no function and is not required.

Target generation start product count (GI)

The signal has no function and is not required.

Position available (DO)

The signal is optional.

The signal indicates if target positions can be received in RAPID to be executed by the robot. Using the *Robot execution* signal affects the output of the *Position available* signal.

If the *Robot execution* signal not is defined, *Position available* is set after:

- A new operation set is generated by the PLC.
- Any operation, except the last one of an operation set, is performed by the robot.

If the *Robot execution* signal is not defined, *Position available* is reset after any operation is received in RAPID.

If the *Robot execution* signal is defined, *Position available* is set after:

- A new operation set is generated and the *Robot execution* signal is set by the PLC.
- Any operation, except the last one of an operation set, is performed by the robot, the *Robot execution* signal is reset and then set again by the PLC.

If the *Robot execution* signal is defined, *Position available* is reset after:

- Any operation is received in RAPID.
- The *Robot execution* signal is reset to finish an uncompleted operation set.

Default signal, example: *pmlInfeeder1_doPosAvail*.

Queue empty (DO)

The signal is optional.

The signal indicates if there are targets generated that yet has not been received in RAPID.

After the last target is received for an operation set, the signal goes to one. Note, the signal will go high before the movements have finished, that is the last products might not yet have been picked/placed.

Default signal, example: *pmlInfeeder1_doQueueEmpty*.

Operation set complete (DO)

The signal is optional.

Continues on next page

The signal is set:

- After all products in an operation set have been placed/picked and the robot has departed from the work area after the last place/pick operation.
- If the current operation set is finished before being completed by resetting the robot execution signal.

The signal is reset when the target generation trigger signal is pulsed. If the target generation signal is set very early, that is, just before or just after operation set is complete, the signal will be reset after a time corresponding to the configured pulse length. For more information on pulse length configuration, see [Controller Settings on page 156](#).

Default signal, example: *pmlInfeeder1_doOpSetCompl*.

Execution state (GO)

The signal is optional.

The signal indicates the runtime state of the work area.

I/O value	Description
0	A project using this work area is not running.
1	Work area is running.
2	Work area has an error. Flow recovery is required to recover from the error.
3	Work area has a response error, that is, the PLC has generated wrong targets. A generation of correct targets is required to recover from the error.

Default signal, example: *pmlInfeeder1_goExecState*.

Height state (GO)

The signal is optional.

The signal indicates the current height of the work area. The signal must have a bit length of at least three to represent the five possible states.

I/O value	Description
0	Full height. The height is equal to the setting of Full height , see Robot path height on page 174 .
1	Active height. An operation set is being executed and the height is updated after each pick or place until the operation set is completed.
2	Latest height. The height is equal to the final height of the latest run operation set.
3	Empty height. The height is equal to the setting of Empty height , see Robot path height on page 174 .
4	Value. The height is set to a value with the RAPID function <code>PmSetDefaultHeight</code> .

Default signal, example: *pmlInfeeder1_goHeightState*.

Layer count (GO)

The signal is optional.

Continues on next page

7 Runtime operation

7.3.3 Basic I/O interface

Continued

The signal value indicates the number of full layers on the work area. For example, for a pallet stack or a slip sheet stack.

Default signal, example: *pmlntfeeder1_goLayerCount*.

Product count (GO)

The signal is optional.

The signal value indicates the number of products in the top layer. If the top layer is full, the signal is set to zero.

Default signal, example: *pmlnfeeder1_goProductCount*.

Stop job (DI)

The signal has no function and is not required.

Robot execution (DI)

The signal is optional.

The signal is used to control whether the robot is allowed to approach the work area or not. If the signal is reset, the RAPID execution will not pass the instruction `PmGetTarget` until the signal is set. After an operation is performed by the robot, the signal must be reset and then set again to allow the robot to approach the work area next time.

The signal can also be used to finish the current operation set before all operations have been completed. If the signal is reset, the remaining targets will be removed.

Default signal, example: *pmlnfeeder1_diRobotExec*.

Redo search (DI)

The signal is optional.

The signal is used with operation sets having stack search activated. If the signal is pulsed, next operation will start with a search movement from the top of the stack. The signal can be used after adding new items on a stack. To affect the next approach to the work area, the signal must be pulsed before the robot receives the operation in RAPID.

Default signal, example: *pmlnfeeder1_diRedoSearch*.

7.3.4 Extended I/O interface

Controller system handling

Introduction

A number of default system signals are installed to handle the controller system, for example to set the controller in motors on state.

See *Technical reference manual - System parameters*, the topic *I/O*, for descriptions of system inputs and outputs.

System inputs

System input	Description
<i>pmSystem_diLoadStart1</i>	Load and start the PmProjMgr module for motion task T_ROB1.
<i>pmSystem_diLoadX</i>	Load the PmProjMgr module for motion task T_ROBX.
<i>pmSystem_diStart</i>	Start RAPID execution.
<i>pmSystem_diStop</i>	Stop RAPID execution.
<i>pmSystem_diStartMain</i>	Start RAPID execution from Main.
<i>pmSystem_diMotorsOn</i>	Set motors on.
<i>pmSystem_diResetEstop</i>	Confirm reset of emergency stop.

System outputs

System output	Description
<i>pmSystem_doLoadReadyX</i>	A robot program (for example, PmProjMgr) is loaded for T_ROBX.
<i>pmSystem_doCycleOn</i>	Robot program is executing.
<i>pmSystem_doMotorOnState</i>	Set while in Motors on State. Otherwise, its reset.
<i>pmSystem_doMotorOn</i>	Set while in Motors on State. If the controller is in guard stop, the output starts pulsing with a frequency of 1 sec. If the controller is not calibrated or the revolution counter is not updated, the output will pulsate even faster in manual mode.
<i>pmSystem_doRunOk</i>	Run chain is closed.
<i>pmSystem_doEmStop</i>	Emergency stop state.
<i>pmSystem_doAutoOn</i>	Automatic mode is used.

Project handling

Overview

It is possible to start, halt, restart, stop, and supervise projects.

Default signals

The following default signals must be used for project handling:

Project signal	Description
<i>pmProject_goCurrent</i>	The current project.
<i>pmProject_goStatus</i>	The status of current project.

Continues on next page

7 Runtime operation

7.3.4 Extended I/O interface

Continued

Project signal	Description
<i>pmProject_diStop</i>	Stop current project.
<i>pmProject_diStart</i>	Start selected project.
<i>pmProject_giSelection</i>	Project selector.
<i>pmProject_diSetDefaultHeight</i>	Set default height for a work area.
<i>pmProject_giDefaultHeight</i>	Default height selector.
<i>pmProject_giDefHeightWaSel</i>	Work area selector for setting the default height.
<i>pmProject_diNoWait</i>	PickWare internal use.
<i>pmProject_diNoWait</i>	PickWare internal use.

Project status values

The current status of the project is reflected by the signal *pmProject_goStatus*.

I/O value	Description
0	Project is stopped.
1	Project is stopping.
2	Project is starting.
3	Project is running.
5	Project in error state.

Default height values

The following selections are supported when setting the default height.

I/O value	Description
0	Full
1	Latest
2	Empty
3	Value
4	Standard, that is, as configured in the Robot Path Height. See Robot path height on page 174 .

Starting a project for a single robot system

	Action
1	Ensure that the previous project is stopped, that is the signal <i>pmProject_goStatus</i> is 0.
2	Switch to motors on state using the controller system signals. See <i>Technical reference manual - System parameters</i> , the topic I/O.
3	Pulse the system input <i>pmSystem_diLoadStart1</i> to load and start the <i>PmProjMgr</i> module.
4	Wait until the robot program is started, that is when <i>pmSystem_doCycleOn</i> is set.
5	Set <i>pmProject_giSelection</i> to select the project to run. The I/O value for the project is set in the Project I/O value editor. See Project Manager on page 106 .
6	Pulse <i>pmProject_diStart</i> to start the project.

Continues on next page

	Action
7	Wait until the project has started, that is when <code>pmProject_goStatus</code> goes to 3.

Starting a project for a multimove system

If the used RobotWare version is older than 6.02, a few manual preparations are needed. A system input must be defined for all the ¹ motion tasks, having the following arguments:

Name	Value
Signal name	<code>pmSystem_diLoadX</code>
Action	Load
Argument1	<code>PmProjMgr.mod</code>
Argument2	<code>T_ROBX</code>
Argument3	N/A
Argument4	N/A

	Action
1	Ensure that the previous project is stopped, that is the signal <code>pmProject_goStatus</code> is 0.
2	Switch to motors on state using the controller system signals. For more information, see Topic I/O in Technical reference manual - System parameters .
3	Pulse the signal <code>pmSystem_diLoadX</code> , to load <code>PmProjMgr</code> module for motion task <code>T_ROBX</code> .
4	Wait until the module is loaded, that is when <code>pmSystem_doLoadReadyX</code> is set.
5	Repeat steps 3 and 4 for the next motion task (for example, <code>T_ROB2</code>) until all motion tasks are loaded.
6	Pulse the signal <code>pmSystem_diStart</code> , to start rapid execution for all motion tasks (this will also cause all <code>pmSystem_doLoadReadyX</code> to reset).
7	Wait until the robot programs has started, that is when <code>pmSystem_doCycleOn</code> is set.
8	Set <code>pmProject_giSelection</code> to select the project to run. The I/O value for the project is set in the Project I/O value editor. For more information, see Project Manager on page 106 .
9	Pulse <code>pmProject_diStart</code> to start the project.
10	Wait until the project is started, that is, when <code>pmProject_goStatus</code> is 3.

Stopping robot program - halting project

	Action
1	Pulse <code>pmSystem_diStop</code> to stop the robot program.
2	Wait until the robot program is stopped, which occurs when <code>pmSystem_doCycleOn</code> is reset.

¹ A system input is preconfigured for `T_ROB1`. This instance can be copied and modified to create system inputs for `T_ROB2`, `T_ROB3` and so on.

7 Runtime operation

7.3.4 Extended I/O interface

Continued

Restarting robot program - restarting project

	Action
1	Switch to motors on state using the controller system signals. See <i>Technical reference manual - System parameters</i> , the topic <i>I/O</i> .
2	Pulse <i>pmSystem_diStart</i> to start the robot program.
3	Wait until the robot program is started, which occurs when <i>pmSystem_doCycleOn</i> is set.

Stopping current project

	Action
1	Pulse <i>pmSystem_diStop</i> to stop the robot program.
2	Wait until the robot program is stopped, which occurs when <i>pmSystem_doCycleOn</i> is reset.
3	Pulse <i>pmProject_diStop</i> to stop the project.
4	Wait until project is stopped, which occurs when <i>pmProject_goStatus</i> goes to 0.

Set a new default height for a work area

Setting a new default height is a possibility to save cycle time without decreasing the margins for collisions, especially if the project consists of many work areas and flows.

For an outfeeder the default height can be set to *Empty* after a finished stack has been unloaded. This may allow the robot to make lower intermediate movements when passing over the outfeeder next time and thus saving cycle time.

For an infeder the default height can be set to *Full* before a new stack is loaded. This will force the robot to make intermediate movements with enough height when passing over the work area.

The new default height is active until new targets have been generated (or after a new default height is set).

	Action
1	Set <i>pmProject_giDefaultHeight</i> to select the new default height.
2	Set <i>pmProject_giDefHeightWaSel</i> to select the work area. The I/O value of the work area is configured in the <i>Work Area I/O Settings</i> editor. See Edit detailed signals for feeder on page 171 .
3	Pulse <i>pmProject_diSetDefaultHeight</i> .
4	Wait until the default height is updated, that is, the work area height state GO signal is updated to reflect the change. Note! If the current height state is 1, which means active height, the height state will not be updated until the last target of the current operation set is picked/placed.

Continues on next page

Flow handling

It is possible to start, stop, and supervise, and recover flows.

Default signals

The following default signals must be used for flow handling:

Flow signal	Description
<i>pmFlow_diStart</i>	Start selected flow.
<i>pmFlow_diStop</i>	Stop selected flow.
<i>pmFlow_diRecover</i>	Recover the selected flow with the selected recover action on the selected work area.
<i>pmFlow_giSelection</i>	Flow selector.
<i>pmFlow_giStopOption</i>	Set stop option.
<i>pmFlow_giRecoverAction</i>	Set recover action.
<i>pmFlow_giWaRecoverSelection</i>	Select work area for recover action.
<i>pmFlowX_goStatus</i>	Status of flow X (X=1,2,3,...).

Flow status values

The statuses of the flows are reflected by the *pmFlowX_goStatus* signals.

The status signal for the flow is setup in the **Flow editor**. See [Flow on page 197](#).

If a flow goes to error state, you can do flow recovery from the I/O Interface or the PickMaster FlexPendant interface.

I/O value	Description
0	Flow is stopped.
1	Flow is running.
2	Flow is stopping after current pick place cycle.
3	Flow is stopping after current layer.
4	Flow is stopping after current pallet/operation set.
5	Flow in error state.

Flow stop options

Stop option is specified with the signal *pmFlow_giStopOption*.

I/O value	Description
0	Stop immediately.
1	Finish cycle.
2	Finish layer.
3	Finish pallet/operation set.

Flow recover actions

A flow recover action is specified with the signal *pmFlow_giRecoverAction*.

I/O value	Description
1	Continue
2	Restart layer

Continues on next page

7 Runtime operation

7.3.4 Extended I/O interface

Continued

I/O value	Description
3	Terminate job/Next pallet
4	Redo last pick

Starting or restarting a flow

	Action
1	Ensure that current project is running. The <i>pmProject_goStatus</i> signal is set to 3.
2	Set <i>pmFlow_giSelection</i> to select flow. The I/O value for the flow is set in the Flow editor . See Flow on page 197 .
3	Pulse <i>pmFlow_diStart</i> to start the project.
4	Wait until the flow is started, which occurs when the flow's status signal, <i>pmFlowX_goStatus</i> , goes to 1.

Stopping a flow

Stopping the flow pause the execution of a running palletizing job. When the flow is restarted, the execution of the job will continue. A flow stop option can be selected to specify how and when the flow shall be stopped.

	Action
1	Set <i>pmFlow_giSelection</i> to select flow. The I/O value for the flow is set in the Flow editor . See Flow on page 197 .
2	Set <i>pmFlow_giStopOption</i> to select stop option.
3	Pulse <i>pmFlow_diStop</i> to stop the project.
4	For stop options 1-3, wait until the flow is stopped, which occurs when the flow's status signal, <i>pmFlowX_goStatus</i> , goes to 0. For stop option 0, wait until the flow changes to error state, which occurs when the flow's status signal goes to 5.

Stopping a flow immediately

When stopping a flow with stop option 0, it stops immediately, a flow recover action, for example *Continue*, must be specified before restarting the flow.

If this is the only running flow or if the robot is currently working on this flow, then the robot will also stop immediately. However, if multiple flows are running, the robot can continue working on the other flows.


To force a stop of the robot, this sequence can be preceded by a *Stopping robot program - halting project* action. This will require a *Restarting robot program - restarting project* action after selecting recover action and restarting the flow.

Recovering a flow

If a flow has entered error state, the *pmFlowX_goStatus* signal is set to 5. Use this procedure to recover the flow.

	Action
1	Set <i>pmFlow_giSelection</i> to select flow. The I/O value for the flow is configured in the Flow editor . See Flow on page 197 .
2	Set <i>pmFlow_giRecoverAction</i> to select recover action.

Continues on next page

Action	
3	<p>Set <i>pmFlow_giWaRecoverSelection</i> to select which work area the recover action shall be applied for.</p> <p>The signal must not be set for the recover actions <i>Continue</i> and <i>Redo last pick</i>. The selected work area must be included in the selected flow, normally the master work area is selected.</p> <p>The I/O value of the work area is configured in the Settings editor. For more details, see Events on page 157.</p>
4	Pulse <i>pmFlow_diRecover</i> to recover the flow.
5	<p>An elog message is logged from the PickMaster RAPID application. The message contains information on the expected state of the robot tool and work areas before restarting the flow (see PmSetRecoverAction - Set flow recover action on page 302).</p> <p>The flow is now prepared for being restarted.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;"></div> <div> <p>Note</p> <p>The error state of the flow indicated by <i>pmFlowX_goStatus</i> will not change until the flow is restarted.</p> </div> </div>

Stopping an infeeder

Stopping the robot from moving to an infeeder, that is a slave work area. The robot program will stop if the robot just has started a movement to the infeeder. In all other situations, the robot will continue to run all possible pick and place cycles that does not include the infeeder. If a flow comes to a point where it needs the infeeder in order to continue palletizing, the flow will stop in error state. But the robot may still continue to run pick and place cycles for other running flows. If the infeeder is redundant within a flow, that is there exists another infeeder that can supply the same units, the flow never stops (unless all redundant infeeders have been stopped).

Action	
1	Set <i>pmEvent_giErrorSource</i> to select the infeeder to be stopped. For more information to setup event signals for the robot controller, see Events on page 157 .
2	Pulse <i>pmEvent_diTrigger</i> to generate an error on the infeeder.
3	Wait until the infeeder is in error state, which occurs when the execution state signal, <i>pmInfeeder1_goExecState</i> goes to 2.



Note

A multiple selection of infeeders is possible as in the preceding sequence.

Restarting an infeeder

Restarting an infeeder that is stopped. The infeeder can be restarted when the flow is executing or from a state where flows have been forced to stop. Afterwards, the robot will be able to pick from the infeeder again.


Action	
1	Select a flow that has reached error state, that is <i>pmFlowX_goStatus</i> = 5, that needs a stopped infeeder. If there are no such flows, select any flow that uses the infeeder. Set <i>pmFlow_giSelection</i> to the selected flow. The I/O value for the flow is configured in the Flow editor. For more information, see Flow on page 197 .

Continues on next page

7 Runtime operation

7.3.4 Extended I/O interface

Continued

	Action
2	Set <code>pmFlow_giRecoverAction</code> to 1 (= Continue).
3	Set <code>pmFlow_giWaRecoverSelection</code> to select the infeed. The I/O value of the work area is configured in the Work Area I/O Settings editor. For more details, see Events on page 157 .
4	Pulse <code>pmFlow_diRecover</code> to set recover action for the flow.
5	Pulse <code>pmFlow_diStart</code> to apply the recover action and start the selected flow.
6	Wait until the flow is running, <code>pmFlowX_goStatus = 1</code> , and the infeed is running, <code>pmInfeeder1_goExecState = 1</code> .
	 Note The flow may stay in error state, if it uses another infeed that has been stopped. To get the flow running, a restart will be needed for that infeed too.
7	If there is another flow that has an error state that needs the previously stopped infeed, continue from Action 1 to restart the flow.



Note

While recovering a flow using other restart actions and work area selections than described above, all infeeders used by the flow will be restarted.

Event and error reporting

Default signals

It is possible to report events and errors for work areas, robots, and controllers that affect the runtime operation. See [Events on page 157](#).

The following default signals can be used for event and error reporting.

Signal	Description
<code>pmEvent_diTrigger</code>	Generate an event.
<code>pmEvent_giErrorSource</code>	Select error source(s).
<code>pmEvent_giMessage</code>	Select elog message.

Example, Report an error for a work area and log an elog message

	Action
1	Set the proper bit for <code>pmEvent_giErrorSource</code> to select a work area. The bit representing the work area is set in the Event settings tab of the Controller Properties . See Events on page 157 .
2	Set <code>pmEvent_giMessage</code> to select a message. Values that represent different messages are set in the Message Settings , see section Messages on page 160 .
3	Pulse <code>pmEvent_diTrigger</code> to generate the error and the elog message.
4	Wait until the work area enters error state, which occurs when the execution state signal of the work area, <code>pmFlowX_goExecState</code> , gets the value 2.

Continues on next page

Example, Log an elog message

Action	
1	Set the proper bit for <i>pmEvent_giErrorSource</i> to select a controller. The bit that represents the controller is set in the Event settings tab of the Controller Properties . See Events on page 157 .
2	Set <i>pmEvent_giMessage</i> to select a message. Values that represent different messages are set in the Message Settings , see section Messages on page 160
3	Pulse <i>pmEvent_diTrigger</i> to generate the elog message.

Robot tool

The control of the robot tool in runtime operation is integrated in the PickMaster RAPID interface and defined by the project configuration.

Available default signals for tools:

Signal	Description
<i>pmGripper1_goActivators</i>	Activators control
<i>pmGripper1_doActivator1Open</i>	Activator control
<i>pmGripper1_doActivator1Close</i>	Activator control
<i>pmGripper1_doActivator2Open</i>	Activator control
<i>pmGripper1_doActivator2Close</i>	Activator control
<i>pmGripper1_doActivator3Open</i>	Activator control
<i>pmGripper1_doActivator3Close</i>	Activator control
<i>pmGripper1_doActivator4Open</i>	Activator control
<i>pmGripper1_doActivator4Close</i>	Activator control
<i>pmGripper1_diActivator1Opened</i>	Activator status
<i>pmGripper1_diActivator1Closed</i>	Activator status
<i>pmGripper1_diActivator2Opened</i>	Activator status
<i>pmGripper1_diActivator2Closed</i>	Activator status
<i>pmGripper1_diActivator3Opened</i>	Activator status
<i>pmGripper1_diActivator3Closed</i>	Activator status
<i>pmGripper1_diActivator4Opened</i>	Activator status
<i>pmGripper1_diActivator4Closed</i>	Activator status
<i>pmGripper1_diPartCheck1</i>	Part check status
<i>pmGripper1_diPartCheck2</i>	Part check status
<i>pmGripper1_diPartCheck3</i>	Part check status
<i>pmGripper1_diPartCheck4</i>	Part check status
<i>pmGripper1_diPartCheck5</i>	Part check status
<i>pmGripper1_giPartCheck1</i>	Part check status
<i>pmGripper1_goSearchActivate</i>	Search tool activation.
<i>pmGripper1_diSearchStop</i>	Stack search stop trigger.
<i>pmGripper1_goToolEvent1</i>	GO tool event.

Continues on next page

7 Runtime operation

7.3.4 Extended I/O interface

Continued

Signal	Description
pmGripper1_goToolEvent2	GO tool event.
pmGripper1_goToolEvent3	GO tool event.
pmGripper1_goToolEvent4	GO tool event.
pmGripper1_goToolEvent5	GO tool event.
<i>pmGripper1_doToolEvent1</i>	DO tool event.
<i>pmGripper1_diToolEvent1</i>	DI tool event.
<i>pmGripper1_giToolEvent1</i>	GI tool event.
pmGripper1_giToolEvent2	
pmGripper1_giToolEvent3	GI tool event.
pmGripper1_giToolEvent4	GI tool event.
pmGripper1_giToolEvent5	GI tool event.

7.3.5 Timing diagrams for PLC communication

Introduction

Each timing diagram shows a basic example on the I/O communication between the robot controller and the PLC when running a PickMaster project. The individual updates of different I/O signals are shown related to important events of the palletizing process, for example when a pickup of a format has been completed.

The following events in the palletizing process can be found in the timing diagrams:

Event	Description
Operate infeed	The RAPID execution has executed the RAPID procedure <code>Operate</code> for the infeed.
Pick	The robot has reached the pick position and picked up a complete format in the tool.
Operate outfeed	The RAPID execution has executed the RAPID procedure <code>Operate</code> for the outfeed.
Place	The robot has reached the place position and placed a complete format on the work area.
Pallet pattern unloaded	A finished pallet pattern leaves the working range of the robot when being transferred from an outfeed.
Operation set complete	An operation set is complete when the robot has picked/placed the last product in a job/operation set and then departed from the last pick/place position. The <code>doOpSetComp1</code> signal is set a short time after the precedent pick/place event when the robot reaches the last depart target action.

See examples:

- [Example minimum process control on a running flow on page 276.](#)
- [Example robot execution control on page 277.](#)
- [Example height control of a running flow on page 278.](#)
- [Example flow control on page 279.](#)

Continues on next page

7 Runtime operation


7.3.5 Timing diagrams for PLC communication

Continued

Example minimum process control on a running flow

Task: Pick single items from infeeders and place pallet pattern with two items on outfeeder.

Settings: Early request, Use concurrency, non-pulsed controller mode.



en1000000195


- A Master outfeeder, process control
- B Master outfeeder, process status
- C Operate outfeeder
- D Place
- E Slave infeeder, process control
- F Slave infeeder, process status
- G Operate infeeder
- H Pick

Continues on next page

Example robot execution control

Task: Pick single items from infeeder and place pallet pattern with two items on outfeeder, control the robot access to work areas by using the robot execution signal.

Settings: Early request, Use concurrency, non-pulsed controller mode, default height *Full* on both infeeder and outfeeder.



en1000000198

- A** Master outfeeder, process control
- B** Master outfeeder, process status
- C** Operate outfeeder
- D** Place
- E** Slave infeeder, process control
- F** Slave infeeder, process status
- G** Operate infeeder
- H** Pick

Continues on next page

7 Runtime operation


7.3.5 Timing diagrams for PLC communication

Continued

Example height control of a running flow

Flow task: Pick single items from infeeder and place pallet pattern with two items on outfeeder. Control the height change of the outfeeder caused by unloading the pallet pattern to minimize the cycle time for other flows.

Settings: Early request, Use concurrency, non-pulsed controller mode, default height *Full* on infeeder and *Latest* on outfeeder.



en1000000202


- | | |
|---|--|
| A | Project control, process control |
| B | Pallet pattern unloaded from outfeeder |
| C | Master outfeeder, process control |
| D | Master outfeeder, process status |
| E | Operate outfeeder |
| F | Place |
| G | Slave infeeder, process control |
| H | Slave infeeder, process status |
| J | Operate infeeder |
| K | Pick |

Continues on next page

Example flow control

Task: Start a flow, pick single items from infeeder and place pallet pattern on outfeeder, control the robot access to work areas by using the robot execution signal, stop the flow with stop option finish cycle, cancel the rest of the job by resetting the robot execution signal from the outfeeder.

Settings: Early request, Use concurrency, non-pulsed controller mode, default height *Full* on both infeeder and outfeeder.



en1000000189

- A** Flow control, process control. In this example, the *giSelection* signal is constantly set to this flow.
- B** Master outfeeder, process control
- C** Master outfeeder, process status. In this example, the *goExecState* signal is constantly set to 1 (running).
- D** Operate outfeeder
- E** Place
- F** Slave infeeder, process control
- G** Slave infeeder, process status. In this example, the *goExecState* signal is constantly set to 1 (running).
- H** Operate infeeder
- J** Pick

This page is intentionally left blank

8 RAPID reference information

8.1 Introduction to RAPID reference information

Structure of this chapter

This chapter describes the RAPID instructions, functions, and data types that are specific for PickMaster.

8 RAPID reference information

8.2.1 PmAckTarget - Acknowledge a target

8.2 Instructions

8.2.1 PmAckTarget - Acknowledge a target

Usage

PmAckTarget is used to acknowledge a target.

Basic examples

```
IF status = OK THEN
  PmAckTarget Wa, Target, PM_ACK;
ELSE
  PmAckTarget Wa, Target, PM_NACK;
ENDIF
```

Arguments

PmAckTarget Wa Target Status

Wa

Data type: pm_wadescr

Contains a reference to a work area.

Target

Data type: pm_targetdata

The target that is acknowledged.

Status

Data type: pm_acktype

The acknowledge status.

Predefined data

The acknowledge status, used in argument *Status*, can be one of the following:

Constant	Description
PM_ACK	The target is acknowledged as used.
PM_NACK	The target is acknowledged as not used.
PM_LOST	If the target is acknowledged as lost.

Syntax

```
PmAckTarget
[ Wa ':' '=' ] < expression (IN) of pm_wadescr > ','
[ Target ':' '=' ] < expression (IN) of pm_targetdata > ','
[ Status ':' '=' ] < expression (IN) of pm_acktype > ';' 
```

Related information

For information about	See
The data type pm_wadescr	pm_wadescr - PickMaster work area reference on page 366.

Continues on next page

For information about	See
The data type <code>pm_targetdata</code>	<i>pm_targetdata - PickMaster target data on page 362.</i>
The data type <code>pm_acktype</code>	<i>pm_acktype - PickMaster target acknowledge type on page 332.</i>

8 RAPID reference information

8.2.2 PmCalcArmConf - Calculates the arm configuration

8.2.2 PmCalcArmConf - Calculates the arm configuration

Usage

PmCalcArmConf is used to calculate a suitable arm configuration for a **robtarg**, that is the **robconf** component of the **robtarg**. Some switches can be selected to optimize the resulting arm configuration, for example for a robot of a certain type. A maximum and minimum angle can be set up for one axis. The resulting arm configuration will also depend on the initial settings of **robconf**.

Basic example

```
PmCalcArmConf RobTgtPoint,TargetTool,TargetWobj\cf6\MaxAngle:=180
\MinAngle:=-180\SingAreaType:=Act.SingAreaType;
```

Arguments

```
PmCalcArmConf RobTgt Tool Wobj [\cf1] | [\cf4] | [\cf6] | [\TypeB1]
[\MaxAngle] [\MinAngle] [\SingAreatype]
```

RobTgt

Robot target

Data type: **robtarg**

The robot target whose arm configuration will be calculated.

Tool

Tool

Data type: **tooldata**

The tool used for calculation of the robot arm configuration.

Wobj

Work object

Data type: **wobjdata**

The work object (coordinate system) to which the robot position is related.

[\cf1]

Data type: **switch**

An arm configuration is calculated where the axis 1 angle is limited by the arguments **MaxAngle** and **MinAngle**. A solution closer to +45 degrees is preferred for axis 1. A solution close to the input arm configuration is preferred for the other axes.

[\cf4]

Data type: **switch**

An arm configuration is calculated where the axis 4 angle is limited by the arguments **MaxAngle** and **MinAngle**. A solution closer to +45 degrees is preferred for axis 4. A solution close to the input arm configuration is preferred for the other axes.

[\cf6]

Data type: **switch**

An arm configuration suitable for a 4 axes palletizer robot or a 6 axes bending backwards robot is calculated. The axis 6 angle is limited by the arguments

Continues on next page

`MaxAngle` and `MinAngle`. A solution closer to +45 degrees is preferred for axis 6. A solution close to the input arm configuration is preferred for the other axes.

[`\TypeB1`]

Data type: `switch`

An arm configuration suitable for a parallel rod robot is calculated. The axis 6 angle is limited by the arguments `MaxAngle` and `MinAngle`. A solution closer to +45 degrees is preferred for axis 6. A solution close to the input arm configuration is preferred for the other axes.

[`\MaxAngle`]

Maximum angle

Data type: `num`

Maximum angle allowed for one axis. Which axis is decided by the selection of `cf1`, `cf4`, `cf6` or `TypeB1`.

[`\MinAngle`]

Minimum angle

Data type: `num`

Minimum angle allowed for one axis. Which axis is decided by the selection of `cf1`, `cf4`, `cf6` or `TypeB1`.

[`\SingAreaType`]

Interpolation mode

Data type: `pm_singareatype`

Specifies the interpolation mode to be used with this `robtarg`. The argument is required to find a configuration with the `LockAx4` interpolation mode.

Error handling

The following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable `ERRNO` is set to:

Error code	Description
<code>PM_ERR_CALCCONF</code>	Failed to calculate arm configuration. A highly complex arm configuration may cause this error.
<code>PM_ERR_AXLIM</code>	Failed to calculate axis limit. The axis angle cannot be calculated due to angle limitations.
<code>PM_ERR_LIM_VALUE</code>	Wrong limitation value. The coordinate is not possible to calculate.

Syntax

Instruction

```
[ RobTgt ':' = ] < expression (INOUT) of robtarget > ','
[ Tool ':' = ] < expression (IN) of tooldata > ','
[ Wobj ':' = ] < expression (IN) of wobjdata >
[ '\ ' cf1 ] | [ '\ ' cf4 ] | [ '\ ' cf6 ] | [ '\ ' TypeB1 ]
[ '\ ' MaxAngle ':' = ] < expression (IN) of num > ]
[ '\ ' MinAngle ':' = ] < expression (IN) of num > ]
```

Continues on next page

8 RAPID reference information

8.2.2 PmCalcArmConf - Calculates the arm configuration

Continued

```
[ '\ ' SingAreaType ':= ' < expression (IN) of pm_singareatype > ]  
    ;'
```

Related information

For information about	See
The data type <code>confdata</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types</i> , section <i>Data types</i> .
The data type <code>robtarg</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types</i> , section <i>Data types</i> .

8.2.3 PmGetFlow - Get flow to execute

Usage

`PmGetFlow` is used to wait until any flow reports that it is ready to be executed. The instruction will return two work area references to the work areas that are ready to be executed within a flow. If several flows are ready to be executed, the process behind the instruction will return references of the highest prioritized flow. If the time-out time is not used, the instruction is blocking until any flow is ready to be executed.

Basic examples

A basic example of the instruction `PMGetFlow` is illustrated below.

```
PROC OperateSequence()
  PmGetFlow waInFeeder, waOutFeeder;
  Operate waInFeeder;
  Operate waOutFeeder;
ENDPROC
```

Arguments

```
PmGetFlow PickWa PlaceWa [\MaxTime] [\TimeFlag]
```

PickWa

Data type: `pm_wadescr`

Variable that is updated to refer to the pick work area of the flow that is ready to be executed.

PlaceWa

Data type: `pm_wadescr`

Variable that is updated to refer to the place work area of the flow that is ready to be executed.

[\MaxTime]

Maximum Time

Data type: `num`

The maximum period of permitted waiting time, expressed in seconds. If this time runs out before the condition is met, the error handler will be called if there is one, with the error code `PM_ERR_TIMEOUT`. If there is no error handler, the execution will be stopped.

[\TimeFlag]

Timeout Flag

Data type: `bool`

The output argument that contains the value `TRUE` if the maximum permitted waiting time runs out before the condition is met. If this argument is included in the instruction, it is not considered an error if the maximum time runs out. This argument is ignored if the `MaxTime` argument is not included in the instruction.

Continues on next page

8 RAPID reference information

8.2.3 PmGetFlow - Get flow to execute

Continued

Program execution

If the programmed condition is not met when executing a `PmGetFlow` instruction, the robot will wait and the time will be supervised. If it exceeds the maximum time value, the program will continue if a `TimeFlag` is specified, or generate an error if it is not specified. If a `TimeFlag` is specified, this will be set to `TRUE` if the time is exceeded, otherwise it will be set to `FALSE`.

More examples

More examples of how to use the instruction `PmGetFlow` are illustrated below.

```
PROC OperateSequence()  
  PmGetFlow waInFeeder, waOutFeeder \MaxTime:=6 \TimeFlag:=bTimeout;  
  IF NOT bTimeout THEN  
    Operate waInFeeder;  
    Operate waOutFeeder;  
  ELSE  
    p1 := CRobT(\Tool:=tool0 \WObj:=wobj0);  
    MoveL RelTool(p1,100,0,0), v100, fine, tool0;  
    MoveL p1, v100, fine, tool0;  
  ENDIF  
ENDPROC
```

Error handling

The following recoverable errors can be generated. The errors can be handled in an `ERROR` handler. The system variable `ERRNO` will be set to:

Error code	Description
PM_ERR_TIMEOUT	No flow was ready to be executed within the time-out time.

Syntax

```
PmGetFlow  
[ PickWa ':' ] < expression (VAR) of pm_wadescr > ','  
[ PlaceWa ':' ] < expression (VAR) of pm_wadescr >  
[ '\ ' MaxTime ':' < expression (IN) of num > ',' ]  
[ '\ ' TimeFlag ':' < variable (VAR) of bool > ] ';' 
```

Related information

For information about	See
The data type <code>pm_wadescr</code>	pm_wadescr - PickMaster work area reference on page 366
The Robot Flow Configuration	Flow on page 197

8.2.4 PmGetFlowInfo - Get information about a specific flow

Usage

PmGetFlowInfo gets information about a flow. The flow must be in the started project.

Basic examples

A basic example of the instruction PmGetFlowInfo is illustrated below.

```
TRAP TrapStartFlow
  VAR pm_flowinfo FlowInfo;
  VAR num FlowSelection;
  ! Get info from selected flow
  PmGetFlowInfo FlowSelection,FlowInfo;
ENDTRAP
```

Arguments

PmGetFlowInfo SelectionNumber | Name FlowInfo

SelectionNumber

Data type: num

The number that maps a specific flow with its signal value.

Name

Data type: string

The name of the flow in a started project.

FlowInfo

Data type: pm_flowinfo

Variable that holds the information about the flow.

Program execution

The program fails with a recoverable error if the flow cannot be found. All other errors are considered to be fatal.

More examples

Another example of how to use the instruction PmGetFlowInfo is illustrated below.

```
TRAP TrapStartFlow
  VAR pm_flowinfo FlowInfo;
  VAR num FlowSelection;
  FlowSelection:=1;
  ! Get info from selected flow
  PmGetFlowInfo FlowSelection,FlowInfo;
  ! Start the selected flow
  PmStartFlow FlowInfo.Name;
  TPWrite "Master work area = "+PmGetWaName (FlowInfo.MasterWa);
ERROR
  ! Continue supervision on recoverable errors
  IF ERRNO=PM_ERR_FLOW_NOT_FOUND THEN
    RETURN;
```

Continues on next page

8 RAPID reference information

8.2.4 PmGetFlowInfo - Get information about a specific flow

Continued

```
ENDIF  
ENDTRAP
```

Error handling

The following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable ERRNO will be set to:

Error code	Description
PM_ERR_FLOW_NOT_FOUND	No flow was found with this selection number or name.
PM_ERR_NO_RUNNING_PROJECT	No running project.

Syntax

```
PmGetFlowInfo  
  [SelectionNumber ':=' ] < expression (IN) of num > ','  
  |[Name ':=' ] < expression (IN) of string > ','  
  [FlowInfo ':=' ] < expression (VAR) of pm_flowinfo > ';' 
```

Related information

For information about	See
The data type pm_flowinfo	pm_flowinfo - PickMaster flow information on page 341.

8.2.5 PmGetLastWa - Get last used work area

Usage

PmGetLastWa gets the last used work area. The work area must previous have been set by the instruction PmSetLastWa.

Basic examples

A basic example of the instruction PmGetLastWa is illustrated below.

```
VAR pm_wadescr WorkArea;
! Get last used work area
PmGetLastWa WorkArea;
```

Arguments

PmGetLastWa Workarea

Workarea

Data type: pm_wadescr

A descriptor to the last set work area.

Program execution

All errors are considered to be fatal.

Syntax

```
PmGetLastWa
[Workarea ':=' ] < expression (VAR) of pm_wadescr > ';'

```

Related information

For information about	See
The data type pm_wadescr	pm_wadescr - PickMaster work area reference on page 366
The instruction PmSetLastWa	PmSetLastWa - Set last used work area on page 301
The instruction PmGetPathHeight	PmGetPathHeight - Get a safe path height for an intermediate movement on page 319

8 RAPID reference information

8.2.6 PmGetOperation - Get operation from a work area

8.2.6 PmGetOperation - Get operation from a work area

Usage

PmGetOperation is used to get operation data from a work area.

Basic example

```
PERS wobjdata wInfeeder2 := [FALSE,TRUE,"", [[2180.65,1430.22,-  
720.753], [0.00104,0.00130,0.00039,1.00000]],  
[[0,0,0],[1,0,0,0]]];  
VAR pm_wadescr PickWa;  
VAR pm_operationdata Op;  
PmGetWaByWobj wInfeeder2, PickWa;  
PmGetOperation PickWa, Op;
```

Get operation data for the work area using work object data wInfeeder2.

Arguments

PmGetOperation Wa Operation [\MaxTime] [\TimeFlag]

Wa

Data type: pm_wadescr

Contains a reference to a work area.

Operation

Data type: pm_operationdata

Operation data that is fetched from a work area.

[\MaxTime]

Maximum Time

Data type: num

The maximum period of waiting time permitted, expressed in seconds. If this time runs out before the condition is met, the error handler will be called, if there is one, with the error code PM_ERR_TIMEOUT. If there is no error handler, the execution will be stopped.

[\TimeFlag]

Timeout Flag

Data type: num

The output argument that contains the value TRUE if the maximum permitted waiting time runs out before the condition is met. If this argument is included in the instruction, it is not considered an error if the maximum time runs out. This argument is ignored if the MaxTime argument is not included in the instruction.

Error handling

The following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable ERRNO will be set to:

Error code	Description
PM_ERR_TIMEOUT	No pm_operationdata could be fetched within the time out time.

Continues on next page

Syntax

PmGetOperation

```
[ Wa ':' ] < expression (IN) of pm_wadescr > ','  
[ Operation ':' ] < expression (INOUT) of pm_operationdata >  
[ '\ ' MaxTime ':' < expression (IN) of num > ]  
[ '\ ' TimeFlag ':' < variable (VAR) of bool > ] ';' 
```

Related information

For information about	See
The data type <code>pm_wadescr</code>	pm_wadescr - PickMaster work area reference on page 366.
The data type <code>pm_operationdata</code>	pm_operationdata - PickMaster operation data on page 348.

8 RAPID reference information

8.2.7 PmGetProjectInfo - Get information about a specific project

8.2.7 PmGetProjectInfo - Get information about a specific project

Usage

`PmGetProjectInfo` gets information about a project. The project must be transferred to the controller.

Basic examples

A basic example of the instruction `PmGetProjectInfo` is illustrated below.

```
PROC main()  
  ! Get info from select project  
  PmGetProjectInfo ProjectSelection, ProjInfo;  
ENDPROC
```

Arguments

`PmGetProjectInfo SelectionNumber | Name ProjectInfo`

SelectionNumber

Data type: `num`

The number that maps a transferred project with its signal value. See [Project Manager on page 106](#).

Name

Data type: `string`

The name of a transferred project.

ProjectInfo

Data type: `pm_projectinfo`

Variable that holds the information about the project.

Program execution

The program will fail with a recoverable error if the project cannot be found. All other errors are considered to be fatal.

More examples

Another example of how to use the instruction `PMGetProjectInfo` is illustrated below.

```
PROC main()  
  VAR pm_projectinfo ProjInfo;  
  VAR num ProjectSelection;  
  ! Wait for start project order from PLC  
  WaitDI pmProject_diStart, 1;  
  ! Check which project to be started  
  ProjectSelection := pmProject_giSelection;  
  ! Get info from select project  
  PmGetProjectInfo ProjectSelection, ProjInfo;  
  ! Start the selected project  
  PmStartProj ProjInfo.Name;
```

Continues on next page

8.2.7 PmGetProjectInfo - Get information about a specific project

Continued

```

WHILE TRUE DO
    ! Execute the main routine in the selected project.
    %"PmMain:Main"%;
ENDWHILE
ERROR
IF ERRNO=PM_ERR_PROJ_NOT_FOUND THEN
    ! There is no project mapped to the selection value
    TRYNEXT;
ENDIF
ENDPROC

```

Error handling

The following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable `ERRNO` will be set to:

Error code	Description
PM_ERR_PROJ_NOT_FOUND	No project was found with this selection number or name.

Syntax

```

PmGetProjectInfo
[SelectionNumber ':= ' ] < expression (IN) of num> ','
| [Name ':= ' ] < expression (IN) of string> ','
[ProjectInfo ':= ' ] < expression (VAR) of pm_projectinfo> ';'

```

Related information

For information about	See
The data type <code>pm_projectinfo</code>	pm_projectinfo - PickMaster project information on page 351.

8 RAPID reference information

8.2.8 PmGetWaByWobj - Get a reference to a work area using a work object data

8.2.8 PmGetWaByWobj - Get a reference to a work area using a work object data

Usage

PmGetWaByWobj gets the reference for a specified work area.

The arguments to the instruction is the work object data, that is to be connected to the work area, and the pm_wadescr.

Basic example

```
PERS wobjdata wInfeeder1 := [FALSE,TRUE,"",[2180.65,1430.22,-
220.753], [0.00104,-
0.00130,0.00039,1.00000]],[[0,0,0],[1,0,0,0]]];
VAR pm_wadescr PickWa;
PmGetWaByWobj wInfeeder1, PickWa;
```

Arguments

PmGetWaByWobj WObj Wa

WObj

Work Object

Data type: wobjdata

The work object data that should be searched for in all work areas.

Wa

Data type: pm_wadescr

Variable that is updated to refer to the work area that corresponds to the provided work object.

Error handling

The following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable ERRNO will be set to:

Error code	Description
PM_ERR_WOBJ	No work area has reference to the work object data used.

Syntax

```
PmGetWaByWobj
[ Wobj ':'= ' ] < persistent (PERS) of wobjdata > ','
[ Wa ':'= ' ] < expression (INOUT) of pm_wadescr > ';'

```

Related information

For information about	See
The data type pm_wadescr	pm_wadescr - PickMaster work area reference on page 366
The data type wobjdata	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Data types</i>

8.2.9 PmGetWaInfo - Get information about a specific work area

Usage

PmGetWaInfo gets information about a work area. The work area must be in the started project. This information can be used in an external user interface or as a way to get a work area descriptor from a selection number. .

Basic examples

Basic examples of the instruction **PmGetWaInfo** are illustrated below.

```
VAR pm_wainfo WaInfo;
VAR num WaSelection:=1;
! Get info from selected Work Area
PmGetWaInfo WaSelection,WaInfo;
```

Arguments

PmGetWaInfo SelectionNumber | WorkArea FlowInfo

SelectionNumber

Data type: num

The number that maps a specific work area with its signal value.

WorkArea

Data type: pm_wadescr

A valid descriptor in a started project. The descriptor could be collected from **PmGetFlow** or **PmGetWaByWobj**.

FlowInfo

Data type: pm_wainfo

Variable that holds the information about the work area.

Program execution

The program will fail with a recoverable error if the work area cannot be found. All other errors are considered to be fatal.

Error handling

The following recoverable errors can be generated. The errors can be handled in an **ERROR** handler. The system variable **ERRNO** will be set to:

Error code	Description
PM_ERR_WA_NOT_FOUND	No work area was found with this selection number or name.
PM_ERR_NO_RUNNING_PROJECT	No running project.

Syntax

```
PmGetWaInfo
[SelectionNumber ':= ' ] < expression (IN) of num > ','
|[Workarea ':= ' ] < expression (VAR) of pm_wadescr > ','
[WaInfo ':= ' ] < expression (VAR) of pm_wainfo > ';'

```

Continues on next page

8 RAPID reference information

8.2.9 PmGetWalInfo - Get information about a specific work area

Continued

Related information

For information about	See
The data type <code>pm_wainfo</code>	<i>pm_wainfo - PickMaster Work Area information on page 367</i>
The data type <code>pm_wadescr</code>	<i>pm_wadescr - PickMaster work area reference on page 366</i>
The instruction <code>PmGetFlow</code>	<i>PmGetFlow - Get flow to execute on page 287</i>
The instruction <code>PmGetWaByWobj</code>	<i>PmGetWaByWobj - Get a reference to a work area using a work object data on page 296</i>

8.2.10 PmSearchAdjust - Adjust number of remaining layers

Usage

`PmSearchAdjust` is used after a stack search to adjust the number of remaining layers in a pallet pattern. It also updates the search frame to improve the picking accuracy for a pallet pattern or format.

Basic examples

Basic examples of the instruction `PmSearchAdjust` are illustrated below.

Example 1

```
VAR pm_wadescr PickWa;
VAR num PalletPatternHeightZ:=1097;
PmSearchAdjust PickWa, PM_SEARCH_Z, PalletPatternHeightZ;
```

A pallet pattern available at the specified work area is updated in the z-direction of the work object. The detected height of the pallet pattern is 1097 mm.

Example 2

```
VAR pm_wadescr PickWa;
VAR num FormatHeightZ:=154;
PmSearchAdjust PickWa, PM_SEARCH_Z, FormatHeightZ;
```

A format available at the specified work area is updated in the z-direction of the work object. The detected height of the format is 154 mm.

Arguments

`PmSearchAdjust Workarea SearchType SearchPos`

WorkArea

Data type: `pm_wadescr`

Contains a reference to a work area.

SearchType

Data type: `pm_searchtype`

Represents an integer with a symbolic constant for different types of searches.

SearchPos

Search Position

Data type: `num`

The detected size in mm of the pallet pattern or format. The size is expressed relative the work object.

Error handling

The following recoverable error can be generated. The errors can be handled in an error handler. The system variable `ERRNO` will be set to:

Error code	Description
<code>PM_ERR_PALLET_REDUCED</code>	A number of layers were removed since the detected stack height was lower (at least half the product height lower) than expected. The error is recovered through acknowledge of the search target and fetching next operation.

Continues on next page

8 RAPID reference information

8.2.10 PmSearchAdjust - Adjust number of remaining layers

Continued

Error code	Description
PM_ERR_PALLET_EMPTY	The detected height of the pallet pattern or format indicates missing parts. The error is recovered through acknowledge of the search target, trigger the Redo Search signal for the work area and fetching next operation.

Limitations

The instruction may only be used after an action containing a `SearchL` movement has been fetched with `PmGetTgtAction` and before the corresponding target has been acknowledged.

Predefined data

The search type, used in argument `SearchType` can be one of the following:

Constant	Value	Description
PM_SEARCH_X	0	Search was performed in the x direction of the work object.
PM_SEARCH_Y	1	Search was performed in the y direction of the work object.
PM_SEARCH_Z	2	Search was performed in the z direction of the work object.

Syntax

```
PmSearchAdjust
[ WorkArea ':= ' ] < expression (IN) of pm_wadescr > ', '
[ SearchType ':= ' ] < expression (IN) of pm_searchtype > ', '
[ SearchPos ':= ' ] < expression (IN) of num > ';' ;
```

Related information

For information about	See
Stack search	Stack search on page 189.
Format frame versus work object in format operation set	Format frame versus work object in format operation set on page 382.
Pallet pattern versus work object in pallet pattern operation set	Pallet pattern frame versus work object in pallet pattern operation set on page 384.
The data type <code>pm_wadescr</code>	pm_wadescr - PickMaster work area reference on page 366.
The data type <code>pm_searchtype</code>	pm_searchtype - PickMaster stack search type on page 357.

8.2.11 PmSetLastWa - Set last used work area

Usage

PmSetLastWa sets the last used work area. Use the instruction PmGetLastWa to get the work area.

Basic examples

Basic examples of the instruction instruction are illustrated below.

```
VAR pm_wadescr WorkArea;
! Set last used work area
PmSetLastWa WorkArea;
```

Arguments

PmSetLastWa Workarea

Workarea

Data type: pm_wadescr

A descriptor to the last used work area.

Program execution

All errors are considered to be fatal.

Syntax

```
PmSetLastWa
[Workarea ':= ' ] < expression (VAR) of pm_wadescr > ';'

```

Related information

For information about	See
The data type pm_wadescr	pm_wadescr - PickMaster work area reference on page 366
The instruction PmGetLastWa	PmGetLastWa - Get last used work area on page 291
The instruction PmGetPathHeight	PmGetPathHeight - Get a safe path height for an intermediate movement on page 319

8 RAPID reference information

8.2.12 PmSetRecoverAction - Set flow recover action

8.2.12 PmSetRecoverAction - Set flow recover action

Usage

`PmSetRecoverAction` sets flow recover action before starting a flow in error state. This instruction must be used before starting a flow with use of the IO interface if the flow is in error state. The instruction also returns information that can be used in an event log message. This message describes circumstances for restarting with selected recover action.

Basic examples

Basic examples of the instruction `PmSetRecoverAction` are illustrated below.

```
VAR pm_flowinfo FlowInfo;  
PmSetRecoverAction FlowInfo.Name, PM_RECOVER_REDO_LAST_PICK;
```

Arguments

```
PmSetRecoverAction Name \WorkArea RecoverAction \EventId \Argument1  
                  \Argument2 \Argument3 \Argument4
```

Name

Data type: string

The name of the flow to set recover action on.

WorkArea

Data type: pm_wadescr

The work area to perform recover action on. This is mandatory if using recover action Restart layer or Terminate job/Next pallet, where it is recommended to select the master work area. This is not required for recover action Continue and Redo last pick.

RecoverAction

Data type: num

The recover action that is performed at next flow start.

[\EventId]

Data type: num

The event message number in process domain that creates a message for the chosen recover action.

[\Argument1]

Data type: errstr

The first argument to the event log message, one space if not used.

[\Argument2]

Data type: errstr

The sencond argument to the event log message, one space if not used.

[\Argument3]

Data type: errstr

Continues on next page

The third argument to the event log message, one space if not used.

[\Argument4]

Data type: `errstr`

The fourth argument to the event log message, one space if not used.

Program execution

The program will fail with a recoverable error with recover action:

- `PM_RECOVER_REDO_LAYER` or `PM_RECOVER_NEXT_PALLET` without a valid work area.
- A recover action not in range.
- `PM_RECOVER_REDO_LAST_PICK` when nothing is picked.

All other errors are considered to be fatal.

Error handling

The following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable `ERRNO` will be set to:

Error code	Description
<code>PM_ERR_WORKAREA_EXPECTED</code>	This recover action demands a work area.
<code>PM_ERR_NOT_VALID_RECOVER_ACTION</code>	The recover action is not one of the supported.
<code>PM_ERR_REDO_LAST_PICK_REJECTED</code>	The redo last pick recover action is rejected, no products picked.
<code>PM_ERR_NO_RUNNING_PROJECT</code>	No running project.

Predefined messages

There are predefined event messages in the process domain for describing what to do before the flow start with the chosen recover action.

```
<Message number="2393">
  Flow recover with redo last pick
  The Flow <Flow name> will redo last unfinished operation at next
    flow start.
  Verify that:
    The tool is empty
    Products from last operation are restored on <WorkArea name>
    The reason for the stop is solved.
</Message>
<Message number="2394">
  Flow recover with continue pick-place
  The Flow <Flow name> will restart from where it was stopped at
    next flow start. Verify that the fault causing the stop has
    been handled.
  Verify expected number of products:
    Tool: <Number of products>
    WorkArea name/Number of products/Layer number
    <WorkArea name/Number of products/Layer number>
    <WorkArea name/Number of products/Layer number>
```

Continues on next page

8 RAPID reference information

8.2.12 PmSetRecoverAction - Set flow recover action

Continued

```
<WorkArea name/Number of products/Layer number>
</Message>
<Message number="2395">
  Flow recover with restart layer
  The Flow <Flow name> will restart from beginning of layer <layer
    number> on WorkArea <WorkArea name> at next flow start.
  Verify that:
    The reason for the stop is solved
    The tool is empty
    Following WorkAreas are empty:
      <WorkArea name>
      <WorkArea name>
</Message>
<Message number="2396">
  Flow recover with next pallet
  The Flow <Flow name> will restart from beginning of next pallet
    on WorkArea <WorkArea name> at next flow start.
  Verify that:
    The reason for the stop is solved.
    The tool is empty
    Following WorkAreas are empty:
      <WorkArea name>
      <WorkArea name>
      <WorkArea name>
</Message>
<Message number="2397">
  Flow recover with redo last pick
  The Flow <Flow name> will redo last unfinished operation at next
    flow start.
  Verify that:
    The tool is empty
    New products can be supplied on <WorkArea name>
    The reason for the stop is solved.
</Message>
```

Predefined data

Constant	Value	Description
PM_RECOVER_CONTINUE_OPERATION	1	The pick-place operation will continue from where it was stopped.
PM_RECOVER_REDO_LAYER	2	The pick-place operation repeats last layer.
PM_RECOVER_NEXT_PALLET	3	The current job is terminated and the flow is prepared to continue with the next pallet.
PM_RECOVER_REDO_LAST_PICK	4	The pick-place operation repeats the last pick operation. This recover action is valid only when the robot has picked up items that has not been placed yet.

Continues on next page

Syntax

```
PmSetRecoverAction
[ Name ':' ] < expression (IN) of string > ','
[ '\ ' WorkArea ':' ] < expression (VAR) of pm_wadescr > ','
[ RecoverAction ':' ] < expression (IN) of num > ','
[ '\ ' EventId ':' ] < expression (IN) of num > ','
[ '\ ' Argument1 ':' ] < expression (VAR) of errstr > ','
[ '\ ' Argument2 ':' ] < expression (VAR) of errstr > ','
[ '\ ' Argument3 ':' ] < expression (VAR) of errstr > ','
[ '\ ' Argument4 ':' ] < expression (VAR) of errstr > ';'

```

Related information

For information about	See
The instruction PmStartFlow	PmStartFlow - Starts a specific flow on page 306

8 RAPID reference information

8.2.13 PmStartFlow - Starts a specific flow

8.2.13 PmStartFlow - Starts a specific flow

Usage

`PmStartFlow` starts a flow. The flow must be in the started project.

Basic examples

A basic example of the instruction `PmStartFlow` is illustrated below.

```
TRAP TrapStartFlow
  VAR pm_flowinfo FlowInfo;
  VAR num FlowSelection;
  ! Get info from selected flow
  PmGetFlowInfo FlowSelection,FlowInfo;
  ! Start the selected flow
  PmStartFlow FlowInfo.Name;
ENDTRAP
```

Arguments

`PmStartFlow` Name

Name

Data type: string

Variable that refers to a flow in a started project.

Program execution

The program will fail with a recoverable error if no project is running. All other errors are considered to be fatal, such as wrong flow name.

Error handling

The following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable `ERRNO` will be set to:

Error code	Description
PM_ERR_NO_RUNNING_PROJECT	No running project.
PM_ERR_WRONG_FLOW_STATE	Starting a flow in error state without setting a recover action.

Predefined data

There are predefined constants for the flow status. The constants are used for setting values on flow status signals, configured in flow editor. See [Flow on page 197](#).

Constant	Value	Description
PM_FLOW_STOPPED	0	The flow is stopped
PM_FLOW_RUNNING	1	The flow is running
PM_FLOW_STOPPING_AFTER_CYCLE	2	The flow is stopping after current cycle is finished
PM_FLOW_STOPPING_AFTER_LAYER	3	The flow is stopping after current layer is finished

Continues on next page

Constant	Value	Description
PM_FLOW_STOPPING_AFTER_PALLET	4	The flow is stopping after current pallet is finished
PM_FLOW_ERROR	5	The flow is in error state

Syntax

```
PmStartFlow  
    [FlowSelector ':'= ' ] < expression (IN) of string > ';' 
```

Related information

For information about	See
The instruction <code>PmGetFlowInfo</code>	PmGetFlowInfo - Get information about a specific flow on page 289.
The instruction <code>PmStopFlow</code>	PmStopFlow - Stop a specific flow on page 309.
The instruction <code>PmSetRecoverAction</code>	PmSetRecoverAction - Set flow recover action on page 302
The data type <code>pm_flowinfo</code>	pm_flowinfo - PickMaster flow information on page 341.

8 RAPID reference information

8.2.14 PmStartProj - Start a PickMaster project

8.2.14 PmStartProj - Start a PickMaster project

Usage

PmStartProj starts a PickMaster project. When this instruction is executed, the project setup is read and all PickMaster internal parts of the project are initialized. The time of execution depends on the size of the project.

Basic example

```
PmStartProj "MyPMProj";  
IF PM_PROJECT_STATUS=PM_PROJECT_STARTING THEN  
  WaitUntil PM_PROJECT_STATUS=PM_PROJECT_RUNNING;  
ENDIF
```

Arguments

PmStartProj Name [**\Signal**]

Name

Data type: string

The name of the project to start.

[**\Signal**]

Data type: signalgo

The signal that shows the status of the project.

Predefined data

There are predefined constants for the status of the project. Those constants are used for setting values on Signal (project status signal) and the installed persistent variable **PM_PROJECT_STATUS**. **PM_PROJECT_STATUS** can be accessed from RAPID program.

Constant	Value	Description
PM_PROJECT_STOPPED	0	The project is stopped.
PM_PROJECT_STOPPING	1	The project is about to stop.
PM_PROJECT_STARTING	2	The project is starting up.
PM_PROJECT_RUNNING	3	The project is running.
PM_PROJECT_ERROR	4	The project is in error state.

Syntax

```
PmStartProj  
  [ Name ':= ' ] < expression (IN) of string > ','  
  [ '\ ' Signal ':= ' ] < expression (VAR) of signalgo > ';' 
```

Related information

For information about	See
The instruction PmStopProj .	PmStopProj - Stop current project on page 311.

8.2.15 PmStopFlow - Stop a specific flow

Usage

PmStopFlow stops a flow. The flow must be in the started project.

Basic examples

A basic example of the instruction PmStopFlow is illustrated below.

```
TRAP TrapStopFlow
  VAR pm_flowinfo FlowInfo;
  VAR num FlowSelection;
  VAR num StopOption;
  ! Get info from selected flow
  PmGetFlowInfo FlowSelection,FlowInfo;
  ! Stop the selected flow
  PmStopFlow FlowInfo.Name, StopOption;
ENDTRAP
```

Arguments

PmStopFlow Name StopOption

Name

Data type: string

Variable that refers to a flow in a started project.

StopOption

Data type: num

Variable that specifies different stop behavior.

Program execution

The program will fail with a recoverable error if no project is running. All other errors are considered to be fatal, such as wrong flow name or wrong value on StopOption.

Error handling

The following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable `ERRNO` will be set to:

Error code	Description
PM_ERR_NO_RUNNING_PROJECT	No running project.
PM_ERR_INVALID_FLOW_STOP_OPTION	Invalid stop option.

Continues on next page

8 RAPID reference information

8.2.15 PmStopFlow - Stop a specific flow

Continued

Predefined data

Flow status constants

There following constants are predefined for the status of the flow. Use the constants to set values on flow status signal, configured in flow I/O settings editor. See [Flow on page 197](#).

Constant	Value	Description
PM_FLOW_STOPPED	0	The flow is stopped
PM_FLOW_RUNNING	1	The flow is running
PM_FLOW_STOPPING_AFTER_CYCLE	2	The flow is stopping after current cycle is finished
PM_FLOW_STOPPING_AFTER_LAYER	3	The flow is stopping after current layer is finished
PM_FLOW_STOPPING_AFTER_PALLET	4	The flow is stopping after current pallet is finished
PM_FLOW_ERROR	5	The flow is in error state

StopOption constants

The following constants are predefined for StopOption.

Constant	Value	Description
PM_FLOW_STOP_IMMEDIATELY	0	The flow will stop immediately and a flow recovery action must be selected before restarting
PM_FLOW_FINISH_CYCLE	1	The flow will finish current cycle before stopping
PM_FLOW_FINISH_LAYER	2	The flow will finish current layer before stopping
PM_FLOW_FINISH_PALLET	3	The flow will finish current pallet before stopping

Syntax

```
PmStopFlow
  [Name ':=' ] < expression (IN) of string > ','
  [StopOption ':=' ] < expression (IN) of num > ';'

```

Related information

For information about	See
The instruction PmGetFlowInfo	PmGetProjectInfo - Get information about a specific project on page 294.
The instruction PmStartFlow	PmStartFlow - Starts a specific flow on page 306.
The data type pm_flowinfo	pm_flowinfo - PickMaster flow information on page 341.

8.2.16 PmStopProj - Stop current project

Usage

PmStopProj stops the active PickMaster project.

Basic example

```
PmStopProj;
```

Syntax

```
PmStopProj;
```

Related information

For information about	See
The instruction PmStartProj	PmStartProj - Start a PickMaster project on page 308.

8 RAPID reference information

8.2.17 PmWaitProjStart - Wait for any active project

8.2.17 PmWaitProjStart - Wait for any active project

Usage

PmWaitProjStart is used to wait until any project is running. The instruction can be used with a timeout; the instruction then waits the timeout time before giving the answer. The instruction is blocking until any project is started from any client.

Basic example

```
PmWaitProjStart \MaxTime := 5;
```

Check if project is started. If not, wait 5 seconds to see if the project is started during that time.

Arguments

```
PmWaitProjStart [\MaxTime] [\TimeFlag]
```

[\MaxTime]

Maximum Time

Data type: num

The maximum period of waiting time permitted, expressed in seconds. If this time runs out before the condition is met, the error handler will be called, if there is one, with the error code PM_ERR_TIMEOUT. If there is no error handler, the execution will be stopped.

[\TimeFlag]

Timeout Flag

Data type: bool

The output argument that contains the value TRUE if the maximum permitted waiting time runs out before the condition is met. If this argument is included in the instruction, it is not considered an error if the maximum time runs out. This argument is ignored if the `MaxTime` argument is not included in the instruction.

Error handling

The following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable ERRNO will be set to:

Error code	Description
PM_ERR_TIMEOUT	The project was not started within the time out time

Syntax

```
PmWaitProjStart  
[ '\ ' MaxTime ' := ' < expression (IN) of num > ]  
[ '\ ' TimeFlag ' := ' < variable (VAR) of bool > ' ; '
```

Related information

For information about	See
The instruction <code>PmStartProj</code>	PmStartProj - Start a PickMaster project on page 308.

8.3 Functions

8.3.1 PmCalcIntermid - Calculate intermediate position

Usage

This function calculates an intermediate position between two targets. If no limitations are set, the calculated position is a part of all axis movements.

Basic example

```
InterMid:=PmCalcIntermid(p10, tool2, wobj2, p20, tool1, wobj1, 0.4
    \MaxAngle:=180 \MinAngle:= -180 \AngleLimAx6 \MaxY:=2200
    \MinY:=-2200 \MinZ:=670 \FromWa:= LastWorkArea
    \ToWa:=WorkArea);
MoveJ InterMid,v1000,z200,tool0\Wobj:=wobj0;
```

Return value

Data type: robtarget

The function will return a robtarget expressed in wobj0 and tool0.

Arguments

```
PmCalcIntermid (StartRobTgt StartTool StartWobj EndRobTgt EndTool
    EndWobj InterMidPart [\MaxAngle] [\MinAngle] [\AngleLimAx1]
    | [\AngleLimAx4] | [\AngleLimAx6] [\MaxX] [\MinX] [\MaxY]
    [\MinY] [\MaxZ] [\MinZ] [\MaxRadius] [\MinRadius] [\FromWa]
    [\ToWa] [\LimitRobBase] | [\LimitWorld])
```

StartRobTgt

Data type: robtarget

The robot target from where the robot starts the move.

StartTool

Data type: tooldata

The tool that is used at the start point.

StartWobj

Data type: wobjdata

The work object that is used at the start point.

EndRobTgt

Data type: robtarget

The robot target where the move shall end.

EndTool

Data type: tooldata

The tool that is used at the end point.

EndWobj

Data type: wobjdata

The work object that is used at the end point.

Continues on next page

8 RAPID reference information

8.3.1 PmCalcIntermid - Calculate intermediate position

Continued

InterMidPart

Data type: num

The part of all the axis moves that is used as an intermediate position. If the intermediate position is in the middle of the start and end positions, the value shall be set to 0.5. The value must be between 0 and 1.

[\MaxAngle]

Data type: num

Maximum allowed axis angle on selected axis.

[\MinAngle]

Data type: num

Minimum allowed axis angle on selected axis.

[\AngleLimAx1]

Data type: num

Limit angle on axis 1.

[\AngleLimAx4]

Data type: num

Limit angle on axis 4.

[\AngleLimAx6]

Data type: num

Limit angle on axis 6.

[\MaxX]

Data type: num

Maximum allowed X-value on intermediate position.

[\MinX]

Data type: num

Minimum allowed X-value on intermediate position.

[\MaxY]

Data type: num

Maximum allowed Y-value on intermediate position.

[\MinY]

Data type: num

Minimum allowed Y-value on intermediate position.

[\MaxZ]

Data type: num

Maximum allowed Z-value on intermediate position.

[\MinZ]

Data type: num

Minimum allowed Z-value on intermediate position.

Continues on next page

[\MaxRadius]

Data type: num

Maximum allowed radius of the intermediate position in the XY plane.

**Note**If `MaxRadius` is specified, limitations on X and Y will not be considered.

[\MinRadius]

Data type: num

Minimum allowed radius of the intermediate position in the XY plane.

**Note**If `MinRadius` is specified, limitations on X and Y will not be considered.

[\LimitRobBase]

Data type: switch

Limitations on X, Y and Z are defined in the base frame of the robot.

[\LimitWorld]

Data type: switch

Limitations on X, Y and Z are defined in the world frame, that is, wobj0. If this switch is not selected, the limitations will be made in the robot base frame as default.

[\FromWa]

Data type: pm_wadescr

Reference to the work area the robot was operating before the intermediate movement. The presence of the reference will not affect the result of the function. The reference is only used to improve error handling of the function.

[\ToWa]

Data type: pm_wadescr

Reference to the next work area the robot will operate. The presence of the reference will not affect the result of the function. The reference is only used to improve error handling of the function.

Error handling

The following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable ERRNO will be set to:

Error code	Description
PM_ERR_CALCONF	Failed to calculate arm configuration. A highly complex arm configuration can cause this error.
PM_ERR_AXLIM	Failed to calculate axis limit. The axis angle cannot be calculated because of the angle limitations.
PM_ERR_LIM_VALUE	Wrong limitation value. The coordinate is not possible to calculate.

Continues on next page

8 RAPID reference information

8.3.1 PmCalcIntermid - Calculate intermediate position

Continued

Error code	Description
PM_ERR_PART_VAL	The value of the InterMidPart is not valid.

Syntax

```
PmCalcIntermid '('  
  [ StartRobTgt ':' ] < expression (IN) of robtarget > ','  
  [ StartTool ':' ] < expression (IN) of tooldata > ','  
  [ StartWobj ':' ] < expression (IN) of wobjdata > ','  
  [ EndRobTgt ':' ] < expression (IN) of robtarget > ','  
  [ EndTool ':' ] < expression (IN) of tooldata > ','  
  [ EndWobj ':' ] < expression (IN) of wobjdata > ','  
  [ InterMidPart ':' ] < expression (IN) of num >  
  [ '\\' MaxAngle ':' ] < expression (IN) of num >  
  [ '\\' MinAngle ':' ] < expression (IN) of num >  
  [ [ '\\' AngleLimAx1 ] | [ '\\' AngleLimAx4 ] | [ '\\' AngleLimAx6 ]  
    ]  
  [ '\\' MaxX := < expression (IN) of num > ]  
  [ '\\' MinX := < expression (IN) of num > ]  
  [ '\\' MaxY := < expression (IN) of num > ]  
  [ '\\' MinY := < expression (IN) of num > ]  
  [ '\\' MaxZ := < expression (IN) of num > ]  
  [ '\\' MinZ := < expression (IN) of num > ]  
  [ '\\' MaxRadius := < expression (IN) of num > ]  
  [ '\\' MinRadius := < expression (IN) of num > ]  
  [ '\\' FromWa := < expression (IN) of pm_wadescr > ]  
  [ '\\' ToWa := < expression (IN) of pm_wadescr > ]')'
```

A function with a return value of the data type robtarget.

8.3.2 PmGetEvent - Get events for an action

Usage

PmGetEvent is used to get an event for an action on a work area.

Basic examples

```

VAR pm_eventdata Event;
ArrSize := Dim(TriggArr,1);
WHILE PmGetEvent(Wa, Tgt.TargetHandle, Act.ActionHandle, Event)
  AND i <= ArrSize DO
  TEST Event.Type
  CASE PM_EVENT_PROC:
    TriggEquip TriggArr{i}, Event.Dist, Event.Time,
      \ProcID:=Event.ProcId, Event.Value;
  CASE PM_EVENT_DO:
    GetDataVal Event.SignalName,doSignal;
    TriggEquip TriggArr{i}, Event.Dist, Event.Time,
      \Dop:=doSignal, Event.Value;
  CASE PM_EVENT_GO:
    GetDataVal Event.SignalName,goSignal;
    TriggEquip TriggArr{i}, Event.Dist, Event.Time,
      \GOp:=goSignal, Event.Value;
  ENDTEST
  Incr i;
ENDWHILE
TEST Act.NumOfEvents
CASE 0:
  MoveL Tgt.RobTgtPoint, Act.Speed, Act.Zone, curr_Tool
    \WObj:=curr_WObj;
CASE 1:
  TriggL Tgt.RobTgtPoint, Act.Speed, TriggArr{1}, Act.Zone,
    curr_Tool \WObj:=curr_WObj;
ENDTEST

```

Return value

Data type: bool

The function will return TRUE as long as a new pm_eventdata can be delivered for the action handle.

Arguments

PmGetEvent (Wa TargetHandle ActionHandle Event)

Wa

Data type: pm_wadescr

Contains a reference to a work area.

TargetHandle

Data type: pm_targethandle

Contains a reference to a target.

Continues on next page

8 RAPID reference information

8.3.2 PmGetEvent - Get events for an action

Continued

ActionHandle

Data type: pm_actionhandle

Contains a reference to an action.

Event

Data type: pm_eventdata

Event data that is fetched from a work area.

Syntax

```
PmGetEvent '('  
  [ Wa ':' '=' ] < expression (IN) of pm_wadescr > ','  
  [ TargetHandle ':' '=' ] < expression (IN) of pm_targethandle > ','  
  [ ActionHandle ':' '=' ] < expression (IN) of pm_actionhandle > ','  
  [ Event ':' '=' ] < expression (INOUT) of pm_eventdata > ')'
```

A function with a return value of the data type bool.

Related information

For information about	See
The data type pm_wadescr	pm_wadescr - PickMaster work area reference on page 366.
The data type pm_targethandle	pm_targethandle - PickMaster target handle on page 365.
The data type pm_actionhandle	pm_actionhandle - PickMaster action handle on page 336.
The data type pm_eventdata	pm_eventdata - PickMaster event data on page 338.
The instruction TriggEquip	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Instructions.</i>
The instruction TriggL	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Instructions.</i>

8.3.3 PmGetPathHeight - Get a safe path height for an intermediate movement

8.3.3 PmGetPathHeight - Get a safe path height for an intermediate movement

Usage

PmGetPathHeight returns a safe lowest path height for an intermediate movement between two work areas. None, one or both of the work areas may be defined as the home position of the robot.

The function returns the maximum height in wobj0 (mm) of the two work areas and their intermediate work areas. The height of a work area is either the *active height* of the products or the *default height*, depending on the *height state* of the work area, see section [Height state \(GO\) on page 259](#). The home position does not have a height itself. The Safety offset is always added to the height of each work area.

The order of the work areas and the home position is defined in the **Feeder Order** tab, see section [Feeder order on page 159](#) in the line configuration. Intermediate work areas are defined as those having an order value between the order values of the two work areas. The default height is used for inactive work areas, for example empty or full work areas waiting for new targets to be generated. The default height can be adjusted in runtime, for example to indicate that a finished stack has been unloaded. See [PmSetDefaultHeight - Set the default height on page 322](#).

Basic examples

Basic examples of the function PmGetPathHeight are illustrated below.

```
VAR pm_wadescr waInFeeder;
VAR pm_wadescr waOutFeeder;
VAR num MinZ;
PmGetFlow waInFeeder,waOutFeeder;
! Calculate MinZ
MinZ:=PmGetPathHeight(waInFeeder,waOutFeeder);
```

Return value

Data type: num

The function returns the lowest safe path height expressed in wobj0.

Arguments

```
PmGetPathHeight (FromWa ToWa [\UseSafePosition] [\UseDefaultHeight])
```

FromWa

Data type: pm_wadescr

The work area from where the robot shall move. May also be selected as the home position, that is, a default installed work area connected to the predefined wobjdata pm_home_Wobj. See section [Procedure MoveHomePos on page 208](#).

ToWa

Data type: pm_wadescr

The work area the robot will move to. May also be selected as the home position, that is a default installed work area connected to the predefined wobjdata pm_home_Wobj. See section [Procedure MoveHomePos on page 208](#).

Continues on next page

8 RAPID reference information

8.3.3 PmGetPathHeight - Get a safe path height for an intermediate movement

Continued

[\UseSafePosition]

Data type: switch

Consider the heights of used safe positions for work areas having an active height. For more information on how to configure safe positions, see [Safe targets on page 173](#).

[\UseDefaultHeight]

Data type: switch

Consider the default heights for work areas having an active height. For more information on how to configure default height, see [Robot path height on page 174](#).

Program execution

All errors are considered to be fatal.

More examples

Example 1

```
PROC MoveInterMid(VAR pm_wadescr WorkArea, VAR pm_targetdata Tgt,
  VAR pm_actiondata Act,num SafetyHeight,\num MaxAngle,\num
  MinAngle,\switch MoveToEndPoint)
  CONST num InterMidPart1:=0.5;
  VAR robtargt InterMid1;
  VAR num MinZ;
  PmGetLastWa LastWorkArea;
  ! Calculate MinZ
  MinZ:=PmGetPathHeight(LastWorkArea,WorkArea\UseSafePosition)
    +Tgt.TargetTool.tframe.trans.z+SafetyHeight;
  ! Use the frame from tool0 and the load from target tool
  TempTool:=Tgt.TargetTool;
  TempTool.tframe:=tool0.tframe;! Travel distance: 50%
  InterMid1:=PmCalcIntermid(LastRobTgt,LastTool,LastWobj,
    Act.RobTgt,Tgt.TargetTool,Tgt.TargetWobj,
    InterMidPart1\MaxAngle?MaxAngle\MinAngle?MinAngle
    \AngleLimAx6\MinZ:=MinZ);
  MoveJ\Conc,InterMid1,Act.Speed,z200,TempTool\Wobj:=wobj0;
ENDPROC
```

Syntax

```
PmGetPathHeight
  [FromWa ':= ' ] < expression (VAR) of pm_wadescr > ','
  [ToWa ':= ' ] < expression (VAR) of pm_wadescr > ','
  [ '\ ' UseSafePosition ] ','
  [ '\ ' UseDefaultHeight ] ';;'
```

Related information

For information about	See
The data type pm_wadescr	pm_wadescr - PickMaster work area reference on page 366
The instruction PmSetLastWa	PmSetLastWa - Set last used work area on page 301

Continues on next page

8.3.3 PmGetPathHeight - Get a safe path height for an intermediate movement

Continued

For information about	See
The instruction <code>PmGetLastWa</code>	<i>PmGetLastWa - Get last used work area on page 291</i>

8 RAPID reference information

8.3.4 PmSetDefaultHeight - Set the default height

8.3.4 PmSetDefaultHeight - Set the default height

Usage

`PmSetDefaultHeight` updates the default height for a work area. It returns the new default height (mm). The height state GO signal of the work area is updated to reflect the change, see [Height state \(GO\) on page 259](#). The signal update occurs immediately if the work area does not have an active height.

Setting a new default height is a possibility to save cycle time without decreasing the margins for collisions, especially if the project consists of many work areas and flows.

For an outfeeder the default height can be set to *Empty* after a finished stack has been unloaded. This allows the robot to make lower intermediate movements when passing over the outfeeder next times and thus saving cycle time.

For an infeeder the default height can be set to *Full* before a new stack is loaded. This will force the robot to make intermediate movements with enough height when passing over the work area.

The new default height is active until new targets have been generated (or after new default height is set).

Basic examples

Basic examples of the function `PmSetDefaultHeight` are illustrated below.

Example 1

```
PERS wobjdata wobjOutfeeder :=  
[FALSE,TRUE,"",[[2180.65,-1430.22,-220.753],[0.00104,-0.00130,0.00039,1.00000]],[[0,0,0],  
[1,0,0,0]]];  
VAR pm_wadescr OutWa;  
VAR num NewDefHeight;  
PmGetWaByWobj wobjOutfeeder, OutWa;  
NewDefHeight:=PmSetDefaultHeight OutWa \Empty;
```

Example 2

```
PERS wobjdata wobjOutfeeder :=  
[FALSE,TRUE,"",[[2180.65,-1430.22,-220.753],[0.00104,-0.00130,0.00039,1.00000]],[[0,0,0],  
[1,0,0,0]]];  
VAR pm_wadescr OutWa;  
VAR num NewDefHeight;  
PmGetWaByWobj wobjOutfeeder, OutWa;  
NewDefHeight:=PmSetDefaultHeight OutWa \Value:=100;
```

Return value

Data type: num

The function returns the new default height.

Arguments

```
PmSetDefaultHeight (Workarea [\Standard] | [\Empty] | [\Full] |  
[\Latest] | [\Value])
```

Continues on next page

Workarea

Data type: pm_wadescr

The work area.

[\Standard]

Data type: switch

Set the default height as configured in the **Robot Path Height** see [Robot path height on page 174](#).

[\Empty]

Data type: switch

Set the default height to Empty.

[\Full]

Data type: switch

Set the default height to Full.

[\Latest]

Data type: switch

Set the default height to the height of the latest completed operation set.

[\Value]

Data type: num

Set the default height to a specified value (mm).



Note

The *Safety offset* defined in the **Robot Path Height** will always be added to the specified height.

8 RAPID reference information

8.3.5 PmGetTarget - Get target

8.3.5 PmGetTarget - Get target

Usage

PmGetTarget is used to get a target for an operation on a work area. If the optional argument `OpHandle` is left out, the function will return the next target without regard to the operation it belongs to.

Basic example

```
PmGetOperation Wa, Op;  
WHILE PmGetTarget(Wa, \OpHandle:=Op.OpHandle, Tgt) DO  
  WHILE PmGetTgtAction(Wa, Tgt.TargetHandle, Act) DO  
    ...  
  ENDWHILE  
ENDWHILE
```

Return value

Data type: bool

The function will return TRUE as long as a new `pm_targetdata` can be delivered.

Arguments

```
PmGetTarget (Wa [\OpHandle] Targets [\MaxTime] [\TimeFlag])
```

`Wa`

Data type: pm_wadescr

Contains a reference to a work area.

`[\OpHandle]`

Data type: pm_ophandle

Contains a reference for an operation on a work area.

`Target`

Data type: pm_targetdata

Target data that is fetched from a work area.

`[\MaxTime]`

Maximum Time

Data type: num

The maximum period of waiting time permitted, expressed in seconds. If this time runs out before the condition is met, the error handler will be called, if there is one, with the error code `PM_ERR_TIMEOUT`. If there is no error handler, the execution will be stopped.

`[\TimeFlag]`

Timeout Flag

Data type: bool

The output argument that contains the value TRUE if the maximum permitted waiting time runs out before the condition is met. If this argument is included in

Continues on next page

the instruction, it is not considered an error if the maximum time runs out. This argument is ignored if the `MaxTime` argument is not included in the instruction.

Error handling

Following recoverable errors can be generated. The errors can be handled in an ERROR handler. The system variable `ERRNO` will be set to:

Error code	Description
<code>PM_ERR_TIMEOUT</code>	No <code>pm_targetdata</code> could be fetched within the time out time.
<code>PM_ERR_OPERATION_LOST</code>	The <code>pm_operationdata</code> is not valid, probably because of a pulse on the robot execution signal.

Syntax

```
PmGetTarget '('
  [ Wa ':' < expression (IN) of pm_wadescr >
  [ '\ ' OpHandle ':' < expression (IN) of pm_ophandle > ] ', '
  [ Target ':' < expression (INOUT) of pm_targetdata >
  [ '\ ' MaxTime ':' < expression (IN) of num > ]
  [ '\ ' TimeFlag ':' < variable (VAR) of bool > ] ')'
```

A function with a return value of the data type `bool` name.

Related information

For information about	See
The data type <code>pm_wadescr</code>	pm_wadescr - PickMaster work area reference on page 366.
The data type <code>pm_ophandle</code>	pm_ophandle - PickMaster operation handle on page 350.
The data type <code>pm_targetdata</code>	pm_targetdata - PickMaster target data on page 362.

8 RAPID reference information

8.3.6 PmGetTgtAction - Get target action

8.3.6 PmGetTgtAction - Get target action

Usage

PmGetTgtAction is used to get an action for a target on a work area.

Basic examples

```
PmGetOperation Wa, Op;  
WHILE PmGetTarget(Wa \OpHandle:=Op.OpHandle, Tgt) DO  
  WHILE PmGetTgtAction(Wa, Tgt.TargetHandle, Act) DO  
    curr_WObj := Tgt.TargetWObj;  
    curr_Tool := Tgt.TargetTool;  
    MoveL Tgt.RobTgtPoint, Act.Speed, Act.Zone, curr_Tool  
      \WObj:=curr_WObj;  
  ENDWHILE  
ENDWHILE
```

Return value

Data type: bool

The function will return TRUE as long as a new pm_actiondata can be delivered for the target handle.

Arguments

PmGetTgtAction (Wa TargetHandle Action)

Wa

Data type: pm_wadescr

Contains a reference to a work area.

TargetHandle

Data type: pm_targethandle

Contains a reference to a target.

Action

Data type: pm_actiondata

Action data that is fetched from a work area.

Error handling

The following recoverable error can be generated. The error can be handled in an ERROR handler. The system variable ERRNO will be set to:

Error code	Description
PM_ERR_OPERATION_LOST	The pm_operationdata is not valid, probably because of a pulse on the robot execution signal.

Syntax

```
PmGetTgtAction '('  
  [ Wa ':=' ] < expression (IN) of pm_wadescr > ','  
  [ TargetHandle ':=' ] < expression (IN) of pm_targethandle > ','  
  [ Action ':=' ] < expression (INOUT) of pm_actiondata > ')'
```

Continues on next page

A function with a return value of the data type `bool` name.

Related information

For information about	See
The data type <code>pm_wadescr</code>	pm_wadescr - <i>PickMaster work area reference on page 366.</i>
The data type <code>pm_targethandle</code>	pm_targethandle - <i>PickMaster target handle on page 365.</i>
The data type <code>pm_actiondata</code>	pm_actiondata - <i>PickMaster action data on page 333.</i>

8 RAPID reference information

8.3.7 PmGetWaHeight - Get the height of a work area

8.3.7 PmGetWaHeight - Get the height of a work area

Usage

PmGetWaHeight gets the current stack height of a specified work area.

Basic examples

```
height := PmGetWaHeight (PickWa);
```

Return value

Data type: num

The function returns the current height of the specified work area in mm. The height is equivalent to the z-coordinate of the current top layer expressed in the work object. If the stack is empty, zero is returned.

Arguments

```
PmGetWaHeight (Wa [\UseSafePosition])
```

Wa

Data type: pm_wadescr

Contains a reference to a work area.

[\UseSafePosition]

Data type: switch

If UseSafePosition is set, the height is equivalent to the maximum z-coordinate of used safe positions and the current top layer expressed in the work object.

Syntax

```
PmGetWaHeight '('  
  [ Wa ':= ' ] < expression (IN) of pm_wadescr >')'
```

A function with a return value of the data type num.

Related information

For information about	See
The data type pm_wadescr	pm_wadescr - PickMaster work area reference on page 366.

8.3.8 PmGetWaName - Get the name of a work area

Usage

PmGetWaName gets the name of a specified work area.

Basic examples

A basic example of the function PmGetWaName is illustrated below.

```
VAR string waname;  
waname:=PmGetWaName(WorkArea);
```

Return value

Data type: string

The function will return the name of the work area.

Arguments

PmGetWaName (WorkArea)

WorkArea

Work Area

Data type: pm_wadescr

Contains a reference to a work area.

Syntax

```
PmGetWaName '('  
[ WorkArea ':= ' ] < expression (VAR) of pm_wadescr > ')'
```

A function with a return value of the data type string.

8 RAPID reference information

8.4.1 pm_accdata - PickMaster acceleration/deceleration data

8.4 Data types

8.4.1 pm_accdata - PickMaster acceleration/deceleration data

Usage

`pm_accdata` is used to describe and restrict accelerations and decelerations.

Description

`pm_accdata` is a part of `pm_actiondata` and is used as input arguments to the instructions `PathAccLim` and `AccSet`. It restricts the robots acceleration and deceleration.

Components

`acc`

acceleration

Data type: `num`

Acceleration and deceleration as a percentage of the normal values. 100% corresponds to maximum acceleration. Maximum value: 100%. Input value lower than 20% gives 20% of maximum acceleration.

Used as argument `Acc` in `AccSet`.

`ramp`

Data type: `num`

The rate at which acceleration and deceleration increases as a percentage of the normal values (see instruction `AccSet` for more information).

Used as argument `Ramp` in `AccSet`.

`acclim`

acceleration limit

Data type: `bool`

TRUE if there is to be a limitation of the acceleration, FALSE otherwise.

Used as argument `AccLim` in `PathAccLim`.

`accmax`

maximum acceleration

Data type: `num`

The absolute value of the acceleration limitation in m/s^2 .

Only used when `acclim` is TRUE.

Used as argument `AccMax` in `PathAccLim`.

`decelim`

deceleration limit

Data type: `bool`

TRUE if there is to be a limitation of the deceleration, FALSE otherwise.

Continues on next page

Used as argument DecelLim in PathAccLim.

decelmax

maximum deceleration

Data type: num

The absolute value of the deceleration limitation in m/s².

Used only when decellim is TRUE.

Used as argument DecelMax in PathAccLim.

Examples

```
VAR pm_actiondata Act;
VAR num my_accmax;
WHILE PmGetTgtAction(WorkArea, Tgt.TargetHandle, Act) DO
  my_accmax := Act.accel.accmax;
  ...
ENDWHILE
```

Limitations

The pm_accdata members can only be set by the instruction PmGetTgtAction.

Structure

```
< dataobject of pm_accdata >
  < acc of num >
  < ramp of num >
  < acclim of bool >
  < accmax of num >
  < decellim of bool >
  < decelmax of num >
```

Related information

For information about	See
The data type pm_actiondata	pm_actiondata - PickMaster action data on page 333.
The function PmGetTgtAction	PmGetTgtAction - Get target action on page 326.
The instruction PathAccLim	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Instructions.</i>
The instruction AccSet	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Instructions.</i>

8 RAPID reference information

8.4.2 pm_acktype - PickMaster target acknowledge type

8.4.2 pm_acktype - PickMaster target acknowledge type

Usage

`pm_acktype` is used to represent an integer with a symbolic constant for different types of acknowledgements.

Description

A `pm_acktype` is used to decide which type of acknowledgement should be used.

Example

```
PmAckTarget WorkArea, WorkArea, PM_ACK;
```

Predefined data

Constant	Value	Comment
PM_ACK	301	The target is acknowledged as used
PM_NACK	302	The target is acknowledged as not used
PM_LOST	303	The target is acknowledged as lost

Characteristics

`pm_acktype` is an alias data type for `num` and consequently inherits its characteristics.

Related information

For information about	See
The instruction <code>PmAckTarget</code>	PmAckTarget - Acknowledge a target on page 282.

8.4.3 pm_actiondata - PickMaster action data

Usage

pm_actiondata specifies an action for a target.

Description

Properties for one target action.

Components

RobTgt

Data type: robtarget

Specifies the position of the robot and external axes.

Type

Data type: pm_actiontype

Specifies type of action.

MoveType

Data type: pm_movetype

Specifies type of movement.

ArmConfMon

Data type: bool

Specifies if the robot's configuration is monitored during the movement.

UseConc

Use concurrent

Data type: bool

Specifies if concurrent program execution is used or not. See *Technical reference manual - RAPID Instructions, Functions and Data types*.

SingAreaType

Data type: pm_singareatype

Specifies type of interpolation mode.

Accel

Acceleration and deceleration data

Data type: pm_accdata

Restrict the robot's acceleration and deceleration.

Search

Data type: pm_searchdata

Defines search type, search stop type and search signal to be used with a search movement.

Speed

Data type: speeddata

Continues on next page

8 RAPID reference information

8.4.3 pm_actiondata - PickMaster action data

Continued

Specifies the movement speed. See *Technical reference manual - RAPID Instructions, Functions and Data types*.

Zone

Data type: zonedata

Specifies the corner path after the movement. See *Technical reference manual - RAPID Instructions, Functions and Data types*.

NumOfEvents

number of events

Data type: num

Specifies number of events.

ActionHandle

Data type: pm_actionhandle

A reference to the action where this pm_actiondata was retrieved.

Examples

```
VAR pm_actiondata Act;  
PmGetOperation WorkArea, Op;  
WHILE PmGetTarget(WorkArea \OpHandle:=Op.OpHandle, Tgt) DO  
  WHILE PmGetTgtAction(WorkArea, Tgt.TargetHandle, Act) DO  
    ...  
  ENDWHILE  
ENDWHILE
```

Limitations

The action data members can only be set by the instruction PmGetTgtAction.

Structure

```
< dataobject of pm_actiondata >  
  < RobTgt of targetdata >  
  < Type of pm_actiontype >  
  < MoveType of pm_movetype >  
  < ArmConfMon of bool >  
  < UseConc of bool >  
  < SingAreaType of pm_singareatype >  
  < Accel of pm_accddata >  
  < Search of pm_searchdata >  
  < Speed of speeddata >  
  < Zone of zonedata >  
  < NumOfEvents of num >  
  < ActionHandle of pm_actionhandle >
```

Related information

For information about	See
The data type pm_movetype	pm_movetype - PickMaster movement type on page 345.

Continues on next page

For information about	See
The data type pm_accdata	pm_accdata - PickMaster acceleration/deceleration data on page 330.
The data type pm_searchdata	pm_searchdata - PickMaster search data on page 355
The function PmGetTgtAction	PmGetTgtAction - Get target action on page 326.
The data type zonedata	Technical reference manual - RAPID Instructions, Functions and Data types, section Data types.
The data type speeddata	Technical reference manual - RAPID Instructions, Functions and Data types, section Data types
The instruction Confl	Technical reference manual - RAPID Instructions, Functions and Data types, section Instructions.
Concurrent program execution	Technical reference manual - RAPID overview, section Synchronisation with logical instructions.

8 RAPID reference information

8.4.4 pm_actionhandle - PickMaster action handle

8.4.4 pm_actionhandle - PickMaster action handle

Usage

`pm_actionhandle` is used to store data about a target action.

Description

Data of the type `pm_actionhandle` contains a reference to an action.

Examples

```
PmGetOperation WorkArea, Op;
WHILE PmGetTarget(WorkArea \OpHandle:=Op.OpHandle, Tgt) DO
  WHILE PmGetTgtAction(WorkArea, Tgt.TargetHandle, Act) DO
    WHILE PmGetEvent(WorkArea, Tgt.TargetHandle, Act.ActionHandle,
      Event) DO
      ...
    ENDWHILE
  ENDWHILE
ENDWHILE
```

Limitations

Describe the limitations for the data type. Names of data types are written in script-text.

Characteristics

`pm_actionhandle` is a non-value data type.

Related information

For information about	See
The data type <code>pm_actiondata</code>	pm_actiondata - PickMaster action data on page 333.
The function <code>PmGetTarget</code>	PmGetTarget - Get target on page 324.
The function <code>PmGetTgtAction</code>	PmGetTgtAction - Get target action on page 326.
The function <code>PmGetEvent</code>	PmGetEvent - Get events for an action on page 317.

8.4.5 pm_actiontype - PickMaster action type

Usage

`pm_actiontype` is used to represent an integer with a symbolic constant for different types of actions.

Description

A `pm_actiontype` is used to decide which payload should be used for the next movement.

Example

```
TEST Tgt.Type
CASE PM_APPROACH_POS:
  curr_Load := Tgt.AppProdsLoad;
CASE PM_TARGET_POS:
  curr_Load := Tgt.AppProdsLoad;
  curr_StopPoint:=Tgt.StopPointData;
CASE PM_DEPART_POS:
  curr_Load := Tgt.DepProdsLoad;
ENDTEST
GripLoad curr_Load;
```

Predefined data

Constant	Value	Comment
PM_APPROACH_POS	200	The action is a part of the approach movement
PM_TARGET_POS	201	The action moves to the target position
PM_DEPART_POS	202	The action is a part of the depart movement

Characteristics

`pm_actiontype` is an alias type for `num` and thus inherits its characteristics.

Related information

For information about	See
The data type <code>pm_actiondata</code>	pm_actiondata - PickMaster action data on page 333.
The instruction <code>GripLoad</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Instructions.</i>

8 RAPID reference information

8.4.6 pm_eventdata - PickMaster event data

8.4.6 pm_eventdata - PickMaster event data

Usage

`pm_eventdata` is used to specify an event.

Description

The components in `pm_eventdata` are used in the instruction `TriggEquip`. The different components decide what kind of trigg should be used for a specific action. For example, it describes when a Gripper should be closed or opened.

Components

`type`

event type

Data type: `pm_eventtype`

Type of event. Used to separate how to set up triggers with instruction `TriggEquip`. Types that are allowed are `PM_EVENT_PROC`, `PM_EVENT_DO`, and `PM_EVENT_GO`.

`time`

Data type: `num`

Input argument `EquipLag` in instruction `TriggEquip`.

`dist`

distance

Data type: `num`

Input argument `Distance` in instruction `TriggEquip`.

`procid`

process id

Data type: `num`

Input argument `ProcID` in instruction `TriggEquip`.

`signalname`

Data type: `string`

Input argument `DOP` or `GOP` in instruction `TriggEquip`.

`Atime`

Data type: `num`

Reserved for future use.

`value`

Data type: `num`

Input argument `SetValue` in instruction `TriggEquip`. Should not be used if a PickMaster project uses longer group signals than 23 bits.

`Dvalue`

Data type: `dnum`

Continues on next page

Input argument `SetDvalue` in instruction `TriggEquip`. Normally used instead of `value` since the numerical resolution is higher. Required for PickMaster projects using long group signals, that is longer than 23 bits and up to 32 bits.

Examples

```
VAR pm_eventdata Event;
ArrSize := Dim(TriggArr,1);
WHILE PmGetEvent(WorkArea, Tgt.TargetHandle, Act.ActionHandle,
  Event) AND i <= ArrSize DO
  TEST Event.Type
  CASE PM_EVENT_PROC:
    TriggEquip TriggArr{i}, Event.Dist, Event.Time,
      \ProcID:=Event.ProcId, Event.Value;
  CASE PM_EVENT_DO:
    GetDataVal Event.SignalName,doSignal;
    TriggEquip TriggArr{i}, Event.Dist, Event.Time,
      \Dop:=doSignal, Event.Value;
  CASE PM_EVENT_GO:
    GetDataVal Event.SignalName,goSignal;
    TriggEquip TriggArr{i}, Event.Dist, Event.Time,
      \Gop:=goSignal, Event.Value;
  ENDTEST
  Incr i;
ENDWHILE
```

Limitations

The event data members can only be set by the instruction `PmGetEvent`.

Structure

```
< dataobject of pm_eventdata >
< type of pm_eventtype >
< time of num >
< dist of num >
< procid of num >
< signalname of string >
< value of num >
```

Related information

For information about	See
The data type <code>pm_eventtype</code>	pm_eventtype - PickMaster event type on page 340.
The function <code>PmGetEvent</code>	PmGetEvent - Get events for an action on page 317.
The instruction <code>TriggEquip</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Instructions.</i>
The instruction <code>TriggL</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Instructions.</i>

8 RAPID reference information

8.4.7 pm_eventtype - PickMaster event type

8.4.7 pm_eventtype - PickMaster event type

Usage

`pm_eventtype` is used to represent an integer with a symbolic constant for different type of events.

Description

A `pm_eventtype` is used to decide which type of trigger event should be used.

Examples

```
TEST Event.Type
CASE PM_EVENT_PROC:
    TriggEquip TriggArr{i}, Event.Dist, Event.Time,
        \ProcID:=Event.ProcId, Event.Value;
CASE PM_EVENT_DO:
    GetDataVal Event.SignalName,doSignal;
    TriggEquip TriggArr{i}, Event.Dist, Event.Time, \DOP:=doSignal,
        Event.Value;
CASE PM_EVENT_GO:
    GetDataVal Event.SignalName,goSignal;
    TriggEquip TriggArr{i}, Event.Dist, Event.Time, \GOP:=goSignal,
        Event.Value;
ENDTEST
```

Predefined data

Constant	Value	Comment
PM_EVENT_PROC	220	Process with identity ProcId should receive the event. (For internal use)
PM_EVENT_DO	221	Digital output signal is changed.
PM_EVENT_GO	222	Digital group output signal is changed.

Characteristics

`pm_eventtype` is an alias type for `num` and thus inherits its characteristics.

Related information

For information about	See
The data type <code>pm_eventdata</code>	pm_eventdata - PickMaster event data on page 338.
The instruction <code>TriggEquip</code> .	<i>Technical reference manual - RAPID Instructions, Functions and Data types</i> , section <i>Instructions</i> .

8.4.8 pm_flowinfo - PickMaster flow information

Usage

`pm_flowinfo` holds information about a flow.

Description

The flow information holds data and references to everything that is needed for starting a flow or viewing user information about a specific flow.

Components

Name

Data type: `string`

The name of the flow.

SelectionNumber

Data type: `num`

The number that connects a flow with its I/O signal value. See [Flow on page 197](#).

SignalName

Data type: `string`

The name of the configured status signal.

MasterWa

Data type: `pm_wadescr`

A work area descriptor to the master work area in the flow.

SlaveWorkAreas

Data type: `pm_slavewainfo`

A collection of slave work areas.

NumberOfSlaveWA

Data type: `num`

Number of slave work areas in the flow.

Examples

```
VAR pm_flowinfo FlowInfo;
PmGetFlowInfo FlowSelection,FlowInfo;
```

Limitations

The flow information members can only be set by the instruction `PmGetFlowInfo`.

Structure

```
< dataobject of pm_flowinfo >
  < Name of string >
  < SelectionNumber of num >
  < MasterWa of pm_wadescr >
  < SlaveWorkAreas of pm_slavewainfo >
  < NumberOfSlaveWA of num >
```

Continues on next page

8 RAPID reference information

8.4.8 pm_flowinfo - PickMaster flow information

Continued

Related information

For information about	See
The instruction <code>PmGetFlowInfo</code>	<i>PmGetFlowInfo - Get information about a specific flow on page 289.</i>
The data type <code>pm_wadescr</code>	<i>pm_wadescr - PickMaster work area reference on page 366.</i>
The data type <code>pm_slavewainfo</code>	<i>pm_slavewainfo - PickMaster slave work area information on page 359.</i>

8.4.9 pm_moduleinfo - PickMaster module information

Usage

`pm_moduleinfo` holds information about the RAPID modules that can be loaded into a task.

Description

The module information contains names of the modules that can be loaded into a RAPID task after the project is started. The modules are selected in Robot settings and transferred with the project. See [Robot Settings on page 163](#).

Components

There are 10 components, named in a number series, `ModName1` to `ModName10`.

`ModName1`

Data type: `string`

The name of the file containing a RAPID module.

...

`ModName10`

Data type: `string`

The name of the file containing a RAPID module.

Examples

```
VAR pm_projectinfo ProjInfo;
PmGetProjectInfo ProjectSelection,ProjInfo;
Load \Dynamic,"HOME:"\File:=ProjInfo.Robot1.ModuleNames.ModName1;
```

Limitations

The operation data members can only be set by the instruction `PmGetProjectInfo`. There can be maximum ten modules.

Structure

```
< dataobject of pm_moduleinfo >
  < ModName1 of string >
  < ModName2 of string >
  < ModName3 of string >
  < ModName4 of string >
  < ModName5 of string >
  < ModName6 of string >
  < ModName7 of string >
  < ModName8 of string >
  < ModName9 of string >
  < ModName10 of string >
```

Continues on next page

8 RAPID reference information

8.4.9 pm_moduleinfo - PickMaster module information

Continued

Related information

For information about	See
The instruction <code>PmGetProjectInfo</code>	<i>PmGetProjectInfo - Get information about a specific project on page 294.</i>
The data type <code>pm_robotinfo</code>	<i>pm_robotinfo - PickMaster robot information on page 353.</i>

8.4.10 pm_movetype - PickMaster movement type

Usage

`pm_movetype` is used to represent an integer with a symbolic constant for different type of movements.

Description

The `pm_movetype` is used to decide which type of movement instruction should be used.

Example

```
TEST Move
CASE PM_MOVE_LIN:
    MoveL ToPoint, Speed, Zone, Tool\WObj:=WObj;
CASE PM_MOVE_JOINT:
    MoveJ ToPoint, Speed, Zone, Tool\WObj:=WObj;
ENDTEST
```

Predefined data

Constant	Value	Comment
PM_MOVE_JOINT	240	The action is a joint movement
PM_MOVE_LIN	241	The action is a linear movement

Characteristics

`pm_movetype` is an alias data type for `num` and consequently inherits its characteristics.

Related information

For information about	See
The data type <code>pm_actiondata</code>	pm_actiondata - PickMaster action data on page 333.
The instruction <code>MoveJ</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Instructions.</i>
The instruction <code>MoveL</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Instructions.</i>

8 RAPID reference information

8.4.11 pm_offsetdata - Offset data

8.4.11 pm_offsetdata - Offset data

Usage

`pm_offsetdata` describes an offset position.

Description

The `pm_offsetdata` is used to displace a robot position in x, y, and z direction and rotation around the axis.

Components

x

Data type: num

The displacement in the x-direction, in the object coordinate system.

y

Data type: num

The displacement in the y-direction, in the object coordinate system.

z

Data type: num

The displacement in the z-direction, in the object coordinate system.

rx

Data type: num

The rotation in degrees around the x-axis of the tool coordinate system.

ry

Data type: num

The rotation in degrees around the y-axis of the tool coordinate system.

rz

Data type: num

The rotation in degrees around the z-axis of the tool coordinate system.

Examples

```
VAR pm_actiondata Act;
VAR num x_offset;
WHILE PmGetTgtAction(WorkArea, Tgt.TargetHandle, Act) DO
  x_offset := Act.offset.x
  ...
ENDWHILE
```

Limitations

The offset data members can only be set by the instruction `PmGetTgtAction`.

Structure

```
< dataobject of pm_offsetdata >
< x of num >
```

Continues on next page

```
< y of num >
< z of num >
< rx of num >
< ry of num >
< rz of num >
```

Related information

For information about	See
The data type <code>pm_actiondata</code>	pm_actiondata - PickMaster action data on page 333.
The function <code>PmGetTgtAction</code>	PmGetTgtAction - Get target action on page 326.
The function <code>Offs</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Functions.</i>

8 RAPID reference information

8.4.12 pm_operationdata - PickMaster operation data

8.4.12 pm_operationdata - PickMaster operation data

Usage

`pm_operationdata` is used to specify an operation on a work area.

Description

The operation data holds data and references to everything that is going to be done when the robot enters a work area.

Components

`operationnumber`

Data type: num

The operation number is the ordinal number of the operation in the layer.

`layernumber`

Data type: num

The layer number is the ordinal number of the layer in the operation set.

`scenenumber`

Data type: num

The scene number is the ordinal number of the current operation set.

`formatid`

Data type: num

The format id value is defined in the **Pick Setting Configuration** window.

`numoftargets`

number of targets

Data type: num

The number of targets that are handled by the operation.

`ophandle`

operation handle

Data type: pm_ophandle

The operation handle is a reference to the operation.

Examples

```
VAR pm_operationdata Op;  
PmGetOperation WorkArea, Op;
```

Limitations

The operation data members can only be set by the instruction `PmGetOperation`.

Structure

```
< dataobject of pm_operationdata >  
  < operationnumber of num >  
  < layernumber of num >
```

Continues on next page

< scenenumber of num >
< formatid of num >
< numoftargets of num >
< ophandle of pm_ophandle >

Related information

For information about	See
The instruction <code>PmGetOperation</code>	PmGetOperation - Get operation from a work area on page 292.
The format id value	The Pick setting on page 77 Configuration.

8 RAPID reference information

8.4.13 pm_ophandle - PickMaster operation handle

8.4.13 pm_ophandle - PickMaster operation handle

Usage

`pm_ophandle` is used to store data about an operation.

Description

Data of the type `pm_ophandle` contains a reference to an operation.

Examples

```
PmGetOperation WorkArea, Op;  
WHILE PmGetTarget(WorkArea \OpHandle:=Op.OpHandle, Tgt) DO  
    ...  
ENDWHILE
```

Characteristics

`pm_ophandle` is a non-value data type.

Related information

For information about	See
The data type <code>pm_operationdata</code>	pm_operationdata - PickMaster operation data on page 348.
The instruction <code>PmGetOperation</code>	PmGetOperation - Get operation from a work area on page 292.

8.4.14 pm_projectinfo - PickMaster project information

Usage

`pm_projectinfo` holds information about a project.

Description

The project information holds data and references to everything that is needed for starting a project or viewing user information about a specific project.

Components

`ProjectDescription`

Data type: `string`

The description used in project properties.

`Name`

Data type: `string`

The name of the project.

`SelectionNumber`

Data type: `num`

The number that connects a project with its I/O signal value. See [Project Manager on page 106](#).

`Robot1`

Data type: `pm_robotinfo`

The information related to the first robot RAPID task.

`Robot2`

Data type: `pm_robotinfo`

The information related to the second robot RAPID task, used in a MultiMove system.

`Robot6`

Data type: `pm_robotinfo`

The information related to the sixth robot RAPID task, used in a MultiMove system.

`NumberOfFlows`

Data type: `num`

The number of flows handled by the project.

Examples

```
VAR pm_projectinfo ProjInfo;
PmGetProjectInfo ProjectSelection,ProjInfo;
```

Limitations

The operation data members can only be set by the instruction `PmGetProjectInfo`.

Continues on next page

8 RAPID reference information

8.4.14 pm_projectinfo - PickMaster project information

Continued

Structure

```
< dataobject of pm_projectinfo >
  < ProjectDescription of string >
  < Name of string >
  < SelectionNumber of num >
  < Robot1 of pm_robotinfo >
  < Robot2 of pm_robotinfo >
  < Robot3 of pm_robotinfo >
  < Robot4 of pm_robotinfo >
  < Robot5 of pm_robotinfo >
  < Robot6 of pm_robotinfo >
  < NumberOfFlows of num >
```

Related information

For information about	See
The instruction <code>PmGetProjectInfo</code>	PmGetProjectInfo - Get information about a specific project on page 294.
The data type <code>pm_robotinfo</code>	pm_robotinfo - PickMaster robot information on page 353.

8.4.15 pm_robotinfo - PickMaster robot information

Usage

pm_robotinfo holds information about a RAPID task connected to a robot.

Description

The robot information holds data and references to everything that is needed for setting up the environment for a RAPID task after starting the project.

Components

Active

Data type: bool

Defines if valid data for this robot exists.

Name

Data type: string

The name of the robot.

TaskName

Data type: string

The name of the RAPID task connected to this robot.

LoadRapid

Data type: bool

Defines if the RAPID modules should be loaded or not after the project starts.

ModuleNames

Data type: pm_moduleinfo

The RAPID modules that should be loaded after the project starts.

Examples

```
VAR pm_projectinfo ProjInfo;
PmGetProjectInfo ProjectSelection,ProjInfo;
IF projInfo.Robot1.LoadRapid THEN
  LoadAllModules projInfo.Robot1.ModuleNames, projInfo.Name,
    projInfo.Robot1.TaskName;
ENDIF
```

Limitations

The robot information members can only be set by the instruction PmGetProjectInfo.

Structure

```
< dataobject of pm_robotinfo >
  < Active of bool >
  < Name of string >
  < TaskName of string >
  < ModuleNames of pm_moduleinfo >
```

Continues on next page

8 RAPID reference information

8.4.15 pm_robotinfo - PickMaster robot information

Continued

Related information

For information about	See
The instruction <code>PmGetProjectInfo</code>	<i>PmGetProjectInfo - Get information about a specific project on page 294.</i>
The data type <code>pm_projectinfo</code>	<i>pm_projectinfo - PickMaster project information on page 351.</i>
The data type <code>pm_moduleinfo</code>	<i>pm_moduleinfo - PickMaster module information on page 343.</i>

8.4.16 pm_searchdata - PickMaster search data

Usage

pm_searchdata is used to store data used for search movements.

Description

pm_searchdata is a part of pm_actiondata and is used as input argument to procedure DoSearch. It defines search specific data.

Components

searchtype

Data type: pm_searchtype

Type of search (x, y or z). Is used as argument in PmSearchAdjust.

stoptype

Data type: pm_stoptype

Search stop type. Defines the robot stop method when performing a search movement.

signalname

Data type: string

Search signal name. The name of the signal to supervise during the search movement.

iotriggtype

Data type: pm_iotriggtype

I/O trigger type. Defines how the search signal is triggered, e.g trigger on both flanks.

Example

```
VAR pm_actiondata Act;
VAR pm_stoptype my_stoptype;
WHILE PmGetTgtAction(WorkArea, Tgt.TargetHandle, Act) DO
  my_stoptype := Act.search.stoptype;
  ...
ENDWHILE
```

Limitations

The pm_searchdata members can only be set by the instruction PmGetTgtAction.

Structure

```
<dataobject of pm_searchdata>
  < searchtype of pm_searchtype >
  < stoptype of pm_stoptype >
  < signalname of string >
  < iotriggtype of pm_iotriggtype >
```

Continues on next page

8 RAPID reference information

8.4.16 pm_searchdata - PickMaster search data

Continued

Related information

For information about	See
The data type <code>pm_actiondata</code>	<i>pm_actiondata - PickMaster action data on page 333.</i>
The function <code>PmGetTgtAction</code>	<i>PmGetTgtAction - Get target action on page 326.</i>

8.4.17 pm_searchtype - PickMaster stack search type

Usage

`pm_searchtype` is used to represent an integer with a symbolic constant for different types of stack search types.

Description

A `pm_searchtype` is used to specify which type of stack search type is used.

Example

```
PmSearchAdjust PickWA, PM_SEARCH_Z, 570;
```

Predefined data

Constant	Value	Comment
PM_SEARCH_X	0	Stack search in the x direction
PM_SEARCH_Y	1	Stack search in the y direction
PM_SEARCH_Z	2	Stack search in the z direction

Characteristics

`pm_searchtype` is an alias data type for `num` and consequently inherits its characteristics.

Related information

For information about	See
The instruction <code>PmSearchAdjust</code>	<i>PmSearchAdjust - Adjust number of remaining layers on page 299.</i>

8 RAPID reference information

8.4.18 pm_singareatype - PickMaster interpolation type around singular points

8.4.18 pm_singareatype - PickMaster interpolation type around singular points

Usage

`pm_singareatype` is used to represent an integer with a symbolic constant for different types of interpolation around singular points.

Description

The `pm_singareatype` is used to decide how the robot is to move in the proximity of singular points.

Examples

```
IF Act.SingAreaType = PM_SING_AREA_OFF THEN
  SingArea\Off;
ELSEIF Act.SingAreaType = PM_SING_AREA_WRI THEN
  SingArea\Wrist;
ELSE
  SingArea\LockAx4;
ENDIF
```

Predefined data

Constant	Value	Description
PM_SING_AREA_OFF	260	The tool orientation is not allowed to differ.
PM_SING_AREA_WRI	261	The tool orientation is allowed to differ somewhat to avoid wrist singularity.
PM_SING_AREA_LOCKAX4	262	The orientation is such that the 4th axis is locked, that is, 6 axis robot behaves like a 4 axis robot.

Characteristics

`pm_singareatype` is an alias type for `num` and thus inherits its characteristics.

Related information

For information about	See
The data type <code>pm_actiondata</code>	pm_actiondata - PickMaster action data on page 333.
The instruction <code>SingArea</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Instructions.</i>

8.4.19 pm_slavewainfo - PickMaster slave work area information

Usage

pm_slavewainfo holds information about the slave work areas in a flow.

Description

The slave work area information is a collection of work areas that can be used in any PickMaster function or instruction that demands pm_wadescr. The maximum number of slaves is 19. Current number of slaves is specified with NumberOfSlaveWA in pm_flowinfo.

Components

There are 19 components, named in a number series, SlaveWa1 to SlaveWa19.

SlaveWa1

Data type: pm_wadescr

The descriptor to a work area.

SlaveWa19

Data type: pm_wadescr

The descriptor to a work area.

Examples

```
VAR pm_flowinfo FlowInfo;
VAR num height;
VAR num FlowSelection;
PmGetFlowInfo FlowSelection,FlowInfo;
height:=PmGetWaHeight(FlowInfo.SlaveWorkAreas.SlaveWa1);
```

Limitations

The slave work area information members can only be set by the instruction PmGetFlowInfo.

Structure

```
< dataobject of pm_slavewainfo >
  < SlaveWa1 of pm_wadescr >
  < SlaveWa2 of pm_wadescr >
  < SlaveWa3 of pm_wadescr >
  < SlaveWa4 of pm_wadescr >
  < SlaveWa5 of pm_wadescr >
  < SlaveWa6 of pm_wadescr >
  < SlaveWa7 of pm_wadescr >
  < SlaveWa8 of pm_wadescr >
  < SlaveWa9 of pm_wadescr >
  < SlaveWa10 of pm_wadescr >
  < SlaveWa11 of pm_wadescr >
  < SlaveWa12 of pm_wadescr >
  < SlaveWa13 of pm_wadescr >
  < SlaveWa14 of pm_wadescr >
```

Continues on next page

8 RAPID reference information

8.4.19 pm_slavewainfo - PickMaster slave work area information

Continued

```
< SlaveWa15 of pm_wadescr >  
< SlaveWa16 of pm_wadescr >  
< SlaveWa17 of pm_wadescr >  
< SlaveWa18 of pm_wadescr >  
< SlaveWa19 of pm_wadescr >
```

Related information

For information about	See
The instruction <code>PmGetProjectInfo</code>	<i>PmGetProjectInfo - Get information about a specific project on page 294.</i>
The data type <code>pm_flowinfo</code>	<i>pm_flowinfo - PickMaster flow information on page 341.</i>

8.4.20 pm_stoptype - PickMaster stop type

Usage

`pm_stoptype` is used to represent an integer with a symbolic constant for different types of stop methods.

Description

A `pm_stoptype` is used to decide which type of robot stop method that shall be used.

`pm_stoptype` is a part of `pm_searchdata`.

Example

```
VAR pm_searchdata SearchData;
VAR signaldi diSearchSignal;
VAR pm_stoptype StopType;
...
GetDataVal SearchData.SignalName,diSearchSignal;
StopType := SearchData.StopType;
TEST StopType
  CASE PM_STOP_NOT_USED:
    ...
  CASE PM_STOP:
    ...
  CASE PM_SSTOP:
    ...
  CASE PM_PSTOP:
    ...
```

Predefined data

Constant	Value	Comment
PM_STOP_NOT_USED	0	No stop is being used
PM_STOP	1	Robot stiff stop
PM_PSTOP	2	Robot path stop
PM_SSTOP	3	Robot soft stop

Characteristics

`pm_stoptype` is an alias data type for `num` and consequently inherits its characteristics.

Related information

For information about	See
The data type <code>pm_searchdata</code>	pm_searchdata - PickMaster search data on page 355.

8 RAPID reference information

8.4.21 pm_targetdata - PickMaster target data

8.4.21 pm_targetdata - PickMaster target data

Usage

`pm_targetdata` specifies a target for a work area.

Description

The target data holds data and a reference to a target.

Components

TargetNumber

Data type: num

Defines the ordinal number of the target.

OperationNumber

Data type: num

Defines the ordinal number of the operation.

LayerNumber

Data type: num

Defines the ordinal number of the layer.

SceneNumber

Data type: num

Defines the ordinal number of the scene.

RobTgtPoint

Data type: robtarget

Defines the position of the robot and external axes.

TargetTool

Data type: tooldata

Defines the tool used with the target.

TargetWobj

Data type: wobjdata

Defines the work object used with the target.

StopPointData

Data type: stoppointdata

Defines the `stoppointdata` to be used when moving to the position of the target.

NumOfAppProds

number of approach products

Data type: num

The number of products held by the robot tool when approaching the target position.

Continues on next page

AppProdsLoad

approach product load

Data type: loaddata

Defines the load attached to the robot tool when approaching the target position.

NumOfDepProds

number of depart products

Data type: num

The number of products held by the robot tool when departing from the target position.

DepProdsLoad

depart product load

Data type: loaddata

Defines the load attached to the robot when departing from the target position.

NumOfActions

number of actions

Data type: num

Specifies the number of target actions.

TargetHandle

Data type: pm_targethandle

A reference to the target from where this pm_targetdata was retrieved.

ProductHeight

Data type: num

The height of the product to place or pick. It is not necessary a product in the tool for this target.

Examples

```
PmGetOperation WorkArea, Op;  
WHILE PmGetTarget(WorkArea \OpHandle:=Op.OpHandle, Tgt) DO  
  ...  
ENDWHILE
```

Limitations

The operation data members can only be set by the instruction PmGetTarget.

Structure

```
< dataobject of pm_targetdata >  
  < TargetNumber of num >  
  < OperationNumber of num >  
  < LayerNumber of num >  
  < SceneNumber of num >  
  < RobTgtPoint of robtarget >  
  < TargetTool of tooldata >  
  < TargetWobj of wobjdata >
```

Continues on next page

8 RAPID reference information

8.4.21 pm_targetdata - PickMaster target data

Continued

```
< StopPointData of stoppointdata >  
< NumOfAppProds of num >  
< AppProdsLoad of loaddata >  
< NumOfDepProds of num >  
< DepProdsLoad of loaddata >  
< NumOfActions of num >  
< TargetHandle of pm_targethandle >  
< ProductHeight of num >
```

Related information

For information about	See
The instruction <code>PmGetTarget</code>	PmGetTarget - Get target on page 324.
The data type <code>robtarg</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Data types.</i>
The data type <code>tooldata</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Data types.</i>
The data type <code>wobjdata</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Data types.</i>
The data type <code>stoppointdata</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Data types.</i>
The data type <code>loaddata</code>	<i>Technical reference manual - RAPID Instructions, Functions and Data types, section Data types.</i>

8.4.22 pm_targethandle - PickMaster target handle

Usage

pm_targethandle is used to store data about a target.

Description

Data of the type pm_targethandle contains a reference to a target.

Example

```
PmGetOperation WorkArea, Op;  
WHILE PmGetTarget(WorkArea \OpHandle:=Op.OpHandle, Tgt) DO  
  WHILE PmGetTgtAction(WorkArea, Tgt.TargetHandle, Act) DO  
    ...  
  ENDWHILE  
ENDWHILE
```

Characteristics

pm_targethandle is a non-value data type.

Related information

For information about	See
The data type pm_targetdata	pm_targetdata - PickMaster target data on page 362.
The function PmGetTarget	PmGetTarget - Get target on page 324.
The function PmGetTgtAction	PmGetTgtAction - Get target action on page 326.

8 RAPID reference information

8.4.23 pm_wadescr - PickMaster work area reference

8.4.23 pm_wadescr - PickMaster work area reference

Usage

`pm_wadescr` is used to store data about a work area.

Description

Data of the type `pm_wadescr` contains a reference to a work area.

Examples

```
PERS wobjdata wInfeeder1 :=  
    [FALSE,TRUE,"",[[2180.65,-1430.22,-220.753],  
    [0.00104,-0.00130,0.00039,1.00000]],[[0,0,0], [1,0,0,0]]];  
VAR pm_wadescr PickWa;  
PmGetWaByWobj wInfeeder1, PickWa;
```

Characteristics

`pm_wadescr` is a non-value data type.

Related information

For information about	See
The function <code>PmGetWaByWobj</code>	PmGetWaByWobj - Get a reference to a work area using a work object data on page 296.

8.4.24 pm_wainfo - PickMaster Work Area information

Usage

pm_wainfo holds information about a work area.

Description

The work area information holds data and references that can be used for viewing user information about the specific work area.

Components

Name

Data type: string

The name of the work area.

SelectionNumber

Data type: num

The number that connects a work area with its I/O signal value. See [I/O values on page 105](#).

Workarea

Data type: pm_wadescr

The work area descriptor.

TaskNo

Data type: num

The RAPID task number this work area is connected to. Only valid after the first call to PmGetTarget for this work area.

Order

Data type: num

The configured order for this work area. See [Feeder order on page 159](#).

DefaultHeight

Data type: num

The configured default height. See [Robot path height on page 174](#).

DiTgtGenTrig

Data type: string

The name of the configured target generation trigger signal.

DoPosRegTrig

Data type: string

The name of the configured position request trigger signal.

GoProdSel

Data type: string

The name of the configured target generation product selection signal.

Continues on next page

8 RAPID reference information

8.4.24 pm_wainfo - PickMaster Work Area information

Continued

GoFormSel

Data type: string

The name of the configured target generation format selection signal.

GiProdSel

Data type: string

The name of the configured position request product selection signal.

GiFormSel

Data type: string

The name of the configured position request format selection signal.

DiRobotExec

Data type: string

The name of the configured robot execution signal.

DiRedoSearch

Data type: string

The name of the configured redo search signal.

DoQueueEmpty

Data type: string

The name of the configured queue empty signal.

DoPosAvail

Data type: string

The name of the configured position available signal.

DoOpSetCompl

Data type: string

The name of the configured operation set complete signal.

DoExecState

Data type: string

The name of the configured execution state signal.

AccumulatedAckTarget

Data type: num

The number of accumulated acknowledged targets since project start for this work area.

AccumulatedNumOfProd

Data type: num

The number of accumulated picked or placed products since project start for this work area.

Examples

```
VAR pm_wainfo WaInfo;  
VAR num WaSelection:=1;
```

Continues on next page


```
PmGetWaInfo WaSelection,WaInfo;
```

Limitations

The work area information members can only be set by the instruction `PmGetWaInfo`.

Structure

```
< dataobject of pm_wainfo >
  < Name of string >
  < SelectionNumber of num >
  < WorkArea of pm_wadescr >
  < TaskNo of num >
  < Order of num >
  < DefaultHeight of num >
  < DiTgtGenTrig of string >
  < DoPosReqTrig of string >
  < GoProdSel of string >
  < GoFormSel of string >
  < GiProdSel of string >
  < GiFormSel of string >
  < DiRobotExec of string >
  < DiRedoSearch of string >
  < DoQueueEmpty of string >
  < DoPosAvail of string >
  < DoOpSetCompl of string >
  < DoExecState of string >
  < AccumulatedAckTarget of num >
  < AccumulatedNumOfProd of num >
```

Related information

For information about	See
The instruction <code>PmGetWaInfo</code>	PmGetWaInfo - Get information about a specific work area on page 297
The data type <code>pm_wadescr</code>	pm_wadescr - PickMaster work area reference on page 366

This page is intentionally left blank

9 Relationships between PickMaster frames

9.1 Structure of this chapter

This chapter describes the different frames used by PickMaster and how they relate to each other. Each section describes the relationship between two (or several) frames.

9 Relationships between PickMaster frames

9.2 Shape frame

9.2 Shape frame

Shape size

The size of the shape is specified as **X size**, **Y size** and **Z size** in the **Product/Pallet/Sheet Configuration** window.

Visualization of the shape frame

The shape frame is shown in the **Product/Pallet/Sheet Configuration** window, but without reference to any other frame.

In the windows **Pick Setting Configuration**, **Pallet Pattern Operation Set Configuration** and **Group Operation Set Configuration** the origin of the shape frame is marked as a blue corner on the shape.

9.3 Format frame versus shape frame

Format frame settings

The relationship between a format frame and shape frames are defined in the **Pick Setting Configuration** by the settings of **Orientation**, **Row**, and **Column**. See the [Pick setting on page 77](#) configuration.

Orientation defines the orientation relationship between the format frame and the shape frames. Possible values are **Front**, **Left**, **Back**, and **Right**.

Row defines number of shapes in the y-direction of the format frame.

Column defines number of shapes in the x-direction of the format frame.

The relationship between the format frame and the shape frames will also depend on the X size, Y size, and Z size of the shape defined in the **Product/Pallet/Sheet Configuration** and the tuning of item size which is displayed in the same dialog.

Orientation explanation

Orientation defines which side of the item to place in the negative y-direction.

Continues on next page


9 Relationships between PickMaster frames

9.3 Format frame versus shape frame

Continued

The following examples show some different orientations.

Orientation: Front



xx0700000255

X_F, Y_F, Z_F Coordinates for the format frame

X_S, Y_S, Z_S Coordinates for the shape frame

F Front side of the shape

R Right side of the shape


L Left side of the shape

B Back side of the shape

U Upper side of the shape


Continues on next page

Orientation: Left



xx0700000256

Orientation: Back



xx0700000257

Continues on next page

9 Relationships between PickMaster frames

9.3 Format frame versus shape frame


Continued

Row explanation

Row defines number of shapes in the y-direction of the format frame.

The following examples show the combination of row, column, and orientation.


Row: 3 ; Column: 1; Orientation: Front



xx0700000258

Continues on next page

Row: 3 ; Column: 1; Orientation: Left




xx0700000259

Column explanation

Column defines number of shapes in the x-direction of the format frame.

The following example shows the combination of row, column, and orientation.

Row: 3; Column: 2; Orientation: Front



xx0800000371

Visualization of the format frame

The format frame is shown in the **Pick Setting Configuration** window. For more information, see the [Pick setting on page 77](#) configuration.

9 Relationships between PickMaster frames

9.4 Pallet pattern frame versus shape frame

9.4 Pallet pattern frame versus shape frame

Use a palletizing area shape

The pallet pattern frame coincides with the shape frame of the palletizing area shape, which is selected in the **Layout Configuration** (only shapes with **Form** set to **Pallet** can be selected).

The palletizing area shape can be used as pallet in the pallet pattern but this is not mandatory.


The palletizing area shape sets the x-y-size of the pallet pattern. Only box shapes and sheet shapes that are smaller than or have the same size as the palletizing area shape will be available for use within the pallet pattern.

Where to see the shape frame and pallet pattern

The location of the shape frame can be viewed in the **Product/Pallet/Sheet Configuration** window.

The location of the pallet pattern frame can be viewed in the **Layout Configuration** or the **Pallet Pattern Configuration** window.

Illustration




xx0700000263

X_S, Z_S Coordinates for the shape frame of the palletizing area shape

X_P, Z_P Coordinates for the pallet pattern frame

9.5 Format frame versus tool frame

Illustration



Format frame

The format frame is defined in the **Item Group Configuration** window, under **Product/Pallet/Sheet** window, shown in the 3D view.

Item frame

The offset frame is selected by setting **Aligned item** in the **Pick Setting Configuration** window, under **Tool location**. The offset frame is positioned on the top of the selected item and has the same orientation as the format frame.

Offset frame

The offset frame has an offset relative to the item frame. This offset is selected by setting **Offset** in the **Pick Setting Configuration** window, under **Tool location**. The offset frame z-direction is always opposite to the item frame. The orientation of the offset frame's xy-plane relative to the item frame can be selected in steps of 90 degrees in the **Pick Setting Configuration** window, under **Tool location**.

Tool frame

The zone frame cannot be directly viewed in the **Pick Setting Configuration** window. Instead, the location of the tool frame is displayed. The tool frame position is different from the zone frame but the orientation is the same.

Zone frame

The zone frame is selected by setting aligned tool configuration and zone in the **Pick Setting Configuration** window, under **Tool location**. The zone frame has an offset relative to the tool frame. The location of the zone frames and the corresponding offsets are displayed in the **Tool Function(Vacuum)** window, under the **Zones** tab. The offset can be changed by selecting **Activator in Zones**, or by setting the activator x, y, z in the **Tool Function(Vacuum)** window, under **Activators** tab.

Continues on next page

9 Relationships between PickMaster frames

9.5 Format frame versus tool frame

Continued

Zone frame and offset frame

When a format is being picked by a robot, a zone frame coincides with an offset frame.

Where to see the tool frame

The location of the tool frame relative to a format can be viewed in the **Pick Setting Configuration** window. See the [Pick setting on page 77](#) configuration.

9.6 Pallet pattern item versus tool frame


Tool location

The location of the tool relative to a specific item when picking/placing it, is automatically solved by PickMaster. The location of the tool is highly dependent on the selected **Formats to use** in the **Pallet Pattern Operation Set Configuration**. Every used format creates a number of possible positions of the tool relative to the item. The solution must also consider that every layer must be completely finished before starting with the next layer in the pallet pattern.

The autogenerated solution can be modified in detail in the **Operation Editor**, which is accessible from the **Pallet Pattern Operation Set Configuration**. For each item in every layer is it possible to modify:

- The pick/place order within the layer.
- The format to be used.
- The item in the selected format to be used.
- The orientation of the item may be flipped 180 degrees.
- Single access or (if possible) grouped access with adjacent items.

Illustration



Where to see the tool frame

The location of the tool frame relative to an item in a pallet pattern can be viewed in the **Pallet Pattern Operation Set Configuration** window. See [Pattern/Stack operation set on page 181](#).

Related information

The [Operation editor on page 193](#).

9 Relationships between PickMaster frames


9.7 Format frame versus work object in format operation set

9.7 Format frame versus work object in format operation set

Overview

The expected location of a format relative to the work object while being picked or placed depends on a chain of frames, starting with the work object and ending with the format frame.

Illustration



Work object

The location of the work object is defined by the selection of **Work object** in the **Feeder Configuration** window.

The location of the work object is affected by all settings in the selected work object, including user frame and object frame settings. It is also affected by use of program displacement.

In Palletizing PowerPac, the position of the work object is aligned with the selected hotspot of the feeder model (Feeder hotspot configuration window).

Tune frame

The location of the tune frame relative the work object is defined by the current online tuning of the work area. By default the tune frame coincides with the work object. The tune frame location may be changed from the PickMaster RC online tuning by updating the following work area properties: **Disp offs x**, **Disp offs y**, **Disp offs z**, and **Disp angle z**. The tune frame is first displaced from the work object with the **Disp offs** vector. Then the tune frame is rotated around the displaced origo in the z-direction with the **Disp angle z**.

Work area frame

The location of the work area frame relative to the tune frame is defined by the **Alignment** and **Rotation** settings of the selected hotspot used by the feeder.

Displacement frame

The location of the displacement frame relative to the work area frame is defined by the settings of **Displacement frame: x, y, z and z angle** in the **Group Operation Set Configuration** window.

Continues on next page

Search frame

Search frame has an offset relative to the displacement frame. The offset is initially zero but is automatically updated after a stack search.

Format frame

At pick/place on a work area, the format frame coincides with the search frame.

Where to see the work object

The location of the work object relative to a general format can be viewed in the **Feeder Hotspot** window. However, the location is only valid if the following are zero: tune frame location, displacement frame offset, reorientation, and search frame.

The location of the work object relative to a specific format can be viewed in the **Group Operation Set Configuration** window. However, the location is only valid if the tune frame location is zero (=default) and if the search frame offset is zero.

9 Relationships between PickMaster frames


9.8 Pallet pattern frame versus work object in pallet pattern operation set

9.8 Pallet pattern frame versus work object in pallet pattern operation set

Overview

The expected location of a pallet pattern frame relative to the work object while being picked or placed depends on a chain of frames, starting with the work object and ending with the pallet pattern frame.

Illustration



Work object

The location of the work object is defined by the selection of **Work object** in the **Feeder Configuration** window.

The location of the work object is affected by all settings in the selected work object, including user frame and object frame settings. It is also affected by use of program displacement.

In Palletizing PowerPac, the position of the work object is aligned with the selected hotspot of the feeder model (Feeder hotspot configuration window).

Tune frame

The location of the tune frame relative the work object is defined by the current online tuning of the work area. By default the tune frame coincides with the work object. The tune frame location may be changed from the PickMaster RC online tuning by updating the following work area properties: **Disp offs x**, **Disp offs y**, **Disp offs z**, and **Disp angle z**. The tune frame is first displaced from the work object with the Disp offs vector. Then the tune frame is rotated around the displaced origo in the z-direction with the Disp angle z.

Work area frame

The location of the work area frame relative to the tune frame is defined by the **Alignment and Orientation** settings of the selected **hotspot** used by the feeder.

Continues on next page

Displacement frame

The location of the displacement frame relative to the work area frame is defined by the settings of **Displacement frame: x, y, z and z angle** in the **Pallet Pattern Operation Set Configuration** window.

Search frame

Search frame has an offset relative to the displacement frame. The offset is initially zero but is automatically updated after a stack search.

Format frame

At pick/place on a work area, the pallet pattern frame coincides with the search frame.

Where to see the work object

The location of the work object relative to a general pallet pattern can be viewed in the **Feeder Hotspot** window. However, the location is only valid if the following are zero: the tune frame location, displacement frame offset, reorientation, and the search frame offset.

The location of the work object relative to a specific pallet pattern can be viewed in the **Pallet Pattern Operation Set Configuration** window. However, the location is only valid if the tune frame location is zero (=default) and if the search frame offset is zero.

9 Relationships between PickMaster frames

9.9 Tune frame versus work area frame

Formats and pallet patterns

The relationship between tune frame and work area frame is valid for both formats and pallet patterns.

Alignment

Alignment defines which side of the work area frame the tune frame is found on, left or right.

The offset of the work area frame is zero with left alignment. With right alignment, the offset becomes equal to the x-size of the format expressed in the format frame.


Orientation

Orientation defines the orientation of the tune frame in the z-direction relative to the work area frame: 0, 90, 180 or 270 degrees.

Examples

The displayed positions of the format in these examples assumes no displacement frame offset/reorientation and zero search offset.

Alignment: Left; Orientation: 0



xx0700000268


X_T, Y_T, Z_T Coordinates for the tune frame

X_{WA}, Y_{WA}, Z_{WA} coordinates for the work area frame

Z_{WA}


Continues on next page

Alignment: Right; Orientation: 0



xx0700000269

Alignment: Left; Orientation: 90



xx0700000270


Continues on next page

9 Relationships between PickMaster frames

9.9 Tune frame versus work area frame

Continued

Alignment: Right; Orientation: 90



9.10 Tune frame versus work area frame versus displacement frame

Displacement frame settings

Displacement frame settings are made in the **Group Operation Set Configuration** window for formats and in the **Pattern Operation Set Configuration** window for pallet patterns.

x, **y**, and **z** defines an offset of the displacement frame relative to the work area frame but in the direction of the tune frame. **z angle** defines a z-rotation of the displacement frame relative the displaced origin.

Example

This example shows the coordinates for the tune frame, the work area frame and the displacement frame. It also shows how the items in the format are placed.


The following settings are made for the work area frame in the **Group Operation Set Configuration** window:

Setting	Value
Alignment	Right
Orientation	270

The following settings are made for the displacement frame in the **Pattern Operation Set Configuration** window:

Setting	Value
x	0
y	1500
z	0
z angle	90°

The displayed position of the format in this example assumes zero search frame offset.



X_T, Y_T, Z_T Coordinates for the tune frame

X_{WA}, Y_{WA}, Z_{WA} Coordinates for the work area frame

Z_{WA}

X_D, Y_D, Z_D Coordinates for the displacement frame

This page is intentionally left blank

Index

A

- actions
 - definition, 22
- activators
 - definition, 22

C

- continue pick-place, 242
- controller system
 - handling, 265

D

- default signals
 - configuration, 254
 - controller system actions, 254
 - controller system handling, 265
 - error reporting, 272
 - event reporting, 255, 272
 - flow handling, 269
 - flows, 255
 - grippers, 255
 - installed, 254
 - project handling, 254, 265
 - work areas, 254
- displacement frame, 382, 384, 389

E

- errors
 - flow recovery, 240
 - Production window, 241
- events
 - definition, 22
 - flow recovery, 240
 - Production window, 241

F

- facing
 - definition, 22
- FlexPendant
 - flow recovery, 240
 - opening project, 232
 - process signals, 246
 - restart options, 242
 - starting production, 233
 - tuning, 249
- flows
 - default signals, 269
 - definition, 22
 - handling, 269
 - recover actions, 269
 - recovering, 270
 - restarting, 270
 - starting, 270
 - status values, 269
 - stop options, 269
 - stopping, 270
 - stopping immediately, 270
- format frame, 373, 379, 382

I

- I/O
 - basic I/O interface, 256
 - extended I/O interface, 265
 - signal descriptions, 256, 265
- item frame, 379

- items
 - definition, 23

L

- layouts
 - definition, 23
- line
 - definition, 23

N

- next pallet, 242

O

- operations
 - definition, 23

P

- palletizing process, 18
- pallet pattern
 - definition, 23
- pallet pattern frame, 378, 384
- pallet pattern operation sets
 - definition, 23
- pm_accdata, 330
- pm_acktype, 332
- pm_actiondata, 333
- pm_actionhandle, 336
- pm_actiontype, 337
- pm_eventdata, 338
- pm_eventtype, 340
- pm_flowinfo, 341
- pm_moduleinfo, 343
- pm_movetype, 345
- pm_offsetdata, 346
- pm_operationdata, 348
- pm_ophandle, 350
- pm_projectinfo, 351
- pm_robotinfo, 353
- pm_searchdata, 355
- pm_searchtype, 357
- pm_singareatype, 358
- pm_slavewainfo, 359
- pm_stoptype, 361
- pm_targetdata, 362
- pm_targethandle, 365
- pm_wadescr, 366
- pm_wainfo, 367
- PmAckTarget, 282
- PmCalcArmConf, 284
- PmCalcIntermid, 313
- PmGetEvent, 317
- PmGetFlow, 287
- PmGetFlowInfo, 289
- PmGetOperation, 292
- PmGetPathHeight, 319
- PmGetProjectInfo, 294
- PmGetQueByWobj, 296
- PmGetTarget, 324
- PmGetTgtAction, 326
- PmGetWaHeight, 328
- PmGetWainfo, 297
- PmGetWaName, 329
- PmSearchAdjust, 299
- PmSetRecoverAction, 302
- PmStartFlow, 306
- PmStartProj, 308
- PmStopFlow, 309

- PmStopProj, 311
- PmWaitProjStart, 312
- position sources
 - definition, 23
- process signals, 246
- production
 - starting overview, 45
 - starting with FlexPendant, 233
- products
 - packing, 19
- project
 - opening on FlexPendant, 232
- projects
 - default signals, 265
 - definition, 23
 - handling, 265
 - restarting, 268
 - starting, 266–267
 - stopping current, 268
 - stopping program, 267

R

RAPID

- action, 200
- DIToolEvent trap, 223
- DoMove3 procedure, 225
- event, 200
- HomePos variable, 212
- LastRobTgt variable, 226
- LastTool variable, 226
- Main procedure, 203, 214
- MaxToolAngle constant, 206
- MinToolAngle constant, 206
- MoveHomePos procedure, 208
- MoveInterMid procedure, 210
- OperateLoop procedure, 204
- Operate procedure, 205
- operation, 200
- pm_accddata data type, 330
- pm_acktype data type, 332
- pm_actiondata data type, 333
- pm_actionhandle data type, 336
- pm_actiontype data type, 337
- pm_eventdata data type, 338
- pm_eventtype data type, 340
- pm_flowinfo data type, 341
- pm_moduleinfo data type, 343
- pm_movetype data type, 345
- pm_offsetdata data type, 346
- pm_operationdata data type, 348
- pm_ophandle data type, 350
- pm_projectinfo data type, 351
- pm_robotinfo data type, 353
- pm_searchdata data type, 355
- pm_searchtype data type, 357
- pm_singareatype data type, 358
- pm_slavewainfo data type, 359
- pm_stoptype data type, 361
- pm_targetdata data type, 362
- pm_targethandle data type, 365
- pm_wadescr data type, 366
- PmAckTarget instruction, 282
- PmCalcArmConf instruction, 284

- PmCalcIntermid function, 313
- PmDoAction procedure, 206, 224
- PmGetEvent function, 317
- PmGetFlowInfo instruction, 289
- PmGetFlow instruction, 287
- PmGetLastWa, 291
- PmGetOperation instruction, 292
- PmGetPathHeight, 319
- PmGetProjectInfo instruction, 294
- PmGetQueByWobj instruction, 296
- PmGetTarget function, 324
- PmGetTgtAction function, 326
- PmGetWaHeight function, 328
- PmGetWalInfo, 297
- PmGetWaName function, 329
- PmSearchAdjust instruction, 299
- PmSetDefaultHeight, 322
- PmSetLastWa, 301
- PmSetRecoverAction, 302
- PmStartFlow instruction, 306
- PmStartProj instruction, 308
- PmStopFlow instruction, 309
- PmStopProj instruction, 311
- PmWaitProjStart instruction, 312
- product, 201
- SetLastPos procedure, 209
- system modules, 202
- target, 200
- templates, 202
- TrapGIToolEvents trap, 223
- TrapProjectStopped, 216, 220
- TrapSetRecoverAction, 218
- TrapStartFlow, 219
- TrapStopFlow, 220
- walnFeeder1 variable, 206
- waOutFeeder1, 206
- redo last pick, 242
- restart layer, 242
- restart options, 242
- robots
 - bending backwards, 26
 - parallel rod, 29
 - using 6 axes, 25

S

- safety, 13
- search frame, 382, 384
- shape frame, 372–373, 378
- slip sheets
 - using, 19

T

- target frame, 379
- timing diagrams, 275
- tool frame, 379, 381
- tuning
 - FlexPendant, 249

W

- work area frame, 382, 384, 386, 389
- work object, 382, 384, 386, 389

Z

- zone frame, 379

Contact us

ABB AB, Robotics
Robotics and Motion
S-721 68 VÄSTERÅS, Sweden
Telephone +46 (0) 21 344 400

ABB AS, Robotics
Robotics and Motion
Nordlysvegen 7, N-4340 BRYNE, Norway
Box 265, N-4349 BRYNE, Norway
Telephone: +47 22 87 2000

ABB Engineering (Shanghai) Ltd.
Robotics and Motion
No. 4528 Kangxin Highway
PuDong District
SHANGHAI 201319, China
Telephone: +86 21 6105 6666

ABB Inc.
Robotics and Motion
1250 Brown Road
Auburn Hills, MI 48326
USA
Telephone: +1 248 391 9000

www.abb.com/robotics