

mitsubishi

ENGINE 4G5 SERIES

WORKSHOP MANUAL

FOREWORD

This Workshop Manual contains procedures for removal, disassembly, inspection, adjustment, reassembly and installation, etc. for service mechanics.

All information, illustrations and product descrip-

Engine 11A

HOW TO USE THIS MANUAL

CONTENTS

The preceding page contains GROUP INDEX which lists the group title and group number.

PAGE NUMBERS

All page numbers consist of three sets of digits separated by a dash. The digits preceding the dash

TEXT

Unless otherwise specified, each service procedure covers all models. Procedures covering specific models and identified by the model codes, destination or similar designation (engine type, transmission type, etc.)

Operating procedures, cautions, etc. on removal, installation, disassembly and reassembly are described.

ENGINE

Cylinder Head and Valves

11A-8-3