

MITSUBISHI

**ENGINE
6A12**

WORKSHOP MANUAL

FOREWORD

This Workshop Manual contains procedures for removal, disassembly, inspection, adjustment, reas-

Engine **11A**

INTRODUCTION

EXPLANATION OF MANUAL CONTENTS

Maintenance and Servicing Procedures

- (1) A diagram of the component parts is provided near the front of each section in order to give the reader a better understanding of the installed condition of component parts.

- Removal steps:
The part designation number corresponds to the number in the illustration to indicate removal steps.
- Disassembly steps:
The part designation number corresponds

INTRODUCTION

Indicates
the group
title.

Indicates
the section
title.

Indicates
the group
number.

Indicates
the section
number.

Indicates
the page
number.

SA1 ENGINE Water Pump and Water Pina

11A-7-1

List of Effective Pages

Page	Revision code	Date	Remarks
11A-0-1		Dec. 1992	
11A-0-3 to 11A-0-5		Dec. 1992	
11A-1-1		Dec. 1992	
11A-1-2 to 11A-1-4	B	Dec. 1995	Revised

Page	Revision code	Date	Remarks
11A-8-1		Dec. 1992	
11A-9-1 to 11A-9-4		Dec. 1992	
11A-10-1	A	Feb. 1994	Revised
11A-10-2		Dec. 1992	