

mitsubishi

ENGINE 4G3 SERIES

WORKSHOP MANUAL

INTRODUCTION

EXPLANATION OF MANUAL CONTENTS

Maintenance and Servicing Procedures

(1) A diagram of the component parts is

- Removal steps:
The part designation number corresponds to the number in the illustration to indicate

INTRODUCTION

Indicates

Indicates

Indicates

Indicates

Indicates

List of Effective Pages

[illegible]