

# MITSUBISHI

## ENGINE 4D6 SERIES

### WORKSHOP MANUAL

#### FOREWORD

This Workshop Manual contains procedures for

Engine

11A

# INTRODUCTION

## EXPLANATION OF MANUAL CONTENTS

### Maintenance and Servicing Procedures

(1) A diagram of the component parts is provided near the front of each section in order to give the reader a better

- Removal steps:  
The part designation number corresponds to the number in the illustration to indicate removal steps.
- Disassembly steps:

# INTRODUCTION

Indicates  
the group  
title.

Indicates  
the section  
title.

Indicates  
the group  
number.

Indicates  
the section  
number.

Indicates  
the page  
number.

## List of Effective Pages

| Page | Revision<br>code | Date | Remarks |
|------|------------------|------|---------|
|------|------------------|------|---------|

|         |   |           |  |
|---------|---|-----------|--|
| 11A-0-1 | A | July 1992 |  |
|---------|---|-----------|--|

| Page | Revision<br>code | Date | Remarks |
|------|------------------|------|---------|
|------|------------------|------|---------|

|                     |   |           |  |
|---------------------|---|-----------|--|
| 11B-1-8 and 11B-1-9 | A | July 1992 |  |
|---------------------|---|-----------|--|