


# Steppermotor-Controller Uni 1500

Pin out of the connection:

Pin1 not used	Pin14 Spindle Motor on/off (Relais)
Pin2 Direction X	Pin16 not used
Pin3 Clock X	Pin17 not used
Pin4 Direction Y	Pin10 not used
Pin5 Clock Y	Pin11 Referenz-Switch X-Y-Z
Pin6 Direction Z	Pin12 Referenz-Switch 4th axis
Pin7 Clock Z	Pin13 not used
Pin8 Direction 4th axis	Pin15 not used
Pin9 Clock 4th axis	Pin18-25 Ground



Fase 1: A and B  
Fase 2: C and D

## 4th axis Modul

Fase 1: 2+3  
Fase 2: 4+5  
Endswitch: 1+6

