
UG0715
User Guide
PolarFire FPGA PDC Commands



Table of Contents

PDC Commands - Introduction	3
Supported Families	3
2 I/O PDC commands	4
set_jobank	4
reserve	5
set_io	6
set_location	14
3 Netlist Attributes PDC Commands	17
set_preserve	17
4 Floorplanning PDC Commands	18
assign_region	18
assign_net_macros	19
define_region	20
move_region	22
A Product Support	23
Customer Service	23
Customer Technical Support Center	23
Technical Support	23
Website	23
Contacting the Customer Technical Support Center	23
ITAR Technical Support	24

PDC Commands - Introduction

In the FPGA design world, constraint files are as important as design source files. Physical design constraints (PDC) are used to constrain the I/Os attributes, placement, and routing during the physical layout phase.

You can enter PDC commands manually using the Libero SoC Text Editor. PDC commands can also be generated by the Libero SoC interactive tools. The I/O Attribute Editor is the interactive tool for making I/O attributes changes and the Chip Planner is the interactive tool for making floorplanning changes. When changes are made in the I/O Attribute Editor or the Chip Planner, the PDC file(s) are updated to reflect the changes. These PDC commands can be used as part of a script file to constrain the Place and Route step of your design.

Supported Families

This User Guide covers the PDC commands applicable to the PolarFire devices.

2 – I/O PDC commands

I/O PDC commands are used to set and reset I/O standards, voltages values, and attributes.

set_iobank

PDC command; sets the input/output supply voltage (vcci) and the input reference voltage (vref) for the specified I/O bank.

All banks have a dedicated vref pin and you do not need to set any pin on these banks.

There are two types of I/O banks: General-Purpose IO (GPIO) and High-Speed IO (HSIO).

Each bank type supports a different set of I/O standards as listed in the Table below.

I/O Bank Type	Supported I/O Standards
High-Speed IO (HSIO)	LVC MOS12, LVC MOS15, LVC MOS18, SSTL18I, SSTL18II, HSUL18I, HSUL18II, SSTL15I, SSTL15II, HSTL15I, HSTL15II, SSTL135I, SSTL135II, HSTL135I, HSTL135II, HSTL12I, HSUL12I, SLVSE15, POD12I, POD12II, LVSTL11I, LVSTL11II, SLVS18, HCSL18, LVDS18, RSDS18, MINILVDS18, SUBLVDS18, PPDS18
General-Purpose IO (GPIO)	LVTTTL, LVC MOS33, PCI, LVC MOS12, LVC MOS15, LVC MOS18, LVC MOS25, SSTL25I, SSTL25II, SSTL18I, SSTL18II, HSUL18I, HSUL18II, SSTL15I, SSTL15II, HSTL15I, HSTL15II, SLVS33, HCSL33, MIPI12, MIPIE33, LVPECL33, LVPECL25, LVPECLE33, LVDS25, LVDS33, RSDS25, RSDS33, MINILVDS25, MINILVDS33, SUBLVDS25, SUBLVDS33, PPDS25, PPDS33, SLVSE15, MLVDSE25, BUSLVDSE25

```
set_iobank -bank_name <bank_name>\
[-vcci <vcci_voltage>]\
[-vref <vref_voltage>]\
[-fixed <value>]\
[-update_iostd <value>]
```

Arguments

-bank_name <bank_name>

Specifies the name of the bank. I/O banks are numbered 0 through N (bank0, bank1,...bankN). The number of I/O banks varies with the device. Refer to the datasheet for your device to determine how many banks it has.

-vcci <vcci_voltage>

Sets the input/output supply voltage. You can enter one of the following values:

Vcci Voltage	Compatible Standards
3.3 V	LVTTTL, LVC MOS33, PCI, LVDS33, LVPECL33, LVPECLE33, SLVS33, HCSL33, RSDS33, MINILVDS33, SUBLVDS33
2.5 V	LVC MOS25, SSTL25I, SSTL25II, LVPECL25, PPDS25, SLVS25, HCSL25, MLVDSE25, MINILVDS25, RSDS25, SUBLVDS25, LVDS25, MLVDSE25, BUSLVDSE25
1.8 V	LVC MOS18, SSTL18I, SSTL18II, HSUL18I, HSUL18II, SLVS18, HCSL18, LVDS18, RSDS18, MINILVDS18, SUBLVDS18, PPDS18
1.5 V	LVC MOS15, SSTL15I, SSTL15II, HSTL15I, HSTL15II, SLVSE15

1.35 V	HSTL135I, HSTL135II, SSTL135I, SSTL135II
1.2 V	LVC MOS12, HSUL12I, HSTL12I, POD12I, MIPI12
1.1V	LVSTL11I, LVSTL11II

-vref <vref_voltage>

Sets the input reference voltage. You can enter one of the following values:

Vref Voltage	Compatible Standards
1.25 V	SSTL25I
1.0 V	SSTL18I, HSUL18I
0.75 V	POD12I, HSTL15I, SSTL15I, HSUL12I, HSTL12I
0.67 V	SSTL135I, HSTL135I

-fixed <value>

Specifies if the I/O technologies (vcci and vccr voltage) assigned to the bank are locked. You can enter one of the following values:

Value	Description
true	The technologies are locked.
false	The technologies are not locked.

-update_iostd <value>

Specifies if the I/O technologies (vcci and vccr voltage) assigned to the bank are locked. You can enter one of the following values:

Value	Description
true	If there are I/O's placed on the bank, we keep the placement and change the host to one which is compatible with this bank setting. Check the I/O Attributes to see the one used by the tool.
false	If there are I/O's placed and locked on the bank, the command will fail. If they are placed I/Os they will be unplaced.

Exceptions

Any pins assigned to the specified I/O bank that are incompatible with the default technology are unassigned.

Examples

The following example assigns 3.3 V to the input/output supply voltage (vcci) for I/O bank 0.

```
set_iobank -bank_name bank0 -vcci 3.3
```

reserve

PDC command; reserves the named pins in the current device package.

```
reserve -pin_name "list of package pins"
```

Arguments

-pin_name "list of package pins"

Specifies the package pin name(s) to reserve. You can reserve one or more pins.

Exceptions

None

Examples

```
reserve -pin_name "F2"
reserve -pin_name "F2 B4 B3"
reserve -pin_name "124 17"
```

set_io

PDC command; You can use the set_io command to assign an I/O technology, place, or lock the I/O at a given pin location. There are two I/O types available for PolarFire: GPIO and HSIO. Each I/O type supports different I/O standards.

I/O Types	Supported I/O Standards
HSIO	LVC MOS12, LVC MOS15, LVC MOS18, SSTL18I, SSTL18II, HSUL18I, HSUL18II, SSTL15I, SSTL15II, HSTL15I, HSTL15II, SSTL135I, SSTL135II, HSTL135I, HSTL135II, HSTL12I, HSUL12I, SLVSE15, POD12I, POD12II, LVSTL11I, LVSTL11II, SLVS18, HCSL18, LVDS18, RSDS18, MINILVDS18, SUBLVDS18, PPDS18
GPIO	LVTTTL, LVC MOS33, PCI, LVC MOS12, LVC MOS15, LVC MOS18, LVC MOS25, SSTL25I, SSTL25II, SSTL18I, SSTL18II, HSUL18I, HSUL18II, SSTL15I, SSTL15II, HSTL15I, HSTL15II, SLVS33, HCSL33, MIPI12, MIPIE33, LVPECL33, LVPECL25, LVPECL33, LVDS25, LVDS33, RSDS25, RSDS33, MINILVDS25, MINILVDS33, SUBLVDS25, SUBLVDS33, PPDS25, PPDS33, SLVSE15, MLVDSE25, BUSLVDS25

```
set_io
  -port_name <port_name> \
  [-pin_name <package_pin>] \
  [-fixed <true|false>] \
  [-io_std <io_std_values>] \
  [-out_load <value>] \
  [-res_pull <value>] \
  [-lock_down <value>] \
  [-ff_io_state <value>] \
  [-clamp_diode <value>] \
  [-schmitt_trigger <value>] \
  [-slew <value>] \
  [-vicm_range <value>] \
  [-ODT <value>] \
  [-ODT_VALUE] \
  [-out_drive <value>] \
  [-impedance <value>]
```

Arguments

-port_name <port_name>

Specifies the portname of the I/O macro.

-pin_name <package_pin>

Specifies the package pin name(s) on which to place the I/O.

-io_std <value>

Sets the I/O standard for this macro. If the voltage standard used with the I/O is not compatible with other I/Os in the I/O bank, assigning an I/O standard to a port will invalidate its location and automatically unassign the I/O.

The following table shows a list of supported I/O standards.

Some I/O standards support only either single I/O or differential I/Os while others support both Single and Differential I/Os. The table below lists the different I/O standards and what they support

IO_STD Value	Single	Differential
LVTTTL	YES	NO
LVSTL11I	YES	YES
LVSTL11II	YES	YES
LVCMOS33	YES	NO
LVCMOS25	YES	NO
LVCMOS18	YES	NO
LVCMOS15	YES	NO
LVCMOS12	YES	NO
PCI	YES	NO
POD12I	YES	YES
POD12II	YES	YES
PPDS33	NO	YES
PPDS25	NO	YES
PPDS18	NO	YES
SLVS33	NO	YES
SLVS25	NO	YES
SLVS18	NO	YES
HCSL33	NO	YES
HCSL25	NO	YES
HCSL18	NO	YES
SLVSE	NO	YES
SLVSE15	NO	YES
BUSLVDSE	NO	YES
BUSLVDSE25	NO	YES
MLVDSE	NO	YES
MLVDSE25	NO	YES
LVDS	NO	YES
LVDS33	NO	YES
LVDS25	NO	YES

LVDS18	NO	YES
BUSLVDS	NO	YES
MLVDS	NO	YES
MIPI12	NO	YES
MIPIE33	NO	YES
MINILVDS	NO	YES
MINILVDS33	NO	YES
MINILVDS25	NO	YES
MINILVDS18	NO	YES
RSDS	NO	YES
RSDS33	NO	YES
RSDS25	NO	YES
RSDS18	NO	YES
LVPECL (only for inputs)	NO	YES
LVPECL33	NO	YES
LVPECL25	NO	YES
LVPECL33	NO	YES
HSTL15I	YES	YES
HSTL15II	YES	YES
HSTL135I	YES	YES
HSTL135II	YES	YES
HSTLI2I	YES	YES
HSTL12II	YES	YES
SSTL18I	YES	YES
SSTL18II	YES	NO
SSTL15I	YES	YES
SSTL15II	YES	NO
SSTL135I	YES	YES
SSTL135II	YES	YES
SSTL25I	YES	YES
SSTL25II	YES	YES
HSUL18I	YES	YES
HSUL18II	YES	YES
HSUL12I	YES	YES
HSUL12II	YES	YES
SUBLVDS33	NO	YES
SUBLVDS25	NO	YES
SUBLVDS18	NO	YES

-fixed <value>

Specifies if the location of this port is fixed (i.e., locked). Locked ports are not moved during layout. The default value is true. You can enter one of the following values:

Value	Description
true	The location of this port is locked.
false	The location of this port is unlocked.

Examples

```
set_io -port_name IO_in\[2\]
-io_std LVCMOS25 \
-fixed true\
```

I/O Directions Not Supported

The following table lists I/O directions that are **not** supported for the I/O standards shown in the table.

I/O Direction	IO_STD Value
Input	SLVSE15, MLVDSE25, BUSLVDSE25, MIP1E33, LVPECLE33
Output	SLVS33, HCSL33, LVPECL33, LVPECL25, MIP112, LVDS18, RSDS18, MINILVDS18, SUBLVDS18, PPDS18, SLVS18, HCSL18, HSTL12I
Inout	LVDS33, LVDS18, LVDS25, RSDS18, RSDS33, RSDS25, MINILVDS18, MINILVDS33, MINILVDS25, SUBLVDS18, SUBLVDS33, SUBLVDS25, PPDS18, PPDS33, PPDS25, SLVS33, SLVS25, HCSL33, HCSL25, LVPECL33, LVPECL25, MIP112, SLVS18, HCSL18, HSTL12I

-out_load <value>

Sets the output load (in pF) of output signals.

The default is 5.

Direction: Output

-res_pull <value>

Allows you to include a weak resistor for either pull-up or pull-down of the input buffer. Not all I/O standards have a selectable resistor pull option.

The following table shows the acceptable values for the -res_pull attribute:

I/O Standard	Value	Description
LVCMOS25, LVCMOS33, LVTTTL, PCI, LVCMOS18, LVCMOS15, LVCMOS12	Up	Includes a weak resistor for pull-up of the input buffer
	Down	Includes a weak resistor for pull-down of the input buffer
	Hold	Holds the last value
	None	Does not include a weak resistor

For all other I/O standards, the value is None.

The default is None.

Direction: Inout

-lock_down <value>

Security feature that locks down the I/Os if tampering is detected.

Values are ON, OFF. The default is OFF.

Direction: Inout

-ff_io_state <value>

Preserves the previous state of the I/O. You can override this default using the FF_IO_STATE attribute. When you set this attribute to LAST_VALUE, the I/O remains in the same state in which it was functioning before the device went into Flash*Freeze mode. Possible values are shown in the table below.

Value	Description
LAST_VALUE	Preserves the previous state of the I/O.
LAST_VALUE_WP	Preserves the last value with weak pull-up.

The default is LAST_VALUE.

Direction: Inout

-clamp_diode <value>

Specifies whether to add a power clamp diode to the I/O buffer. This attribute option is available to all I/O buffers with I/O technology set to LVTTTL. A clamp diode provides circuit protection from voltage spikes, surges, electrostatic discharge, and other over-voltage conditions.

Values are OFF, ON.

The following table lists the values for GPIO standards.

I/O Standard	Values
LVC MOS12, LVC MOS15, LVC MOS18, SSTL18I, SSTL18II, SSTL15I, SSTL15II, HSTL15I, HSTL15II, LVTTTL, LVC MOS33, LVC MOS25, SSTL25I, SSTL25II	OFF, ON. The default is ON.
HSUL18I, HSUL18II, SLVSE15, MIPI12, PCI, SLVS33, HCSL33, MIPIE33, LVPECL33, LVPECL25, LVPECLE33, LVDS25, LVDS33, RSDS25, RSDS33, MINILVDS25, MINILVDS33, SUBLVDS25, SUBLVDS33, PPDS25, PPDS33, MLVDSE25, BUSLVDS25	ON
MIPI12	OFF

For HSIO standards, the value is always ON.

Direction: Inout

-schmitt_trigger <value>

Specifies whether this I/O has an input schmitt trigger. The schmitt trigger introduces hysteresis on the I/O input. This allows very slow moving or noisy input signals to be used with the part without false or multiple I/O transitions taking place in the I/O.

For the following I/O standards, the values are OFF, ON. The default is OFF.

I/O Standard	Values
GPIO	
LVC MOS25, LVC MOS33, LVTTTL, PCI	OFF, ON

HSIO	
LVC MOS18, LVC MOS15	OFF, ON

For all other I/O standards, the value is OFF.

Direction: Input

-slew <value>

Sets the output slew rate. Slew control affects only the falling edges for some families. Slew control affects both rising and falling edges. Not all I/O standards have a selectable slew. Whether you can use the slew attribute depends on which I/O standard you have specified for this command.

The following I/O standards have values OFF, ON. The default is OFF.

I/O Standard	Values
LVC MOS25, LVC MOS33, LVTTTL, PCI	OFF, ON

For all other I/O standards, the value is OFF,

Direction: Output

-vicm_range <value>

Sets the VCM input range.

For SLVSE15, the value is MID.

Values for all other I/O standards are MID, LOW. The default is MID.

Direction: Input

-ODT <value>

On-die termination (ODT) is the technology where the termination resistor for impedance matching in transmission lines is located inside a semiconductor chip instead of on a printed circuit board.

Values are OFF, ON. The default is OFF.

Direction: Input

-ODT_VALUE

Sets the ODT value (in Ohms) for On Die Termination.

Values vary depending on the I/O standard. The table below lists acceptable values.

I/O Standard	Values
LVC MOS12, LVC MOS15, LVC MOS18, HSUL12I	60, 120, 240. The default is 60.
LVC MOS25	120, 240. The default is 120.
SSTL15I, SSTL15II,POD 12I, POD12II, SSTL135I, SSTL135II	20, 30, 40, 60, 120. The default is 60.
SSTL18I, SSTL18II	50, 75, 150. The default is 50.

LVSTL11I, LVSTL11II	40, 48, 60, 80, 120. The default is 60.
BUSLVDSE25, LVDS33, LVDS25, LVPECL33, LVPECL25, MINILVDS33, MINILVDS25, MLVDSE25, RSDS33, RSDS25, SLVSE15, SUBLVDS33, SUBLVDS25	100
HSTL15I, HSTL15II, HSUL18I, HSUL18II	50

Direction: Input

-out_drive <value>

Sets the strength of the output buffer to 1.5, 2, 3.5, 4, 6, 8, 10, 12, 16, or 20 in mA, weakest to strongest. The list of I/O standards for which you can change the output drive and the list of values you can assign for each I/O standard is family-specific. Not all I/O standards have a selectable output drive strength.

Also, each

I/O standard has a different range of legal output drive strength values. The values you can choose from depend on which I/O standard you have specified for this command. The table below lists acceptable values.

I/O Standard	Values
LVC MOS12, LVC MOS15	2, 4, 6, 8, 10. The default is 8.
LVC MOS18	2, 4, 6, 8, 10, 12. The default is 8.
LVC MOS25	2, 4, 6, 8, 12, 16. The default is 8.
LVC MOS33, LV TTL	2, 4, 8, 12, 16, 20. The default is 8.
LVDS25, LVDS33, MINILVDS25, MINILVDS33	3, 3.5, 4, 6. The default is 6.
PPDS25, PPDS33, RSDS25, RSDS33	1.5, 2, 3. The default is 3.
SUBLVDS25, SUBLVDS33	1, 1.5, 2. The default is 2.

BUSLVDSE25, MLVDSE25	16
MIPIE33, SLVSE15	8
PCI	20

Direction: Output

-impedance

Sets the Impedance value (in Ohms).

Values vary depending on the I/O standard. The table below lists acceptable values.

I/O Standard	Values
HSTL135I, HSTL15I	34, 40, 50, 60. The default is 60.
HSTL135II, HSTL15II, HSUL18II,	22, 25, 27, 30. The default is 25.
HSUL12I	34, 40, 48, 60, 80, 120. The default is 40.
HSUL18I	34, 40, 55, 60. The default is 55.
LVSTL11I, LVSTL11II	30, 34, 40, 48, 60, 80, 120, 240. The default is 40.
POD12I	40, 48, 60. The default is 48.
POD12II, SSTL135II, SSTL15II	27, 30, 34. The default is 34.
SSTL135I, SSTL15I	40, 48. The default is 40.
SSTL18I	40, 48, 60, 80. The default is 60.
SSTL18II	30, 34, 40, 48. The default is 40.
SSTL25I	48, 60, 80, 120. The default is 80.
SSTL25II	34, 40, 48, 60. The default is 48.

Direction: Output

set_location

PDC command; assigns the specified macro to a particular location on the chip.

```
set_location -inst_name <macro_inst_name> -fixed <true|false> -x <integer> -y <integer>
```

Arguments

-inst_name

Specifies the instance name of the macro in the netlist to assign to a particular location on the chip.

-fixed <true / false>

Sets whether the location of this instance is fixed (that is, locked). Locked instances are not moved during layout. The default is yes. The following table shows the acceptable values for this argument.

Value	Description
true	The location of this instance is locked.
false	The location of this instance is unlocked.

-x -y

The x and y coordinates specify where to place the macro on the chip. Use the Chip Planner tool to determine the x and y coordinates of the location.

Exceptions

None

Example

This example assigns and locks the macro with the name "mem_data_in\[57]" at the location x=7, y=2:

```
set_location -inst_name mem_data_in\[57\] -fixed true -x 7 -y 2
```

DDR3 Memory Placement

DDR3 memory needs to be placed in specific locations on the PolarFire chip to meet timing requirements. For DDR3 memory placement, the set_location command has the following syntax:

```
set_location -inst_name <hierarchical path to DDR instance> -location <edge>_<anchor>
```

-inst_name <hierarchical path to DDR instance>

Specifies the hierarchical path to the DDR instance.

-location <edge>_<anchor>

Specifies the edge_anchor location.

Example

```
set_location -inst_name {DDR3_TOP/DDR3_0}\ -location {NORTH_NE}
```

The maximum DDR width varies with the die/package combinations and the location they are placed in. Check the following table for the correct location to place the DDR3 memory. The numbers in the table refer to the maximum DDR3 width.

	Location (Edge_Anchor) Edge={NORTH/SOUTH/WEST}, Anchor={NE/NW/SE/SW}					
Die/Package	NORTH_NE	NORTH_NW	SOUTH_SE	SOUTH_SW	WEST_NW	WEST_SW
MPF200/FULLPKG	16	16	Invalid Loc	40	64	40
MPF300/FCG1152	64	72	16	40	72	64
MPF300/FCG484	8	8	Invalid Loc	32	Invalid Loc	16
MPF300/FCVG484	16	16	Invalid Loc	40	16	16

PLL Placement

For PLL placement, the set_location command has the following syntax:

```
set_location -inst_name <hierarchical inst name> -location <PLL location>
```

-inst_name <hierarchical inst name>

Specifies the hierarchical instance name.

-location <PLL location>

Specifies the PLL location. Location can be one of the following:

PLL0_NW
 PLL1_NW
 PLL0_NE
 PLL1_NE
 PLL0_SW
 PLL1_SW
 PLL0_SE
 PLL1_SE

DLL Placement

For DLL placement, the set_location command has the following syntax:

```
set_location -inst_name <hierarchical inst name> -location <DLL location>
```

-inst_name <hierarchical inst name>

Specifies the hierarchical instance name.

-location <DLL location>

Specifies the DLL location. Location can be one of the following:

DLL0_NW
 DLL1_NW
 DLL0_NE
 DLL1_NE
 DLL0_SW
 DLL1_SW
 DLL0_SE
 DLL1_SE

TxPLL Placement

For TxPLL placement, the set_location command has the following syntax:

```
set_location -inst_name <hierarchical inst name> -location <TxPLL location>
```

-inst_name <hierarchical inst name>

Specifies the hierarchical instance name.

-location <TxPLL location>

Specifies the TxPLL location. Location can be one of the following:

Q2_TXPLL0

Q2_TXPLL_SSC

Q2_TXPLL1

Q0_TXPLL0

Q0_TXPLL_SSC

Q0_TXPLL1

Q1_TXPLL0

Q1_TXPLL_SSC

Q1_TXPLL1

Q3_TXPLL_SSC

Q3_TXPLL1

3 – Netlist Attributes PDC Commands

Netlist Attributes PDC Commands are used to set netlist-specific constraints. These commands are placed in a Compile Netlist Constraint (*.ndc) file and used by the Libero SoC Compile engine to optimize the post-synthesis netlist.

set_preserve

This command sets a preserve property on instances before compile, so compile will preserve these instances and not combine them.

```
set_preserve -inst_name <instance_name>
```

Arguments

-inst_name

Specifies the full hierarchical name of the macro in the netlist to preserve.

Exceptions

You must put this command in a PDC constraint file and associate it with Place and Route.

Example

```
set_preserve -inst_name "test1/AND2_0"
```

4 – Floorplanning PDC Commands

Floorplanning PDC commands are used to create and edit user regions and to assign/unassign logic to these regions.

assign_region

PDC command; constrains a set of macros to a specified region.

```
assign_region -region_name <region_name> -inst_name <macro_name>+
```

Arguments

-region_name

Specifies the region to which the macros are assigned. The macros are constrained to this region. Because the define_region command returns a region object, you can write a simpler command such as assign_region [define_region]+ [macro_name]+

-inst_name

Specifies the macro(s) to assign to the region. You must specify at least one macro name. You can use the following wild card characters in macro names:

Wild Card	What it does
\	Interprets the next character as a non-special character
?	Matches any single character
*	Matches any string

Note:

- The region must be created before you can assign macros to it. If the region creation PDC command and the macro assignment command are in different PDC files, the order of the PDC files is important.
- You can assign only hard macros or their instances to a region. You cannot assign a group name. A hard macro is a logic cell consisting of one or more silicon modules with locked relative placement.
- The macro name must be a name with full hierarchical path.

Examples

In the following example, two macros are assigned to a region:

```
assign_region -region_name UserRegion1 -inst_name "test_0/AND2_0 test_0/AND2_1"
```

In the following example, all macros whose names have the prefix des01/Counter_1 (or all macros whose names match the expression des01/Counter_1/*) are assigned to a region:

```
assign_region -region_name User_region2 -inst_name des01/Counter_1/*
```

See Also

""

assign_net_macros

PDC command; assigns to a user-defined region all the macros that are connected to a net.

```
assign_net_macros -region_name <region_name> -net_name <net_name> -include_driver
<true|false>
```

Arguments

-region_name

Specifies the name of the region to which you are assigning macros. The region must exist before you use this command. See `define_region (rectangular)` or `define_region (rectilinear)`. Because the `define_region` command returns a region object, you can write a simple command such as `assign_net_macros [define_region]+ [net]+`

-net_name

You must specify at least one net name. Net names are AFL-level (flattened netlist) names. These names match your netlist names most of the time. When they do not, you must export AFL and use the AFL names. Net names are case insensitive. Hierarchical net names from ADL are not allowed. You can use the following wild card characters in net names:

Wild Card	What it does
\	Interprets the next character as a non-special character
?	Matches any single character
*	Matches any string

-include_driver

Specifies whether to add the driver of the net(s) to the region. You can enter one of the following values:

Value	Descriptions
true	Include the driver in the list of macros assigned to the region (default).
false	Do not assign the driver to the region.

Note:

- Placed macros (not connected to the net) that are inside the area occupied by the net region are automatically unplaced.
- Net region constraints are internally converted into constraints on macros. PDC export results as a series of `assign_region <region_name> macro1` statements for all the connected macros.
- If the region does not have enough space for all of the macros, or if the region constraint is impossible, the constraint is rejected and a warning message appears in the Log window.
- For overlapping regions, the intersection must be at least as big as the overlapping macro count.
- If a macro on the net cannot legally be placed in the region, it is not placed and a warning message appears in the Log window.
- Net region constraints may result in a single macro being assigned to multiple regions. These net region constraints result in constraining the macro to the intersection of all the regions affected by the constraint.

Examples

```
assign_net_macros -region_name UserRegion1 -net_name Y -include_driver false
```

define_region

PDC command; defines either a rectangular region or a rectilinear region.

```
define_region -region_name <region_name> -type <inclusive|exclusive|empty> -x1
<integer> -y1 <integer> -x2 <integer> -y2 <integer> [-color <integer>] [-route
<true|false>]
```

Note: The -color and -route parameters are optional.

Arguments

-region_name <region_name>

Specifies the region name. The name must be unique. Do not use reserved names such as "bank0" and "bank<N>" for region names. If the region cannot be created, the name is empty. A default name is generated if a name is not specified in this argument.

-type <inclusive / exclusive / empty>

Specifies the region type. The following table shows the acceptable values for this argument:













Region Type	Description
Empty	Empty regions cannot contain macros
Exclusive	Only contains macros assigned to the region
Inclusive	Can contain macros both assigned and unassigned to the region

-x1 -y1 -x2 -y2

Specifies the series of coordinate pairs that constitute the region. These rectangles may or may not overlap. They are given as x1 y1 x2 y2 (where x1, y1 is the lower left and x2 y2 is the upper right corner in row/column coordinates). You must specify at least one set of coordinates.

-color <value>

Specifies the color of the region. The following table shows the recommended values for this argument:

Color	Decimal Value
	16776960
	65280
	16711680
	16760960
	255
	16711935
	65535
	33023
	8421631
	9568200
	8323199
	12632256

-route <value>

Specifies whether to direct the routing of all nets internal to a region to be constrained within that region. A net is internal to a region if its source and destination pins are assigned to the region. You can enter one of the following values:

Constrain Routing Value	Description
true	Constrain the routing of nets within the region as well as the placement.
false	Do not constrain the routing of nets within the region. Only constrain the placement. This is the default value.

Note: Local clocks and global clocks are excluded from the -route option. Also, interface nets are excluded from the -route option because they cross region boundaries.

An empty routing region is an empty placement region. If -route is "true", then no routing is allowed inside the empty region. However, local clocks and globals can cross empty regions.

An exclusive routing region is an exclusive placement region (rectilinear area with assigned macros) along with the following additional constraints:

- For all nets internal to the region (the source and all destinations belong to the region), routing must be inside the region (that is, such nets cannot be assigned any routing resource which is outside the region or crosses the region boundaries).
- Nets without pins inside the region cannot be assigned any routing resource which is inside the region or crosses any region boundaries.

An inclusive routing region is an inclusive placement region (rectilinear area with assigned macros) along with the following additional constraints:

- For all nets internal to the region (the source and all destinations belong to the region), routing must be inside the region (that is, such nets cannot be assigned any routing resource which is outside the region or crosses the region boundaries).
- Nets not internal to the region can be assigned routing resources within the region.

Description

Unlocked macros in empty or exclusive regions are unassigned from that region. You cannot create empty regions in areas that contain locked macros.

Use inclusive or exclusive region constraints if you intend to assign logic to a region. An inclusive region constraint with no macros assigned to it has no effect. An exclusive region constraint with no macros assigned to it is equivalent to an empty region.

Note: If macros assigned to a region exceed the area's capacity, the region's Properties Window displays the overbooked resources (over 100 percent resource utilization) in red.

Examples

The following example defines an empty rectangular region called UserRegion1 with lower-left co-ordinates (100,46) and upper-right co-ordinates (102,50).

```
define_region -region_name UserRegion1 -type empty -x1 100 -y1 46 -x2 102 -y2 50
```

The following example defines an inclusive rectilinear region with the name UserRegion2. This region contains two rectangular areas, one with lower-left co-ordinates (12,39) and upper-right co-ordinates (23,41) and another rectangle with lower-left co-ordinates (12,33) and upper-right co-ordinates (23,35).

```
define_region -region_name UserRegion2 -type exclusive -x1 12 -y1 39 -x2 23 -y2 41 -x1 12 -y1 33 -x2 23 -y2 35
```

The following examples define three regions with three different colors:

```
define_region -region_name UserRegion0 -color 128 -x1 50 -y1 19 -x2 60 -y2 25
define_region -region_name UserRegion1 -color 16711935 -x1 11 -y1 2 -x2 55 -y2 29
define_region -region_name UserRegion2 -color 8388736 -x1 61 -y1 6 -x2 69 -y2 19
```

See Also

["assign_region"](#)

move_region

PDC command; moves the named region to the coordinates specified.

```
move_region -region_name <region_name> -x1 <integer> -y1 <integer> -x2 <integer> -y2  
<integer>
```

Arguments

-region_name

Specifies the name of the region to move. This name must be unique.

-x1 -y1 -x2 -y2

Specifies the series of coordinate pairs representing the location in which to move the named region. These rectangles can overlap. They are given as x1, y1, x2, y2, where x1, y1 represents the lower-left corner of the rectangle and x2 y2 represents the upper-right corner. You must specify at least one set of coordinates.

Example

This example moves the region named UserRegion1 to a new region with lower-left co-ordinates (0,40) and upper-right co-ordinates (3,42):

```
move_region -region_name UserRegion1 -x1 0 -y1 40 -x2 3 -y2 42
```

See Also

["define_region"](#)

A – Product Support

Microsemi SoC Products Group backs its products with various support services, including Customer Service, Customer Technical Support Center, a website, electronic mail, and worldwide sales offices. This appendix contains information about contacting Microsemi SoC Products Group and using these support services.

Customer Service

Contact Customer Service for non-technical product support, such as product pricing, product upgrades, update information, order status, and authorization.

From North America, call **800.262.1060**
From the rest of the world, call **650.318.4460**
Fax, from anywhere in the world, **650.318.8044**

Customer Technical Support Center

Microsemi SoC Products Group staffs its Customer Technical Support Center with highly skilled engineers who can help answer your hardware, software, and design questions about Microsemi SoC Products. The Customer Technical Support Center spends a great deal of time creating application notes, answers to common design cycle questions, documentation of known issues, and various FAQs. So, before you contact us, please visit our online resources. It is very likely we have already answered your questions.

Technical Support

For Microsemi SoC Products Support, visit <http://www.microsemi.com/products/fpga-soc/design-support/fpga-soc-support>.

Website

You can browse a variety of technical and non-technical information on the Microsemi SoC Products Group [home page](#), at www.microsemi.com/soc.

Contacting the Customer Technical Support Center

Highly skilled engineers staff the Technical Support Center. The Technical Support Center can be contacted by email or through the Microsemi SoC Products Group website.

Email

You can communicate your technical questions to our email address and receive answers back by email, fax, or phone. Also, if you have design problems, you can email your design files to receive assistance. We constantly monitor the email account throughout the day. When sending your request to us, please be sure to include your full name, company name, and your contact information for efficient processing of your request.

The technical support email address is soc_tech@microsemi.com.

My Cases

Microsemi SoC Products Group customers may submit and track technical cases online by going to [My Cases](#).

Outside the U.S.

Customers needing assistance outside the US time zones can either contact technical support via email (soc_tech@microsemi.com) or contact a local sales office.

Visit [About Us](#) for sales office listings and corporate contacts.

Sales office listings can be found at www.microsemi.com/soc/company/contact/default.aspx.

ITAR Technical Support

For technical support on RH and RT FPGAs that are regulated by International Traffic in Arms Regulations (ITAR), contact us via soc_tech_itar@microsemi.com. Alternatively, within My Cases, select **Yes** in the ITAR drop-down list. For a complete list of ITAR-regulated Microsemi FPGAs, visit the ITAR web page.



Microsemi Corporate Headquarters
One Enterprise, Aliso Viejo,
CA 92656 USA

Within the USA: +1 (800) 713-4113
Outside the USA: +1 (949) 380-6100
Sales: +1 (949) 380-6136
Fax: +1 (949) 215-4996

E-mail: sales.support@microsemi.com

©2016 Microsemi Corporation. All rights reserved. Microsemi and the Microsemi logo are trademarks of Microsemi Corporation. All other trademarks and service marks are the property of their respective owners.

About Microsemi

Microsemi Corporation (Nasdaq: MSCC) offers a comprehensive portfolio of semiconductor and system solutions for communications, defense & security, aerospace, and industrial markets. Products include high-performance and radiation-hardened analog mixed-signal integrated circuits, FPGAs, SoCs, and ASICs; power management products; timing and synchronization devices and precise time solutions, setting the world's standard for time; voice processing devices; RF solutions; discrete components; Enterprise Storage and Communication solutions, security technologies and scalable anti-tamper products; Ethernet solutions; Power-over-Ethernet ICs and midspans; as well as custom design capabilities and services. Microsemi is headquartered in Aliso Viejo, Calif. and has approximately 4,800 employees globally. Learn more at www.microsemi.com.

Microsemi makes no warranty, representation, or guarantee regarding the information contained herein or the suitability of its products and services for any particular purpose, nor does Microsemi assume any liability whatsoever arising out of the application or use of any product or circuit. The products sold hereunder and any other products sold by Microsemi have been subject to limited testing and should not be used in conjunction with mission-critical equipment or applications. Any performance specifications are believed to be reliable but are not verified, and Buyer must conduct and complete all performance and other testing of the products, alone and together with, or installed in, any end-products. Buyer shall not rely on any data and performance specifications or parameters provided by Microsemi. It is the Buyer's responsibility to independently determine suitability of any products and to test and verify the same. The information provided by Microsemi hereunder is provided "as is, where is" and with all faults, and the entire risk associated with such information is entirely with the Buyer. Microsemi does not grant, explicitly or implicitly, to any party any patent rights, licenses, or any other IP rights, whether with regard to such information itself or anything described by such information. Information provided in this document is proprietary to Microsemi, and Microsemi reserves the right to make any changes to the information in this document or to any products and services at any time without notice.