



# **PRECISION IMPEDANCE ANALYZER 6500B Series**

**Remote Control Commands  
User Manual**

**Issue B draft**

<b>ILLUSTRATIONS.....</b>	<b>8</b>
<b>1. REMOTE CONTROL.....</b>	<b>9</b>
1.1 GPIB Interface .....	9
1.1.1 Introduction.....	9
1.1.1.1 Interface Specification .....	9
1.1.1.2 GPIB Address .....	9
1.2 Remote Programming .....	10
1.2.1 Remote Messages and Commands .....	10
1.2.1.1 Command Strings .....	10
1.2.1.2 Paths .....	11
1.2.2 Command Structure .....	11
1.3 Data Output.....	12
1.3.1 Output Syntax.....	12
1.3.2 Real Data Errors.....	12
1.4 Status Groups .....	13
1.5 List of Commands and Queries.....	14
Delta Marker Functions.....	18
Peak Search Functions .....	18
1.6 /E Equivalent Circuit Analysis Option.....	18
1.7 /K Materials Test Option .....	19
1.8 Common Commands .....	21
*ESE <integer>.....	21
*ESE? .....	21
*ESR? .....	21
*IDN? .....	21
*OPT? .....	21
*SRE <integer> (GPIB only).....	22
*SRE? (GPIB only).....	22
*STB? .....	22
*TRG .....	22
1.9 Status Commands.....	23
OPERation:ENABLE <integer> .....	23
OPERation:EVENT?.....	23
OPERation:CONDition? .....	23
1.10 Calibration.....	24
:OpenCircuit-TRIM .....	24
:OpenCircuit-TRIM?.....	24
:ShortCircuit-TRIM .....	24
:ShortCircuit-TRIM?.....	24
:HF-COMPensation .....	25
:FREQuency-LIMIT <real>.....	25
:FREQuency-LIMIT? .....	25
:STORE-TRIMS .....	25
:CLEAR-TRIMS .....	25
:STORE-HF-COMPensation .....	25
:CLEAR-HF-COMPensation .....	26
1.11 Meter Mode.....	27

## 6500B Remote Control User Manual Issue B

:TRIGger.....	27
:FUNCTION:1 <discrete>   :FUNCTION:2 <discrete> .....	27
:FUNCTION:1?   :FUNCTION:2? .....	27
:EQU-CCT <discrete> .....	28
:EQU-CCT? .....	28
:SPEED <discrete> .....	28
:SPEED? .....	28
:FREQuency <real> .....	29
:FREQuency? .....	29
:LEVel <discrete>.....	29
:LEVel? .....	29
:DRIVE? .....	30
:RANGE <discrete>.....	30
:RANGE?.....	30
:BIAS <real>.....	30
:BIAS? .....	30
:BIAS-STATe <disc> .....	31
:BIAS-STATe? .....	31
:BIAS-TYPE <disc> .....	31
:BIAS-TYPE? .....	31
:DISPlay <discrete>.....	31
:DISPlay? .....	33
:DEViation-TERM <integer> .....	33
:DEViation-TERM? .....	33
:DEViation-TYPE <discrete> .....	33
:DEViation-TYPE? .....	33
:NOMinal <real>.....	34
:NOMinal? .....	34
:SAVE-NOMinal .....	34
:SHOW-SCALE1 <discrete>   :SHOW-SCALE2 <discrete> .....	34
:SHOW-SCALE1?   :SHOW-SCALE2? .....	34
:SCALE1-HIgh <real>   :SCALE2-HIgh <real>.....	34
:SCALE1-HIgh?   :SCALE2-HIgh? .....	35
:SCALE1-LOw <real>   :SCALE2-LOw <real>.....	35
:SCALE1-LOw?   :SCALE2-LOw? .....	35
:SCALE1-NOMinal <real>   :SCALE2-NOMinal <real>.....	35
:SCALE1-NOMinal?   :SCALE2-NOMinal? .....	35
:SCALE1-SAVENOMinal   :SCALE2-SAVENOMinal.....	36
:SCALE1-TYPE <discrete>   :SCALE2-TYPE <discrete> .....	36
:SCALE1-TYPE?   :SCALE2-TYPE? .....	36
:FAST-GPIB <discrete> .....	36
:Q-SAVE.....	36
:Q-LOAD .....	37
:RESOnance:StarT <real> .....	37
:RESOnance:StarT? .....	37
:RESOnance:StoP <real>.....	37
:RESOnance:StoP? .....	37
:RESOnance:EQU-CCT <disc>.....	37

:RESOnance:EQU-CCT?	38
:RESOnance:TRIG	38
:RESOnance:TRAINing	38
:RESOnance:FM-FN?	39
:RESOnance:FS-FP?	39
:RESOnance:CP-1K?	39
:RESOnance:KEFF?	40
:RESOnance:ENABLE-CP <int>	40
:RESOnance:ENABLE-CP?	40
:RESOnance:DEPTH <integer>	40
:RESOnance:DEPTH?	40
:RESOnance:SPEED <disc>	41
:RESOnance:SPEED?	41
:RESOnance: LO-LIM <real>	41
:RESOnance: LO-LIM?	41
:RESOnance: HI-LIM <real>	42
:RESOnance: : HI-LIM?	42
:RESOnance:ENABLE-HILO	42
:RESOnance:ENABLE-HILO?	42
1.12 Analysis Mode (:ANALysis)	43
:ANA:EXPORT-OVERWRITE <discrete>	43
:ANA:EXPORT-OVERWRITE?	43
:ANA:EXPORT \xxx\yyyy.csv	43
:ANA:BITMAP-OVERWRITE <discrete>	44
:ANA:BITMAP-OVERWRITE?	44
:ANA:BITMAP \xxx\yyyy.bmp	44
:Q-SAVE	45
:Q-LOAD	45
:TRIGger	45
PROPerTy1 <discrete> PROPerTy2 <discrete>	45
PROPerTy1? PROPerTy2?	46
:EQU-CCT <discrete>	46
:EQU-CCT?	46
SPEED <discrete>	46
SPEED?	47
RANGE <discrete>	47
RANGE?	47
:LEVel <discrete>	47
:LEVEL?	48
:DRIVE?	48
:FREQuency <real>	48
:FREQuency?	48
:BIAS <real>	49
:BIAS?	49
:BIAS-STATe	49
:BIAS-STATe?	49
:BIAS-TYPE	50
:BIAS-TYPE?	50

:PARAMETER <disc> .....	50
:PARAMETER? .....	50
:POINTS <real> .....	50
:POINTS? .....	51
:LOG-X <discrete> .....	51
:LOG-X? .....	51
:START <real> .....	51
:START? .....	51
:STOP <real> .....	52
:STOP? .....	52
:LOG-Y <discrete> .....	52
:LOG-Y? .....	52
:MAXimum1 <real> :MAXimum2 <real> .....	52
:MAXimum1? :MAXimum2? .....	52
:MINimum1 <real> :MINimum2 <real> .....	53
:MINimum1? :MINimum2? .....	53
:TITLE <discrete> .....	53
:TITLE? .....	53
:AVEerages <integer> .....	53
:AVEerages? .....	54
:RESET-AVEraging .....	54
:FIT <integer> .....	54
POINT? <integer> .....	54
RESULT? <real> .....	54
<i>Analysis Mode – Marker (ANALysis:MarKeR)</i> .....	55
:MKR:STATE <discrete> .....	55
:MKR:STATE? .....	55
:MKR:TYPE <discrete> .....	55
:MKR:TYPE? .....	55
:MKR:SELECT <integer> .....	56
:MKR:SELECT? .....	56
:MKR:POSITION <real> .....	56
:MKR:POSITION? .....	56
:MKR:LEFT .....	56
:MKR:RIGHT .....	56
<i>Delta Marker Functions</i> .....	57
:MKR:DELTA-PARAMETER <real> .....	57
:MKR:DELTA-PARAMETER? .....	57
:MKR:DELTA-VALUE1 <real> :MKR:DELTA-VALUE2 <real> .....	57
:MKR:DELTA-VALUE1? :MKR:DELTA-VALUE2? .....	57
:MKR:DELTA-USE-MARKER .....	57
:MKR:RELATIVE-RESULT? .....	58
:MKR:DELTA-RESULT? .....	58
:MKR:RELATIVE-MARKER <integer> .....	58
:MKR:RELATIVE-MARKER? .....	58
:MKR:RESULT? .....	58
<i>Peak Search Functions</i> .....	58
:MKR:SEARCH-TYPE <integer> .....	58

:MKR:SEARCH-TYPE? .....	59
:MKR:SEARCH-TRACE <integer>.....	59
:MKR:SEARCH-TRACE? .....	59
:MKR:SEARCH-FIND.....	59
:MKR:SEARCH-LEFT.....	59
:MKR:SEARCH-RIGHT .....	60
:MKR:SEARCH-NEXT-HIGH .....	60
:MKR:SEARCH-NEXT-LOW .....	60
1.13 /E Equivalent Circuit Analysis Option.....	61
DISPLAY <disc>.....	61
CCT <integer> .....	61
CCT?.....	61
R1 <real> .....	61
R1?.....	62
C1 <real> .....	62
C1?.....	62
L1 <real> .....	62
L1?.....	63
C0 <real> .....	63
C0?.....	63
TRACE <disc> .....	64
TRACE? .....	64
CALC-PARS .....	64
MODE <disc>.....	64
MODE?.....	64
POINT? <integer> .....	65
RESULT? <real> .....	65
1.14 /K Materials Test Option .....	66
TYPE <disc> .....	66
TYPE? .....	66
D <real> .....	66
D?.....	66
CONTACT-TM <real> .....	66
CONTACT-TM?.....	67
TG <real> .....	67
TG? .....	67
NONCONTACT-TM <real>.....	67
NONCONTACT-TM? .....	67
MEASURE-CG .....	67
MEASURE-CG?.....	68
N <integer>.....	68
N?.....	68
L <real> .....	68
L? .....	68
A <real> .....	68
A?.....	69
MEASURE-LR.....	69
MEASURE-LR? .....	69

<i>Analysis Mode –(ANALYSIS)</i> .....	69
PROPerTy1 <disc>    PROPerTy2 <disc>.....	69
PROPerTy1?    PROPerTy2?.....	70
<i>Meter Mode –(METEr:)</i> .....	70
FUNCTion:1 <disc>    FUNCTion:2 <disc>.....	70
FUNC:1?    FUNC:2?.....	71
1.15 /Y Polar Complex Plots .....	72
DISPLAY-MODE <discrete>.....	72
DISPLAY-MODE?.....	72
<i>POLAR PLOT</i> .....	72
POLAR-PROPerTy <discrete> .....	72
POLAR-PROPerTy? .....	72
POLAR-SCALE <real> .....	73
POLAR-SCALE?.....	73
POLAR-DIVisionFullScale <integer>.....	73
POLAR-DIVisionFullScale? .....	73
POLAR-FRaMe <discrete> .....	73
POLAR-FRaMe? .....	74
POLAR-FIT <integer>.....	74
LOG-SWeePPARameter <disc>.....	74
LOG-SWeePPARameter?.....	74
<i>COMPLEX PLOT</i> .....	74
COMPLEX-PROPerTy <disc> .....	74
COMPLEX-PROPerTy? .....	75
COMPLEX-FrameWidth <real>.....	75
COMPLEX-FrameWidth? .....	75
COMPLEX-FrameCentreX <real> .....	75
COMPLEX-FrameCentreX?.....	76
COMPLEX-FrameCentreY <real> .....	76
COMPLEX-FrameCentreY?.....	76
COMPLEX-FIT .....	76

**ILLUSTRATIONS**

Figure 1-1 Remote Message Structure..... 10

Figure 1-2 Command Paths ..... 11

Figure 1-3 Command Path Example ..... 11

Figure 1-4 GPIB Command Structure ..... 11

Figure 1-5 Remote Data Output..... 12



# 1. REMOTE CONTROL

The 6500B series of instruments may be remotely controlled using the General Purpose Interface Bus (GPIB) or a Local Area Network (LAN). This chapter describes the interface specification and the command structure for both forms of remote instrument control.

## 1.1 GPIB Interface

### 1.1.1 Introduction

The General Purpose Interface Bus (GPIB) is a parallel port designed to be used for communication between instruments and control devices such as PCs fitted with a suitable interface card.

The GPIB interface is used where relatively local control and data logging of an instrument is required. For extended operating distance and a reduction in computer costs consider using the industry standard LAN (Ethernet IEEE802.3) control port.

#### 1.1.1.1 Interface Specification

The IEEE 488.1 bus standard and the IEEE 488.2 code standard are fully supported. The structure of the command set broadly follows the SCPI standard.

SH1	Full source handshake
AH1	Full acceptor handshake
T6	Basic talker, serial poll, no talk only, untalk if MLA
TE0	No talker with secondary addressing
L4	Basic listener, no listen only, unlisten if MTA
LE0	No listener with secondary addressing
SR1	Full service request
DC1	Full device clear
RL1	Full remote/local compatibility
PP0	No parallel poll
DT1	Full device trigger compatibility
C0	No controller

*Table 1-1 IEEE 488.1 Supported Functions*

#### 1.1.1.2 GPIB Address

Each instrument on the GPIB bus requires a unique address within the range 1 to 16.

The default address for this 6500 is 6 and is stored in non-volatile memory. This may be changed in the **Settings** page found in the **mode** menu item in Meter or Analysis mode.

## 1.2 Remote Programming

### 1.2.1 Remote Messages and Commands

A remote message is made up of one or more commands. Remote commands are divided into two groups.

- Common commands – These commands query/change the instrument's status, e.g. querying the status groups or identifying the instrument.
- Subsystem commands – These commands are used to query/control the instrument's function, e.g. to change frequency or perform measurements.

#### 1.2.1.1 Command Strings

Command strings are the basic form of communication with the instrument. Command strings can contain one or more individual commands. A semicolon is used to separate multiple commands within one command string. The linefeed character and/or asserting EOI (*GPIB only*) terminates the string. Once a string has been received all the commands it contains are executed in the order that they occur within the string from left to right. Command strings are not case sensitive.




Figure 1-1 Remote Message Structure

Example:

Set the frequency and level in meter mode:

```
:METER:LEVEL 0.5;:METER:FREQ 1E4<lf>
```

### 1.2.1.2 Paths

Subsystem commands are accessed via a command path. Paths group the instrument commands into related categories to ease programming. The paths are defined in a tree structure:




Figure 1-2 Command Paths

For example to access the marker sub system command to move the marker right:




Figure 1-3 Command Path Example

### 1.2.2 Command Structure




Figure 1-4 GPIB Command Structure

Examples

No parameter: `:ANALYSIS:MARKER:LEFT`

Discrete parameter: `:METER:BIAS-STAT ON`

Real parameter: `:METER:FREQ 1.2E6`

Integer parameter: `:ANALYSIS:MARKER:SELECT 1`

## 1.3 Data Output

Data is returned from the instrument as an ASCII character string that is terminated with a line feed character.

### 1.3.1 Output Syntax




Figure 1-5 Remote Data Output

#### Examples

String data: IMPEDANCE vs. FREQUENCY

Real data: 1.344517e+005

Integer data: 2

Multiple data: 9.243736e+002, 4.748015e+004

### 1.3.2 Real Data Errors

Real data may be output from the instrument containing a leading '#' character. This indicates that the instrument encountered a numerical error while processing the previous GPIB command. This error is usually caused by submitting a query for an instrument parameter which has not been set or a measurement not completed.

## 1.4 Status Groups

Bit	Name	Description
0	<b>OPC</b>	Operation Complete: Not used, commands are processed sequentially.
1	<b>RQC</b>	Not used.
2	<b>QYE</b>	Not used.
3	<b>DDE</b>	Device Dependant Error
4	<b>EXE</b>	Execution Error: Command could not be processed, ie parameter out of range.
5	<b>CME</b>	Command Error: Command not understood, ie syntax error.
6	<b>URQ</b>	Not used.
7	<b>PON</b>	1 if the instrument has been powered down since the last read, 0 otherwise.

Table 1-2 Standard Event Group

Bit	Name	Description
0	<b>Calibrating</b>	Set when calibration in progress.
1-2	<b>Settling</b>	Not used.
3	<b>Sweeping</b>	Set when sweeping.
4	<b>Measuring</b>	Set when measuring.
5-14	-	Not used.
15	<b>Always Zero</b>	Always Zero.

Table 1-3 Standard Operation Status Group

Bit	Name	Description
0-2		Not used.
3	<b>QUE</b>	Not used.
4	<b>MAV</b>	Message available in output queue.
5	<b>ESB</b>	Standard Event group summary bit.
6	<b>RQS</b>	Service Request.
7	<b>OPR</b>	Standard Operation group summary bit.

Table 1-4 Status Group

Group summary bits are set when the value of the group register masked with the value of the enable register (logical AND) is not zero (logical OR).

RQS is set when the value of the Status Group masked with the value of the Status Group Enable register (logical AND) is not zero (logical OR).

RQS being set will generate a GPIB service request (*GPIB only*).

## 1.5 List of Commands and Queries

Command	Query	Brief Description	Page
<b>COMMON COMMANDS &amp; QUERIES</b>			
*ESE <int>	*ESE?	Standard Event Enable group value	21
-	*ESR?	Standard Event group value	21
-	*IDN?	Instrument identification	21
-	*OPT?	Instrument hardware options	21
*SRE <int>	*SRE?	Status Byte Enable group value (GPIB only)	22
-	*STB?	Status Byte group value	22
*TRG	-	Trigger a measurement	22
<b>:STATUS (STATUS COMMANDS &amp; QUERIES)</b>			
:OPER:ENAB <int>	-	Standard Operation Status group enable register	23
-	:OPER:EVEN?	Standard Operation Group event register	23
-	:OPER:COND?	Standard Operation Group register	23

<b>CALIBRATION COMMANDS &amp; QUERIES</b>			
:FREQ-LIMIT	:FREQ-LIMIT?	Set Upper Frequency Limit for trims and HF Comp	25
:OC-TRIM	:OC-TRIM?	Perform an Open Circuit Trim	24
:SC-TRIM	:SC-TRIM?	Perform a Short Circuit Trim	24
:HF-COMP	:HF-COMP?	Start the HF Compensation	25
:STORE-TRIMS	-	Store user short circuit and open circuit trim values	25
:CLEAR-TRIMS	-	Clear user short circuit and open circuit trim values	25
:STORE-HF-COMP	-	Store user HF Compensation values	25
:CLEAR-HF-COMP	-	Clear user HF Compensation values	26

METER MODE COMMANDS & QUERIES (:METER)			
:TRIG	-	Trigger a measurement	27
:FUNC:1	:FUNC:1?	Term 1 measurement parameter	27
:FUNC:2	:FUNC:2?	Term 2 measurement parameter	27
:EQU-CCT	:EQU-CCT?	Equivalent circuit setting	28
:SPEED	:SPEED?	Speed setting	28
:FREQ	:FREQ?	Frequency setting	29
:LEV	:LEV?	AC Drive level	29
-	:DRIVE?	AC Drive type	30
:RANGE	:RANGE?	Range	30
:BIAS	:BIAS?	Set the DC Bias Source Level	30
:BIAS-STAT	:BIAS-STAT?	Change the state of the DC Bias Source	31
:BIAS-TYPE	:BIAS-TYPE?	Select the DC Bias Source.	31
:DISP	:DISP?	Display Absolute / Deviation	31
:DEV-TERM	:DEV-TERM?	Term 1 / 2 used for deviation display	33
:DEV-TYPE	:DEV-TYPE?	Absolute / % / ppm deviation format	33
:NOM	:NOM?	Nominal value in deviation mode	34
:SAVE-NOM	-	Used last measurement as nominal value	34
:SHOW-SCALE1	:SHOW-SCALE1?	Term 1 scale bar on / off	34
:SHOW-SCALE2	:SHOW-SCALE2?	Term 2 scale bar on / off	34
:SCALE1-HI	SCALE1-HI?	Term 1 scale bar high limit	34
:SCALE2-HI	:SCALE2-HI?	Term 2 scale bar high limit	34
:SCALE1-LO	SCALE1-LO?	Term 1 scale bar low limit	35
:SCALE2-LO	:SCALE2-LO?	Term 2 scale bar low limit	35
:SCALE1-NOM	SCALE1-NOM?	Term 1 scale bar nominal value	35
:SCALE2-NOM	:SCALE2-NOM?	Term 2 scale bar nominal value	35
:SCALE1-SAVENOM	-	Use last measurement as Term 1 scale bar nominal value	36
:SCALE2-SAVENOM	-	Use last measurement as Term 2 scale bar nominal value	36
:SCALE1-TYPE	:SCALE1-TYPE?	Term 1 scale bar as Absolute / Relative	36
:SCALE2-TYPE	:SCALE2-TYPE?	Term 2 scale bar as Absolute / Relative	36
:Q-SAVE	-	Save the current Meter Mode Measurement Setup	36
:Q-LOAD	-	Load the previously saved Meter Mode Measurement Setup	37
:RESO:ST	:RESO:ST?	Set the Start Frequency for the search	37

:RESO:SP	:RESO:SP?	Set the Stop Frequency of the search	37
:RESO:EQU-CCT	:RESO:EQU-CCT?	Select the Equivalent Circuit Type	37
:RESO:TRIG	-	Begin a Resonance Search	38
:RESO:TRAIN	-	Execute the 'Check Valid' function	38
-	:RESO:FM-FN?	Query the frequencies at Zmin and Zmax (fm and fn).	39
-	:RESO:FS-FP?	Query the frequencies at Gmax and Rmax (fs and fp)	39
-	:RESO:CP-1K?	Query the Cp reading at 1kHz	39
-	:RESO:KEFF?	Query the Keff result	40
:RESO:ENABLE-CP:	RESO:ENABLE-CP?	Enable/Disable the Cp at 1kHz calculation	40
:RESO:DEPTH	:RESO:DEPTH?	Set Resonance Search Depth	40
:RESO:SPEED	:RESO:SPEED?	Set the Measurement Speed	41
:RESO:LO-LIM	:RESO:LO-LIM?	Set the Low Limit Frequency	41
:RESO:HI-LIM	:RESO:HI-LIM?	Set the High Limit Frequency	42
:RESO:ENABLE-HILO	:RESO:ENABLE-HILO?	Enable/Disable the Hi/Lo Test Limits	42
:FAST-GPIB	-	Enable / disable display update	36
<b>:ANA (ANALYSIS MODE COMMANDS &amp; QUERIES)</b>			
:EXPORT-OVERWRITE	:EXPORT-OVERWRITE	File Overwrites setting in Export Trace	43
:EXPORT \xxxx\yyyy.csv	-	Write 'export data' file to USB	43
:BITMAP-OVERWRITE	:BITMAP-OVERWRITE?	File Overwrites setting in Save Bitmap	44
:BITMAP \xxxx\yyyy.bmp	-	Write 'save bitmap' file to USB	44
:Q-SAVE	-	Save the current Analysis Mode Measurement Setup	45
:Q-LOAD	-	Load the previously saved Analysis Mode Measurement Setup	45
:TRIG	-	Start a sweep	45
:PROP1	:PROP1?	Trace 1 measurement parameter	45
:PROP2	:PROP2?	Trace 2 measurement parameter	45
:EQU-CCT	:EQU-CCT?	Equivalent Circuit setting	46
:SPEED	:SPEED?	Speed setting	46



:RANGE	:RANGE?	Range	47
:LEV	:LEV?	AC Drive level for frequency and DC Bias sweeps	47
-	:DRIVE?	AC Drive type for frequency and DC Bias sweeps	48
:FREQ	:FREQ?	Frequency setting for AC Drive and DC Bias sweeps	48
:BIAS	:BIAS?	Set the DC Bias Source Level	49
:BIAS-STAT	:BIAS-STAT?	Change the state of the DC Bias Source	49
:BIAS-TYPE	:BIAS-TYPE?	Select the DC Bias Source.	50
:POINTS	:POINTS?	Number of measurement points in a trace	50
:LOG-X	:LOG-X?	X-axis as log/linear scale	51
:START	:START?	X-axis start value	51
:STOP	:STOP?	X-axis stop value	52
:LOG-Y	:LOG-Y?	Y-axis as log/linear scale	52
:MAX1	:MAX1?	Trace 1 Y-axis maximum value	52
:MAX2	:MAX2?	Trace 2 Y-axis maximum value	52
:MIN1	:MIN1?	Trace 1 Y-axis minimum value	53
:MIN2	:MIN2?	Trace 2 Y-axis minimum value	53
:TITLE	:TITLE?	Graph title	53
:AVE	:AVE?	Trace averages	53
:RESET-AVE	-	Reset trace averaged values to zero	54
:FIT	-	Auto Fit Y-axes	54
-	:POINT?	Query X-value and Trace 1 / 2 Y-values at the $n^{\text{th}}$ point on the traces	54
-	:RESULT?	Query the measurement result nearest to the defined X-axis value	54
:MKR:STATE	:MKR:STATE?	Enable / disable the Active Marker	55
:MKR:TYPE	:MKR:TYPE?	Select the Active Marker <b>Display</b> type	55
:MKR:SELECT	:MKR:SELECT?	Select the Active Marker Number	56
:MKR:POSITION	:MKR:POSITION?	Move the Active Marker to the point nearest the X-value	56
:MKR:LEFT	-	Move the Active Marker left to the next measurement on the traces	56
:MKR:RIGHT	-	Move the Active Marker right to the next measurement on the traces	56

<b>Delta Marker Functions</b>			
:MKR:DELTA-PARAMETER	:MKR:DELTA-PARAMETER?	Set the X-value to which the delta marker will be relative	57
:MKR:DELTA-VALUE1	:MKR:DELTA-VALUE1?	Set the Trace 1 value to which the delta marker will be relative	57
:MKR:DELTA-VALUE2	:MKR:DELTA-VALUE2?	Set the Trace 2 value to which the delta marker will be relative	57
:MKR:DELTA-USE-MARKER	-	Set the Current Marker Value as the nominal	57
:MKR:RELATIVE-MARKER	:MKR:RELATIVE-MARKER?	Set the marker to use for the relative marker calculations.	58
-	:MKR:RESULT?	Returns the result of the Delta Marker	58
<b>Peak Search Functions</b>			
:MKR:SEARCH-TYPE	:MKR:SEARCH-TYPE?	Select Search Type as Peak or Dip	58
:MKR:SEARCH-TRACE	:MKR:SEARCH-TRACE?	Select the Trace to use for peak/dip searching	59
:MKR:SEARCH-FIND	-	Move the Active Marker to the peak / dip	59
:MKR:SEARCH-LEFT	-	Move the Active Marker to the next peak / dip to the left	59
:MKR:SEARCH-RIGHT	-	Move the Active Marker to the next peak / dip to the right	60
:MKR:SEARCH-NEXT-HIGH	-	Move the Active Marker to the next highest peak / dip	60
:MKR:SEARCH-NEXT-LOW	-	Move the Active Marker to the next lowest peak / dip	60

## 1.6 /E Equivalent Circuit Analysis Option

DISPLAY	-	Show/Hide Equivalent Circuit mode dialog box	61
CCT	CCT?	Set the Equivalent Circuit type	61
R1	R1?	Set the R1 Equivalent Circuit component value	61
C1	C1?	Set the C1 Equivalent Circuit component value	62
L1	L1?	Set the L1 Equivalent Circuit component value	62
C0	C0?	Set the C0 Equivalent Circuit component value	63

TRACE	TRACE?	Turn Equivalent Circuit traces on and off	64
CALC-PARS	-	Calculate Equivalent Circuit Parameters	64
MODE	MODE?	Select Equivalent Circuit Mode	64
-	POINT?	Query a point on the Equivalent Circuit trace	65
-	RESULT?	Query the Equivalent Circuit result nearest to the defined X-axis value	65

## 1.7 /K Materials Test Option

### Materials Function – (MATERials:)

TYPE	TYPE?	Select the Relative Permittivity test type	66
D	D?	Set the Guard Electrode diameter 'd' in mm	66
CONtact-TM	CONtact-TM?	Set the Material Thickness 'tm' in mm (Contact Method)	66
TG	TG?	Set the Electrode Separation 'tg' in mm (Non-Contact Method)	67
NONCONtact-TM	NONCONtact-TM?	Set the Material Thickness 'tm' in mm (Non-Contact Method)	67
MEASure-CG	MEASure-CG?	Measure the Capacitance Without MUT 'Cg'	67
N	N?	Set the Number of Turns 'N'	68
L	L?	Set the Average Path Length 'l' in mm	68
A	A?	Set the Cross Sectional Area of toroid 'A' in mm <sup>2</sup>	68
MEASure-LR	MEASure-LR?	Measure L <sub>w</sub> /R <sub>w</sub> reference data.	69
PROPerTy1	PROPerTy1?	Select the Measurement Property for Trace 1 / 2	69
PROPerTy2	PROPerTy2?	Select the Measurement Property for Trace 1 / 2	69
FUNcTion:1	FUNc:1?	Select Function (Term) 1 / 2 Measurement Parameter	70
FUNcTion:2	FUNc:2?	Select Function (Term) 1 / 2 Measurement Parameter	70

## 1.8 /Y Polar Complex Plots

DISPLAY-MODE	DISPLAY-MODE?	Select the Display Mode	72
POLAR PLOT			
POLAR-PROPerTy	POLAR-PROPerTy?	Select the measurement Parameter for the polar plot.	72
POLAR-SCALE	POLAR-SCALE?	Set the Polar Plot Scale	73

POLAR-DIVisionFullScale	POLAR-DIVisionFullScale ?	Set the number of divisions for full scale on the polar plot	73
POLA-FRaMe	POLAR-FRaMe?	Enable/disable the Cursor Frame on the polar plot.	73
POLAR-FIT <integer>		Autofit the Polar Plot	74
LOG-SWeePPARameter <disc>	LOG-SWeePPARameter?	Select Logarithmic or Linear Sweep	74
COMPLEX-PROPerTy <disc>	COMPLEX-PROPerTy?	Select Measurement Parameters for the complex plot	74
COMPLEX-FrameWidth <real>	COMPLEX-FrameWidth?	Set the Frame Width (and height) of the complex plot	75
COMPLEX-FrameCentreX <real>	COMPLEX-FrameCentreX?	Set the X-axis Frame Centre of the complex plot	75
COMPLEX-FrameCentreY <real>	COMPLEX-FrameCentreY?	Set the Y-axis Frame Centre of the complex plot	76
COMPLEX-FIT		Fit the complex plot to the display area	76

## Common Commands

### 1.9 Common Commands

#### **\*ESE <integer>**

Set the value of the Standard Event Enable group

**Parameter:** The Standard Event Enable group value as an integer

**Response:** None

**Note:** See **Status Groups** section

#### **\*ESE?**

Query the Standard Event Enable Group Mask

**Parameter:** None

**Response:** The value of the Standard Event Enable Group Mask as an integer

#### **\*ESR?**

Query the Standard Event Group Value

**Parameter:** None

**Response:** The Standard Event Group Value as an integer

#### **\*IDN?**

Query the instrument identification

**Parameter:** None

**Response:** The instrument identification string in the form:  
Manufacturer, Model, 0, Software Revision

**Example**

WAYNE KERR, 65120B, 3.382

#### **\*OPT?**

Query the hardware options fitted in the instrument.

**Parameter:** None

**Response:** A comma separated list of options:

0	No hardware options fitted
D1	/D1 DC Bias option fitted
D2	/D2 DC Bias option fitted

## Common Commands

### **\*SRE <integer> (GPIB only)**

Set the value of the Status Byte Enable group. (See **Status Groups** section).

**Parameter:** The Status Byte Enable Group Value as an integer.

**Response:** None

### **\*SRE? (GPIB only)**

Query the Status Byte Enable group

**Parameter:** None

**Response:** The value of the Status Byte Enable group as an integer.

### **\*STB?**

Query the Status Byte Group

**Parameter:** None

**Response:** The value of the Status Byte group as an integer

**Note:** This group can also be read by a GPIB serial poll (*GPIB only*)

### **\*TRG**

Trigger a measurement

**Parameter:** None

**Response:** Mode dependant

**Note:** See :TRIG command in Meter Mode and Analysis Mode

## Common Commands

### 1.10 Status Commands

#### **OPERation:ENABLE <integer>**

Set the value of the Standard Operation Status Group Enable Register

**Parameter:** None

The value of the register as an integer

**Response:** None

#### **OPERation:EVENT?**

Query the Standard Operation Group Event Register

**Parameter:** None

**Response:** The value of the register as an integer

**Note:** The Standard Operation Group Event Register latches transitions of the condition register.

#### **OPERation:CONDition?**

Query the value of the Standard Operation Group register

**Parameter:** None

**Response:** The value of the register as an integer

Common Commands

1.11 Calibration

:OpenCircuit-TRIM

Perform an Open Circuit Trim

<b>Parameter:</b>	None
<b>Response:</b>	The Open Circuit Trim result
1	Trim passed
0	Trim failed

:OpenCircuit-TRIM?

Query the Open Circuit Trim status

<b>Parameter:</b>	None
<b>Response:</b>	The Open Circuit Trim status
1	Trim valid
0	Trim invalid

:ShortCircuit-TRIM

Perform a Short Circuit Trim

<b>Parameter:</b>	None
<b>Response:</b>	The Short Circuit Trim result
1	Trim passed
0	Trim failed

:ShortCircuit-TRIM?

Query the Short Circuit Trim status

<b>Parameter:</b>	None
<b>Response:</b>	The Short Circuit Trim status
1	Trim valid
0	Trim invalid



## Common Commands

### :HF-COMPensation

Start the HF Compensation routine

**Parameter:** None

**Response:** None

**Note:** The \*STATUS? command should be used to determine what stage of the HF Compensation routine has been reached and when to fit the relevant transfer standard component.

### :FREQuency-LIMIT <real>

Set the Upper Frequency Limit for Trims and HF Compensation

**Parameter:** Set the value of Upper Frequency Limit as a real number

**Response:** None.

**Example:** Set 1MHz limit

```
:CAL:FREQ-LIMIT 1E6
```

**Note:** This command is only required when an Upper Frequency Limit less than the instrument's maximum frequency is required.

### :FREQuency-LIMIT?

Query the Upper Frequency Limit for Trims and HF Compensation

**Parameter:** None

**Response:** The value of Upper Frequency Limit as a real number

**Example:** When limit is set to 1MHz

```
1.000000e+006
```

### :STORE-TRIMS

Store User Short Circuit and Open Circuit Trim values

**Parameter:** None

**Response:** None

### :CLEAR-TRIMS

Clear User Short Circuit and Open Circuit Trim values

**Parameter:** None

**Response:** None

### :STORE-HF-COMPensation

Store User HF Compensation values

**Parameter:** None

## Common Commands

**Response:** None

### **:CLEAR-HF-COMPensation**

Clear User HF Compensation values

**Parameter:** None

**Response:** None

Common Commands

1.12 Meter Mode

:TRIGger

Trigger a measurement

**Parameter:** None

**Response:** The measurement results as comma delimited real numbers.

**Example:** Response for measurements of Function 1 (set to C) = 47.1404nF and Function 2 (set to D) = 0.00133

4.714043e-008,1.337683e-003

:FUNCtion:1 <discrete> :FUNCtion:2 <discrete>

Select the Function (Term) 1 / 2 Measurement Parameter

<b>Parameter</b>	L	Inductance	C	Capacitance
	R	Resistance	Z	Impedance
	Y	Admittance	X	Reactance
	G	Conductance	B	Susceptance
	Q	Quality Factor	D	Dissipation Factor
	Angle	Phase Angle		

**Response:** None.

**Example:** Set Term 1 to Phase Angle

:METER:FUNC:1 ANGLE

**Note:** 6 extra Parameter are available when the /K Materials Test option is installed.

:FUNCtion:1? :FUNCtion:2?

Query the Function (Term) 1 / 2 Measurement Parameter

**Parameter:** None

**Response:**

0	Inductance	1	Capacitance
2	Resistance	3	Impedance
4	Admittance	5	Reactance
6	Conductance	7	Susceptance
8	Quality Factor	9	Dissipation Factor
10	Phase Angle		

**Note:** 6 extra Parameter are available when the /K Materials Test option is installed.

## Common Commands

### :EQU-CCT <discrete>

Select the Equivalent Circuit type

**Parameter:** SER Series  
PAR Parallel

**Response:** None

**Example:** Set the Equivalent Circuit to Series  
:METER:EQU-CCT SER

### :EQU-CCT?

Query the Equivalent Circuit type

**Parameter:** None

**Response:** 0 Series  
1 Parallel

### :SPEED <discrete>

Select the Measurement Speed

**Parameter:** MAXimum Maximum speed  
FAST Fast speed  
MEDium Medium speed  
SLOW Slow speed  
<integer> Custom speed

**Response:** None

**Example 1:** Set Speed to Maximum  
:METER:SPEED MAX

**Example 2:** Set Speed to Custom Speed 128:  
:METER:SPEED 128

### :SPEED?

Query the Measurement Speed

**Parameter:** None.

**Response** -4 Maximum speed  
-3 Fast speed  
-2 Medium speed  
-1 Slow speed  
1-256 Custom speed

## Common Commands

### **:FREQuency <real>**

Set the AC Drive Frequency

**Parameter:** The Frequency as a real number  
**Response:** None  
**Example:** Set 1MHz AC Drive Frequency  
:METER:FREQ 1M

### **:FREQuency?**

Query the AC Drive Frequency

**Parameter:** None  
**Response:** The Frequency as a real number  
**Example:** For 1MHz AC Drive Frequency  
1.000000e+006

### **:LEVel <discrete>**

Set the AC Drive Level

**Parameter:** The AC Drive Level as real number, followed by the Drive type suffix if required (i.e. when changing from V to I or I to V):  
V Voltage Drive  
A Current Drive  
**Response:** None  
**Example 1:** Set 1V AC Voltage Drive if existing Drive is Current  
:METER:LEVEL 1V  
**Example 2:** Set 10mA AC Current Drive if existing Drive is Voltage  
:METER:LEVEL 0.01A

### **:LEVel?**

Query the AC Drive Level

**Parameter:** None  
**Response:** The value of the AC Drive Level  
**Example 1:** For 1V AC Voltage Drive:  
1.000000e+000  
**Example 2:** For 10mA AC Current Drive  
1.000000e-002

**Note:** Use DRIVE? to query if the AC Drive type is set to voltage or current

## Common Commands

### :DRIVE?

Query the AC Drive type

<b>Parameter:</b>	None		
<b>Response</b>	0	Voltage Drive	
	1	Current Drive	

**Note:** The `LEVEL` command is used to set the value of the AC Drive Level.

### :RANGE <discrete>

Select the Measurement Hardware Range

<b>Parameter:</b>	AUTO	Auto-range	1	Range 1
	2	Range 2	3	Range 3
	4	Range 4	5	Range 5
	6	Range 6	7	Range 7
<b>Response:</b>	None			
<b>Example:</b>	Set Measurement Hardware Range 3			
	<code>:METER:RANGE 3</code>			

### :RANGE?

Query the Measurement Hardware Range

<b>Parameter:</b>	None			
<b>Response:</b>	0	Auto-range	1	Range 1
	2	Range 2	3	Range 3
	4	Range 4	5	Range 5
	6	Range 6	7	Range 7

**Note:** Auto-range always returns 0 regardless of the range actually used for the measurement.

### :BIAS <real>

Set the DC Bias Source Level

<b>Parameter:</b>	The DC Bias Source Level as a real number			
<b>Response:</b>	None			
<b>Example:</b>	Set 1V DC Bias Source Level to 1V			
	<code>:METER:BIAS 1.0</code>			

**Note:** Command `:METER:BIAS-TYPE VOL` is used to select Voltage bias.

### :BIAS?

## Common Commands

Query the DC Bias Source Level

**Parameter:** None

**Response:** The DC Bias Source Level as a real number

**Example:** When DC Bias Source Level is set to 1V

1.0

### :BIAS-STATE <disc>

Change the state of the DC Bias Source

**Parameter:** ON Turn Bias On

OFF Turn Bias Off

**Response:** None

**Example:** Turn DC Bias Source on

:METER:BIAS-STAT ON

### :BIAS-STATE?

Query the state of the DC Bias Source

**Parameter:** None

**Response:** 0 Bias Off

1 Bias On

### :BIAS-TYPE <disc>

Select the DC Bias Source.

**Parameter:** VOLTage Voltage bias

CURrent Current bias

**Response:** None

**Example:** Select voltage bias

:METER:BIAS-TYPE VOL

### :BIAS-TYPE?

Query the selected bias source

**Parameter:** None.

**Response:** 0 Current bias

1 Voltage bias

### :DISPlay <discrete>

Select the Meter Mode Display Format

**Common Commands**

<b>Parameter</b>	ABSolute	Absolute Display
	DEViation	Deviation Display
<b>Response:</b>	None	
<b>Example:</b>	Set Deviation Display	
	:METER:DISP DEV	



## Common Commands

### :DISPlay?

Query the Meter Mode Display Format

<b>Parameter:</b>	None
<b>Response:</b>	0      Absolute Display
	1      Deviation Display

### :DEViation-TERM <integer>

Select Term 1 or Term 2 to use for Deviation Display

<b>Parameter:</b>	1      Term 1
	2      Term 2
<b>Response:</b>	None
<b>Example:</b>	Set Term 1
	<code>:METER:DEV-TERM 1</code>

### :DEViation-TERM?

Query the Measurement Term which is used for Deviation Display

<b>Parameter:</b>	None
<b>Response:</b>	1      Term 1
	2      Term 2

### :DEViation-TYPE <discrete>

Select the Deviation Display Format

<b>Parameter:</b>	ABSolute	Absolute Deviation
	PERCentage	Percentage Deviation
	PPM	Parts-per-million Deviation
<b>Response:</b>	None	
<b>Example:</b>	Set Percentage Deviation	
	<code>:METER:DEV-TYPE PERC</code>	

### :DEViation-TYPE?

Query the Deviation Display Format

<b>Parameter:</b>	None
<b>Response:</b>	0      Absolute Deviation
	1      Percentage Deviation
	2      Parts-per-million Deviation

## Common Commands

### :NOMinal <real>

Set the Nominal Value used in deviation mode

**Parameter:** The Nominal Value as a real number.  
**Response:** None  
**Example:** Set 10uH Nominal Value (Term set to L):  
: METER:NOM 10u

### :NOMinal?

Query the Nominal Value used in Deviation Mode

**Parameter:** None  
**Response:** The Nominal Value as a real number  
**Example:** For 10uH nominal value (Term set to L)  
1.000000e-005

### :SAVE-NOMinal

Set the Nominal Value used in deviation mode to the last measured value

**Parameter:** None  
**Response:** None

### :SHOW-SCALE1 <discrete>      :SHOW-SCALE2 <discrete>

Select the Term 1 / Term 2 Scale Bar on/off

**Parameter**      OFF      Scale Bar Off  
                     ON      Scale Bar On  
**Response:** None  
**Example:** Set Term 1 Scale Bar On:  
: METER:SHOW-SCALE1 ON

### :SHOW-SCALE1?      :SHOW-SCALE2?

Query the Term 1 / Term 2 Scale Bar on/off

**Parameter:** None  
**Response:** The Term 1 / 2 Scale Bar state  
0      Scale Bar Off  
1      Scale Bar On

### :SCALE1-High <real>      :SCALE2-High <real>

Set the Term 1 / Term 2 Scale Bar High Limit

## Common Commands

**Parameter:** The High Limit as a real number  
**Response:** None  
**Example:** Set Term 1 Scale Bar High Limit to 110 (in Absolute Mode):  
:METER:SCALE1-HI 110

### :SCALE1-High?

### :SCALE2-High?

Query the Term 1 / Term 2 Scale Bar High Limit

**Parameter:** None  
**Response:** The High Limit as a real number  
**Example:** For Term 1 Scale Bar High Limit set to 110 (in Absolute Mode):  
1.100000e+002

### :SCALE1-LOW <real>

### :SCALE2-LOW <real>

Set the Term 1 / Term 2 Scale Bar Low Limit

**Parameter:** The Low Limit as a real number  
**Response:** None  
**Example:** Set Term 1 Scale Bar Low Limit to -10% (in Relative Mode):  
:METER:SCALE1-LO -10

### :SCALE1-LOW?

### :SCALE2-LOW?

Query the Term 1 / Term 2 Scale Bar Low Limit

**Parameter:** None  
**Response:** The Low Limit as a real number  
**Example:** For Term 1 Scale Bar Low Limit set to -10% (in Relative Mode):  
-1.000000e+001

### :SCALE1-NOMinal <real>

### :SCALE2-NOMinal <real>

Set the Term 1 / Term 2 Scale Bar Nominal Value

**Parameter:** The Nominal Value as a real number  
**Response:** None  
**Example:** Set Term 1 Scale Bar Nominal Value to 100:  
:METER:SCALE1-NOM 100

### :SCALE1-NOMinal?

### :SCALE2-NOMinal?

Query the Term 1 / Term 2 Scale Bar Nominal Value

**Parameter:** None

## Common Commands

**Response:** The Nominal Value as a real number

**Example:** For Term 1 Scale Bar Nominal Value set to 100:

1.000000e+002

### :SCALE1-SAVENOMinal

### :SCALE2-SAVENOMinal

Set the Term 1 / Term 2 Scale Bar Nominal Value to the most recent measurement

**Parameter:** None

**Response:** None

### :SCALE1-TYPE <discrete>

### :SCALE2-TYPE <discrete>

Select the Term 1 / Term 2 Scale Bar Display Type

<b>Parameter</b>	RELative	Relative(%)
	ABSolute	Absolute

**Response:** None

**Example:** Set Term 1 Scale Bar Display Type to Relative:

:METER:SCALE1-TYPE REL

### :SCALE1-TYPE?

### :SCALE2-TYPE?

Query the Term 1 / Term 2 Scale Bar Display Type

**Parameter:** None

<b>Response:</b>	0	Relative
	1	Absolute

### :FAST-GPIB <discrete>

Enable / Disable display update for every measurement

<b>Parameter:</b>	ON	Disable display updates (Fast Mode)
	OFF	Enable display updates (Standard Mode)

**Response:** None

**Example:** Set Fast Mode:

:METER:FAST-GPIB ON

**Note:** Fast Mode is not available with front panel (local) control.

### :Q-SAVE

Save the current Meter Mode Measurement Setup as the QuickSave file

**Parameter:** None

**Response:** None

## Common Commands

### **:Q-LOAD**

Load the Meter Mode Measurement Setup previously saved as the QuickSave file

<b>Parameter:</b>	None	
<b>Response:</b>	0	File not found
	1	File found

### **:RESOnance:StarT <real>**

Set the Start Frequency for the search

<b>Parameter:</b>	Start Frequency in Hertz
<b>Response:</b>	None
<b>Example:</b>	Set the Start Frequency to 1kHz  :METER:RESO:ST 1k

### **:RESOnance:StarT?**

Query the Start Frequency of the search

<b>Parameter:</b>	None
<b>Response:</b>	Start Frequency in engineering format
<b>Example:</b>	Set Start Frequency set to 1kHz  +.10000000E+04

### **:RESOnance:StoP <real>**

Set the Stop Frequency of the search

<b>Parameter:</b>	Stop Frequency in Hertz
<b>Response:</b>	None
<b>Example:</b>	Set the Stop Frequency to 10kHz  :METER:RESO:SP 10k

### **:RESOnance:StoP?**

Query the Stop Frequency of the search

<b>Parameter:</b>	None
<b>Response:</b>	Stop Frequency in engineering format
<b>Example:</b>	Stop Frequency set to 1kHz:      +.10000000E+05

### **:RESOnance:EQU-CCT <disc>**

Select the Equivalent Circuit Type

## Common Commands

**Parameter:** SER Series Resonance  
 PAR Parallel Resonance  
 XTAL Dual Resonance Device

**Response:** None

**Example:** To select Series Resonance Search:

:METER:RESO:EQU-CCT SER

### :RESOnance:EQU-CCT?

Query the Equivalent Circuit Type

**Parameter:** None

**Response:** 0 Series Resonance  
 1 Parallel Resonance  
 2 Dual Resonance Device

### :RESOnance:TRIG

Begin a Resonance Search.

**Parameter:** None

**Response:** Returns 7 values and 1 Pass/Fail Result (all separated by commas)

The values depend on the Equivalent Circuit set using the :RESO:EQU-CCT command:

Equivalent Circuit	Value #1	Value #2	Value #3	Value #4	Value #5	Value #6	Value #7	PASS /FAIL
Series	Fo	0	0	C	L	R	Q	
Parallel	Fo	0	0	C	L	R	Q	
XTAL	Fr	Fa	C0	C1	L	R	Q	

Example (Crystal/Piezo Mode): :METER:RESO:TRIG

returns

+ .77534195E+06, + .77535195E+06, + .47321000E-05, + .47321000E-12,  
 + .89043000E-08, + .19562000E-02, + .221748E+02, -1

indicating resonant frequencies of fr = 775.342kHz and fa = 775.352kHz with equivalent circuit values of C0 = 4.7321μF, C1 = 4.7321pF, L = 8.904nH, R = 1.956mΩ, a Q value of 22.175 and Pass/Fail disabled

775.342 kHz	775.352 kHz	4.7321 μF	4.7321 pF	8.904 nH	1.956 mΩ	22.175	disabled
Fr	Fa	C0	C1	L	R	Q	

### :RESOnance:TRAINing

## Common Commands

Execute the 'Check Valid' function.

<b>Parameter:</b>	None
<b>Response:</b>	0      Unknown state
	1      Search range valid
	2      No resonances found. Decrease Start frequency and/or increase Stop frequency. Start and Stop frequencies are either both above or both below the 2 resonance frequencies.
	3      Parallel resonance not found. Increase Stop frequency
	4      No resonances found. Decrease Start frequency and increase Stop frequency. Start and Stop frequencies are between the 2 resonance frequencies.
	5      Series resonance not found. Decrease Start frequency.

### :RESOnance:FM-FN?

Query the frequencies at Zmin and Zmax (fm and fn).

<b>Parameter:</b>	None
<b>Response:</b>	fm and fn values separated by a comma
<b>Example:</b>	For fm = 775.342kHz and fn = 775.352kHz +.77534195E+06, +.77535195E+06

### :RESOnance:FS-FP?

Query the frequencies at Gmax and Rmax (fs and fp)

<b>Parameter:</b>	None
<b>Response:</b>	fs and fp values separated by a comma
<b>Example:</b>	For fs = 775.342kHz and fp = 775.352kHz +.77534195E+06, +.77535195E+06

### :RESOnance:CP-1K?

Query the Cp reading at 1kHz (enabled/disabled using the :RESO:ENABLE-CP function)

<b>Parameter:</b>	None
<b>Response:</b>	The Cp reading at 1kHz in engineering format
<b>Example1:</b>	For C0 = 1pF +.10000000E-11
<b>Example2:</b>	if the function is not enabled. +0.0000000E+000

## Common Commands

### :RESOnance:KEFF?

Query the Keff result

**Parameter:** None

**Response:** Keff in engineering format

**Example:** Keff = 0.0001  
+.10000000E-3

### :RESOnance:ENABLE-CP <int>

Enable/Disable the Cp at 1kHz calculation

**Parameter:** 0 Disable  
1 Enable

**Response:** None

**Example:** Enable the Cp at 1kHz calculation:  
:METER:RESO:ENABLE-CP 1

### :RESOnance:ENABLE-CP?

Query the status of the 'ENABLE-CP' function

**Parameter:** None

**Response:** 0 Disable  
1 Enable

### :RESOnance:DEPTH <integer>

Set Resonance Search Depth

**Parameter:** 0 to 16

**Response:** None

**Example:** Set the Resonance Search Depth to 2 iterations  
:METER:RESO:DEPTH 2

Note: This command can only be used when the Equivalent Circuit Type has been set to SER (Series) or PAR (Parallel) i.e. not XTAL, using the RESO:EQU-CCT command.

### :RESOnance:DEPTH?

Query the Resonance Search Depth

**Parameter:** None

**Response:** The Resonance Search Depth as an integer

**Example:** 0



### Common Commands

Indicates that resonance is calculated using the entered frequency limits. No resonance search is carried out prior to calculation.

#### **:RESOnance:SPEED <disc>**

Set the Measurement Speed for the measurements used to calculate resonance

<b>Parameter:</b>	MAX	Maximum speed
	FAST	Fast speed
	MED	Medium speed
	SLOW	Slow speed
	<INTEGER>	Custom speed
<b>Response:</b>	None	
<b>Example:</b>	To set the Measurement Speed to Slow	
	<code>:METER:RESO:SPEED SLOW</code>	

#### **:RESOnance:SPEED?**

Query the Measurement Speed for the measurements used to calculate resonance

<b>Parameter:</b>	None	
<b>Response:</b>	The Measurement Speed as an integer	
	-4	Maximum
	-3	Fast
	-2	Medium
	-1	Slow
	1-256	Custom

#### **:RESOnance: LO-LIM <real>**

Set the Low Limit Frequency

<b>Parameter:</b>	The Low Limit Frequency in Hz
<b>Response:</b>	None
<b>Example:</b>	Set the Low Limit Frequency to 1kHz:
	<code>:METER:RESO:LO-LIM 1k</code>

#### **:RESOnance: LO-LIM?**

Query the Low Limit Frequency

<b>Parameter:</b>	None
<b>Response:</b>	Low Limit Frequency in engineering format
<b>Example:</b>	For a low limit frequency of 1kHz

## Common Commands

+ .10000000E+04

### **:RESOnance: HI-LIM <real>**

Set the High Limit Frequency

**Parameter:** The required frequency in Hz  
**Response:** None  
**Example:** Set High Limit Frequency to 2kHz  
:METER:RESO:HI-LIM 2k

### **:RESOnance: : HI-LIM?**

Query the High Limit Frequency

**Parameter:** None  
**Response:** Returns the high limit frequency in engineering format.  
**Example:** For a High Limit Frequency of 2kHz  
+ .20000000E+04

### **:RESOnance:ENABLE-HILO**

Enable/Disable the Hi/Lo Test Limits

**Parameter:** 0 Disable  
1 Enable  
**Response:** None  
**Example:** To enable the Hi/Lo test limits:  
:METER:RESO:ENABLE-HILO 1

### **:RESOnance:ENABLE-HILO?**

Query the status of the Hi/Lo Test Limits

**Parameter:** None  
**Response:** 0 Disabled  
1 Enabled

## Common Commands

### 1.13 Analysis Mode (:ANAlysis)

#### :ANA:EXPORT-OVERWRITE <discrete>

Enable/Disable 'file overwrites' in Export Trace

<b>Parameter</b>	ON	Allow 'EXPORT TRACE' files to be overwritten if they exist
	OFF	Disable file overwrites
<b>Response:</b>	None	
<b>Example:</b>	Enable file overwrites:	
	:ANA:EXPORT-OVERWRITE ON	

#### :ANA:EXPORT-OVERWRITE?

Query 'file overwrites' setting in Export Trace

<b>Parameter:</b>	None	
<b>Response:</b>	1	Overwrites disabled
	0	Overwrites enabled

#### :ANA:EXPORT \xxxx\yyyy.csv

Write 'Export data' file to USB at path location 'xxxx' with the filename 'yyyy.csv'

<b>Parameter (case insensitive)</b>	xxxx	Path name
	yyyy.csv	Filename

<b>Response:</b>	0	File written successfully (no pre-existing file of that name).
	1	File overwritten successfully (file of that name already existed).
	2	File not written (filename already existed but overwrite not enabled).
	3	No file extension or incorrect file extension.
	4	File not written. Incorrect path specification.
	5	File not written. No USB memory fitted.
	6	File not written. Disk full.
	7	File not overwritten. Disk full.

**Example:** Write data to file \DATA\RESULTS.CSV and then check the status

```
:ANA:EXPORT \DATA\RESULTS.CSV
0
```

**Note 1:** The path must already exist on the USB. It cannot be created by this method.

**Note 2:** If two USB memories are fitted, the file will be written to USB2. USB1 and USB2 do not relate to the physical ports on the rear panel of the instrument, but relate to the time at which each device was recognised by

## Common Commands

the system. To ensure a particular device is USB1 remove all devices and wait 15 seconds before plugging a device in again. Then wait 15 seconds before plugging in the second device.

If the two USB memories are plugged in at power up, there is no guarantee which one will be USB1 and which one will be USB2. So it is recommended that this feature only be used with one USB device.

**Note 3:** Writing the file may take 3-4 seconds. Time should be allowed between writing the file and reading back the status.

### :ANA:BITMAP-OVERWRITE <discrete.

Enable/Disable file overwrites in Save Bitmap

<b>Parameter</b>	ON	Allow 'Save Bitmap' files to be overwritten if they exist.
	OFF	Disable file overwrites.

**Response:** None

**Example:** Enable file overwrites:

```
:ANA:BITMAP-OVERWRITE ON
```

### :ANA:BITMAP-OVERWRITE?

Read 'file overwrites' setting in Save Bitmap

**Parameter:** None

<b>Response:</b>	0	Overwrites disabled
	1	Overwrites enabled

### :ANA:BITMAP \xxxx\yyyy.bmp

Write 'Save Bitmap' file to USB at path location '\xxxx' with the filename 'yyyy.csv'

<b>Parameter (case insensitive)</b>	xxxx	Path name
	yyyy.csv	Filename

**Note 1:** The path must already exist on the USB. It cannot be created by this method.

**Note 2:** If two USB memories are fitted, the file will be written to USB2. USB1 and USB2 do not relate to the physical ports on the rear panel of the instrument, but relate to the time at which each device was recognised by the system. To ensure a particular device is USB1 remove all devices and wait 15 seconds before plugging a device in again. Then wait 15 seconds before plugging in the second device.

If the two USB memories are plugged in at power up, there is no guarantee which one will be USB1 and which one will be USB2. So it is recommended that this feature only be used with one USB device fitted.

**Note 3:** Writing the file may take up to 15 seconds. Time should be allowed between writing the file and reading back the status.

**Note 4:** The 'GPIB Remote/LAN Remote' flag at the top right-hand corner of the screen is disabled during the execution of this function so that it does not appear on the final screenshot.

#### Response

## Common Commands

0	File written successfully (no pre-existing file of that name).
1	File overwritten successfully (file of that name already existed).
2	File not written (filename already existed but overwrite not enabled).
3	No file extension or incorrect file extension.
4	File not written. Incorrect path specification.
5	File not written. No USB memory fitted.
6	File not written. Disk full.
7	File not overwritten. Disk full.

**Example:** Write data to file \SCREEN\DISPLAY.BMP and then check the status

```
:ANA:BITMAP \ SCREEN\DISPLAY.BMP
0
```

### :Q-SAVE

Save the current Analysis Mode Measurement Setup as the QuickSave file

**Parameter:** None

**Response:** None

### :Q-LOAD

Load the Analysis Mode Measurement Setup previously saved as the QuickSave file

**Parameter:** None

**Response:**

0	File not found
1	File found

### :TRIGger

Start a measurement sweep

**Parameter:** None

**Response:** None

## PROPerTy1 <discrete>      PROPerTy2 <discrete>

Select the Measurement Parameter for Trace 1 / 2

<b>Parameter:</b>	L	Inductance	C	Capacitance
	R	Resistance	Z	Impedance
	Y	Admittance	X	Reactance
	G	Conductance	B	Susceptance
	Q	Quality Factor	D	Dissipation Factor

## Common Commands

ANGLE Angle

**Response:** None

**Example:** Set Trace 1 to Impedance:

:ANA:PROP1 Z

## PROPerTy1? PROPerTy2?

Query the Trace 1 / 2 Measurement Parameter

**Parameter:** None.

<b>Response:</b>	0	Inductance	1	Capacitance
	2	Resistance	3	Impedance
	4	Admittance	5	Reactance
	6	Conductance	7	Susceptance
	8	Quality Factor	9	Dissipation Factor
	10	Angle		

## :EQU-CCT <discrete>

Select the Equivalent Circuit type

**Parameter:** SER Series  
PAR Parallel

**Response:** None

**Example:** Set the Equivalent Circuit to Series:

:ANA:EQU-CCT SER

## :EQU-CCT?

Query the Equivalent Circuit type

**Parameter:** None

**Response** 0 Series  
1 Parallel

## SPEED <discrete>

Select the Measurement Speed

<b>Parameter</b>	MAXimum	Maximum speed
	FAST	Fast speed
	MEDium	Medium speed
	SLOW	Slow speed

Common Commands

<integer> Custom speed

Response: None

Example: Set the Speed to Maximum:

:ANA:SPEED MAX

SPEED?

Query the measurement speed

Parameter: None

Response: -4 Maximum speed  
-3 Fast speed  
-2 Medium speed  
-1 Slow speed  
1-256 Custom speed

RANGE <discrete>

Select the measurement range

Parameter:	AUTO	Auto-range.	1	Range 1
	2	Range 2	3	Range 3
	4	Range 4	5	Range 5
	6	Range 6	7	Range 7

Response: None

Example: Set the Range to Auto:

:ANA:RANGE AUTO

RANGE?

Query the measurement range.

Parameter: None

Response:	0	Auto-range	1	Range 1
	2	Range 2	3	Range 3
	4	Range 4	5	Range 5
	6	Range 6	7	Range 7

:LEVel <discrete>

Set the AC Drive Level for frequency and DC Bias Level sweeps

Parameter: The AC Drive Level as a real number

## Common Commands

**Response:** None

**Example:** Set 1V AC Voltage Drive

```
:ANA:LEVEL 1V
```

Set 10mA AC Current Drive

```
:ANA:LEVEL 0.01A
```

### :LEVEL?

Query the AC Drive Level

**Parameter:** None

**Response:** The AC Drive level

**Example:** For 1V AC Voltage Drive:

```
1.000000e+000
```

For 10mA AC Current Drive

```
1.000000e-002
```

**Note:** Use the **DRIVE?** query to see if AC Drive type is set to voltage or current.

When AC Drive sweeps are set, this query will respond with the last AC Drive level set for frequency or bias sweeps

### :DRIVE?

Query the AC Drive type

**Parameter:** None

**Response:** The AC Drive type

```
0      Voltage drive
```

```
1      Current drive
```

**Note:** The **LEVEL** command is used to set the value of the AC Drive level

### :FREQuency <real>

Set the AC Drive Frequency for AC Drive Level and DC Bias Level sweeps

**Parameter:** The frequency as a real number.

**Response:** None

**Example:** Set 10MHz AC Drive frequency.

```
:ANA:FREQ 10M
```

### :FREQuency?

Query the AC Drive Frequency

**Parameter:** None



## Common Commands

**Response:** The frequency as a real number

**Example:** For 10MHz AC Drive frequency:

1.000000e+007

**Note:** When frequency sweeps are set, this query will respond with the last frequency set for AC Drive or bias sweeps

### DC Bias

#### :BIAS <real>

Set the DC Bias Source Level

**Parameter:** The DC Bias Source Level as a real number

**Response:** None

**Example:** Set 1V DC Bias Source Level to 1V

:ANA:BIAS 1.0

Note: Command :ANA:BIAS-TYPE VOL is used to select Voltage bias.

#### :BIAS?

Query the DC Bias Source Level

**Parameter:** None

**Response:** The DC Bias Source Level as a real number

**Example:** When DC Bias Source Level is set to 1V

1.0

#### :BIAS-STATe

Change the state of the DC Bias Source

**Parameter:** ON Turn Bias On

OFF Turn Bias Off

**Response:** None

**Example:** Turn DC Bias Source on

:ANA:BIAS-STAT ON

#### :BIAS-STATe?

Query the state of the DC Bias Source

**Parameter:** None

**Response:** 0 Bias Off

1 Bias On

## Common Commands

### :BIAS-TYPE

Select the bias source.

**Parameter:**      VOLtage      Voltage bias.  
                          CURrent      Current bias.

**Response:**      None.

**Example:**      Select voltage bias:  
                          :ANA:BIAS-TYPE VOL

### :BIAS-TYPE?

Query the selected bias source

**Parameter:**      None.

**Response:**      0      Current bias  
                          1      Voltage bias

### :PARAMETER <disc>

Select the X-axis Sweep Parameter

**Parameter:**      FREquency      Frequency Sweep  
                          LEVEL      AC Level Sweep  
                          BIAS      DC Bias Level Sweep

**Response:**      None

**Note:** DC Bias Level Sweep is only available when /D1 or /D2 options are fitted to the 6500

### :PARAMETER?

Query the X-axis Sweep Parameter

**Parameter:**      None

**Response:**      0      Frequency Sweep  
                          1      AC Level Sweep  
                          2      DC Bias Level Sweep

**Note:** DC Bias Level Sweep is only available when /D1 or /D2 options are fitted to the 6500

### :POINTS <real>

Set the number of Measurement Points in a trace

**Parameter:**      The number of points as an integer.  
                          Valid values are 50, 100, 200, 400, 800 and 1600 points.

**Response:**      None

## Common Commands

**Example:** Set the number of measurement points to 100:

:ANA:POINTS 100

### :POINTS?

Query the number of Measurement Points in a trace

**Parameter:** None

**Response:** The number of points as an integer

### :LOG-X <discrete>

Select X-axis as Logarithmic or Linear scale

**Parameter:** ON Logarithmic scale  
OFF Linear scale

**Response:** None

**Example:** Set X axis as Logarithmic scale

:ANA:LOG-X ON

### :LOG-X?

Query the X-axis Log / Linear scale setting

**Parameter:** None

**Response:** 0 Linear scale  
1 Logarithmic scale

### :START <real>

Set the X-axis Start Value

**Parameter:** The value as a real number

**Response:** None

**Example:** Set X-axis start value to 100:

:ANA:START 100

### :START?

Query the X-axis Start Value

**Parameter:** None

**Response:** The value as a real number

**Example:** For a X-axis which starts at 100:

1.000000e+002

## Common Commands

### :STOP <real>

Set the X-axis parameter stop value.

**Parameter:** The value as a real number  
**Response:** None  
**Example:** Set X axis stop value to 120MHz:  
:ANA:STOP 120M

### :STOP?

Query the X-axis stop value

**Parameter:** None  
**Response:** The value as a real number.  
**Example:** For a X-axis which stops at 120MHz:  
1.200000e+008

### :LOG-Y <discrete>

Select Y-axis as Log or Linear scale

**Parameter:** ON Log scale  
OFF Linear scale  
**Response:** None  
**Example:** Set X axis as log:  
:ANA:LOG-Y ON

### :LOG-Y?

Query the Y-axis Log / Linear scale setting

**Parameter:** None  
**Response:** 0 Linear scale  
1 Log scale

### :MAXimum1 <real> :MAXimum2 <real>

Set Trace 1 / 2 Y-axis Maximum Value

**Parameter:** The value as a real number.  
**Response:** None  
**Example:** Set Trace 1 Y-axis Maximum Value to 100  
:ANA:MAX1 100

### :MAXimum1? :MAXimum2?

## Common Commands

Query Trace 1 / 2 Y-axis Maximum Value.

**Parameter:** None

**Response:** The value as a real number

**Example:** When Trace 1 Y-axis maximum value is 100  
1.000000e+002

### **:MINimum1 <real>**                      **:MINimum2 <real>**

Set Trace 1 / 2 Y-axis Minimum Value

**Parameter:** The value as a real number

**Response:** None

**Example:** Set Trace 1 Y-axis minimum value to 1:  
:ANA:MIN1 1

### **:MINimum1?**                                      **:MINimum2?**

Query Trace 1 / 2 Y-axis Minimum Value

**Parameter:** None

**Response:** The value as a real number.

**Example:** When Trace 1 Y-axis Minimum Value is 1  
1.000000e+000

### **:TITLE <discrete>**

Define the Sweep (Graph) Title

**Parameter:** The Sweep Title as a string enclosed in single quotes

**Response:** None

**Example:** Set the Sweep Title IND VS FREQ:  
:ANA:TITLE 'IND VS FREQ'

### **:TITLE?**

Query the Sweep (Graph) Title

**Parameter:** None

**Response:** The Sweep Title as a string

**Example:** When the Sweep Title is IND VS FREQ  
IND VS FREQ

### **:AVERages <integer>**

Set the Number of Trace Averages

## Common Commands

**Parameter:** The number of averages as an integer.

**Response:** None

**Example:** Set the number of averages to 4:

```
:ANA:AVE 4
```

### :AVEerages?

Query the number of trace averages.

**Parameter:** None

**Response:** The number of averages as an integer

### :RESET-AVEraging

Reset the trace averaged values to zero (both traces set to zero)

**Parameter:** None

**Response:** None

### :FIT <integer>

Auto Fit the Y axes to the measurement traces.

**Parameter:**

1	Auto Fit to Trace 1
2	Auto Fit to Trace 2
3	Auto Fit to Trace 1 and Trace 2

**Response:** None

**Example:** Auto Fit Y axes to both traces:

```
:ANA:FIT 3
```

### POINT? <integer>

Query X-value and Trace 1 / 2 Y-values at the  $n^{\text{th}}$  point on the traces

**Parameter:** The  $n^{\text{th}}$  point on the trace as an integer

**Response:** The X-axis value of the  $n^{\text{th}}$  point, the Trace 1 Y-axis value and the Trace 2 Y-axis value in comma separated form

**Example:** Retrieve the measurement result of the first measurement point:

```
:ANA:POINT? 0
```

```
1.00000000e+003,9.24710841e+002, 5.68111232e-002
```

Where the frequency is 1kHz, the Trace 1 Y-axis value is 924.71 and the Trace 2 Y-axis value is 0.05681.

### RESULT? <real>

## Common Commands

Query the measurement result nearest to the defined X-axis value

**Parameter:** The defined x-value as a real number.

**Response:** The measurement result nearest to the defined x-value as the nearest x-value measurement, the Trace 1 y-value and the Trace 2 y-value in comma separated form.

**Example:** Query the measurement result nearest to the frequency parameter 10kHz.

```
:ANA:RESULT? 10k
```

```
9.43609621e+003, 9.24650318e+002, 3.98660591e-002
```

Where the frequency is 9.436kHz, the Trace 1 value is 924.65 and the Trace 2 value is 0.039866.

## Analysis Mode – Marker (ANALysis:MarKeR)

### :MKR:STATE <discrete>

Enable / disable the Active Marker

**Parameter:** ON Turn marker on  
OFF Turn marker off

**Response:** None

### :MKR:STATE?

Query the state of the Active Marker

**Parameter:** None

**Response:** 0 Marker off  
1 Marker on

### :MKR:TYPE <discrete>

Select the Active Marker **Display** type

**Parameter:** NORmal Normal display  
DELta Delta marker  
RELative Relative marker

**Response:** None

### :MKR:TYPE?

Query the Active Marker **Display** type

**Parameter:** None

**Response:** 0 Normal  
1 Delta

## Common Commands

2

Relative

### **:MKR:SELECT <integer>**

Select the Active Marker Number

**Parameter:** An integer in the range 1 to 8

**Response:** None

### **:MKR:SELECT?**

Query the Active Marker.

**Parameter:** None

**Response:** An integer in the range 1 to 8

### **:MKR:POSITION <real>**

Move the Active Marker to the point nearest the X-value

**Parameter:** The X-value as a real number

**Response:** None

**Example:** Move the marker to 98MHz

:ANA:MKR:POSITION 98M

### **:MKR:POSITION?**

Query the Active Marker X-value.

**Parameter:** None

**Response:** The X-value of the Active Marker

**Example:** For the nearest point to 98MHz:

1.041778e+008

### **:MKR:LEFT**

Move the Active Marker left to the next measurement on the traces

**Parameter:** None

**Response:** None

### **:MKR:RIGHT**

Move the Active Marker right to the next measurement on the traces

**Parameter:** None

**Response:** None



## Common Commands

### Delta Marker Functions

#### **:MKR:DELTA-PARAMETER <real>**

Set the X-value to which the delta marker will be relative

**Parameter:** The X-value as a real number

**Response:** None

**Example:** Delta marker will be relative to 1MHz:

```
:ANA:MKR:DELTA-PARAMETER 1M
```

#### **:MKR:DELTA-PARAMETER?**

Query the X-value to which the delta marker will be relative.

**Parameter:** None

**Response:** The delta parameter value as a real number

**Example:** Delta marker will be relative to 1MHz

```
:ANA:MKR:DELTA-PARAMETER 1M
```

#### **:MKR:DELTA-VALUE1 <real>**

#### **:MKR:DELTA-VALUE2 <real>**

Set the Trace 1 / 2 value to which the delta marker will be relative

**Parameter:** The value as a real number

**Response:** None

**Example:** Set Trace 1 value to 100:

```
:ANA:MKR:DELTA-VALUE 100
```

#### **:MKR:DELTA-VALUE1?**

#### **:MKR:DELTA-VALUE2?**

Query the Trace 1 / 2 delta value.

**Parameter:** None

**Response:** The trace 1 delta value as a real number.

**Example:** Trace 1 value set to 100:

```
100
```

#### **:MKR:DELTA-USE-MARKER**

Set the Current Marker Value as the nominal

**Parameter:** None

**Response:** None

## Common Commands

### **:MKR:RELATIVE-RESULT?**

Returns the result at the Relative Marker

**Parameter:** None

**Response:** ???

### **:MKR:DELTA-RESULT?**

Returns the result of the Delta Marker

**Parameter:** None

**Response:** ???

### **:MKR:RELATIVE-MARKER <integer>**

Set the marker to use for the relative marker calculations.

**Parameter:** An integer in the range 1 to 8.

**Response:** None

**Example:** Set marker 1 for relative marker calculations:

```
:ANA:MKR:RELATIVE-MARKER 1
```

### **:MKR:RELATIVE-MARKER?**

Query the relative marker number.

**Parameter:** None

**Response:** The marker number as an integer.

### **:MKR:RESULT?**

Query a measurement result at the Active Marker position.

**Parameter:** None

**Response:** The Trace 1 and Trace 2 result for the currently selected marker.

**Example:** Where the Trace 1 value is 924.96 and the Trace 2 value is -0.7491.

```
9.24963156e+002, -7.49138398e-001
```

## Peak Search Functions

### **:MKR:SEARCH-TYPE <integer>**

Select Search Type as Peak or Dip

**Parameter:** 0 Peak search

1 Dip search

**Response:** None

## Common Commands

**Example:** Select Search Type as Peak  
`:ANA:MKR:SEARCH-TYPE 0`

### **:MKR:SEARCH-TYPE?**

Query the Search Type

**Parameter:** None  
**Response:** 0 Peak search.  
1 Dip search.

### **:MKR:SEARCH-TRACE <integer>**

Select the Trace to use for peak/dip searching

**Parameter:** 1 Trace 1  
2 Trace 2  
**Response:** None  
**Example:** Select Trace 1 for peak/dip searching:  
`:ANA:MKR:SEARCH-TRACE 1`

**Note:** the `:ANA:MKR:SEARCH-TYPE` command is used to select Peak Search or Dip Search

### **:MKR:SEARCH-TRACE?**

Query the trace used for peak/dip searching

**Parameter:** None  
**Response:** 1 Trace 1  
2 Trace 2

### **:MKR:SEARCH-FIND**

Move the Active Marker **to the** peak / dip

**Parameter:** None  
**Response:** None  
Example  
`:ANA:MKR:SEARCH-FIND`

### **:MKR:SEARCH-LEFT**

Move the Active Marker to the next peak / dip to the left

**Parameter:** None  
**Response:** None  
**Example:** Move the Active Marker to the next left

## Common Commands

:ANA:MKR:SEARCH-LEFT

### :MKR:SEARCH-RIGHT

Move the Active Marker to the next peak / dip to the right

**Parameter:** None

**Response:** None

**Example:** Move the Active Marker to the next right

:ANA:MKR:SEARCH-RIGHT

### :MKR:SEARCH-NEXT-HIGH

Move the Active Marker to the next highest peak / dip

**Parameter:** None

**Response:** None

**Example:** Move the Active Marker to the next highest

:ANA:MKR:SEARCH-NEXT-HIGH

### :MKR:SEARCH-NEXT-LOW

Move the Active Marker to the next lowest peak / dip.

**Parameter:** None

**Response:** None

**Example:** Move the Active Marker to the next lowest

:ANA:MKR:SEARCH-NEXT-LOW

Common Commands

1.14 /E Equivalent Circuit Analysis Option

DISPLAY <disc>

Show/Hide Equivalent Circuit mode dialog box

**Parameter:**      ON      Show Equivalent Circuit mode dialog box  
                     OFF      Hide Equivalent Circuit mode dialog box  
**Response:**      None  
**Example**      Show Equivalent Circuit mode dialog box:  
                     :ANA:EC:DISPLAY ON

CCT <integer>

Set the Equivalent Circuit type

**Parameter:**      1      Circuit 1  
                     2      Circuit 2  
                     3      Circuit 3  
                     4      Circuit 4  
                     5      Circuit 5  
**Response:**      None  
**Example**      Set circuit 5:  
                     :ANA:EC:CCT 5

CCT?

Query the Equivalent Circuit type

**Parameter:**      None  
**Response:**      1      Circuit 1  
                     2      Circuit 2  
                     3      Circuit 3  
                     4      Circuit 4  
                     5      Circuit 5

R1 <real>

Set the R1 Equivalent Circuit component value. (only when :ANA:EC:MODE is set to SET)

**Parameter**      Set the value of R1 as a real number in ohms  
**Response:**      None  
**Example:**      Set R1 to 1kohm

## Common Commands

:ANA:EC:R1 1000

### R1?

Query the R1 Equivalent Circuit component value

**Parameter:** None

**Response:** Value of R1 as a real number

**Example:** For R1 to 1kohm

:ANA:EC:R1?

1.000000000e+003

### C1 <real>

Set the C1 Equivalent Circuit component value. (only when :ANA:EC:MODE is set to SET)

**Parameter** Set the value of C1 as a real number

**Response:** None

**Example:** Set C1 to 10pF

:ANA:EC:C1 10e-12

### C1?

Query the C1 Equivalent Circuit component value

**Parameter:** None

**Response** Value of C1 as a real number

**Example:**

:ANA:EC:C1?

10.000e-12

### L1 <real>

Set the L1 Equivalent Circuit component value. (only when :ANA:EC:MODE is set to SET)

**Parameter** Set the value of L1 as a real number

**Response:** None

**Example:** Set L1 to 10uH

:ANA:EC:L1 10e-6

## Common Commands

### L1?

Query the L1 Equivalent Circuit component value

**Parameter:** None  
**Response:** Value of L1 as a real number

Example:

```
:ANA:EC:L1?
10.000e-12
```

### C0 <real>

Set the C0 Equivalent Circuit component value.

**Parameter:** Set the value of C0 as a real number  
**Response:** None  
**Example:** Set C0 to 10pF

```
:ANA:EC:C0 10e-12
```

**Note:** C0? Is only available after :ANA:EC:MODE SET and ANA:EC:CCT 5 commands have been sent i.e. the Equivalent Circuit Mode is set to Auto Mode and the Equivalent Circuit type as been set to Circuit 5

### C0?

Query the C0 Equivalent Circuit component value.

**Parameter:** None  
**Response:** Value of C0 as a real number  
**Example1:** Set C0 to 10pF in Set Mode  
+10.000e-12  
**Example2:** C0 is calculated as 10pF in Auto Mode  
+10.000e-12

**Note:** C0? Is only available after :ANA:EC:CCT 5 command has been sent i.e. the Equivalent Circuit type as been set to Circuit 5

Common Commands

TRACE <disc>

Turn Equivalent Circuit traces on and off

<b>Parameter</b>	ON	Turn Equivalent Circuit traces on
	OFF	Turn Equivalent Circuit traces off
<b>Response:</b>	None	
<b>Example:</b>	Turn Equivalent Circuit traces on	
	:ANA:EC:TRACE ON	

TRACE?

Query Equivalent Circuit trace state

<b>Parameter:</b>	None	
<b>Response</b>	1	EC trace on
	0	EC trace off

CALC-PARS

Calculate Equivalent Circuit Parameters

<b>Parameter:</b>	None	
<b>Response:</b>	None	
<b>Example:</b>	Update EC trace	

:ANA:EC:CALC-PARS

MODE <disc>

Select Equivalent Circuit Mode

<b>Parameter</b>	SET	Set Mode
	AUTO	Auto Mode
<b>Response:</b>	None	
<b>Example:</b>	Select Auto Mode	
	:ANA:EC:MODE AUTO	

MODE?

Query Equivalent Circuit Mode

<b>Parameter:</b>	None	
<b>Response:</b>	0	Set Mode
	1	Auto Mode



## Common Commands

### POINT? <integer>

Query a point on the Equivalent Circuit trace

- Parameter**      The required measurement point as an integer
- Response**      The measurement parameter of the point, the first result and the second result in comma separated form
- Example**      Retrieve the measurement result of the first measurement point:

```
:ANA:EC:POINT? 0  
  
1.00000000e+003,9.24710841e+002, 5.68111232e-002
```

### RESULT? <real>

Query the Equivalent Circuit result nearest to the defined X-axis value

- Parameter:**      The X-axis value as a real number
- Response:**      The measurement results nearest to the supplied X-axis value as:  
Nearest X-axis value to the parameter value, the first result and the second result in comma separated form
- Example**      Retrieve the measurement result nearest to the frequency parameter 10kHz.

```
:ANA:EC:RESULT? 10k  
  
9.43609621e+003, 9.24650318e+002, 3.98660591e-002
```

## Common Commands

### 1.15 /K Materials Test Option

#### Materials Function – (MATerials:)

##### TYPE <disc>

Select the Relative Permittivity test type

**Parameter:** E-CONT Permittivity Contact Method  
 E-NONCONT Permittivity Non-Contact Method  
**Response:** None  
**Example:** Select Permittivity Contact Method  
 :MAT:TYPE E-CONT

##### TYPE?

Query the Relative Permittivity test type

**Parameter:** None  
**Response:** 1 Permittivity Contact Method  
 2 Permittivity Non-Contact Method

##### D <real>

Set the Guard Electrode diameter 'd' in mm

**Parameter:** The value of 'd' as a real number  
**Response:** None  
**Example:** Set 'd' to 32mm  
 :MAT:D 32.0

##### D?

Query the Guard Electrode diameter 'd'

**Parameter:** None  
**Response:** The value of 'd' as a real number  
**Example:** When the value of 'd' is set to 32mm  
 32.000000

##### CONtact-TM <real>

Set the Material Thickness 'tm' in mm (Contact Method)

**Parameter:** The value of 'tm' as a real number  
**Response:** None  
**Example:** Set 'tm' to 2mm  
 :MAT:CONt-TM 2.0

## Common Commands

### CONtact-TM?

Query the material thickness 'tm' in mm (Contact Method)

**Parameter:** None

**Response:** The value of 'tm' as a real number

**Example:** When the value of 'tm' is 2mm

2.00000e+000

### TG <real>

Set the Electrode Separation 'tg' in mm (Non-Contact Method)

**Parameter:** The value of 'tg' as a real number

**Response:** None

**Example:** Set 'tg' to 4mm

:MAT:TG 4.0

### TG?

Query the Electrode Separation 'tg' in mm (Non-Contact Method)

**Parameter:** None

**Response:** The value of 'tg' as a real number

**Example:** When 'tg' is set to 4mm

0.40000E+1

### NONCONtact-TM <real>

Set the Material Thickness 'tm' in mm (Non-Contact Method)

**Parameter:** The value of 'tm' as a real number

**Response:** None

**Example:** Set 'tm' to 2mm

:MAT:NONCONT-TM 2.0

### NONCONtact-TM?

Query the Material Thickness 'tm' in mm (Non-Contact Method)

**Parameter:** None

**Response:** The value of 'tm' as a real number

**Example:** When 'tm' is set to 2mm

0.20000E+1

### MEASure-CG

Measure the Capacitance Without MUT 'Cg'

**Parameter:** None

## Common Commands

**Response:** None

### MEASure-CG?

Query the Capacitance Without MUT 'Cg'

**Parameter:** None

**Response:** 1 Cg data valid  
0 Cg data not valid

### N <integer>

Set the Number of Turns 'N'

**Parameter:** The value of 'N' as an integer

**Response:** None

**Example:** Set 'N' to 4  
:MAT:N 4

### N?

Query the Number of Turns 'N'

**Parameter:** None

**Response:** Value of 'N' as an integer

**Example:** When N is set to 4  
4

### L <real>

Set the Average Path Length 'l' in mm

**Parameter:** The value of 'l' as a real number

**Response:** None

**Example:** Set 'l' to 14mm  
:MAT:L 14.0

### L?

Query the Average Path Length 'l' in mm

**Parameter:** None

**Response:** Value of 'l' as a real number

**Example:** When 'l' is set to 14mm  
1.400000e+001

### A <real>

Set the Cross Sectional Area of toroid 'A' in mm<sup>2</sup>

## Common Commands

**Parameter:** The value of 'A' as a real number

**Response:** None

**Example:** Set 'A' to 10mm<sup>2</sup>

:MAT:A 10.0

### A?

Query the Cross Sectional Area of toroid 'A' in mm<sup>2</sup>

**Parameter:** None

**Response:** Value of 'A' as a real number

**Example:** When 'A' is set to 10mm<sup>2</sup>

1.0000000e+001

### Materials Function – (MATERials:)

#### MEASure-LR

Measure L<sub>W</sub>/R<sub>W</sub> reference data.

**Parameter:** None

**Response:** None

#### MEASure-LR?

Query L<sub>W</sub>/R<sub>W</sub> reference data status

**Parameter:** None

**Response:** 1 L<sub>W</sub>/R<sub>W</sub> data valid  
0 L<sub>W</sub>/R<sub>W</sub> data not valid

## Analysis Mode –(ANAlysis)

### PROPerTy1 <disc>

### PROPerTy2 <disc>

Select the Measurement Property for Trace 1 / 2

<b>Parameter:</b>	L	Inductance	C	Capacitance
	R	Resistance	Z	Impedance.
	Y	Admittance	X	Reactance.
	G	Conductance.	B	Susceptance.
	Q	Q-factors	D	D-factor.
	ANGLE	Angle.		
	EPR	Complex Permittivity-Real.		
	EPFR	Complex Permittivity-Imag.		
	DE	D-factor (Permittivity).		
	UPR	Complex Permeability –Real.		

## Common Commands

UPPR Complex Permeability –Imag

DU D-factor (Permeability

**Response:** None

### PROPerTy1?

### PROPerTy2?

Query the Trace 1 / 2 Measurement Property

**Parameter:** None.

<b>Response:</b>	0	Inductance	1	Capacitance
	2	Resistance	3	Impedance.
	4	Admittance	5	Reactance.
	6	Conductance	7	Susceptance
	8	Q-factors	9	D-factor
	10	Angle		
	11	Complex Permittivity-Real		
	12	Complex Permittivity-Imag		
	13	D-factor (Permittivity)		
	14	Complex Permeability –Real		
	15	Complex Permeability –Imag		
	16	D-factor (Permeability		

## Meter Mode –(METer:)

### FUNCTion:1 <disc>

### FUNCTion:2 <disc>

Select Function (Term) 1 / 2 Measurement Parameter

<b>Parameter:</b>	L	Inductance	C	Capacitance
	R	Resistance	Z	Impedance
	Y	Admittance	X	Reactance
	G	Conductance	B	Susceptance
	Q	Q-factors	D	D-factor
	ANGLE	Angle		
	EPR	Complex Permittivity-Real		
	EPFR	Complex Permittivity-Imag		
	DE	D-factor (Permittivity)		
	UPR	Complex Permeability –Real		
	UPFR	Complex Permeability –Imag		

Common Commands

DU D-factor (Permeability)

Response: None

FUNC:1?

FUNC:2?

Query the Function (Term) 1 / 2 Measurement Parameter

Parameter: None.

Response:	0	Inductance	1	Capacitance
	2	Resistance	3	Impedance
	4	Admittance	5	Reactance
	6	Conductance.	7	Susceptance
	8	Q-factors	9	D-factor
	10	Angle		
	11	Complex Permittivity-Real		
	12	Complex Permittivity-Imag		
	13	D-factor (Permittivity)		
	14	Complex Permeability –Real		
	15	Complex Permeability –Imag		
	16	D-factor (Permeability)		

Common Commands

1.16 /Y Polar Complex Plots

DISPLAY-MODE <discrete>

Select the Display Mode

Parameter:	COMB	Combined
	SPLIT	Split
	POLAR	Polar
	COMPLEX	Complex
Response:	None	
Example:	Set Polar mode	
	:ANA:DISPLAY-MODE POLAR	

Note:

DISPLAY-MODE?

Query the Display Mode

Parameter:	None	
Response:	0	Combined
	1	Split
	2	Polar
	3	Complex

POLAR PLOT

POLAR-PROPerTy <discrete>

Select the measurement Parameter for the polar plot.

Parameter	Z	Measure Z and angle
	Y	Measure Y and angle
Response:	None	
Example:	Set Parameter to Y/angle	
	:ANA:POLAR-PROP Y	

POLAR-PROPerTy?

Query the measurement Parameter of the polar plot.

Parameter:	None
------------	------



### Common Commands

<b>Response</b>	0	Z/angle
	1	Y/angle

### POLAR-SCALE <real>

Set the Polar Plot Scale

<b>Parameter:</b>	Set the Polar Plot Scale as a real number
<b>Response:</b>	None
<b>Example:</b>	Set Polar Plot Scale to 1k $\Omega$ /division  :ANA:POLAR-SCALE 1000

### POLAR-SCALE?

Query the Polar Plot Scale

<b>Parameter:</b>	None
<b>Response:</b>	Value of Polar Plot Scale as a real number
<b>Example:</b>	When the Polar Plot Scale is set to 1k $\Omega$ /division  1.000000e+3

### POLAR-DIVisionFullScale <integer>

Set the number of divisions for full scale on the polar plot

<b>Parameter:</b>	Set the number of divisions for full scale as an integer number
<b>Response:</b>	None
<b>Example:</b>	Set number of divisions to 5  :ANA:POLAR-DIVFS 5

### POLAR-DIVisionFullScale?

Query the number of divisions for full scale on the polar plot

<b>Parameter:</b>	None
<b>Response:</b>	Value of the number of divisions as an integer
<b>Example:</b>	When the number of divisions is set to 5  5

### POLAR-FRaMe <discrete>

Enable/disable the Cursor Frame on the polar plot.

<b>Parameter</b>	OFF	Disable the Cursor Frame
	ON	Enable the Cursor Frame

## Common Commands

**Response:** None

**Example:** Enable the Cursor Frame

:ANA:POLAR-FRM ON

### POLAR-FRaMe?

Query the Cursor Frame status on the polar plot

**Parameter:** None

**Response** 0 OFF

1 ON

### POLAR-FIT <integer>

Autofit the Polar Plot

**Parameter** 1 Round Scale

2 Full Scale divisions to 5

**Response:** None

**Example:** Set the number of divisions for full scale to 5.

:ANA:POLAR-FIT 2

### LOG-SWEEPParameter <disc>

Select Logarithmic or Linear Sweep

**Parameter:** ON Logarithmic Sweep

OFF Linear Sweep

**Response:** None

**Example:** Set Logarithmic Sweep

:ANA:LOG-SWPPAR ON

### LOG-SWEEPParameter?

Query the Sweep setting

**Parameter:** None

**Response:** 0 Logarithmic Sweep

1 Linear Sweep

## COMPLEX PLOT

### COMPLEX-PROPerTy <disc>

## Common Commands

Select Measurement Parameters for the complex plot.

**Parameter:**      R-X      Measure Rs and Xs  
                          G-B      Measure Gp and Bp  
                          ZP-ZPP      Measure Z' and Z''

**Response:**      None

**Example:**      Set measure parameters to Rs/Xs  
                          :ANA:COMPLEX-PROP R-X

### COMPLEX-PROPerTy?

Query the Measurement Parameters of the complex plot

**Parameter:**      None

**Response:**      0      Rs/Xs  
                          1      Gp/Bp  
                          2      Z'/Z''

### COMPLEX-FrameWidth <real>

Set the Frame Width (and height) of the complex plot

**Parameter:**      Set the width & height of the complex frame as a real number

**Response:**      None

**Example:**      Set the frame width to 10kR  
                          :ANA:COMPLEX-FW 10k

### COMPLEX-FrameWidth?

Query the Frame Width of the complex plot

**Parameter:**      None

**Response:**      Value of the width as a real number

**Example:**      When the frame width is set to 10kR  
                          1.000000e+004

### COMPLEX-FrameCentreX <real>

Set the X-axis Frame Centre of the complex plot

**Parameter:**      Set the X-axis Centre of the complex plot frame as a real number

**Response:**      None

**Example:**      Set the X-axis frame centre to 5kR  
                          :ANA:COMPLEX-FCX 5000

## Common Commands

### COMPLEX-FrameCentreX?

Query X-axis Frame Centre of the complex plot

**Parameter:** None  
**Response:** Value of the X-axis Frame Centre as a real number  
**Example:** When the X-axis Frame Centre to 5kR

5.000000e+003

### COMPLEX-FrameCentreY <real>

Set the Y-axis Frame Centre of the complex plot

**Parameter:** Set the Y-axis Frame Centre of the complex plot frame as a real number  
**Response:** None  
**Example:** Set the Y-axis frame centre to 5kR

:ANA:COMPLEX-FCY 5k

### COMPLEX-FrameCentreY?

Query the Y-axis Frame Centre of the complex plot

**Parameter:** None  
**Response:** Value of the Y-axis Frame Centre as a real number  
**Example:** When the Y-axis frame centre is set to 5kR

5.000000e+003

### COMPLEX-FIT

Fit the complex plot to the display area

**Parameter:** None  
**Response:** None