

The Mediatek logo consists of the word "MEDIATEK" in white, uppercase, sans-serif font, centered within an orange parallelogram shape that is wider on the left and tapers to the right.

**MEDIATEK**

# **MT7623 Flashtool Quick Start**

# Revision History

Revision	Date	Author	Description
v1	2015/01/26	Landen	Initial Version
v2	2015/01/27	Landen	(P6.) Add USB driver download information
v3	2015/01/30	Landen	(P12. P25.) The location of preloader image must be set.
v4	2015/02/26	Landen	(P6.) Add file path.
v5	2015/05/05	Landen	Correct the product name.

# Agenda


- Initialization SOP of Flashtool download.
  - Environment setup.
  - Format the flash.
  - Download images.
- FAQ
  1. How to download a image after SOP done.
  2. How to get debug logs when something wrong of Flashtool.
  3. How to verify the USB driver is installed successfully.

# Agenda

- Initialization SOP of Flashtool download.
  - Environment setup.
  - Format the flash.
  - Download images.
- FAQ
  1. How to download a image after SOP done.
  2. How to get debug logs when something wrong of Flashtool.
  3. How to verify the USB driver is installed successfully.


# Setup DUT Environment

- At least 1 un-used USB port on PC/NB are required for downloading images by flashtool.
- It is recommended to use another USB port or 4-pin UART-Lite cable for console log.



# Setup DUT Console

- You can choose either a normal 4-pin UART-Lite cable or a *daughter board (DTB)* for console connection.
- Log console is UART-Lite#2.
- Baudrate is 115200.



Daughter board for UART-Lite#0 and UART-Lite#2

Normal 4-pin UART-Lite port

# Install USB Driver

- 1) Extract “*Driver\_auto\_Installer\_v5.1341.02.rar*”
- 2) Double click “*DriverInstall.exe*”
- 3) Press “Next” button until finish installation.
- 4) **Note** that if you encounter USB detection problem, please refer to the FAQ 3 for USB debugging.


# Agenda

- Initialization SOP of Flashtool download.
  - Environment setup.
  - Format the flash.
  - Download images.
- FAQ
  1. How to download a image after SOP done.
  2. How to get debug logs when something wrong of Flashtool.
  3. How to verify the USB driver is installed successfully.




# Power off DUT (1/8)

- Power off DUT by power switch.



# Run Flashtool on PC/NB (2/8)

- Go to “FlashTool\_win32” folder.
- Run the  flash\_tool.exe




# Run Flashtool on PC/NB (3/8)

- Choose DA and Scatter file.



# Setup Download Port (4/8)

- The flashtool communicates with DUT by Micro-USB.



# Select Preloader Image (5/8)

- The preloader image must be selected for necessary device information.

**10** Select partition of preloader images for downloading


**11** Click "Location" field of the row to select correct image. Flashtool will search proper images in the same folder of the *Scatter file*. (Please see next page)

Name	Begin Address	End Address	Region	Location
PRELOADER	0x0000000000000000	0x00000000000015543	EMMC_BOOT	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
MBR	0x0000000000000000	0x000000000000001ff	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
EBR1	0x0000000000000000		EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
UBOOT	0x0000000000000000		EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
BOOTIMG	0x0000000000000000		EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
RECOVERY	0x0000000000000000		EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
SEC_RO	0x0000000000000000		EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
LOGO	0x0000000000000000		EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
EBR2	0x0000000000000000		EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
TEE1	0x0000000000000000		EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
TEE2	0x00000000015680000	0x00000000000000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
ANDROID	0x00000000015d80000	0x00000000000000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt
CACHE	0x00000000055d80000	0x00000000000000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_android\MT7623_Android_scatter.txt

0 B/s | 0 Bytes | **EMMC** | High Speed | 0:00 | USB: DA Download All(high speed,auto detect)

# Format Whole Flash (6/8)


- Format flash when first time use DUT or when change the preloader image.





# Power On DUT to Start Format (7/8)

- Make sure that Micro-USB cable connects DUT and the PC.




# Format Successfully (8/8)

- After a while, the window will pop-up to show the process finished. If NG, please refer to following FAQ for debugging.

[FAQ 3] for process not start.

[FAQ 2] for process failed.






# Agenda

- Initialization SOP of Flashtool download.
  - Environment setup.
  - Format the flash.
  - Download images.
- FAQ
  1. How to download a image after SOP done.
  2. How to get debug logs when something wrong of Flashtool.
  3. How to verify the USB driver is installed successfully.

# Power off DUT Again (1/5)

- Power off DUT by power switch.



# Select Images (2/5)

18 Select partitions that will be updated by images


19 Click "Location" field of each row to select correct image if you want to change default images.

Name	Begin Address	End Address	Region	Location
<input checked="" type="checkbox"/> PRELOADER	0x0000000000000000	0x00000000000015543	EMMC_BOOT_1	C:\Users\mtk06339\Desktop\SDK_5000_au...
<input checked="" type="checkbox"/> MBR	0x0000000000000000	0x000000000000001ff	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
<input checked="" type="checkbox"/> EBR1	0x00000000000080000			C:\Users\mtk06339\Desktop\SDK_5000_au...
<input checked="" type="checkbox"/> UBOOT	0x000000000001d20000			C:\Users\mtk06339\Desktop\SDK_5000_au...
<input checked="" type="checkbox"/> BOOTIMG	0x000000000001d80000			C:\Users\mtk06339\Desktop\SDK_5000_au...
<input type="checkbox"/> RECOVERY	0x000000000002d80000			
<input type="checkbox"/> SEC_RO	0x000000000003d80000			
<input type="checkbox"/> LOGO	0x000000000004400000			
<input checked="" type="checkbox"/> EBR2	0x000000000004700000			C:\Users\mtk06339\Desktop\SDK_5000_au...
<input type="checkbox"/> TEE1	0x0000000000015180000	0x00000000000000000	EMMC_USER	
<input type="checkbox"/> TEE2	0x0000000000015680000	0x00000000000000000	EMMC_USER	
<input type="checkbox"/> ANDROID	0x0000000000015d80000	0x00000000000000000	EMMC_USER	
<input type="checkbox"/> CACHE	0x0000000000055d80000	0x00000000000000000	EMMC_USER	

0 B/s | 0 Bytes | **EMMC** | High Speed | 0:00 | USB: DA Download All(high speed,auto detect)

# Prepare to Download Images (3/5)


- Make sure the DUT is in power-off state before this step.





## Start Download Process (4/5)

- Make sure that Micro-USB cable connects DUT and the PC.




# Download Successfully (5/5)

- After a while, the window will pop-up to show the process finished. If NG, please refer to following FAQ for debugging.

[FAQ 3] for process not start.

[FAQ 2] for process failed.



22

Download successfully.

# Agenda

- Initialization SOP of Flashtool download.
  - Environment setup.
  - Format the flash.
  - Download images.
- FAQ
  1. How to download a image after SOP done.
  2. How to get debug logs when something wrong of Flashtool.
  3. How to verify the USB driver is installed successfully.


# Conditions

- Has Finished the SOP already.
- There is a preloader image in the flash.
  - **Note** that bad preloader images will cause booting fail.
- Only want to update some images.



# Power off DUT (1/3)

- Power off DUT by power switch.



# Select Images (2/3)

Download-Agent: Flash\_MT7623\_MT7683\_Images\FlashTool\_MT8590\_emmc\_nand\_v5\_golden\MTK\_AllInOne\_DA\_MT7623.bin

Scatter-loading File: [Dropdown]

☐ Download Only

Select partitions that you want to update.


Click "Location" field of each row to select correct image.

Name	Start	End	Region	Location
PRELOADER	0x00000000	0x00000000	EMMC_BOOT_1	C:\Users\mtk06339\Desktop\SDK_5000_au...
MBR	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
EBR1	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
<input checked="" type="checkbox"/> UBOOT	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
<input checked="" type="checkbox"/> BOOTIMG	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
RECOVERY	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
SEC_RO	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
LOGO	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
EBR2	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
TEE1	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
TEE2	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
ANDROID	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...
CACHE	0x00000000	0x00000000	EMMC_USER	C:\Users\mtk06339\Desktop\SDK_5000_au...

0 B/s | 0 Bytes | **EMMC** | High Speed | 0:00 | USB: DA Download All(high speed,auto detect)

# Start Download Process (3/3)

- Make sure that Micro-USB cable connects DUT and the PC.




# Agenda

- Initialization SOP of Flashtool download.
  - Environment setup.
  - Format the flash.
  - Download images.
- FAQ
  1. How to download a image after SOP done.
  2. How to get debug logs when something wrong of Flashtool.
  3. How to verify the USB driver is installed successfully.



# Screen Capture the Error Message

- For example, this message means flash partitions described in the images is different from the current flash partitions.
- Please format the flash first, and download images again.



# Collect Debug Logs

- Make sure the DUT is in power-off state before this step.

2

3

4

5

Provide the **latest log** of flashtool to Flashtool owner for debug.

Note that the complete **console log** of DUT when downloading images is also required.

Smart Phone Flasher (Runtime Trace Mode)

File Options Window Help

Show Welcome

Contents F1

Index F2

About...

Software Update...

Open Logs Folder

Download Only

Name Begin Address End Address

SP\_FT\_Dump\_01-08-2015-20-34-06

SP\_FT\_Dump\_01-15-2015-16-44-29

SP\_FT\_Dump\_01-15-2015-20-02-30

SP\_FT\_Dump\_01-15-2015-20-04-25

SP\_FT\_Dump\_01-16-2015-12-10-30

2015/1/8 下午 08:34

2015/1/15 下午 04:44

2015/1/15 下午 08:02

2015/1/15 下午 08:04

2015/1/16 下午 12:10

檔案資料夾

ramData SP\_FT\_Logs SP\_FT\_Dump\_01-08-2015-20-34-06

至媒體槽 共用對象 新增資料夾

BROM\_DLL\_V5.log

QT\_FLASH\_TOOL.log

2015/1/9 下午 07...

2015/1/9 下午 07...

文字文件

文字文件

23,952 KB

824 KB

# Agenda

- Initialization SOP of Flashtool download.
  - Environment setup.
  - Format the flash.
  - Download images.
- FAQ
  1. How to download a image after SOP done.
  2. How to get debug logs when something wrong of Flashtool.
  3. How to verify the USB driver is installed successfully.

# USB Driver Verification

- If the USB driver is successfully installed. It will show in the device list of PC as DUT power up.
  - **Note** that this COM port is used to communicate with PC tools in early boot up process, so it will be disabled in a short time if PC tools are not detected.



- If you do not see the “MTK USB Port” device in the device list, please check the following steps.
  - Try other USB port of PC.
  - Search unknown USB device in the device list, and install USB driver again manually.
  - Try reboot the PC.
  - Try another PC.
  - Try another DUT if above steps are NG.