

ADS1115 Driver

1.0.0

Generated by Doxygen 1.14.0

1 Class Index	1
1.1 Class List	1
2 File Index	3
2.1 File List	3
3 Class Documentation	5
3.1 ads1115_config_t Struct Reference	5
3.1.1 Detailed Description	5
3.1.2 Member Data Documentation	5
3.1.2.1 comp_latch	5
3.1.2.2 comp_mode	6
3.1.2.3 comp_pol	6
3.1.2.4 comp_queue	6
3.1.2.5 data_rate	6
3.1.2.6 high_threshold	6
3.1.2.7 low_threshold	6
3.1.2.8 mode	7
3.1.2.9 mux	7
3.1.2.10 range	7
3.2 ads1115_handle_t Struct Reference	7
3.2.1 Detailed Description	7
3.2.2 Member Data Documentation	8
3.2.2.1 config	8
3.2.2.2 delay_ms	8
3.2.2.3 i2c_addr	8
3.2.2.4 i2c_read	8
3.2.2.5 i2c_write	8
3.2.2.6 is_initialized	8
4 File Documentation	9
4.1 interface/ads1115_interface.c File Reference	9
4.1.1 Detailed Description	9
4.1.2 Function Documentation	9
4.1.2.1 ads1115_delay_ms()	9
4.1.2.2 ads1115_i2c_read()	10
4.1.2.3 ads1115_i2c_write()	10
4.2 ads1115_interface.c	11
4.3 interface/ads1115_interface.h File Reference	11
4.3.1 Detailed Description	11
4.3.2 Function Documentation	11
4.3.2.1 ads1115_delay_ms()	11
4.3.2.2 ads1115_i2c_read()	12

4.3.2.3 ads1115_i2c_write()	12
4.4 ads1115_interface.h	13
4.5 src/ads1115.c File Reference	13
4.5.1 Detailed Description	15
4.5.2 Macro Definition Documentation	15
4.5.2.1 ADS1115_COMP_LAT_MASK	15
4.5.2.2 ADS1115_COMP_LAT_SHIFT	15
4.5.2.3 ADS1115_COMP_MODE_MASK	15
4.5.2.4 ADS1115_COMP_MODE_SHIFT	15
4.5.2.5 ADS1115_COMP_POL_MASK	16
4.5.2.6 ADS1115_COMP_POL_SHIFT	16
4.5.2.7 ADS1115_COMP_QUE_MASK	16
4.5.2.8 ADS1115_COMP_QUE_SHIFT	16
4.5.2.9 ADS1115_DR_MASK	16
4.5.2.10 ADS1115_DR_SHIFT	16
4.5.2.11 ADS1115_MAX_VALUE	16
4.5.2.12 ADS1115_MIN_VALUE	16
4.5.2.13 ADS1115_MODE_MASK	17
4.5.2.14 ADS1115_MODE_SHIFT	17
4.5.2.15 ADS1115_MUX_MASK	17
4.5.2.16 ADS1115_MUX_SHIFT	17
4.5.2.17 ADS1115_OS_IDLE	17
4.5.2.18 ADS1115_OS_MASK	17
4.5.2.19 ADS1115_OS_SHIFT	17
4.5.2.20 ADS1115_OS_START_SINGLE	17
4.5.2.21 ADS1115_PGA_MASK	18
4.5.2.22 ADS1115_PGA_SHIFT	18
4.5.2.23 ADS1115_REG_CONFIG	18
4.5.2.24 ADS1115_REG_CONVERSION	18
4.5.2.25 ADS1115_REG_HI_THRESH	18
4.5.2.26 ADS1115_REG_LO_THRESH	18
4.5.3 Function Documentation	18
4.5.3.1 ads1115_continuous_conversion_read()	18
4.5.3.2 ads1115_continuous_conversion_start()	19
4.5.3.3 ads1115_continuous_conversion_stop()	19
4.5.3.4 ads1115_deinit()	19
4.5.3.5 ads1115_get_channel()	20
4.5.3.6 ads1115_get_compare_alert()	20
4.5.3.7 ads1115_get_compare_latch()	20
4.5.3.8 ads1115_get_compare_mode()	21
4.5.3.9 ads1115_get_compare_queue()	21
4.5.3.10 ads1115_get_compare_threshold()	21

4.5.3.11 ads1115_get_data_rate()	22
4.5.3.12 ads1115_get_range()	22
4.5.3.13 ads1115_init()	22
4.5.3.14 ads1115_is_ready()	23
4.5.3.15 ads1115_set_channel()	23
4.5.3.16 ads1115_set_compare_alert()	23
4.5.3.17 ads1115_set_compare_latch()	24
4.5.3.18 ads1115_set_compare_mode()	24
4.5.3.19 ads1115_set_compare_queue()	24
4.5.3.20 ads1115_set_compare_threshold()	25
4.5.3.21 ads1115_set_data_rate()	25
4.5.3.22 ads1115_set_range()	25
4.5.3.23 ads1115_single_read()	26
4.6 ads1115.c	26
4.7 src/ads1115.h File Reference	34
4.7.1 Detailed Description	37
4.7.2 Macro Definition Documentation	37
4.7.2.1 ADS1115_DEFAULT_CONFIGURATION	37
4.7.3 Typedef Documentation	37
4.7.3.1 ads1115_delay_ms_t	37
4.7.3.2 ads1115_i2c_read_t	38
4.7.3.3 ads1115_i2c_write_t	38
4.7.4 Enumeration Type Documentation	38
4.7.4.1 ads1115_comp_latch_t	38
4.7.4.2 ads1115_comp_mode_t	39
4.7.4.3 ads1115_comp_polarity_t	39
4.7.4.4 ads1115_comp_queue_t	39
4.7.4.5 ads1115_data_rate_t	39
4.7.4.6 ads1115_error_t	40
4.7.4.7 ads1115_i2c_addr_t	40
4.7.4.8 ads1115_mode_t	40
4.7.4.9 ads1115_mux_t	41
4.7.4.10 ads1115_range_t	41
4.7.5 Function Documentation	41
4.7.5.1 ads1115_continuous_conversion_read()	41
4.7.5.2 ads1115_continuous_conversion_start()	42
4.7.5.3 ads1115_continuous_conversion_stop()	42
4.7.5.4 ads1115_deinit()	42
4.7.5.5 ads1115_get_channel()	43
4.7.5.6 ads1115_get_compare_alert()	43
4.7.5.7 ads1115_get_compare_latch()	43
4.7.5.8 ads1115_get_compare_mode()	44

4.7.5.9 ads1115_get_compare_queue()	44
4.7.5.10 ads1115_get_compare_threshold()	44
4.7.5.11 ads1115_get_data_rate()	45
4.7.5.12 ads1115_get_range()	45
4.7.5.13 ads1115_init()	45
4.7.5.14 ads1115_is_ready()	46
4.7.5.15 ads1115_set_channel()	46
4.7.5.16 ads1115_set_compare_alert()	46
4.7.5.17 ads1115_set_compare_latch()	47
4.7.5.18 ads1115_set_compare_mode()	47
4.7.5.19 ads1115_set_compare_queue()	47
4.7.5.20 ads1115_set_compare_threshold()	48
4.7.5.21 ads1115_set_data_rate()	48
4.7.5.22 ads1115_set_range()	48
4.7.5.23 ads1115_single_read()	49
4.8 ads1115.h	49

Index**53**

Chapter 1

Class Index

1.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

ads1115_config_t		
ADS1115 configuration structure	5
ads1115_handle_t		
ADS1115 device handle structure	7

Chapter 2

File Index

2.1 File List

Here is a list of all documented files with brief descriptions:

interface/ ads1115_interface.c	
ADS1115 I2C read/write and delay callback function implementations	9
interface/ ads1115_interface.h	
ADS1115 I2C read/write and delay callback function declarations	11
src/ ads1115.c	
ADS1115 16-Bit ADC Driver Implementation	13
src/ ads1115.h	
ADS1115 16-Bit ADC Driver - Platform Independent	34

Chapter 3

Class Documentation

3.1 `ads1115_config_t` Struct Reference

ADS1115 configuration structure.

```
#include <ads1115.h>
```

Public Attributes

- [ads1115_mux_t mux](#)
- [ads1115_range_t range](#)
- [ads1115_mode_t mode](#)
- [ads1115_data_rate_t data_rate](#)
- [ads1115_comp_mode_t comp_mode](#)
- [ads1115_comp_polarity_t comp_pol](#)
- [ads1115_comp_latch_t comp_latch](#)
- [ads1115_comp_queue_t comp_queue](#)
- [int16_t low_threshold](#)
- [int16_t high_threshold](#)

3.1.1 Detailed Description

ADS1115 configuration structure.

Definition at line 172 of file [ads1115.h](#).

3.1.2 Member Data Documentation

3.1.2.1 `comp_latch`

```
ads1115\_comp\_latch\_t ads1115_config_t::comp_latch
```

Comparator latching

Definition at line 179 of file [ads1115.h](#).

3.1.2.2 comp_mode

`ads1115_comp_mode_t` `ads1115_config_t::comp_mode`

Comparator mode

Definition at line 177 of file [ads1115.h](#).

3.1.2.3 comp_pol

`ads1115_comp_polarity_t` `ads1115_config_t::comp_pol`

Comparator polarity

Definition at line 178 of file [ads1115.h](#).

3.1.2.4 comp_queue

`ads1115_comp_queue_t` `ads1115_config_t::comp_queue`

Comparator queue

Definition at line 180 of file [ads1115.h](#).

3.1.2.5 data_rate

`ads1115_data_rate_t` `ads1115_config_t::data_rate`

Data rate (samples per second)

Definition at line 176 of file [ads1115.h](#).

3.1.2.6 high_threshold

`int16_t` `ads1115_config_t::high_threshold`

High threshold value

Definition at line 182 of file [ads1115.h](#).

3.1.2.7 low_threshold

`int16_t` `ads1115_config_t::low_threshold`

Low threshold value

Definition at line 181 of file [ads1115.h](#).

3.1.2.8 mode

`ads1115_mode_t` `ads1115_config_t::mode`

Operating mode

Definition at line 175 of file [ads1115.h](#).

3.1.2.9 mux

`ads1115_mux_t` `ads1115_config_t::mux`

Input multiplexer configuration

Definition at line 173 of file [ads1115.h](#).

3.1.2.10 range

`ads1115_range_t` `ads1115_config_t::range`

Programmable gain amplifier

Definition at line 174 of file [ads1115.h](#).

The documentation for this struct was generated from the following file:

- [src/ads1115.h](#)

3.2 ads1115_handle_t Struct Reference

ADS1115 device handle structure.

```
#include <ads1115.h>
```

Public Attributes

- [ads1115_i2c_addr_t](#) `i2c_addr`
- [ads1115_config_t](#) `config`
- [ads1115_i2c_write_t](#) `i2c_write`
- [ads1115_i2c_read_t](#) `i2c_read`
- [ads1115_delay_ms_t](#) `delay_ms`
- `bool` `is_initialized`

3.2.1 Detailed Description

ADS1115 device handle structure.

Definition at line 188 of file [ads1115.h](#).

3.2.2 Member Data Documentation

3.2.2.1 config

`ads1115_config_t` `ads1115_handle_t::config`

Current device configuration

Definition at line 190 of file [ads1115.h](#).

3.2.2.2 delay_ms

`ads1115_delay_ms_t` `ads1115_handle_t::delay_ms`

Delay callback

Definition at line 193 of file [ads1115.h](#).

3.2.2.3 i2c_addr

`ads1115_i2c_addr_t` `ads1115_handle_t::i2c_addr`

I2C device address

Definition at line 189 of file [ads1115.h](#).

3.2.2.4 i2c_read

`ads1115_i2c_read_t` `ads1115_handle_t::i2c_read`

I2C read callback

Definition at line 192 of file [ads1115.h](#).

3.2.2.5 i2c_write

`ads1115_i2c_write_t` `ads1115_handle_t::i2c_write`

I2C write callback

Definition at line 191 of file [ads1115.h](#).

3.2.2.6 is_initialized

`bool` `ads1115_handle_t::is_initialized`

Initialization status

Definition at line 194 of file [ads1115.h](#).

The documentation for this struct was generated from the following file:

- [src/ads1115.h](#)

Chapter 4

File Documentation

4.1 interface/ads1115_interface.c File Reference

ADS1115 I2C read/write and delay callback function implementations.

```
#include "ads1115_interface.h"
```

Functions

- uint8_t [ads1115_i2c_write](#) (uint8_t i2c_addr, uint8_t reg_addr, uint8_t *data, uint16_t len)
ADS1115 I2C write function ([ads1115_i2c_write_t](#) callback)
- uint8_t [ads1115_i2c_read](#) (uint8_t i2c_addr, uint8_t reg_addr, uint8_t *data, uint16_t len)
ADS1115 I2C read function ([ads1115_i2c_read_t](#) callback)
- void [ads1115_delay_ms](#) (uint32_t milliseconds)
ADS1115 delay_ms function ([ads1115_delay_ms_t](#) callback)

4.1.1 Detailed Description

ADS1115 I2C read/write and delay callback function implementations.

Author

Şükrü Can Kılıç

Date

19.01.2026

Definition in file [ads1115_interface.c](#).

4.1.2 Function Documentation

4.1.2.1 ads1115_delay_ms()

```
void ads1115_delay_ms (  
    uint32_t milliseconds)
```

ADS1115 delay_ms function ([ads1115_delay_ms_t](#) callback)

Parameters

<i>milliseconds</i>	Delay time in milliseconds
---------------------	----------------------------

Definition at line 24 of file [ads1115_interface.c](#).

4.1.2.2 ads1115_i2c_read()

```
uint8_t ads1115_i2c_read (
    uint8_t i2c_addr,
    uint8_t reg_addr,
    uint8_t * data,
    uint16_t len)
```

ADS1115 I2C read function ([ads1115_i2c_read_t](#) callback)

Parameters

<i>i2c_addr</i>	ADS1115 I2C address
<i>reg_addr</i>	ADS1115 register address
<i>data</i>	Pointer to register value
<i>len</i>	Length of register value

Returns

Error code

Definition at line 17 of file [ads1115_interface.c](#).

4.1.2.3 ads1115_i2c_write()

```
uint8_t ads1115_i2c_write (
    uint8_t i2c_addr,
    uint8_t reg_addr,
    uint8_t * data,
    uint16_t len)
```

ADS1115 I2C write function ([ads1115_i2c_write_t](#) callback)

Parameters

<i>i2c_addr</i>	ADS1115 I2C address
<i>reg_addr</i>	ADS1115 register address
<i>data</i>	Pointer to register value
<i>len</i>	Length of register value

Returns

Error code

Definition at line 10 of file [ads1115_interface.c](#).

4.2 ads1115_interface.c

[Go to the documentation of this file.](#)

```

00001
00007
00008 #include "ads1115_interface.h"
00009
00010 uint8_t ads1115_i2c_write(uint8_t i2c_addr, uint8_t reg_addr, uint8_t *data, uint16_t len)
00011 {
00012     /* Write your platform code for I2C write function (STM32, ESP32, ARDUINO etc.) */
00013
00014     return 0;
00015 }
00016
00017 uint8_t ads1115_i2c_read(uint8_t i2c_addr, uint8_t reg_addr, uint8_t *data, uint16_t len)
00018 {
00019     /* Write your platform code for I2C read function (STM32, ESP32, ARDUINO etc.) */
00020
00021     return 0;
00022 }
00023
00024 void ads1115_delay_ms(uint32_t milliseconds)
00025 {
00026     /* Write your platform code for delay in milliseconds function (STM32, ESP32, ARDUINO etc.) */
00027 }

```

4.3 interface/ads1115_interface.h File Reference

ADS1115 I2C read/write and delay callback function declarations.

```
#include "ads1115.h"
```

Functions

- uint8_t [ads1115_i2c_write](#) (uint8_t i2c_addr, uint8_t reg_addr, uint8_t *data, uint16_t len)
ADS1115 I2C write function ([ads1115_i2c_write_t](#) callback)
- uint8_t [ads1115_i2c_read](#) (uint8_t i2c_addr, uint8_t reg_addr, uint8_t *data, uint16_t len)
ADS1115 I2C read function ([ads1115_i2c_read_t](#) callback)
- void [ads1115_delay_ms](#) (uint32_t milliseconds)
ADS1115 delay_ms function ([ads1115_delay_ms_t](#) callback)

4.3.1 Detailed Description

ADS1115 I2C read/write and delay callback function declarations.

Author

Şükrü Can Kılıç

Date

19.01.2026

Definition in file [ads1115_interface.h](#).

4.3.2 Function Documentation

4.3.2.1 ads1115_delay_ms()

```
void ads1115_delay_ms (
    uint32_t milliseconds)
```

ADS1115 delay_ms function ([ads1115_delay_ms_t](#) callback)

Parameters

<i>milliseconds</i>	Delay time in milliseconds
---------------------	----------------------------

Definition at line 24 of file [ads1115_interface.c](#).

4.3.2.2 ads1115_i2c_read()

```
uint8_t ads1115_i2c_read (
    uint8_t i2c_addr,
    uint8_t reg_addr,
    uint8_t * data,
    uint16_t len)
```

ADS1115 I2C read function ([ads1115_i2c_read_t](#) callback)

Parameters

<i>i2c_addr</i>	ADS1115 I2C address
<i>reg_addr</i>	ADS1115 register address
<i>data</i>	Pointer to register value
<i>len</i>	Length of register value

Returns

Error code

Definition at line 17 of file [ads1115_interface.c](#).

4.3.2.3 ads1115_i2c_write()

```
uint8_t ads1115_i2c_write (
    uint8_t i2c_addr,
    uint8_t reg_addr,
    uint8_t * data,
    uint16_t len)
```

ADS1115 I2C write function ([ads1115_i2c_write_t](#) callback)

Parameters

<i>i2c_addr</i>	ADS1115 I2C address
<i>reg_addr</i>	ADS1115 register address
<i>data</i>	Pointer to register value
<i>len</i>	Length of register value

Returns

Error code

Definition at line 10 of file [ads1115_interface.c](#).

4.4 ads1115_interface.h

[Go to the documentation of this file.](#)

```
00001
00007
00008 #include "ads1115.h"
00009
00019 uint8_t ads1115_i2c_write(uint8_t i2c_addr, uint8_t reg_addr, uint8_t *data, uint16_t len);
00020
00030 uint8_t ads1115_i2c_read(uint8_t i2c_addr, uint8_t reg_addr, uint8_t *data, uint16_t len);
00031
00037 void ads1115_delay_ms(uint32_t milliseconds);
```

4.5 src/ads1115.c File Reference

ADS1115 16-Bit ADC Driver Implementation.

```
#include "ads1115.h"
#include <stddef.h>
```

Macros

- #define [ADS1115_REG_CONVERSION](#) 0x00
ADS1115 Register addresses.
- #define [ADS1115_REG_CONFIG](#) 0x01
- #define [ADS1115_REG_LO_THRESH](#) 0x02
- #define [ADS1115_REG_HI_THRESH](#) 0x03
- #define [ADS1115_OS_MASK](#) 0x8000
- #define [ADS1115_OS_SHIFT](#) 15
- #define [ADS1115_OS_IDLE](#) 0x8000
- #define [ADS1115_OS_START_SINGLE](#) 0x8000
- #define [ADS1115_MUX_MASK](#) 0x7000
- #define [ADS1115_MUX_SHIFT](#) 12
- #define [ADS1115_PGA_MASK](#) 0x0E00
- #define [ADS1115_PGA_SHIFT](#) 9
- #define [ADS1115_MODE_MASK](#) 0x0100
- #define [ADS1115_MODE_SHIFT](#) 8
- #define [ADS1115_DR_MASK](#) 0x00E0
- #define [ADS1115_DR_SHIFT](#) 5
- #define [ADS1115_COMP_MODE_MASK](#) 0x0010
- #define [ADS1115_COMP_MODE_SHIFT](#) 4
- #define [ADS1115_COMP_POL_MASK](#) 0x0008
- #define [ADS1115_COMP_POL_SHIFT](#) 3
- #define [ADS1115_COMP_LAT_MASK](#) 0x0004
- #define [ADS1115_COMP_LAT_SHIFT](#) 2
- #define [ADS1115_COMP_QUE_MASK](#) 0x0003
- #define [ADS1115_COMP_QUE_SHIFT](#) 0
- #define [ADS1115_MAX_VALUE](#) 32767
- #define [ADS1115_MIN_VALUE](#) -32768

Functions

- [ads1115_error_t ads1115_init](#) ([ads1115_handle_t](#) *handle)
Initialize ADS1115 device.
- [ads1115_error_t ads1115_deinit](#) ([ads1115_handle_t](#) *handle)
De-initialize ADS1115 device.
- [ads1115_error_t ads1115_set_range](#) ([ads1115_handle_t](#) *handle, [ads1115_range_t](#) range)
Set range of adc.
- [ads1115_error_t ads1115_get_range](#) ([ads1115_handle_t](#) *handle, [ads1115_range_t](#) *range)
Get range of adc.
- [ads1115_error_t ads1115_set_data_rate](#) ([ads1115_handle_t](#) *handle, [ads1115_data_rate_t](#) data_rate)
Set adc data sample rate.
- [ads1115_error_t ads1115_get_data_rate](#) ([ads1115_handle_t](#) *handle, [ads1115_data_rate_t](#) *data_rate)
Get adc data sample rate.
- [ads1115_error_t ads1115_continuous_conversion_start](#) ([ads1115_handle_t](#) *handle)
Start adc continuous conversion mode.
- [ads1115_error_t ads1115_continuous_conversion_stop](#) ([ads1115_handle_t](#) *handle)
Stop adc continuous conversion mode.
- [ads1115_error_t ads1115_continuous_conversion_read](#) ([ads1115_handle_t](#) *handle, [int16_t](#) *adc_raw, float *voltage)
Read the result of adc continuously.
- [ads1115_error_t ads1115_single_read](#) ([ads1115_handle_t](#) *handle, [int16_t](#) *adc_raw, float *voltage)
Read adc result once.
- [ads1115_error_t ads1115_set_channel](#) ([ads1115_handle_t](#) *handle, [ads1115_mux_t](#) channel)
Set adc input channel from mux.
- [ads1115_error_t ads1115_get_channel](#) ([ads1115_handle_t](#) *handle, [ads1115_mux_t](#) *channel)
Set adc input channel from mux.
- [ads1115_error_t ads1115_set_compare_mode](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_mode_t](#) compare)
Set comparator mode.
- [ads1115_error_t ads1115_get_compare_mode](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_mode_t](#) *compare)
Get current comparator mode from device.
- [ads1115_error_t ads1115_set_compare_queue](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_queue_t](#) comp_queue)
Set comparatore queue.
- [ads1115_error_t ads1115_get_compare_queue](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_queue_t](#) *comp_queue)
Get comparatore queue.
- [ads1115_error_t ads1115_set_compare_latch](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_latch_t](#) latch)
Set comparator latching mode.
- [ads1115_error_t ads1115_get_compare_latch](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_latch_t](#) *latch)
Get comparator latching mode.
- [ads1115_error_t ads1115_set_compare_alert](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_polarity_t](#) polarity)
Set the alert pin polatiry mode (ACTIVE_HIGH or ACTIVE_LOW)
- [ads1115_error_t ads1115_get_compare_alert](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_polarity_t](#) *polarity)
Get the alert pin polatiry (ACTIVE_HIGH or ACTIVE_LOW)
- [ads1115_error_t ads1115_set_compare_threshold](#) ([ads1115_handle_t](#) *handle, [int16_t](#) low_threshold, [int16_t](#) high_threshold)
Set the comparator low and high threshold.

- [ads1115_error_t ads1115_get_compare_threshold](#) ([ads1115_handle_t](#) *handle, [int16_t](#) *low_threshold, [int16_t](#) *high_threshold)
Get the comparator low and high threshold.
- [ads1115_error_t ads1115_is_ready](#) ([ads1115_handle_t](#) *handle, [bool](#) *flag)
Check if conversion is ready.

4.5.1 Detailed Description

ADS1115 16-Bit ADC Driver Implementation.

Author

Şükrü Can Kılıç

Date

19.01.2026

Definition in file [ads1115.c](#).

4.5.2 Macro Definition Documentation

4.5.2.1 ADS1115_COMP_LAT_MASK

```
#define ADS1115_COMP_LAT_MASK 0x0004
```

Definition at line 58 of file [ads1115.c](#).

4.5.2.2 ADS1115_COMP_LAT_SHIFT

```
#define ADS1115_COMP_LAT_SHIFT 2
```

Definition at line 59 of file [ads1115.c](#).

4.5.2.3 ADS1115_COMP_MODE_MASK

```
#define ADS1115_COMP_MODE_MASK 0x0010
```

Definition at line 50 of file [ads1115.c](#).

4.5.2.4 ADS1115_COMP_MODE_SHIFT

```
#define ADS1115_COMP_MODE_SHIFT 4
```

Definition at line 51 of file [ads1115.c](#).

4.5.2.5 ADS1115_COMP_POL_MASK

```
#define ADS1115_COMP_POL_MASK 0x0008
```

Definition at line 54 of file [ads1115.c](#).

4.5.2.6 ADS1115_COMP_POL_SHIFT

```
#define ADS1115_COMP_POL_SHIFT 3
```

Definition at line 55 of file [ads1115.c](#).

4.5.2.7 ADS1115_COMP_QUE_MASK

```
#define ADS1115_COMP_QUE_MASK 0x0003
```

Definition at line 62 of file [ads1115.c](#).

4.5.2.8 ADS1115_COMP_QUE_SHIFT

```
#define ADS1115_COMP_QUE_SHIFT 0
```

Definition at line 63 of file [ads1115.c](#).

4.5.2.9 ADS1115_DR_MASK

```
#define ADS1115_DR_MASK 0x00E0
```

Definition at line 46 of file [ads1115.c](#).

4.5.2.10 ADS1115_DR_SHIFT

```
#define ADS1115_DR_SHIFT 5
```

Definition at line 47 of file [ads1115.c](#).

4.5.2.11 ADS1115_MAX_VALUE

```
#define ADS1115_MAX_VALUE 32767
```

Definition at line 69 of file [ads1115.c](#).

4.5.2.12 ADS1115_MIN_VALUE

```
#define ADS1115_MIN_VALUE -32768
```

Definition at line 70 of file [ads1115.c](#).

4.5.2.13 ADS1115_MODE_MASK

```
#define ADS1115_MODE_MASK 0x0100
```

Definition at line 42 of file [ads1115.c](#).

4.5.2.14 ADS1115_MODE_SHIFT

```
#define ADS1115_MODE_SHIFT 8
```

Definition at line 43 of file [ads1115.c](#).

4.5.2.15 ADS1115_MUX_MASK

```
#define ADS1115_MUX_MASK 0x7000
```

Definition at line 34 of file [ads1115.c](#).

4.5.2.16 ADS1115_MUX_SHIFT

```
#define ADS1115_MUX_SHIFT 12
```

Definition at line 35 of file [ads1115.c](#).

4.5.2.17 ADS1115_OS_IDLE

```
#define ADS1115_OS_IDLE 0x8000
```

Definition at line 30 of file [ads1115.c](#).

4.5.2.18 ADS1115_OS_MASK

```
#define ADS1115_OS_MASK 0x8000
```

Definition at line 28 of file [ads1115.c](#).

4.5.2.19 ADS1115_OS_SHIFT

```
#define ADS1115_OS_SHIFT 15
```

Definition at line 29 of file [ads1115.c](#).

4.5.2.20 ADS1115_OS_START_SINGLE

```
#define ADS1115_OS_START_SINGLE 0x8000
```

Definition at line 31 of file [ads1115.c](#).

4.5.2.21 ADS1115_PGA_MASK

```
#define ADS1115_PGA_MASK 0x0E00
```

Definition at line 38 of file [ads1115.c](#).

4.5.2.22 ADS1115_PGA_SHIFT

```
#define ADS1115_PGA_SHIFT 9
```

Definition at line 39 of file [ads1115.c](#).

4.5.2.23 ADS1115_REG_CONFIG

```
#define ADS1115_REG_CONFIG 0x01
```

Chip configuration register (read/write)

Definition at line 19 of file [ads1115.c](#).

4.5.2.24 ADS1115_REG_CONVERSION

```
#define ADS1115_REG_CONVERSION 0x00
```

ADS1115 Register addresses.

ADC result register (read-only)

Definition at line 18 of file [ads1115.c](#).

4.5.2.25 ADS1115_REG_HI_THRESH

```
#define ADS1115_REG_HI_THRESH 0x03
```

Interrupt high threshold register (read/write)

Definition at line 21 of file [ads1115.c](#).

4.5.2.26 ADS1115_REG_LO_THRESH

```
#define ADS1115_REG_LO_THRESH 0x02
```

Interrupt low threshold register (read/write)

Definition at line 20 of file [ads1115.c](#).

4.5.3 Function Documentation

4.5.3.1 ads1115_continuous_conversion_read()

```
ads1115_error_t ads1115_continuous_conversion_read (  
    ads1115_handle_t * handle,  
    int16_t * adc_raw,  
    float * voltage)
```

Read the result of adc continuously.

Parameters

<i>handle</i>	Pointer to device handle
<i>adc_raw</i>	Pointer to raw adc result
<i>voltage</i>	Pointer to converted adc result

Returns

[ads1115_error_t](#) Error code

Definition at line 322 of file [ads1115.c](#).

4.5.3.2 ads1115_continuous_conversion_start()

```
ads1115_error_t ads1115_continuous_conversion_start (  
    ads1115_handle_t * handle)
```

Start adc continuous conversion mode.

Parameters

<i>handle</i>	Pointer to device handle
---------------	--------------------------

Returns

[ads1115_error_t](#) Error code

Definition at line 300 of file [ads1115.c](#).

4.5.3.3 ads1115_continuous_conversion_stop()

```
ads1115_error_t ads1115_continuous_conversion_stop (  
    ads1115_handle_t * handle)
```

Stop adc continuous conversion mode.

Parameters

<i>handle</i>	Pointer to device handle
---------------	--------------------------

Returns

[ads1115_error_t](#) Error code

Definition at line 311 of file [ads1115.c](#).

4.5.3.4 ads1115_deinit()

```
ads1115_error_t ads1115_deinit (  
    ads1115_handle_t * handle)
```

De-initialize ADS1115 device.

Parameters

<i>handle</i>	Pointer to device handle
---------------	--------------------------

Returns

[ads1115_error_t](#) Error code

Definition at line 211 of file [ads1115.c](#).

4.5.3.5 [ads1115_get_channel\(\)](#)

```
ads1115_error_t ads1115_get_channel (  
    ads1115_handle_t * handle,  
    ads1115_mux_t * channel)
```

Set adc input channel from mux.

Parameters

<i>handle</i>	Pointer to device handle
<i>channel</i>	Pointer to input adc channel from mux

Returns

[ads1115_error_t](#) Error code

Definition at line 409 of file [ads1115.c](#).

4.5.3.6 [ads1115_get_compare_alert\(\)](#)

```
ads1115_error_t ads1115_get_compare_alert (  
    ads1115_handle_t * handle,  
    ads1115_comp_polarity_t * polarity)
```

Get the alert pin polatiry (ACTIVE_HIGH or ACTIVE_LOW)

Parameters

<i>handle</i>	Pointer to device handle
<i>polarity</i>	Pointer to alert pin polarity

Returns

[ads1115_error_t](#) Error code

Definition at line 565 of file [ads1115.c](#).

4.5.3.7 [ads1115_get_compare_latch\(\)](#)

```
ads1115_error_t ads1115_get_compare_latch (  
    ads1115_handle_t * handle,  
    ads1115_comp_latch_t * latch)
```

Get comparator latching mode.

Parameters

<i>handle</i>	Pointer to device handle
<i>latch</i>	Pointer to comparator latch

Returns

[ads1115_error_t](#) Error code

Definition at line 526 of file [ads1115.c](#).

4.5.3.8 ads1115_get_compare_mode()

```
ads1115_error_t ads1115_get_compare_mode (  
    ads1115_handle_t * handle,  
    ads1115_comp_mode_t * compare)
```

Get current comparator mode from device.

Parameters

<i>handle</i>	Pointer to device handle
<i>compare</i>	Pointer to interrupt compare mode

Returns

[ads1115_error_t](#) Error code

Definition at line 448 of file [ads1115.c](#).

4.5.3.9 ads1115_get_compare_queue()

```
ads1115_error_t ads1115_get_compare_queue (  
    ads1115_handle_t * handle,  
    ads1115_comp_queue_t * comp_queue)
```

Get comparatore queue.

Parameters

<i>handle</i>	Pointer to device handle
<i>comp_queue</i>	Pointer to comparator queue

Returns

[ads1115_error_t](#) Error code

Definition at line 487 of file [ads1115.c](#).

4.5.3.10 ads1115_get_compare_threshold()

```
ads1115_error_t ads1115_get_compare_threshold (  
    ads1115_handle_t * handle,  
    int16_t * low_threshold,  
    int16_t * high_threshold)
```

Get the comparator low and high threshold.

Parameters

<i>handle</i>	Pointer to device handle
<i>low_threshold</i>	Pointer to compare low threshold
<i>high_threshold</i>	Pointer to compare high threshold

Returns

[ads1115_error_t](#) Error code

Definition at line 607 of file [ads1115.c](#).

4.5.3.11 ads1115_get_data_rate()

```
ads1115_error_t ads1115_get_data_rate (  
    ads1115_handle_t * handle,  
    ads1115_data_rate_t * data_rate)
```

Get adc data sample rate.

Parameters

<i>handle</i>	Pointer to device handle
<i>data_rate</i>	Data rate setting

Returns

[ads1115_error_t](#) Error code

Definition at line 277 of file [ads1115.c](#).

4.5.3.12 ads1115_get_range()

```
ads1115_error_t ads1115_get_range (  
    ads1115_handle_t * handle,  
    ads1115_range_t * range)
```

Get range of adc.

Parameters

<i>handle</i>	Pointer to device handle
<i>range</i>	Maximum voltage range

Returns

[ads1115_error_t](#) Error code

Definition at line 238 of file [ads1115.c](#).

4.5.3.13 ads1115_init()

```
ads1115_error_t ads1115_init (  
    ads1115_handle_t * handle)
```

Initialize ADS1115 device.

Parameters

<i>handle</i>	Pointer to device handle
---------------	--------------------------

Returns

[ads1115_error_t](#) Error code

Definition at line 175 of file [ads1115.c](#).

4.5.3.14 ads1115_is_ready()

```
ads1115_error_t ads1115_is_ready (  
    ads1115_handle_t * handle,  
    bool * flag)
```

Check if conversion is ready.

Parameters

<i>handle</i>	Pointer to device handle
<i>flag</i>	Pointer to store flag status

Returns

[ads1115_error_t](#) Error code

Definition at line 639 of file [ads1115.c](#).

4.5.3.15 ads1115_set_channel()

```
ads1115_error_t ads1115_set_channel (  
    ads1115_handle_t * handle,  
    ads1115_mux_t channel)
```

Set adc input channel from mux.

Parameters

<i>handle</i>	Pointer to device handle
<i>channel</i>	Input adc channel from mux

Returns

[ads1115_error_t](#) Error code

Definition at line 393 of file [ads1115.c](#).

4.5.3.16 ads1115_set_compare_alert()

```
ads1115_error_t ads1115_set_compare_alert (  
    ads1115_handle_t * handle,  
    ads1115_comp_polarity_t polarity)
```

Set the alert pin polatiry mode (ACTIVE_HIGH or ACTIVE_LOW)

Parameters

<i>handle</i>	Pointer to device handle
<i>polarity</i>	Alert pin polarity

Returns

[ads1115_error_t](#) Error code

Definition at line 549 of file [ads1115.c](#).

4.5.3.17 ads1115_set_compare_latch()

```
ads1115_error_t ads1115_set_compare_latch (  
    ads1115_handle_t * handle,  
    ads1115_comp_latch_t latch)
```

Set comparator latching mode.

Parameters

<i>handle</i>	Pointer to device handle
<i>latch</i>	Comparator latch

Returns

[ads1115_error_t](#) Error code

Definition at line 510 of file [ads1115.c](#).

4.5.3.18 ads1115_set_compare_mode()

```
ads1115_error_t ads1115_set_compare_mode (  
    ads1115_handle_t * handle,  
    ads1115_comp_mode_t compare)
```

Set comparator mode.

Parameters

<i>handle</i>	Pointer to device handle
<i>compare</i>	Interrupt compare mode

Returns

[ads1115_error_t](#) Error code

Definition at line 432 of file [ads1115.c](#).

4.5.3.19 ads1115_set_compare_queue()

```
ads1115_error_t ads1115_set_compare_queue (  
    ads1115_handle_t * handle,  
    ads1115_comp_queue_t comp_queue)
```

Set comparatore queue.

Parameters

<i>handle</i>	Pointer to device handle
<i>comp_queue</i>	Comparator queue

Returns

[ads1115_error_t](#) Error code

Definition at line 471 of file [ads1115.c](#).

4.5.3.20 ads1115_set_compare_threshold()

```
ads1115_error_t ads1115_set_compare_threshold (  
    ads1115_handle_t * handle,  
    int16_t low_threshold,  
    int16_t high_threshold)
```

Set the comparator low and high threshold.

Parameters

<i>handle</i>	Pointer to device handle
<i>low_threshold</i>	Compare low threshold
<i>high_threshold</i>	Compare high threshold

Returns

[ads1115_error_t](#) Error code

Definition at line 588 of file [ads1115.c](#).

4.5.3.21 ads1115_set_data_rate()

```
ads1115_error_t ads1115_set_data_rate (  
    ads1115_handle_t * handle,  
    ads1115_data_rate_t data_rate)
```

Set adc data sample rate.

Parameters

<i>handle</i>	Pointer to device handle
<i>data_rate</i>	Data rate setting

Returns

[ads1115_error_t](#) Error code

Definition at line 261 of file [ads1115.c](#).

4.5.3.22 ads1115_set_range()

```
ads1115_error_t ads1115_set_range (  
    ads1115_handle_t * handle,  
    ads1115_range_t range)
```

Set range of adc.

Parameters

<i>handle</i>	Pointer to device handle
<i>range</i>	Maximum voltage range

Returns

[ads1115_error_t](#) Error code

Definition at line 222 of file [ads1115.c](#).

4.5.3.23 [ads1115_single_read\(\)](#)

```
ads1115_error_t ads1115_single_read (
    ads1115_handle_t * handle,
    int16_t * adc_raw,
    float * voltage)
```

Read adc result once.

Parameters

<i>handle</i>	Pointer to device handle
<i>adc_raw</i>	Pointer to raw adc result
<i>voltage</i>	Pointer to converted adc result

Returns

[ads1115_error_t](#) Error code

Definition at line 347 of file [ads1115.c](#).

4.6 [ads1115.c](#)

[Go to the documentation of this file.](#)

```
00001
00007
00008 #include "ads1115.h"
00009 #include <stddef.h>
00010
00011 /*=====*/
00012 /* PRIVATE REGISTER DEFINITION */
00013 /*=====*/
00014
00018 #define ADS1115_REG_CONVERSION 0x00
00019 #define ADS1115_REG_CONFIG 0x01
00020 #define ADS1115_REG_LO_THRESH 0x02
00021 #define ADS1115_REG_HI_THRESH 0x03
00022
00023 /*=====*/
00024 /* PRIVATE BIT MASKS AND SHIFTS */
00025 /*=====*/
00026
00027 /* Operational Status (Bit 15) */
00028 #define ADS1115_OS_MASK 0x8000
00029 #define ADS1115_OS_SHIFT 15
00030 #define ADS1115_OS_IDLE 0x8000
```



```

00031 #define ADS1115_OS_START_SINGLE 0x8000
00032
00033 /* Input Multiplexer (Bits 14:12) */
00034 #define ADS1115_MUX_MASK 0x7000
00035 #define ADS1115_MUX_SHIFT 12
00036
00037 /* Programmable Gain (Bits 11:9) */
00038 #define ADS1115_PGA_MASK 0x0E00
00039 #define ADS1115_PGA_SHIFT 9
00040
00041 /* Operating Mode (Bit 8) */
00042 #define ADS1115_MODE_MASK 0x0100
00043 #define ADS1115_MODE_SHIFT 8
00044
00045 /* Data Rate (Bits 7:5) */
00046 #define ADS1115_DR_MASK 0x00E0
00047 #define ADS1115_DR_SHIFT 5
00048
00049 /* Comparator Mode (Bit 4) */
00050 #define ADS1115_COMP_MODE_MASK 0x0010
00051 #define ADS1115_COMP_MODE_SHIFT 4
00052
00053 /* Comparator Polarity (Bit 3) */
00054 #define ADS1115_COMP_POL_MASK 0x0008
00055 #define ADS1115_COMP_POL_SHIFT 3
00056
00057 /* Latching Comparator (Bit 2) */
00058 #define ADS1115_COMP_LAT_MASK 0x0004
00059 #define ADS1115_COMP_LAT_SHIFT 2
00060
00061 /* Comparator Queue (Bits 1:0) */
00062 #define ADS1115_COMP_QUE_MASK 0x0003
00063 #define ADS1115_COMP_QUE_SHIFT 0
00064
00065 /*=====*/
00066 /* PRIVATE CONSTANTS */
00067 /*=====*/
00068
00069 #define ADS1115_MAX_VALUE 32767
00070 #define ADS1115_MIN_VALUE -32768
00071
00072 /* Full Scale Range values in millivolts */
00073 static const uint16_t ADS1115_FSR_VALUES[] = {
00074     6144, /* ADS1115_RANGE_6_144V */
00075     4096, /* ADS1115_RANGE_4_096V */
00076     2048, /* ADS1115_RANGE_2_048V */
00077     1024, /* ADS1115_RANGE_1_024V */
00078     512, /* ADS1115_RANGE_0_512V */
00079     256, /* ADS1115_RANGE_0_256V */
00080 };
00081
00082 /* Conversion time in microseconds */
00083 static const uint32_t ADS1115_CONV_TIME_US[] = {
00084     125000, /* ADS1115_DR_8_SPS */
00085     62500, /* ADS1115_DR_16_SPS */
00086     31250, /* ADS1115_DR_32_SPS */
00087     15625, /* ADS1115_DR_64_SPS */
00088     7813, /* ADS1115_DR_128_SPS */
00089     4000, /* ADS1115_DR_250_SPS */
00090     2106, /* ADS1115_DR_475_SPS */
00091     1163, /* ADS1115_DR_860_SPS */
00092 };
00093
00094 /*=====*/
00095 /* PRIVATE FUNCTIONS */
00096 /*=====*/
00097
00098 static ads1115_error_t write_register(ads1115_handle_t *handle, uint8_t reg_addr, uint16_t value)
00099 {
00100     uint8_t data[2];
00101
00102     /* ADS1115 uses big-endian (MSB first) */
00103     data[0] = (uint8_t)((value >> 8) & 0xFF);
00104     data[1] = (uint8_t)(value & 0xFF);
00105
00106     if (!handle->i2c_write((uint8_t)handle->i2c_addr, reg_addr, data, 2))
00107     {
00108         return ADS1115_ERROR_I2C_WRITE;
00109     }
00110
00111     return ADS1115_OK;
00112 }
00113
00114 static ads1115_error_t read_register(ads1115_handle_t *handle, uint8_t reg_addr, uint16_t *value)
00115 {
00116     uint8_t data[2];
00117

```

```

00118     if (!handle->i2c_read((uint8_t)handle->i2c_addr, reg_addr, data, 2))
00119     {
00120         return ADS1115_ERROR_I2C_READ;
00121     }
00122
00123     /* ADS1115 uses big-endian (MSB first) */
00124     *value = ((uint16_t)data[0] << 8) | data[1];
00125
00126     return ADS1115_OK;
00127 }
00128
00129 static uint16_t build_config_register(const ads1115_config_t *config)
00130 {
00131     uint16_t reg_value = 0;
00132
00133     reg_value |= ((uint16_t)config->mux << ADS1115_MUX_SHIFT) & ADS1115_MUX_MASK;
00134     reg_value |= ((uint16_t)config->range << ADS1115_PGA_SHIFT) & ADS1115_PGA_MASK;
00135     reg_value |= ((uint16_t)config->mode << ADS1115_MODE_SHIFT) & ADS1115_MODE_MASK;
00136     reg_value |= ((uint16_t)config->data_rate << ADS1115_DR_SHIFT) & ADS1115_DR_MASK;
00137     reg_value |= ((uint16_t)config->comp_mode << ADS1115_COMP_MODE_SHIFT) & ADS1115_COMP_MODE_MASK;
00138     reg_value |= ((uint16_t)config->comp_pol << ADS1115_COMP_POL_SHIFT) & ADS1115_COMP_POL_MASK;
00139     reg_value |= ((uint16_t)config->comp_latch << ADS1115_COMP_LAT_SHIFT) & ADS1115_COMP_LAT_MASK;
00140     reg_value |= ((uint16_t)config->comp_queue << ADS1115_COMP_QUE_SHIFT) & ADS1115_COMP_QUE_MASK;
00141
00142     return reg_value;
00143 }
00144
00145 static ads1115_error_t update_config_register(ads1115_handle_t *handle)
00146 {
00147     uint16_t config_reg = build_config_register(&handle->config);
00148     return write_register(handle, ADS1115_REG_CONFIG, config_reg);
00149 }
00150
00151 static uint32_t get_conversion_time_us(ads1115_data_rate_t data_rate)
00152 {
00153     if (data_rate > ADS1115_DR_860_SPS)
00154     {
00155         return ADS1115_CONV_TIME_US[ADS1115_DR_128_SPS];
00156     }
00157     return ADS1115_CONV_TIME_US[data_rate];
00158 }
00159
00160 static float raw_to_voltage(ads1115_range_t range, int16_t raw_value)
00161 {
00162     if (range > ADS1115_RANGE_0V256)
00163     {
00164         range = ADS1115_RANGE_2V048;
00165     }
00166
00167     float fsr = (float)ADS1115_FSR_VALUES[range];
00168     return (raw_value * fsr) / 32768.0f;
00169 }
00170
00171 /*=====*/
00172 /* PUBLIC API IMPLEMENTATIONS */
00173 /*=====*/
00174
00175 ads1115_error_t ads1115_init(ads1115_handle_t *handle)
00176 {
00177     if (handle == NULL)
00178     {
00179         return ADS1115_ERROR_NULL_POINTER;
00180     }
00181
00182     if ((handle->i2c_read == NULL) || (handle->i2c_write == NULL) || (handle->delay_ms == NULL))
00183     {
00184         return ADS1115_ERROR_INVALID_PARAM;
00185     }
00186
00187     /* Write default configuration */
00188     ads1115_error_t err = update_config_register(handle);
00189     if (err != ADS1115_OK)
00190     {
00191         return err;
00192     }
00193
00194     /* Write default thresholds */
00195     err = write_register(handle, ADS1115_REG_LO_THRESH, (uint16_t)handle->config.low_threshold);
00196     if (err != ADS1115_OK)
00197     {
00198         return err;
00199     }
00200
00201     err = write_register(handle, ADS1115_REG_HI_THRESH, (uint16_t)handle->config.high_threshold);
00202     if (err != ADS1115_OK)
00203     {
00204         return err;

```

```

00205     }
00206
00207     handle->is_initialized = true;
00208     return ADS1115_OK;
00209 }
00210
00211 ads1115_error_t ads1115_deinit(ads1115_handle_t *handle)
00212 {
00213     if (handle == NULL)
00214     {
00215         return ADS1115_ERROR_NULL_POINTER;
00216     }
00217
00218     handle->is_initialized = false;
00219     return ADS1115_OK;
00220 }
00221
00222 ads1115_error_t ads1115_set_range(ads1115_handle_t *handle, ads1115_range_t range)
00223 {
00224     if (!handle->is_initialized)
00225     {
00226         return ADS1115_ERROR_NOT_INITIALIZED;
00227     }
00228
00229     if (range > ADS1115_RANGE_0V256)
00230     {
00231         return ADS1115_ERROR_INVALID_PARAM;
00232     }
00233
00234     handle->config.range = range;
00235     return update_config_register(handle);
00236 }
00237
00238 ads1115_error_t ads1115_get_range(ads1115_handle_t *handle, ads1115_range_t *range)
00239 {
00240     if (!handle->is_initialized)
00241     {
00242         return ADS1115_ERROR_NOT_INITIALIZED;
00243     }
00244
00245     if (range == NULL)
00246     {
00247         return ADS1115_ERROR_NULL_POINTER;
00248     }
00249
00250     uint16_t config_reg;
00251     ads1115_error_t err = read_register(handle, ADS1115_REG_CONFIG, &config_reg);
00252     if (err != ADS1115_OK)
00253     {
00254         return err;
00255     }
00256
00257     *range = (ads1115_range_t)((config_reg & ADS1115_PGA_MASK) » ADS1115_PGA_SHIFT);
00258     return ADS1115_OK;
00259 }
00260
00261 ads1115_error_t ads1115_set_data_rate(ads1115_handle_t *handle, ads1115_data_rate_t data_rate)
00262 {
00263     if (!handle->is_initialized)
00264     {
00265         return ADS1115_ERROR_NOT_INITIALIZED;
00266     }
00267
00268     if (data_rate > ADS1115_DR_860_SPS)
00269     {
00270         return ADS1115_ERROR_INVALID_PARAM;
00271     }
00272
00273     handle->config.data_rate = data_rate;
00274     return update_config_register(handle);
00275 }
00276
00277 ads1115_error_t ads1115_get_data_rate(ads1115_handle_t *handle, ads1115_data_rate_t *data_rate)
00278 {
00279     if (!handle->is_initialized)
00280     {
00281         return ADS1115_ERROR_NOT_INITIALIZED;
00282     }
00283
00284     if (data_rate == NULL)
00285     {
00286         return ADS1115_ERROR_NULL_POINTER;
00287     }
00288
00289     uint16_t config_reg;
00290     ads1115_error_t err = read_register(handle, ADS1115_REG_CONFIG, &config_reg);
00291     if (err != ADS1115_OK)

```

```

00292     {
00293         return err;
00294     }
00295
00296     *data_rate = (ads1115_data_rate_t)((config_reg & ADS1115_DR_MASK) » ADS1115_DR_SHIFT);
00297     return ADS1115_OK;
00298 }
00299
00300 ads1115_error_t ads1115_continuous_conversion_start(ads1115_handle_t *handle)
00301 {
00302     if (!handle->is_initialized)
00303     {
00304         return ADS1115_ERROR_NOT_INITIALIZED;
00305     }
00306
00307     handle->config.mode = ADS1115_MODE_CONTINUOUS;
00308     return update_config_register(handle);
00309 }
00310
00311 ads1115_error_t ads1115_continuous_conversion_stop(ads1115_handle_t *handle)
00312 {
00313     if (!handle->is_initialized)
00314     {
00315         return ADS1115_ERROR_NOT_INITIALIZED;
00316     }
00317
00318     handle->config.mode = ADS1115_MODE_SINGLE_SHOT;
00319     return update_config_register(handle);
00320 }
00321
00322 ads1115_error_t ads1115_continuous_conversion_read(ads1115_handle_t *handle, int16_t *adc_raw, float
00323 *voltage)
00324 {
00325     if (!handle->is_initialized)
00326     {
00327         return ADS1115_ERROR_NOT_INITIALIZED;
00328     }
00329
00330     if ((adc_raw == NULL) || (voltage == NULL))
00331     {
00332         return ADS1115_ERROR_NULL_POINTER;
00333     }
00334
00335     uint16_t raw_data;
00336     ads1115_error_t err = read_register(handle, ADS1115_REG_CONVERSION, &raw_data);
00337     if (err != ADS1115_OK)
00338     {
00339         return err;
00340     }
00341
00342     *adc_raw = (int16_t)raw_data;
00343     *voltage = raw_to_voltage(handle->config.range, *adc_raw);
00344
00345     return ADS1115_OK;
00346 }
00347 ads1115_error_t ads1115_single_read(ads1115_handle_t *handle, int16_t *adc_raw, float *voltage)
00348 {
00349     if (!handle->is_initialized)
00350     {
00351         return ADS1115_ERROR_NOT_INITIALIZED;
00352     }
00353
00354     if ((adc_raw == NULL) || (voltage == NULL))
00355     {
00356         return ADS1115_ERROR_NULL_POINTER;
00357     }
00358
00359     /* Read current config */
00360     uint16_t config_reg;
00361     ads1115_error_t err = read_register(handle, ADS1115_REG_CONFIG, &config_reg);
00362     if (err != ADS1115_OK)
00363     {
00364         return err;
00365     }
00366
00367     /* Start single conversion */
00368     config_reg |= ADS1115_OS_START_SINGLE;
00369     err = write_register(handle, ADS1115_REG_CONFIG, config_reg);
00370     if (err != ADS1115_OK)
00371     {
00372         return err;
00373     }
00374
00375     /* Wait for conversion */
00376     uint32_t conv_time_us = get_conversion_time_us(handle->config.data_rate);
00377     handle->delay_ms((conv_time_us / 1000) + 1);

```

```

00378
00379     /* Read conversion result */
00380     uint16_t raw_data;
00381     err = read_register(handle, ADS1115_REG_CONVERSION, &raw_data);
00382     if (err != ADS1115_OK)
00383     {
00384         return err;
00385     }
00386
00387     *adc_raw = (int16_t)raw_data;
00388     *voltage = raw_to_voltage(handle->config.range, *adc_raw);
00389
00390     return ADS1115_OK;
00391 }
00392
00393 ads1115_error_t ads1115_set_channel(ads1115_handle_t *handle, ads1115_mux_t channel)
00394 {
00395     if (!handle->is_initialized)
00396     {
00397         return ADS1115_ERROR_NOT_INITIALIZED;
00398     }
00399
00400     if (channel > ADS1115_MUX_AIN3_GND)
00401     {
00402         return ADS1115_ERROR_INVALID_PARAM;
00403     }
00404
00405     handle->config.mux = channel;
00406     return update_config_register(handle);
00407 }
00408
00409 ads1115_error_t ads1115_get_channel(ads1115_handle_t *handle, ads1115_mux_t *channel)
00410 {
00411     if (!handle->is_initialized)
00412     {
00413         return ADS1115_ERROR_NOT_INITIALIZED;
00414     }
00415
00416     if (channel == NULL)
00417     {
00418         return ADS1115_ERROR_NULL_POINTER;
00419     }
00420
00421     uint16_t config_reg;
00422     ads1115_error_t err = read_register(handle, ADS1115_REG_CONFIG, &config_reg);
00423     if (err != ADS1115_OK)
00424     {
00425         return err;
00426     }
00427
00428     *channel = (ads1115_mux_t)((config_reg & ADS1115_MUX_MASK) » ADS1115_MUX_SHIFT);
00429     return ADS1115_OK;
00430 }
00431
00432 ads1115_error_t ads1115_set_compare_mode(ads1115_handle_t *handle, ads1115_comp_mode_t compare)
00433 {
00434     if (!handle->is_initialized)
00435     {
00436         return ADS1115_ERROR_NOT_INITIALIZED;
00437     }
00438
00439     if (compare > ADS1115_COMP_MODE_WINDOW)
00440     {
00441         return ADS1115_ERROR_INVALID_PARAM;
00442     }
00443
00444     handle->config.comp_mode = compare;
00445     return update_config_register(handle);
00446 }
00447
00448 ads1115_error_t ads1115_get_compare_mode(ads1115_handle_t *handle, ads1115_comp_mode_t *compare)
00449 {
00450     if (!handle->is_initialized)
00451     {
00452         return ADS1115_ERROR_NOT_INITIALIZED;
00453     }
00454
00455     if (compare == NULL)
00456     {
00457         return ADS1115_ERROR_NULL_POINTER;
00458     }
00459
00460     uint16_t config_reg;
00461     ads1115_error_t err = read_register(handle, ADS1115_REG_CONFIG, &config_reg);
00462     if (err != ADS1115_OK)
00463     {
00464         return err;

```

```

00465     }
00466
00467     *compare = (ads1115_comp_mode_t)((config_reg & ADS1115_COMP_MODE_MASK) » ADS1115_COMP_MODE_SHIFT);
00468     return ADS1115_OK;
00469 }
00470
00471 ads1115_error_t ads1115_set_compare_queue(ads1115_handle_t *handle, ads1115_comp_queue_t comp_queue)
00472 {
00473     if (!handle->is_initialized)
00474     {
00475         return ADS1115_ERROR_NOT_INITIALIZED;
00476     }
00477
00478     if (comp_queue > ADS1115_COMP_QUE_DISABLE)
00479     {
00480         return ADS1115_ERROR_INVALID_PARAM;
00481     }
00482
00483     handle->config.comp_queue = comp_queue;
00484     return update_config_register(handle);
00485 }
00486
00487 ads1115_error_t ads1115_get_compare_queue(ads1115_handle_t *handle, ads1115_comp_queue_t *comp_queue)
00488 {
00489     if (!handle->is_initialized)
00490     {
00491         return ADS1115_ERROR_NOT_INITIALIZED;
00492     }
00493
00494     if (comp_queue == NULL)
00495     {
00496         return ADS1115_ERROR_NULL_POINTER;
00497     }
00498
00499     uint16_t config_reg;
00500     ads1115_error_t err = read_register(handle, ADS1115_REG_CONFIG, &config_reg);
00501     if (err != ADS1115_OK)
00502     {
00503         return err;
00504     }
00505
00506     *comp_queue = (ads1115_comp_queue_t)((config_reg & ADS1115_COMP_QUE_MASK) »
ADS1115_COMP_QUE_SHIFT);
00507     return ADS1115_OK;
00508 }
00509
00510 ads1115_error_t ads1115_set_compare_latch(ads1115_handle_t *handle, ads1115_comp_latch_t latch)
00511 {
00512     if (!handle->is_initialized)
00513     {
00514         return ADS1115_ERROR_NOT_INITIALIZED;
00515     }
00516
00517     if (latch > ADS1115_COMP_LAT_LATCHING)
00518     {
00519         return ADS1115_ERROR_INVALID_PARAM;
00520     }
00521
00522     handle->config.comp_latch = latch;
00523     return update_config_register(handle);
00524 }
00525
00526 ads1115_error_t ads1115_get_compare_latch(ads1115_handle_t *handle, ads1115_comp_latch_t *latch)
00527 {
00528     if (!handle->is_initialized)
00529     {
00530         return ADS1115_ERROR_NOT_INITIALIZED;
00531     }
00532
00533     if (latch == NULL)
00534     {
00535         return ADS1115_ERROR_NULL_POINTER;
00536     }
00537
00538     uint16_t config_reg;
00539     ads1115_error_t err = read_register(handle, ADS1115_REG_CONFIG, &config_reg);
00540     if (err != ADS1115_OK)
00541     {
00542         return err;
00543     }
00544
00545     *latch = (ads1115_comp_latch_t)((config_reg & ADS1115_COMP_LAT_MASK) » ADS1115_COMP_LAT_SHIFT);
00546     return ADS1115_OK;
00547 }
00548
00549 ads1115_error_t ads1115_set_compare_alert(ads1115_handle_t *handle, ads1115_comp_polarity_t polarity)
00550 {

```

```

00551     if (!handle->is_initialized)
00552     {
00553         return ADS1115_ERROR_NOT_INITIALIZED;
00554     }
00555
00556     if (polarity > ADS1115_COMP_POL_ACTIVE_HIGH)
00557     {
00558         return ADS1115_ERROR_INVALID_PARAM;
00559     }
00560
00561     handle->config.comp_pol = polarity;
00562     return update_config_register(handle);
00563 }
00564
00565 ads1115_error_t ads1115_get_compare_alert(ads1115_handle_t *handle, ads1115_comp_polarity_t *polarity)
00566 {
00567     if (!handle->is_initialized)
00568     {
00569         return ADS1115_ERROR_NOT_INITIALIZED;
00570     }
00571
00572     if (polarity == NULL)
00573     {
00574         return ADS1115_ERROR_NULL_POINTER;
00575     }
00576
00577     uint16_t config_reg;
00578     ads1115_error_t err = read_register(handle, ADS1115_REG_CONFIG, &config_reg);
00579     if (err != ADS1115_OK)
00580     {
00581         return err;
00582     }
00583
00584     *polarity = (ads1115_comp_polarity_t)((config_reg & ADS1115_COMP_POL_MASK) >>
ADS1115_COMP_POL_SHIFT);
00585     return ADS1115_OK;
00586 }
00587
00588 ads1115_error_t ads1115_set_compare_threshold(ads1115_handle_t *handle, int16_t low_threshold, int16_t
high_threshold)
00589 {
00590     if (!handle->is_initialized)
00591     {
00592         return ADS1115_ERROR_NOT_INITIALIZED;
00593     }
00594
00595     handle->config.low_threshold = low_threshold;
00596     handle->config.high_threshold = high_threshold;
00597
00598     ads1115_error_t err = write_register(handle, ADS1115_REG_LO_THRESH, (uint16_t)low_threshold);
00599     if (err != ADS1115_OK)
00600     {
00601         return err;
00602     }
00603
00604     return write_register(handle, ADS1115_REG_HI_THRESH, (uint16_t)high_threshold);
00605 }
00606
00607 ads1115_error_t ads1115_get_compare_threshold(ads1115_handle_t *handle, int16_t *low_threshold,
int16_t *high_threshold)
00608 {
00609     if (!handle->is_initialized)
00610     {
00611         return ADS1115_ERROR_NOT_INITIALIZED;
00612     }
00613
00614     if ((low_threshold == NULL) || (high_threshold == NULL))
00615     {
00616         return ADS1115_ERROR_NULL_POINTER;
00617     }
00618
00619     uint16_t low_reg, high_reg;
00620
00621     ads1115_error_t err = read_register(handle, ADS1115_REG_LO_THRESH, &low_reg);
00622     if (err != ADS1115_OK)
00623     {
00624         return err;
00625     }
00626
00627     err = read_register(handle, ADS1115_REG_HI_THRESH, &high_reg);
00628     if (err != ADS1115_OK)
00629     {
00630         return err;
00631     }
00632
00633     *low_threshold = (int16_t)low_reg;
00634     *high_threshold = (int16_t)high_reg;

```

```

00635
00636     return ADS1115_OK;
00637 }
00638
00639 ads1115_error_t ads1115_is_ready(ads1115_handle_t *handle, bool *flag)
00640 {
00641     if (!handle->is_initialized)
00642     {
00643         return ADS1115_ERROR_NOT_INITIALIZED;
00644     }
00645
00646     if (flag == NULL)
00647     {
00648         return ADS1115_ERROR_NULL_POINTER;
00649     }
00650
00651     uint16_t config_reg;
00652     ads1115_error_t err = read_register(handle, ADS1115_REG_CONFIG, &config_reg);
00653     if (err != ADS1115_OK)
00654     {
00655         return err;
00656     }
00657
00658     *flag = (config_reg & ADS1115_OS_MASK) ? true : false;
00659     return ADS1115_OK;
00660 }

```

4.7 src/ads1115.h File Reference

ADS1115 16-Bit ADC Driver - Platform Independent.

```

#include <stdint.h>
#include <stdbool.h>

```

Classes

- struct [ads1115_config_t](#)
ADS1115 configuration structure.
- struct [ads1115_handle_t](#)
ADS1115 device handle structure.

Macros

- #define [ADS1115_DEFAULT_CONFIGURATION](#)
Default configuration values at compile time.

Typedefs

- typedef bool(* [ads1115_i2c_write_t](#)) (uint8_t device_addr, uint8_t reg_addr, const uint8_t *data, uint8_t length)
I2C write callback function type.
- typedef bool(* [ads1115_i2c_read_t](#)) (uint8_t device_addr, uint8_t reg_addr, uint8_t *data, uint8_t length)
I2C read callback function type.
- typedef void(* [ads1115_delay_ms_t](#)) (uint32_t milliseconds)
Delay callback function type.

Enumerations

- enum `ads1115_error_t` {
`ADS1115_OK` = 0 , `ADS1115_ERROR_INVALID_PARAM` , `ADS1115_ERROR_I2C_WRITE` , `ADS1115_ERROR_I2C_READ`
, `ADS1115_ERROR_TIMEOUT` , `ADS1115_ERROR_NOT_INITIALIZED` , `ADS1115_ERROR_CONVERSION_BUSY`
, `ADS1115_ERROR_NULL_POINTER` }
Error codes for ADS1115 operations.
- enum `ads1115_i2c_addr_t` { `ADS1115_ADDR_GND` = 0x48 , `ADS1115_ADDR_VDD` = 0x49 ,
`ADS1115_ADDR_SDA` = 0x4A , `ADS1115_ADDR_SCL` = 0x4B }
I2C address selection based on ADDR pin connection.
- enum `ads1115_mux_t` {
`ADS1115_MUX_AIN0_AIN1` = 0 , `ADS1115_MUX_AIN0_AIN3` = 1 , `ADS1115_MUX_AIN1_AIN3` = 2 ,
`ADS1115_MUX_AIN2_AIN3` = 3 ,
`ADS1115_MUX_AIN0_GND` = 4 , `ADS1115_MUX_AIN1_GND` = 5 , `ADS1115_MUX_AIN2_GND` = 6 ,
`ADS1115_MUX_AIN3_GND` = 7 }
Input multiplexer configuration (channel selection)
- enum `ads1115_range_t` {
`ADS1115_RANGE_6V144` = 0 , `ADS1115_RANGE_4V096` = 1 , `ADS1115_RANGE_2V048` = 2 ,
`ADS1115_RANGE_1V024` = 3 ,
`ADS1115_RANGE_0V512` = 4 , `ADS1115_RANGE_0V256` = 5 }
Programmable gain amplifier configuration.
- enum `ads1115_mode_t` { `ADS1115_MODE_CONTINUOUS` = 0 , `ADS1115_MODE_SINGLE_SHOT` = 1 }
Device operating mode.
- enum `ads1115_data_rate_t` {
`ADS1115_DR_8_SPS` = 0 , `ADS1115_DR_16_SPS` = 1 , `ADS1115_DR_32_SPS` = 2 , `ADS1115_DR_64_SPS`
= 3 ,
`ADS1115_DR_128_SPS` = 4 , `ADS1115_DR_250_SPS` = 5 , `ADS1115_DR_475_SPS` = 6 , `ADS1115_DR_860_SPS`
= 7 }
Data rate (samples per second)
- enum `ads1115_comp_mode_t` { `ADS1115_COMP_MODE_TRADITIONAL` = 0 , `ADS1115_COMP_MODE_WINDOW`
= 1 }
Comparator mode.
- enum `ads1115_comp_polarity_t` { `ADS1115_COMP_POL_ACTIVE_LOW` = 0 , `ADS1115_COMP_POL_ACTIVE_HIGH`
= 1 }
Comparator polarity.
- enum `ads1115_comp_latch_t` { `ADS1115_COMP_LAT_NON_LATCHING` = 0 , `ADS1115_COMP_LAT_LATCHING`
= 1 }
Latching comparator.
- enum `ads1115_comp_queue_t` { `ADS1115_COMP_QUE_1_CONV` = 0 , `ADS1115_COMP_QUE_2_CONV`
= 1 , `ADS1115_COMP_QUE_4_CONV` = 2 , `ADS1115_COMP_QUE_DISABLE` = 3 }
Comparator queue and disable.

Functions

- `ads1115_error_t ads1115_init (ads1115_handle_t *handle)`
Initialize ADS1115 device.
- `ads1115_error_t ads1115_deinit (ads1115_handle_t *handle)`
De-initialize ADS1115 device.
- `ads1115_error_t ads1115_set_range (ads1115_handle_t *handle, ads1115_range_t range)`
Set range of adc.
- `ads1115_error_t ads1115_get_range (ads1115_handle_t *handle, ads1115_range_t *range)`
Get range of adc.

- [ads1115_error_t ads1115_set_data_rate](#) ([ads1115_handle_t](#) *handle, [ads1115_data_rate_t](#) data_rate)
Set adc data sample rate.
- [ads1115_error_t ads1115_get_data_rate](#) ([ads1115_handle_t](#) *handle, [ads1115_data_rate_t](#) *data_rate)
Get adc data sample rate.
- [ads1115_error_t ads1115_continuous_conversion_start](#) ([ads1115_handle_t](#) *handle)
Start adc continuous conversion mode.
- [ads1115_error_t ads1115_continuous_conversion_stop](#) ([ads1115_handle_t](#) *handle)
Stop adc continuous conversion mode.
- [ads1115_error_t ads1115_continuous_conversion_read](#) ([ads1115_handle_t](#) *handle, [int16_t](#) *adc_raw, float *voltage)
Read the result of adc continuously.
- [ads1115_error_t ads1115_single_read](#) ([ads1115_handle_t](#) *handle, [int16_t](#) *adc_raw, float *voltage)
Read adc result once.
- [ads1115_error_t ads1115_set_channel](#) ([ads1115_handle_t](#) *handle, [ads1115_mux_t](#) channel)
Set adc input channel from mux.
- [ads1115_error_t ads1115_get_channel](#) ([ads1115_handle_t](#) *handle, [ads1115_mux_t](#) *channel)
Set adc input channel from mux.
- [ads1115_error_t ads1115_set_compare_mode](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_mode_t](#) compare)
Set comparator mode.
- [ads1115_error_t ads1115_get_compare_mode](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_mode_t](#) *compare)
Get current comparator mode from device.
- [ads1115_error_t ads1115_set_compare_queue](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_queue_t](#) comp_queue)
Set comparatore queue.
- [ads1115_error_t ads1115_get_compare_queue](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_queue_t](#) *comp_queue)
Get comparatore queue.
- [ads1115_error_t ads1115_set_compare_alert](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_polarity_t](#) polarity)
Set the alert pin polatiry mode (ACTIVE_HIGH or ACTIVE_LOW)
- [ads1115_error_t ads1115_get_compare_alert](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_polarity_t](#) *polarity)
Get the alert pin polatiry (ACTIVE_HIGH or ACTIVE_LOW)
- [ads1115_error_t ads1115_set_compare_threshold](#) ([ads1115_handle_t](#) *handle, [int16_t](#) low_threshold, [int16_t](#) high_threshold)
Set the comparator low and high threshold.
- [ads1115_error_t ads1115_get_compare_threshold](#) ([ads1115_handle_t](#) *handle, [int16_t](#) *low_threshold, [int16_t](#) *high_threshold)
Get the comparator low and high threshold.
- [ads1115_error_t ads1115_set_compare_latch](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_latch_t](#) latch)
Set comparator latching mode.
- [ads1115_error_t ads1115_get_compare_latch](#) ([ads1115_handle_t](#) *handle, [ads1115_comp_latch_t](#) *latch)
Get comparator latching mode.
- [ads1115_error_t ads1115_is_ready](#) ([ads1115_handle_t](#) *handle, bool *flag)
Check if conversion is ready.

4.7.1 Detailed Description

ADS1115 16-Bit ADC Driver - Platform Independent.

Author

Şükrü Can Kılıç

Date

19.01.2026

Texas Instruments ADS1115 4-Channel 16-Bit ADC with I2C Interface Datasheet: <https://www.ti.com/lit/ds/symlink/ads1115.pdf>

Definition in file [ads1115.h](#).

4.7.2 Macro Definition Documentation

4.7.2.1 ADS1115_DEFAULT_CONFIGURATION

```
#define ADS1115_DEFAULT_CONFIGURATION
```

Value:

```
{
    .mux = ADS1115_MUX_AIN0_AIN1,
    .range = ADS1115_RANGE_2V048,
    .mode = ADS1115_MODE_SINGLE_SHOT,
    .data_rate = ADS1115_DR_128_SPS,
    .comp_mode = ADS1115_COMP_MODE_TRADITIONAL,
    .comp_pol = ADS1115_COMP_POL_ACTIVE_LOW,
    .comp_latch = ADS1115_COMP_LAT_NON_LATCHING,
    .comp_queue = ADS1115_COMP_QUEUE_DISABLE,
    .low_threshold = 0x8000,
    .high_threshold = 0x7FFF
}
```

Default configuration values at compile time.

These values match the ADS1115 power-up defaults as per datasheet. Users can modify these at runtime using setter functions.

Definition at line 207 of file [ads1115.h](#).

4.7.3 Typedef Documentation

4.7.3.1 ads1115_delay_ms_t

```
typedef void(* ads1115_delay_ms_t) (uint32_t milliseconds)
```

Delay callback function type.

Parameters

<i>milliseconds</i>	Delay duration in milliseconds
---------------------	--------------------------------

Definition at line 163 of file [ads1115.h](#).

4.7.3.2 ads1115_i2c_read_t

```
typedef bool(* ads1115_i2c_read_t) (uint8_t device_addr, uint8_t reg_addr, uint8_t *data,  
uint8_t length)
```

I2C read callback function type.

Parameters

<i>device_addr</i>	I2C device address (7-bit)
<i>reg_addr</i>	Register address to read from
<i>data</i>	Pointer to buffer to store read data
<i>length</i>	Number of bytes to read

Returns

true if read successful, false otherwise

Definition at line 156 of file [ads1115.h](#).

4.7.3.3 ads1115_i2c_write_t

```
typedef bool(* ads1115_i2c_write_t) (uint8_t device_addr, uint8_t reg_addr, const uint8_  
t *data, uint8_t length)
```

I2C write callback function type.

Parameters

<i>device_addr</i>	I2C device address (7-bit)
<i>reg_addr</i>	Register address to write to
<i>data</i>	Pointer to data buffer to write
<i>length</i>	Number of bytes to write

Returns

true if write successful, false otherwise

Definition at line 145 of file [ads1115.h](#).

4.7.4 Enumeration Type Documentation**4.7.4.1 ads1115_comp_latch_t**

```
enum ads1115\_comp\_latch\_t
```

Latching comparator.

Enumerator

ADS1115_COMP_LAT_NON_LATCHING	Nonlatching comparator - Default
ADS1115_COMP_LAT_LATCHING	Latching comparator

Definition at line 117 of file [ads1115.h](#).

4.7.4.2 ads1115_comp_mode_t

enum [ads1115_comp_mode_t](#)

Comperator mode.

Enumerator

ADS1115_COMP_MODE_TRADITIONAL	Traditional comparator
ADS1115_COMP_MODE_WINDOW	Window comparator

Definition at line 101 of file [ads1115.h](#).

4.7.4.3 ads1115_comp_polarity_t

enum [ads1115_comp_polarity_t](#)

Comparator polarity.

Enumerator

ADS1115_COMP_POL_ACTIVE_LOW	Active low - Default
ADS1115_COMP_POL_ACTIVE_HIGH	Active high

Definition at line 109 of file [ads1115.h](#).

4.7.4.4 ads1115_comp_queue_t

enum [ads1115_comp_queue_t](#)

Comparator queue and disable.

Enumerator

ADS1115_COMP_QUE_1_CONV	Assert after one conversion
ADS1115_COMP_QUE_2_CONV	Assert after two conversions
ADS1115_COMP_QUE_4_CONV	Assert after four conversions
ADS1115_COMP_QUE_DISABLE	Disable comparator and set ALERT/RDY pin to high-impedance - Default

Definition at line 125 of file [ads1115.h](#).

4.7.4.5 ads1115_data_rate_t

enum [ads1115_data_rate_t](#)

Data rate (samples per second)

Enumerator

ADS1115_DR_8_SPS	8 samples per second
ADS1115_DR_16_SPS	16 samples per second
ADS1115_DR_32_SPS	32 samples per second
ADS1115_DR_64_SPS	64 samples per second
ADS1115_DR_128_SPS	128 samples per second - Default
ADS1115_DR_250_SPS	250 samples per second
ADS1115_DR_475_SPS	475 samples per second
ADS1115_DR_860_SPS	860 samples per second

Definition at line 87 of file [ads1115.h](#).

4.7.4.6 ads1115_error_t

enum [ads1115_error_t](#)

Error codes for ADS1115 operations.

Enumerator

ADS1115_OK	Operation successful
ADS1115_ERROR_INVALID_PARAM	Invalid parameter passed
ADS1115_ERROR_I2C_WRITE	I2C write operation failed
ADS1115_ERROR_I2C_READ	I2C read operation failed
ADS1115_ERROR_TIMEOUT	Operation timeout
ADS1115_ERROR_NOT_INITIALIZED	Device not initialized
ADS1115_ERROR_CONVERSION_BUSY	Conversion in progress
ADS1115_ERROR_NULL_POINTER	Null pointer passed

Definition at line 29 of file [ads1115.h](#).

4.7.4.7 ads1115_i2c_addr_t

enum [ads1115_i2c_addr_t](#)

I2C address selection based on ADDR pin connection.

Enumerator

ADS1115_ADDR_GND	ADDR pin connected to GND
ADS1115_ADDR_VDD	ADDR pin connected to VDD
ADS1115_ADDR_SDA	ADDR pin connected to SDA
ADS1115_ADDR_SCL	ADDR pin connected to SCL

Definition at line 43 of file [ads1115.h](#).

4.7.4.8 ads1115_mode_t

enum [ads1115_mode_t](#)

Device operating mode.

Enumerator

ADS1115_MODE_CONTINUOUS	Continuous conversion mode
ADS1115_MODE_SINGLE_SHOT	Single-shot conversion mode

Definition at line 79 of file [ads1115.h](#).

4.7.4.9 ads1115_mux_t

enum [ads1115_mux_t](#)

Input multiplexer configuration (channel selection)

Enumerator

ADS1115_MUX_AIN0_AIN1	Differential: AIN0 - AIN1
ADS1115_MUX_AIN0_AIN3	Differential: AIN0 - AIN3
ADS1115_MUX_AIN1_AIN3	Differential: AIN1 - AIN3
ADS1115_MUX_AIN2_AIN3	Differential: AIN2 - AIN3
ADS1115_MUX_AIN0_GND	Single-ended: AIN0
ADS1115_MUX_AIN1_GND	Single-ended: AIN1
ADS1115_MUX_AIN2_GND	Single-ended: AIN2
ADS1115_MUX_AIN3_GND	Single-ended: AIN3

Definition at line 53 of file [ads1115.h](#).

4.7.4.10 ads1115_range_t

enum [ads1115_range_t](#)

Programmable gain amplifier configuration.

Enumerator

ADS1115_RANGE_6V144	+/- 6.144V range (FSR = 6.144V)
ADS1115_RANGE_4V096	+/- 4.096V range (FSR = 4.096V)
ADS1115_RANGE_2V048	+/- 2.048V range (FSR = 2.048V) - Default
ADS1115_RANGE_1V024	+/- 1.024V range (FSR = 1.024V)
ADS1115_RANGE_0V512	+/- 0.512V range (FSR = 0.512V)
ADS1115_RANGE_0V256	+/- 0.256V range (FSR = 0.256V)

Definition at line 67 of file [ads1115.h](#).

4.7.5 Function Documentation

4.7.5.1 ads1115_continuous_conversion_read()

```
ads1115_error_t ads1115_continuous_conversion_read (
    ads1115_handle_t * handle,
    int16_t * adc_raw,
    float * voltage)
```

Read the result of adc continuously.

Parameters

<i>handle</i>	Pointer to device handle
<i>adc_raw</i>	Pointer to raw adc result
<i>voltage</i>	Pointer to converted adc result

Returns

[ads1115_error_t](#) Error code

Definition at line 322 of file [ads1115.c](#).

4.7.5.2 ads1115_continuous_conversion_start()

```
ads1115_error_t ads1115_continuous_conversion_start (  
    ads1115_handle_t * handle)
```

Start adc continuous conversion mode.

Parameters

<i>handle</i>	Pointer to device handle
---------------	--------------------------

Returns

[ads1115_error_t](#) Error code

Definition at line 300 of file [ads1115.c](#).

4.7.5.3 ads1115_continuous_conversion_stop()

```
ads1115_error_t ads1115_continuous_conversion_stop (  
    ads1115_handle_t * handle)
```

Stop adc continuous conversion mode.

Parameters

<i>handle</i>	Pointer to device handle
---------------	--------------------------

Returns

[ads1115_error_t](#) Error code

Definition at line 311 of file [ads1115.c](#).

4.7.5.4 ads1115_deinit()

```
ads1115_error_t ads1115_deinit (  
    ads1115_handle_t * handle)
```

De-initialize ADS1115 device.

Parameters

<i>handle</i>	Pointer to device handle
---------------	--------------------------

Returns

[ads1115_error_t](#) Error code

Definition at line 211 of file [ads1115.c](#).

4.7.5.5 ads1115_get_channel()

```
ads1115_error_t ads1115_get_channel (  
    ads1115_handle_t * handle,  
    ads1115_mux_t * channel)
```

Set adc input channel from mux.

Parameters

<i>handle</i>	Pointer to device handle
<i>channel</i>	Pointer to input adc channel from mux

Returns

[ads1115_error_t](#) Error code

Definition at line 409 of file [ads1115.c](#).

4.7.5.6 ads1115_get_compare_alert()

```
ads1115_error_t ads1115_get_compare_alert (  
    ads1115_handle_t * handle,  
    ads1115_comp_polarity_t * polarity)
```

Get the alert pin polatiry (ACTIVE_HIGH or ACTIVE_LOW)

Parameters

<i>handle</i>	Pointer to device handle
<i>polarity</i>	Pointer to alert pin polarity

Returns

[ads1115_error_t](#) Error code

Definition at line 565 of file [ads1115.c](#).

4.7.5.7 ads1115_get_compare_latch()

```
ads1115_error_t ads1115_get_compare_latch (  
    ads1115_handle_t * handle,  
    ads1115_comp_latch_t * latch)
```

Get comparator latching mode.

Parameters

<i>handle</i>	Pointer to device handle
<i>latch</i>	Pointer to comparator latch

Returns

[ads1115_error_t](#) Error code

Definition at line 526 of file [ads1115.c](#).

4.7.5.8 ads1115_get_compare_mode()

```
ads1115_error_t ads1115_get_compare_mode (  
    ads1115_handle_t * handle,  
    ads1115_comp_mode_t * compare)
```

Get current comparator mode from device.

Parameters

<i>handle</i>	Pointer to device handle
<i>compare</i>	Pointer to interrupt compare mode

Returns

[ads1115_error_t](#) Error code

Definition at line 448 of file [ads1115.c](#).

4.7.5.9 ads1115_get_compare_queue()

```
ads1115_error_t ads1115_get_compare_queue (  
    ads1115_handle_t * handle,  
    ads1115_comp_queue_t * comp_queue)
```

Get comparatore queue.

Parameters

<i>handle</i>	Pointer to device handle
<i>comp_queue</i>	Pointer to comparator queue

Returns

[ads1115_error_t](#) Error code

Definition at line 487 of file [ads1115.c](#).

4.7.5.10 ads1115_get_compare_threshold()

```
ads1115_error_t ads1115_get_compare_threshold (  
    ads1115_handle_t * handle,  
    int16_t * low_threshold,  
    int16_t * high_threshold)
```

Get the comparator low and high threshold.

Parameters

<i>handle</i>	Pointer to device handle
<i>low_threshold</i>	Pointer to compare low threshold
<i>high_threshold</i>	Pointer to compare high threshold

Returns

[ads1115_error_t](#) Error code

Definition at line 607 of file [ads1115.c](#).

4.7.5.11 ads1115_get_data_rate()

```
ads1115_error_t ads1115_get_data_rate (  
    ads1115_handle_t * handle,  
    ads1115_data_rate_t * data_rate)
```

Get adc data sample rate.

Parameters

<i>handle</i>	Pointer to device handle
<i>data_rate</i>	Data rate setting

Returns

[ads1115_error_t](#) Error code

Definition at line 277 of file [ads1115.c](#).

4.7.5.12 ads1115_get_range()

```
ads1115_error_t ads1115_get_range (  
    ads1115_handle_t * handle,  
    ads1115_range_t * range)
```

Get range of adc.

Parameters

<i>handle</i>	Pointer to device handle
<i>range</i>	Maximum voltage range

Returns

[ads1115_error_t](#) Error code

Definition at line 238 of file [ads1115.c](#).

4.7.5.13 ads1115_init()

```
ads1115_error_t ads1115_init (  
    ads1115_handle_t * handle)
```

Initialize ADS1115 device.

Parameters

<i>handle</i>	Pointer to device handle
---------------	--------------------------

Returns

[ads1115_error_t](#) Error code

Definition at line 175 of file [ads1115.c](#).

4.7.5.14 [ads1115_is_ready\(\)](#)

```
ads1115_error_t ads1115_is_ready (  
    ads1115_handle_t * handle,  
    bool * flag)
```

Check if conversion is ready.

Parameters

<i>handle</i>	Pointer to device handle
<i>flag</i>	Pointer to store flag status

Returns

[ads1115_error_t](#) Error code

Definition at line 639 of file [ads1115.c](#).

4.7.5.15 [ads1115_set_channel\(\)](#)

```
ads1115_error_t ads1115_set_channel (  
    ads1115_handle_t * handle,  
    ads1115_mux_t channel)
```

Set adc input channel from mux.

Parameters

<i>handle</i>	Pointer to device handle
<i>channel</i>	Input adc channel from mux

Returns

[ads1115_error_t](#) Error code

Definition at line 393 of file [ads1115.c](#).

4.7.5.16 [ads1115_set_compare_alert\(\)](#)

```
ads1115_error_t ads1115_set_compare_alert (  
    ads1115_handle_t * handle,  
    ads1115_comp_polarity_t polarity)
```

Set the alert pin polatiry mode (ACTIVE_HIGH or ACTIVE_LOW)

Parameters

<i>handle</i>	Pointer to device handle
<i>polarity</i>	Alert pin polarity

Returns

[ads1115_error_t](#) Error code

Definition at line 549 of file [ads1115.c](#).

4.7.5.17 ads1115_set_compare_latch()

```
ads1115_error_t ads1115_set_compare_latch (  
    ads1115_handle_t * handle,  
    ads1115_comp_latch_t latch)
```

Set comparator latching mode.

Parameters

<i>handle</i>	Pointer to device handle
<i>latch</i>	Comparator latch

Returns

[ads1115_error_t](#) Error code

Definition at line 510 of file [ads1115.c](#).

4.7.5.18 ads1115_set_compare_mode()

```
ads1115_error_t ads1115_set_compare_mode (  
    ads1115_handle_t * handle,  
    ads1115_comp_mode_t compare)
```

Set comparator mode.

Parameters

<i>handle</i>	Pointer to device handle
<i>compare</i>	Interrupt compare mode

Returns

[ads1115_error_t](#) Error code

Definition at line 432 of file [ads1115.c](#).

4.7.5.19 ads1115_set_compare_queue()

```
ads1115_error_t ads1115_set_compare_queue (  
    ads1115_handle_t * handle,  
    ads1115_comp_queue_t comp_queue)
```

Set comparatore queue.

Parameters

<i>handle</i>	Pointer to device handle
<i>comp_queue</i>	Comparator queue

Returns

[ads1115_error_t](#) Error code

Definition at line 471 of file [ads1115.c](#).

4.7.5.20 ads1115_set_compare_threshold()

```
ads1115_error_t ads1115_set_compare_threshold (
    ads1115_handle_t * handle,
    int16_t low_threshold,
    int16_t high_threshold)
```

Set the comparator low and high threshold.

Parameters

<i>handle</i>	Pointer to device handle
<i>low_threshold</i>	Compare low threshold
<i>high_threshold</i>	Compare high threshold

Returns

[ads1115_error_t](#) Error code

Definition at line 588 of file [ads1115.c](#).

4.7.5.21 ads1115_set_data_rate()

```
ads1115_error_t ads1115_set_data_rate (
    ads1115_handle_t * handle,
    ads1115_data_rate_t data_rate)
```

Set adc data sample rate.

Parameters

<i>handle</i>	Pointer to device handle
<i>data_rate</i>	Data rate setting

Returns

[ads1115_error_t](#) Error code

Definition at line 261 of file [ads1115.c](#).

4.7.5.22 ads1115_set_range()

```
ads1115_error_t ads1115_set_range (
    ads1115_handle_t * handle,
    ads1115_range_t range)
```

Set range of adc.

Parameters

<i>handle</i>	Pointer to device handle
<i>range</i>	Maximum voltage range

Returns

[ads1115_error_t](#) Error code

Definition at line 222 of file [ads1115.c](#).

4.7.5.23 ads1115_single_read()

```
ads1115_error_t ads1115_single_read (
    ads1115_handle_t * handle,
    int16_t * adc_raw,
    float * voltage)
```

Read adc result once.

Parameters

<i>handle</i>	Pointer to device handle
<i>adc_raw</i>	Pointer to raw adc result
<i>voltage</i>	Pointer to converted adc result

Returns

[ads1115_error_t](#) Error code

Definition at line 347 of file [ads1115.c](#).

4.8 ads1115.h

[Go to the documentation of this file.](#)

```
00001
00010
00011 #ifndef ADS1115_H
00012 #define ADS1115_H
00013
00014 #ifdef __cplusplus
00015 extern "C"
00016 {
00017 #endif
00018
00019 #include <stdint.h>
00020 #include <stdbool.h>
00021
00022 /*=====*/
00023 /* TYPE DEFINITIONS */
00024 /*=====*/
00025
00029 typedef enum {
00030     ADS1115_OK = 0,
00031     ADS1115_ERROR_INVALID_PARAM,
00032     ADS1115_ERROR_I2C_WRITE,
00033     ADS1115_ERROR_I2C_READ,
```

```

00034     ADS1115_ERROR_TIMEOUT,
00035     ADS1115_ERROR_NOT_INITIALIZED,
00036     ADS1115_ERROR_CONVERSION_BUSY,
00037     ADS1115_ERROR_NULL_POINTER
00038 } ads1115_error_t;
00039
00043 typedef enum {
00044     ADS1115_ADDR_GND = 0x48,
00045     ADS1115_ADDR_VDD = 0x49,
00046     ADS1115_ADDR_SDA = 0x4A,
00047     ADS1115_ADDR_SCL = 0x4B,
00048 } ads1115_i2c_addr_t;
00049
00053 typedef enum {
00054     ADS1115_MUX_AIN0_AIN1 = 0,
00055     ADS1115_MUX_AIN0_AIN3 = 1,
00056     ADS1115_MUX_AIN1_AIN3 = 2,
00057     ADS1115_MUX_AIN2_AIN3 = 3,
00058     ADS1115_MUX_AIN0_GND = 4,
00059     ADS1115_MUX_AIN1_GND = 5,
00060     ADS1115_MUX_AIN2_GND = 6,
00061     ADS1115_MUX_AIN3_GND = 7,
00062 } ads1115_mux_t;
00063
00067 typedef enum {
00068     ADS1115_RANGE_6V144 = 0,
00069     ADS1115_RANGE_4V096 = 1,
00070     ADS1115_RANGE_2V048 = 2,
00071     ADS1115_RANGE_1V024 = 3,
00072     ADS1115_RANGE_0V512 = 4,
00073     ADS1115_RANGE_0V256 = 5,
00074 } ads1115_range_t;
00075
00079 typedef enum {
00080     ADS1115_MODE_CONTINUOUS = 0,
00081     ADS1115_MODE_SINGLE_SHOT = 1,
00082 } ads1115_mode_t;
00083
00087 typedef enum {
00088     ADS1115_DR_8_SPS = 0,
00089     ADS1115_DR_16_SPS = 1,
00090     ADS1115_DR_32_SPS = 2,
00091     ADS1115_DR_64_SPS = 3,
00092     ADS1115_DR_128_SPS = 4,
00093     ADS1115_DR_250_SPS = 5,
00094     ADS1115_DR_475_SPS = 6,
00095     ADS1115_DR_860_SPS = 7,
00096 } ads1115_data_rate_t;
00097
00101 typedef enum {
00102     ADS1115_COMP_MODE_TRADITIONAL = 0,
00103     ADS1115_COMP_MODE_WINDOW = 1,
00104 } ads1115_comp_mode_t;
00105
00109 typedef enum {
00110     ADS1115_COMP_POL_ACTIVE_LOW = 0,
00111     ADS1115_COMP_POL_ACTIVE_HIGH = 1,
00112 } ads1115_comp_polarity_t;
00113
00117 typedef enum {
00118     ADS1115_COMP_LAT_NON_LATCHING = 0,
00119     ADS1115_COMP_LAT_LATCHING = 1,
00120 } ads1115_comp_latch_t;
00121
00125 typedef enum {
00126     ADS1115_COMP_QUE_1_CONV = 0,
00127     ADS1115_COMP_QUE_2_CONV = 1,
00128     ADS1115_COMP_QUE_4_CONV = 2,
00129     ADS1115_COMP_QUE_DISABLE = 3,
00130 } ads1115_comp_queue_t;
00131
00132 /*=====*/
00133 /* CALLBACK FUNCTION TYPES */
00134 /*=====*/
00135
00145 typedef bool (*ads1115_i2c_write_t)(uint8_t device_addr, uint8_t reg_addr, const uint8_t *data,
uint8_t length);
00146
00156 typedef bool (*ads1115_i2c_read_t)(uint8_t device_addr, uint8_t reg_addr, uint8_t *data, uint8_t
length);
00157
00163 typedef void (*ads1115_delay_ms_t)(uint32_t milliseconds);
00164
00165 /*=====*/
00166 /* CONFIGURATION STRUCTURES */
00167 /*=====*/
00168

```



```

00172 typedef struct {
00173     ads1115_mux_t mux;
00174     ads1115_range_t range;
00175     ads1115_mode_t mode;
00176     ads1115_data_rate_t data_rate;
00177     ads1115_comp_mode_t comp_mode;
00178     ads1115_comp_polarity_t comp_pol;
00179     ads1115_comp_latch_t comp_latch;
00180     ads1115_comp_queue_t comp_queue;
00181     int16_t low_threshold;
00182     int16_t high_threshold;
00183 } ads1115_config_t;
00184
00188 typedef struct {
00189     ads1115_i2c_addr_t i2c_addr;
00190     ads1115_config_t config;
00191     ads1115_i2c_write_t i2c_write;
00192     ads1115_i2c_read_t i2c_read;
00193     ads1115_delay_ms_t delay_ms;
00194     bool is_initialized;
00195 } ads1115_handle_t;
00196
00197 /*=====*/
00198 /* DEFAULT CONFIGURATION */
00199 /*=====*/
00200
00207 #define ADS1115_DEFAULT_CONFIGURATION { \
00208     .mux = ADS1115_MUX_AIN0_AIN1, \
00209     .range = ADS1115_RANGE_2V048, \
00210     .mode = ADS1115_MODE_SINGLE_SHOT, \
00211     .data_rate = ADS1115_DR_128_SPS, \
00212     .comp_mode = ADS1115_COMP_MODE_TRADITIONAL, \
00213     .comp_pol = ADS1115_COMP_POL_ACTIVE_LOW, \
00214     .comp_latch = ADS1115_COMP_LAT_NON_LATCHING, \
00215     .comp_queue = ADS1115_COMP_QUE_DISABLE, \
00216     .low_threshold = 0x8000, \
00217     .high_threshold = 0x7FFF \
00218 }
00219
00220 /*=====*/
00221 /* PUBLIC API FUNCTIONS */
00222 /*=====*/
00223
00230 ads1115_error_t ads1115_init(ads1115_handle_t *handle);
00231
00238 ads1115_error_t ads1115_deinit(ads1115_handle_t *handle);
00239
00247 ads1115_error_t ads1115_set_range(ads1115_handle_t *handle, ads1115_range_t range);
00248
00256 ads1115_error_t ads1115_get_range(ads1115_handle_t *handle, ads1115_range_t *range);
00257
00265 ads1115_error_t ads1115_set_data_rate(ads1115_handle_t *handle, ads1115_data_rate_t data_rate);
00266
00274 ads1115_error_t ads1115_get_data_rate(ads1115_handle_t *handle, ads1115_data_rate_t *data_rate);
00275
00282 ads1115_error_t ads1115_continuous_conversion_start(ads1115_handle_t *handle);
00283
00290 ads1115_error_t ads1115_continuous_conversion_stop(ads1115_handle_t *handle);
00291
00300 ads1115_error_t ads1115_continuous_conversion_read(ads1115_handle_t *handle, int16_t *adc_raw, float
    *voltage);
00301
00310 ads1115_error_t ads1115_single_read(ads1115_handle_t *handle, int16_t *adc_raw, float *voltage);
00311
00319 ads1115_error_t ads1115_set_channel(ads1115_handle_t *handle, ads1115_mux_t channel);
00320
00328 ads1115_error_t ads1115_get_channel(ads1115_handle_t *handle, ads1115_mux_t *channel);
00329
00337 ads1115_error_t ads1115_set_compare_mode(ads1115_handle_t *handle, ads1115_comp_mode_t compare);
00338
00346 ads1115_error_t ads1115_get_compare_mode(ads1115_handle_t *handle, ads1115_comp_mode_t *compare);
00347
00355 ads1115_error_t ads1115_set_compare_queue(ads1115_handle_t *handle, ads1115_comp_queue_t comp_queue);
00356
00364 ads1115_error_t ads1115_get_compare_queue(ads1115_handle_t *handle, ads1115_comp_queue_t *comp_queue);
00365
00373 ads1115_error_t ads1115_set_compare_alert(ads1115_handle_t *handle, ads1115_comp_polarity_t polarity);
00374
00382 ads1115_error_t ads1115_get_compare_alert(ads1115_handle_t *handle, ads1115_comp_polarity_t
    *polarity);
00383
00392 ads1115_error_t ads1115_set_compare_threshold(ads1115_handle_t *handle, int16_t low_threshold, int16_t
    high_threshold);
00393
00402 ads1115_error_t ads1115_get_compare_threshold(ads1115_handle_t *handle, int16_t *low_threshold,
    int16_t *high_threshold);
00403

```

```
00411 ads1115_error_t ads1115_set_compare_latch(ads1115_handle_t *handle, ads1115_comp_latch_t latch);
00412
00420 ads1115_error_t ads1115_get_compare_latch(ads1115_handle_t *handle, ads1115_comp_latch_t *latch);
00421
00429 ads1115_error_t ads1115_is_ready(ads1115_handle_t *handle, bool *flag);
00430
00431 #ifdef __cplusplus
00432 }
00433 #endif
00434
00435 #endif /* ADS1115_H*/
```

Index

ads1115.c

ADS1115_COMP_LAT_MASK, [15](#)
ADS1115_COMP_LAT_SHIFT, [15](#)
ADS1115_COMP_MODE_MASK, [15](#)
ADS1115_COMP_MODE_SHIFT, [15](#)
ADS1115_COMP_POL_MASK, [15](#)
ADS1115_COMP_POL_SHIFT, [16](#)
ADS1115_COMP_QUE_MASK, [16](#)
ADS1115_COMP_QUE_SHIFT, [16](#)
ads1115_continuous_conversion_read, [18](#)
ads1115_continuous_conversion_start, [19](#)
ads1115_continuous_conversion_stop, [19](#)
ads1115_deinit, [19](#)
ADS1115_DR_MASK, [16](#)
ADS1115_DR_SHIFT, [16](#)
ads1115_get_channel, [20](#)
ads1115_get_compare_alert, [20](#)
ads1115_get_compare_latch, [20](#)
ads1115_get_compare_mode, [21](#)
ads1115_get_compare_queue, [21](#)
ads1115_get_compare_threshold, [21](#)
ads1115_get_data_rate, [22](#)
ads1115_get_range, [22](#)
ads1115_init, [22](#)
ads1115_is_ready, [23](#)
ADS1115_MAX_VALUE, [16](#)
ADS1115_MIN_VALUE, [16](#)
ADS1115_MODE_MASK, [16](#)
ADS1115_MODE_SHIFT, [17](#)
ADS1115_MUX_MASK, [17](#)
ADS1115_MUX_SHIFT, [17](#)
ADS1115_OS_IDLE, [17](#)
ADS1115_OS_MASK, [17](#)
ADS1115_OS_SHIFT, [17](#)
ADS1115_OS_START_SINGLE, [17](#)
ADS1115_PGA_MASK, [17](#)
ADS1115_PGA_SHIFT, [18](#)
ADS1115_REG_CONFIG, [18](#)
ADS1115_REG_CONVERSION, [18](#)
ADS1115_REG_HI_THRESH, [18](#)
ADS1115_REG_LO_THRESH, [18](#)
ads1115_set_channel, [23](#)
ads1115_set_compare_alert, [23](#)
ads1115_set_compare_latch, [24](#)
ads1115_set_compare_mode, [24](#)
ads1115_set_compare_queue, [24](#)
ads1115_set_compare_threshold, [25](#)
ads1115_set_data_rate, [25](#)
ads1115_set_range, [25](#)

ads1115_single_read, [26](#)

ads1115.h

ADS1115_ADDR_GND, [40](#)
ADS1115_ADDR_SCL, [40](#)
ADS1115_ADDR_SDA, [40](#)
ADS1115_ADDR_VDD, [40](#)
ADS1115_COMP_LAT_LATCHING, [39](#)
ADS1115_COMP_LAT_NON_LATCHING, [39](#)
ads1115_comp_latch_t, [38](#)
ads1115_comp_mode_t, [39](#)
ADS1115_COMP_MODE_TRADITIONAL, [39](#)
ADS1115_COMP_MODE_WINDOW, [39](#)
ADS1115_COMP_POL_ACTIVE_HIGH, [39](#)
ADS1115_COMP_POL_ACTIVE_LOW, [39](#)
ads1115_comp_polarity_t, [39](#)
ADS1115_COMP_QUE_1_CONV, [39](#)
ADS1115_COMP_QUE_2_CONV, [39](#)
ADS1115_COMP_QUE_4_CONV, [39](#)
ADS1115_COMP_QUE_DISABLE, [39](#)
ads1115_comp_queue_t, [39](#)
ads1115_continuous_conversion_read, [41](#)
ads1115_continuous_conversion_start, [42](#)
ads1115_continuous_conversion_stop, [42](#)
ads1115_data_rate_t, [39](#)
ADS1115_DEFAULT_CONFIGURATION, [37](#)
ads1115_deinit, [42](#)
ads1115_delay_ms_t, [37](#)
ADS1115_DR_128_SPS, [40](#)
ADS1115_DR_16_SPS, [40](#)
ADS1115_DR_250_SPS, [40](#)
ADS1115_DR_32_SPS, [40](#)
ADS1115_DR_475_SPS, [40](#)
ADS1115_DR_64_SPS, [40](#)
ADS1115_DR_860_SPS, [40](#)
ADS1115_DR_8_SPS, [40](#)
ADS1115_ERROR_CONVERSION_BUSY, [40](#)
ADS1115_ERROR_I2C_READ, [40](#)
ADS1115_ERROR_I2C_WRITE, [40](#)
ADS1115_ERROR_INVALID_PARAM, [40](#)
ADS1115_ERROR_NOT_INITIALIZED, [40](#)
ADS1115_ERROR_NULL_POINTER, [40](#)
ads1115_error_t, [40](#)
ADS1115_ERROR_TIMEOUT, [40](#)
ads1115_get_channel, [43](#)
ads1115_get_compare_alert, [43](#)
ads1115_get_compare_latch, [43](#)
ads1115_get_compare_mode, [44](#)
ads1115_get_compare_queue, [44](#)
ads1115_get_compare_threshold, [44](#)

- ads1115_get_data_rate, 45
- ads1115_get_range, 45
- ads1115_i2c_addr_t, 40
- ads1115_i2c_read_t, 38
- ads1115_i2c_write_t, 38
- ads1115_init, 45
- ads1115_is_ready, 46
- ADS1115_MODE_CONTINUOUS, 41
- ADS1115_MODE_SINGLE_SHOT, 41
- ads1115_mode_t, 40
- ADS1115_MUX_AIN0_AIN1, 41
- ADS1115_MUX_AIN0_AIN3, 41
- ADS1115_MUX_AIN0_GND, 41
- ADS1115_MUX_AIN1_AIN3, 41
- ADS1115_MUX_AIN1_GND, 41
- ADS1115_MUX_AIN2_AIN3, 41
- ADS1115_MUX_AIN2_GND, 41
- ADS1115_MUX_AIN3_GND, 41
- ads1115_mux_t, 41
- ADS1115_OK, 40
- ADS1115_RANGE_0V256, 41
- ADS1115_RANGE_0V512, 41
- ADS1115_RANGE_1V024, 41
- ADS1115_RANGE_2V048, 41
- ADS1115_RANGE_4V096, 41
- ADS1115_RANGE_6V144, 41
- ads1115_range_t, 41
- ads1115_set_channel, 46
- ads1115_set_compare_alert, 46
- ads1115_set_compare_latch, 47
- ads1115_set_compare_mode, 47
- ads1115_set_compare_queue, 47
- ads1115_set_compare_threshold, 48
- ads1115_set_data_rate, 48
- ads1115_set_range, 48
- ads1115_single_read, 49
- ADS1115_ADDR_GND
 - ads1115.h, 40
- ADS1115_ADDR_SCL
 - ads1115.h, 40
- ADS1115_ADDR_SDA
 - ads1115.h, 40
- ADS1115_ADDR_VDD
 - ads1115.h, 40
- ADS1115_COMP_LAT_LATCHING
 - ads1115.h, 39
- ADS1115_COMP_LAT_MASK
 - ads1115.c, 15
- ADS1115_COMP_LAT_NON_LATCHING
 - ads1115.h, 39
- ADS1115_COMP_LAT_SHIFT
 - ads1115.c, 15
- ads1115_comp_latch_t
 - ads1115.h, 38
- ADS1115_COMP_MODE_MASK
 - ads1115.c, 15
- ADS1115_COMP_MODE_SHIFT
 - ads1115.c, 15
- ads1115_comp_mode_t
 - ads1115.h, 39
- ADS1115_COMP_MODE_TRADITIONAL
 - ads1115.h, 39
- ADS1115_COMP_MODE_WINDOW
 - ads1115.h, 39
- ADS1115_COMP_POL_ACTIVE_HIGH
 - ads1115.h, 39
- ADS1115_COMP_POL_ACTIVE_LOW
 - ads1115.h, 39
- ADS1115_COMP_POL_MASK
 - ads1115.c, 15
- ADS1115_COMP_POL_SHIFT
 - ads1115.c, 16
- ads1115_comp_polarity_t
 - ads1115.h, 39
- ADS1115_COMP_QUE_1_CONV
 - ads1115.h, 39
- ADS1115_COMP_QUE_2_CONV
 - ads1115.h, 39
- ADS1115_COMP_QUE_4_CONV
 - ads1115.h, 39
- ADS1115_COMP_QUE_DISABLE
 - ads1115.h, 39
- ADS1115_COMP_QUE_MASK
 - ads1115.c, 16
- ADS1115_COMP_QUE_SHIFT
 - ads1115.c, 16
- ads1115_comp_queue_t
 - ads1115.h, 39
- ads1115_config_t, 5
 - comp_latch, 5
 - comp_mode, 5
 - comp_pol, 6
 - comp_queue, 6
 - data_rate, 6
 - high_threshold, 6
 - low_threshold, 6
 - mode, 6
 - mux, 7
 - range, 7
- ads1115_continuous_conversion_read
 - ads1115.c, 18
 - ads1115.h, 41
- ads1115_continuous_conversion_start
 - ads1115.c, 19
 - ads1115.h, 42
- ads1115_continuous_conversion_stop
 - ads1115.c, 19
 - ads1115.h, 42
- ads1115_data_rate_t
 - ads1115.h, 39
- ADS1115_DEFAULT_CONFIGURATION
 - ads1115.h, 37
- ads1115_deinit
 - ads1115.c, 19
 - ads1115.h, 42
- ads1115_delay_ms

- ads1115_interface.c, [9](#)
- ads1115_interface.h, [11](#)
- ads1115_delay_ms_t
 - ads1115.h, [37](#)
- ADS1115_DR_128_SPS
 - ads1115.h, [40](#)
- ADS1115_DR_16_SPS
 - ads1115.h, [40](#)
- ADS1115_DR_250_SPS
 - ads1115.h, [40](#)
- ADS1115_DR_32_SPS
 - ads1115.h, [40](#)
- ADS1115_DR_475_SPS
 - ads1115.h, [40](#)
- ADS1115_DR_64_SPS
 - ads1115.h, [40](#)
- ADS1115_DR_860_SPS
 - ads1115.h, [40](#)
- ADS1115_DR_8_SPS
 - ads1115.h, [40](#)
- ADS1115_DR_MASK
 - ads1115.c, [16](#)
- ADS1115_DR_SHIFT
 - ads1115.c, [16](#)
- ADS1115_ERROR_CONVERSION_BUSY
 - ads1115.h, [40](#)
- ADS1115_ERROR_I2C_READ
 - ads1115.h, [40](#)
- ADS1115_ERROR_I2C_WRITE
 - ads1115.h, [40](#)
- ADS1115_ERROR_INVALID_PARAM
 - ads1115.h, [40](#)
- ADS1115_ERROR_NOT_INITIALIZED
 - ads1115.h, [40](#)
- ADS1115_ERROR_NULL_POINTER
 - ads1115.h, [40](#)
- ads1115_error_t
 - ads1115.h, [40](#)
- ADS1115_ERROR_TIMEOUT
 - ads1115.h, [40](#)
- ads1115_get_channel
 - ads1115.c, [20](#)
 - ads1115.h, [43](#)
- ads1115_get_compare_alert
 - ads1115.c, [20](#)
 - ads1115.h, [43](#)
- ads1115_get_compare_latch
 - ads1115.c, [20](#)
 - ads1115.h, [43](#)
- ads1115_get_compare_mode
 - ads1115.c, [21](#)
 - ads1115.h, [44](#)
- ads1115_get_compare_queue
 - ads1115.c, [21](#)
 - ads1115.h, [44](#)
- ads1115_get_compare_threshold
 - ads1115.c, [21](#)
 - ads1115.h, [44](#)
- ads1115_get_data_rate
 - ads1115.c, [22](#)
 - ads1115.h, [45](#)
- ads1115_get_range
 - ads1115.c, [22](#)
 - ads1115.h, [45](#)
- ads1115_handle_t, [7](#)
 - config, [8](#)
 - delay_ms, [8](#)
 - i2c_addr, [8](#)
 - i2c_read, [8](#)
 - i2c_write, [8](#)
 - is_initialized, [8](#)
- ads1115_i2c_addr_t
 - ads1115.h, [40](#)
- ads1115_i2c_read
 - ads1115_interface.c, [10](#)
 - ads1115_interface.h, [12](#)
- ads1115_i2c_read_t
 - ads1115.h, [38](#)
- ads1115_i2c_write
 - ads1115_interface.c, [10](#)
 - ads1115_interface.h, [12](#)
- ads1115_i2c_write_t
 - ads1115.h, [38](#)
- ads1115_init
 - ads1115.c, [22](#)
 - ads1115.h, [45](#)
- ads1115_interface.c
 - ads1115_delay_ms, [9](#)
 - ads1115_i2c_read, [10](#)
 - ads1115_i2c_write, [10](#)
- ads1115_interface.h
 - ads1115_delay_ms, [11](#)
 - ads1115_i2c_read, [12](#)
 - ads1115_i2c_write, [12](#)
- ads1115_is_ready
 - ads1115.c, [23](#)
 - ads1115.h, [46](#)
- ADS1115_MAX_VALUE
 - ads1115.c, [16](#)
- ADS1115_MIN_VALUE
 - ads1115.c, [16](#)
- ADS1115_MODE_CONTINUOUS
 - ads1115.h, [41](#)
- ADS1115_MODE_MASK
 - ads1115.c, [16](#)
- ADS1115_MODE_SHIFT
 - ads1115.c, [17](#)
- ADS1115_MODE_SINGLE_SHOT
 - ads1115.h, [41](#)
- ads1115_mode_t
 - ads1115.h, [40](#)
- ADS1115_MUX_AIN0_AIN1
 - ads1115.h, [41](#)
- ADS1115_MUX_AIN0_AIN3
 - ads1115.h, [41](#)
- ADS1115_MUX_AIN0_GND

- ads1115.h, [41](#)
- ADS1115_MUX_AIN1_AIN3
 - ads1115.h, [41](#)
- ADS1115_MUX_AIN1_GND
 - ads1115.h, [41](#)
- ADS1115_MUX_AIN2_AIN3
 - ads1115.h, [41](#)
- ADS1115_MUX_AIN2_GND
 - ads1115.h, [41](#)
- ADS1115_MUX_AIN3_GND
 - ads1115.h, [41](#)
- ADS1115_MUX_MASK
 - ads1115.c, [17](#)
- ADS1115_MUX_SHIFT
 - ads1115.c, [17](#)
- ads1115_mux_t
 - ads1115.h, [41](#)
- ADS1115_OK
 - ads1115.h, [40](#)
- ADS1115_OS_IDLE
 - ads1115.c, [17](#)
- ADS1115_OS_MASK
 - ads1115.c, [17](#)
- ADS1115_OS_SHIFT
 - ads1115.c, [17](#)
- ADS1115_OS_START_SINGLE
 - ads1115.c, [17](#)
- ADS1115_PGA_MASK
 - ads1115.c, [17](#)
- ADS1115_PGA_SHIFT
 - ads1115.c, [18](#)
- ADS1115_RANGE_0V256
 - ads1115.h, [41](#)
- ADS1115_RANGE_0V512
 - ads1115.h, [41](#)
- ADS1115_RANGE_1V024
 - ads1115.h, [41](#)
- ADS1115_RANGE_2V048
 - ads1115.h, [41](#)
- ADS1115_RANGE_4V096
 - ads1115.h, [41](#)
- ADS1115_RANGE_6V144
 - ads1115.h, [41](#)
- ads1115_range_t
 - ads1115.h, [41](#)
- ADS1115_REG_CONFIG
 - ads1115.c, [18](#)
- ADS1115_REG_CONVERSION
 - ads1115.c, [18](#)
- ADS1115_REG_HI_THRESH
 - ads1115.c, [18](#)
- ADS1115_REG_LO_THRESH
 - ads1115.c, [18](#)
- ads1115_set_channel
 - ads1115.c, [23](#)
 - ads1115.h, [46](#)
- ads1115_set_compare_alert
 - ads1115.c, [23](#)
- ads1115.h, [46](#)
- ads1115_set_compare_latch
 - ads1115.c, [24](#)
 - ads1115.h, [47](#)
- ads1115_set_compare_mode
 - ads1115.c, [24](#)
 - ads1115.h, [47](#)
- ads1115_set_compare_queue
 - ads1115.c, [24](#)
 - ads1115.h, [47](#)
- ads1115_set_compare_threshold
 - ads1115.c, [25](#)
 - ads1115.h, [48](#)
- ads1115_set_data_rate
 - ads1115.c, [25](#)
 - ads1115.h, [48](#)
- ads1115_set_range
 - ads1115.c, [25](#)
 - ads1115.h, [48](#)
- ads1115_single_read
 - ads1115.c, [26](#)
 - ads1115.h, [49](#)
- comp_latch
 - ads1115_config_t, [5](#)
- comp_mode
 - ads1115_config_t, [5](#)
- comp_pol
 - ads1115_config_t, [6](#)
- comp_queue
 - ads1115_config_t, [6](#)
- config
 - ads1115_handle_t, [8](#)
- data_rate
 - ads1115_config_t, [6](#)
- delay_ms
 - ads1115_handle_t, [8](#)
- high_threshold
 - ads1115_config_t, [6](#)
- i2c_addr
 - ads1115_handle_t, [8](#)
- i2c_read
 - ads1115_handle_t, [8](#)
- i2c_write
 - ads1115_handle_t, [8](#)
- interface/ads1115_interface.c, [9](#), [11](#)
- interface/ads1115_interface.h, [11](#), [13](#)
- is_initialized
 - ads1115_handle_t, [8](#)
- low_threshold
 - ads1115_config_t, [6](#)
- mode
 - ads1115_config_t, [6](#)
- mux
 - ads1115_config_t, [7](#)

range

 ads1115_config_t, [7](#)

src/ads1115.c, [13](#), [26](#)

src/ads1115.h, [34](#), [49](#)