

STRAIGHT SALE

1. Terminal Idle Display


To start transaction:

- Click HERE to proceed to ENTER amount screen
- Insert or Swipe Card from Idle mode
- Click Menu to navigate




2. Select Transaction Type

Select MC/VISA/JCB/Union Pay – for Credit transaction




3. Select Transaction Type

Select Straight Sale




4. Amount Entry

Enter the desire amount then press [ENTER] button to confirm



6. FOR DCC TRANSACTION ONLY

Terminal will ask the desired currency.



7. Card Entry

Customer can Tap/Insert/Swipe/Key-in card or press [BACK] to cancel



8. FOR MANUAL KEY ENTRY TRANSACTIONS ONLY:

From Card Entry, Input the Customer Card number then press [OK] to confirm

Input the expiry date seen in card then press [ENTER] to confirm



9. FOR EMV PIN BASED TRANSACTION ONLY

If card has pin, hand the terminal to customer to input pin, then press [ENTER] button to confirm. If not, press [ENTER] button for pin bypass




10. Card Confirmation

Terminal will display the total amount; Press [PROCEED] to Continue or [X] to cancel and will back to idle.



11. Connecting to bank host

Terminal will send and receive data to/from host



12. Printing of Receipt

Terminal will print the receipt



13 Printing of Merchant Receipt

Press PRINT Button to print MERCHANT COPY, [CANCEL] button if not




14. Printing of Bank Receipt

Press PRINT Button to print MERCHANT COPY, [CANCEL] button if not




15 FOR CHIP/EMV TRANSACTIONS ONLY:

Wait for terminal to display “PLEASE REMOVE CARD” before pulling out the chip/EMV card from the terminal



1. Terminal Idle Display

Click Menu to navigate




2. Select Transaction Type

Select MC/VISA/JCB/Union Pay – for Credit transaction




3. Select PREAUTH COMPLETION Transaction



4. Card Entry

Customer can Insert/Swipe/Key-in card or press [BACK] to cancel



5. Approval Code Entry

Input Approval code (seen on receipt PREAUTH RECEIPT) then press [ENTER] button to continue




6. Amount Entry

Enter the desire amount then press [ENTER] button to confirm




7. Card Confirmation

Terminal will display the total amount; Press [PROCEED] to Continue or [CANCEL] to return to idle.




8. Printing of Receipt

Terminal will print the receipt




9 FOR CHIP/EMV TRANSACTIONS ONLY:

Wait for terminal to display “PLEASE REMOVE CARD” before pulling out the chip/EMV card from the terminal




10. Connecting to bank host

Terminal will send and receive data to/from host




1. Terminal Idle Display

Click Menu to navigite




2. Select Transaction Type

Select MC/VISA/JCB/Union Pay – for Credit transaction




3. Select VOID




4. Enter Password:

Input marchant password



5. Invoice Number Entry:


Input invoice number of transaction needed to void then press [ENTER] to continue NOTE: Debit sales cannot be voided



VOID


6. Void Confirmation

Terminal will display amount of transaction needed to void. Press [OK] to confirm, Press [CANCEL] to EXIT




7.Connecting to bank host

Terminal will send and receive data to/from host




8. Printing of Receipt

Terminal will print the receipt




OFFLINE

1. Terminal Idle Display Click Menu to navigate




2. Select Transaction Type

Select MC/VISA/JCB/Union Pay – for Credit transaction




3. Select OFFLINE Transaction



4. Enter Password:


Input merchant password



5. Card Entry

Customer can Insert/Swipe/Key-in card or


press [BACK] to cancel



6. FOR MANUAL KEY ENTRY TRANSACTIONS ONLY:


From Card Entry, Input the Customer Card number then press [ENTER] to confirm

Input the expiry date seen in card then press [ENTER] to confirm




7. Amount Entry

Enter the desire amount then press [ENTER] button to confirm



8. Approval Code Entry


Input Approval code (seen on receipt PREAUTH RECEIPT) then press [ENTER] button to continue



9. Card Confirmation


Terminal will display the total amount; Press [PROCEED] to

Continue or [CANCEL] to return to idle screen



10. Printing of Receipt

Terminal will print the receipt



1. Terminal Idle Display
Click Menu to navigate




6. Confirm to add TIP
Terminal will display the total amount;
Press [OK] to
Continue or [CANCEL] to return screen to idle.



2. Select Transaction Type


Select MC/VISA/JCB/Union Pay – for Credit transaction



7. TIP Amount Entry
Enter the desire tip amount then press [ENTER] button to confirm




3. Select TIP ADJUST Transaction



8. Card Confirmation
Terminal will display the total amount;
Press [PROCEED] to
Continue or [CANCEL] to return to idle.




4. Enter Password:
Input merchant password



9. Printing of Receipt
Terminal will print the receipt



5. Invoice Number Entry:
Input invoice number of transaction needed to void then press [ENTER] to continue
NOTE: Debit sales cannot be voided




1. Terminal Idle Display
Click Menu to navigate




2. Select Transaction Type


Select MC/VISA/JCB/Union Pay – for Credit transaction



3. Select PREAUTHORIZATION Transaction




4. Card Entry
Customer can Insert/Swipe/Key-in card or press [BACK] to cancel



5. FOR MANUAL KEY ENTRY TRANSACTIONS ONLY:

From Card Entry, Input the Customer Card number then press [ENTER] to confirm


Input the expiry date seen in card then press [ENTER] to confirm



PREAUTHORIZATION


6. Amount Entry

Enter the desire amount then press [ENTER] button to confirm



7. Card Confirmation

Terminal will display the total amount; Press [PROCEED] to Continue or [CANCEL] go back to idle.



8.Connecting to bank host

Terminal will send and receive data to/from host



9. Printing of Receipt

Terminal will print the receipt



10 FOR CHIP/EMV TRANSACTIONS ONLY:

Wait for terminal to display “PLEASE REMOVE CARD” before pulling out the chip/EMV card from the terminal




PREAUTH VOID

1. Terminal Idle Display Click Menu to navigate




2. Select Transaction Type

Select MC/VISA/JCB/Union Pay – for Credit transaction




3. Select PREAUTH VOID Transaction



4. Card Entry

Customer can Insert/Swipe/Key-in card or press [BACK] to cancel



5. Enter RRN:

Input RRN (seen on receipt PREAUTH RECEIPT) then press [ENTER] button to continue




6. Approval Code Entry

Input Approval code (seen on receipt PREAUTH RECEIPT) then press [ENTER] button to continue




7. Amount Entry

Enter the desire amount then press [ENTER] button to confirm




8. Card Confirmation

Terminal will display the total amount; Press [PROCEED] to Continue or [CANCEL] go back to idle.



9.Connecting to bank host

Terminal will send and receive data to/from host



10. Printing of Receipt

Terminal will print the receipt




1. Terminal Idle Display


Click Menu to navigate



2. Select Bancnet




3. Select LOGON



4.Connecting to bank host

Terminal will send and receive data to/from host




1. Terminal Idle Display


Click Menu to navigate



2. Select Bancnet




3. Select SALE transaction




4. Card Entry

Customer can Insert/Swipe/Key-in card or press [BACK] to cancel




5. Account Selection

Terminal will ask for debit account selection, Savings account and Current account




6. Amount Entry

Enter the desire amount then press [ENTER] button to confirm




7. Card Confirmation

Terminal will display the total amount; Press [PROCEED] to Continue or [CANCEL] go back to idle.



8. ENTER PIN

If card has pin, hand the terminal to customer to input pin, then press [ENTER] button to confirm.



9.Connecting to bank host

Terminal will send and receive data to/from host



10. Printing of Receipt


Terminal will print the receipt



1. Terminal Idle Display
Click Menu to navigate




6. Card Confirmation
Terminal will display card details Press [PROCEED] to Continue or [CANCEL] go back to idle.



1. Terminal Idle Display
Click Menu to navigate




2. Select Bancnet




7. ENTER PIN
If card has pin, hand the terminal to customer to input pin, then press [ENTER] button to confirm.




2. Select REPORT



3, Select Balance Inquiry Transaction




8.Connecting to bank host
Terminal will send and receive data to/from host




3. Select REPORTS
Press [2] button for REPORTS




4. Card Entry
Customer can Insert/Swipe/Key-in card or press [BACK] to cancel




9. Balance Inquiry
Terminal will display remaining balance on the card.



4. FOR DETAIL AND SUMMARY REPORT ONLY:
Select host for desired report



5. Account Selection
Terminal will ask for debit account selection, Savings account and Current account



5. Printing of Report
Terminal will print report that was selected



1. Terminal Idle Display

Click Menu to navigate




6. Settlement Totals

per host:

Terminal display
totals on the screen.
Press [PROCEED] to
continue then
[CANCEL] to return
to idle mode




2. Select Settlement



7 .Connecting to bank host

Terminal will send
and receive data
to/from host



3. Select Single Settle or Settle All

Terminal will ask if
Settle all card types,
Press [1] button if Yes,
Press [2] button for
No.



8. Printing of Settlement Receipt

Terminal will print
the receipt



4. Enter Password:

Input merchant
password

**METROBANK**

TEL NO: +63 2 8870-0999
PLDT TOLL FREE: 1-800-10-870 0999
EMAIL: merchanthelpdesk@metrobankcard.com

CASTLES TECHNOLOGY

SMART: +63 929-346-3452
GLOBE: +63 966-345-8040
OFFICE NO: +632 8584-3540
 +632 7728-0672
EMAIL: CITAS_Customercare@castech.asia

5.1. SINGLE SETTLE

Select host needs to settle, use [↓↑] down and up button to navigate for other host

Hosts with Asterisk (*) means it has batch, if not, batch is empty

