



[Home](#) » [Products](#) » Sleepy Pi External Programming Adapter / Serial Console Cable



[Home](#) / [Kits](#) / Sleepy Pi External Programming Adapter / Serial Console Cable

Sleepy Pi External Programming Adapter / Serial Console Cable

£23.98 (£19.98 ex. VAT)

External Arduino Programming Cable lets you use a PC or Mac to develop Sleepy Pi Apps

Compatible with Sleepy Pi 1 and Sleepy Pi 2

Availability: Available on backorder

1

Add to cart



SKU: SFY-10037-1

Categories: [Kits](#), [Raspberry Pi](#), [Sleepy Pi](#)

Tags: [Sleepy Pi](#), [Sleepy Pi 2](#)

Description **Additional Information** **Reviews**

We use cookies to ensure that we give you the best experience on our website. If you continue to use this site we will assume that you are happy with it.

Ok

Privacy policy



External Programming Cable OR RPi Serial Console



Do I need this cable? No. You can develop code, debug and program the [Sleepy Pi](#) or [Sleepy Pi 2](#) from your Raspberry Pi quite happily...

...But there are times when you think:

"Do you know what? why am I waiting for the RPi to compile and upload my code? I've got that nutter fast PC in the corner, couldn't I use that?"


"I'd like to debug my code whilst I'm shutting down / booting up my Raspberry Pi"

If you are doing any serious code-smithing on your Sleepy Pi, then this is **the tool for you.**

Host Your Development On Another Machine

Run the Arduino IDE on your fast PC / Mac / Linux box and download the code direct to the Sleepy Pi.

Serial Console For Raspberry Pi



The Board has two jumper positions:

- DBG
- TERM

When in "DBG" the communication link connects a computer (PC / Mac / Linux) to the Sleepy Pi. This is the standard programming mode and allows you to program and debug Arduino code on the Sleepy Pi.

When in "TERM" the communication link is from the computer to the Raspberry Pi. In this configuration the you can log into the Raspberry Pi via the serial terminal.