

brsmemset()

Fills the memory area with specific values

This function block can only be used conditionally for **redundancy**.
The applicable limitations are described in the following sections:

[Hidden pointer usage](#)

Additional information can be found in the ["Redundancy"](#) section.

Parameters

I/O	Parameter	Data type	Description
IN	pDest	ANY (transferred as a pointer)	Address of destination memory
IN	value	USINT	Initialization value
IN	length	UDINT	Number of bytes to be initialized
OUT	nxt_adr	UDINT	Address of the byte following the initialized bytes in the destination memory

Call syntax (Automation Basic)

```
nxt_adr = brsmemset(adr(Dest),value,length)
```

Note

Starting from the specified destination address, "length" bytes are initialized bitwise with the value "value" (independent of the data type of the array).

Examples

[Automation Basic](#)

[ANSI C](#)

[Structured Text](#)