

UdpDisconnect()

This FBK removes the connection between a UDP port and the opposite station (IP address and port number).

Asynchronous handling causes the function block to return [ERR_FUB_BUSY](#) until the FBK is either finished successfully or an error occurs.

This function block can only be used conditionally for **redundancy**.
The applicable limitations are described in the following sections:

[Communication](#)
[Handle must be initialized](#)
[Asynchronous execution](#)

Additional information can be found in the ["Redundancy"](#) section.

Parameters

I/O	Parameter	Data type	Description
IN	enable	BOOL	Enables the FBK.
IN	ident	UDINT	Ident from UdpOpen.
OUT	status	UINT	Function return value (error numbers , 0 = no error)

Call syntax (Automation Basic)

UdpDisconnect (enable, ident, status)

Function description

This FBK removes the connection between a UDP port and the opposite station (IP address and port number). It is still possible to send to various receivers or receive from various senders.

Error numbers

Value	Name	Description	Correction
0	ERR_OK	Status OK.	
32500	udpERR_INVALID_IDENT	The specified ident is not valid.	Check the specified ident.
65534	ERR_FUB_ENABLE_FALSE	FBK not enabled.	Enable the FBK.
65535	ERR_FUB_BUSY	FBK still working.	Call it again.