

n00	module RUNNING/IDLE
n001	INITIATE MODE : RUN
n002	SEQUENCER : FREEZE (mask)
n003	SEQUENCER : RUN
n004	SEQUENCER : UNFREEZE (using SEQn UNFREEZE RESYNC)
n005	SERVO PWM output : RUN
n006	STOP
n007	SEQUENCER : EXECUTE STEPPOINT
n008	
n009	special : OUTPUT BURST TTL DATA on INPUT B : ENABLE
n010	special : OUTPUT BURST TTL DATA on INPUT B : DISABLE
n01c	special : EXECUTE OUTPUT BURST : variable interval time mode
n01d	special : EXECUTE OUTPUT BURST : fixed interval time mode
n01e	config : WRITE
n01f	config : READ
n012	config : INITIAL