

Container and Genset Manual Index

CRR Units

Container Model	Maintenance Manual #	Parts Manual #
CRR DF MPC2000	TK 50134	TK 50262
CRR DF MPC2000ID	TK 50134	TK 50262
CRR DF MP3000	TK 50134	TK 50262
CRR40-52	TK 50094	TK 50193
CRR40-54	TK 50094	TK 50193
CRR40-63	TK 50094	TK 50193
CRR40-100	TK 50094	TK 50193
CRR40-101	TK 50094	TK 50469
CRR40-102	TK 50094	TK 50193
CRR40-103	TK 50094	TK 50528
CRR40-106	TK 50094	TK 50193
CRR40-107	TK 50094	TK 50193
CRR40-110	TK 50094	TK 50193
CRR40-111	TK 50094	TK 50193
CRR40-112	TK 50094	TK 50193
CRR40-113	TK 50094	TK 50193
CRR40-114	TK 50094	TK 50193
CRR40-115	TK 50094	TK 50193
CRR40-116	TK 50094	TK 50193
CRR40-117	TK 50094	TK 50193
CRR40-119	TK 50743	TK 50680
CRR40-119A	TK 50743	TK 50680
CRR40-121	TK 50094	TK 50193
CRR40-123	TK 50094	TK 50193
CRR40-125	TK 50094	TK 50469
CRR40-126	TK 50094	TK 50469
CRR40-128	TK 50094	TK 50193
CRR40-130	TK 50094	TK 50193
CRR40-131	TK 50094	TK 50193
CRR40-132	TK 50094	TK 50193
CRR40-133	TK 50094	TK 50528
CRR40-134	TK 50511	TK 50701
CRR40-136	TK 50094	TK 50528
CRR40-138	TK 50094	TK 50193
CRR40-139	TK 50094	TK 50193
CRR40-141	TK 50094	TK 50193
CRR40-142	TK 50094	TK 50193
CRR40-143	TK 50094	TK 50193
CRR40-144	TK 50094	TK 50193
CRR40-145	TK 50094	TK 50193
CRR40-146	TK 50511	TK 50701
CRR40-147	TK 50094	TK 50193
CRR40-148	TK 50094	TK 50193
CRR40-150	TK 50094	TK 50193
CRR40-151	TK 50094	TK 50193
CRR40-152	TK 50511	TK 50680
CRR40-153	TK 50094	TK 50193
CRR40-154	TK 50094	TK 50193
CRR40-155	TK 50511	TK 50680
CRR40-156	TK 50094	TK 50193
CRR40-157	TK 50094	TK 50193
CRR40-159	TK 50094	TK 50193
CRR40-160	TK 50094	TK 50193

CRR Units (continued)

Container Model	Maintenance Manual #	Parts Manual #
CRR40-161	TK 50094	TK 50193
CRR40-162	TK 50511	TK 50680
CRR40-164	TK 50094	TK 50193
CRR40-165	TK 50094	TK 50193
CRR40-166	TK 50094	TK 50193
CRR40-171	TK 50094	TK 50193
CRR40-172	TK 50743	TK 50680
CRR40-173	TK 50094	TK 50193
CRR40-181	TK 50094	TK 50193
CRR40-186	TK 50094	TK 50193
CRR40-800	TK 50743	TK 50680
CRR40-800A	TK 50743	TK 50680
CRR40-800B	TK 50743	TK 50680
CRR40-810B	TK 50743	TK 50680

CRR PS & PS+ Units

Container Model	Maintenance Manual #	Parts Manual #
CRR40-155 PS	TK 50874	TK 50961
CRR40-167 PS	TK 50874	TK 50961
CRR40-168 PS	TK 50874	TK 50961
CRR40-170 PS	TK 50874	TK 50961
CRR40-172 PS	TK 50874	TK 50961
CRR40-172 PS	TK 50874	TK 50961
CRR40-173 PS	TK 50874	TK 50961
CRR40-178 PS	TK 50874	TK 50961
CRR40-179 PS+	TK 50874	TK 50961
CRR40-180 PS+	TK 50874	TK 50961
CRR40-181 PS	TK 51078	TK 50961
CRR40-182 PS	TK 51078	TK 50961
CRR40-183 PS	TK 51078	TK 50961
CRR40-184 PS	TK 51078	TK 50961
CRR40-185 PS	TK 50874	TK 50961
CRR40-186 PS	TK 50874	TK 50961
CRR40-188 PS	TK 50874	TK 50961
CRR40-189 PS+	TK 50874	TK 50961
CRR40-190 PS	TK 50874	TK 50961
CRR40-191 PS	TK 50874	TK 50961
CRR40-192 PS	TK 50874	TK 50961
CRR40-193 PS	TK 50874	TK 50961
CRR40-194 PS	TK 50874	TK 50961
CRR40-195 PS	TK 50874	TK 50961
CRR40-196 PS	TK 50874	TK 50961
CRR40-197 PS	TK 50874	TK 50961
CRR40-300 PS	TK 51156	TK 51197
CRR40-302 PS	TK 50874	TK 50961
CRR40-303 PS	TK 50874	TK 50961
CRR40-305 PS	TK 50874	TK 50961
CRR40-306 PS	TK 50874	TK 50961
CRR40-308 PS	TK 50874	TK 50961
CRR40-309 PS	TK 50874	TK 50961
CRR40-310 PS	TK 50874	TK 50961
CRR40-311PS	TK 50874	TK 50961
CRR40-312 PS	TK 50874	TK 50961
CRR40-313 PS	TK 50874	TK 50961
CRR40-314 PS	TK 50874	TK 50961
CRR40-315 PS	TK 50874	TK 50961

CRR PS & PS+ Units (continued)

Container Model	Maintenance Manual #	Parts Manual #
CRR40-318 PS	TK 50874	TK 50961
CRR40-319 PS	TK 50874	TK 50961
CRR40-321 PS	TK 50874	TK 50961
CRR40-322 PS	TK 50874	TK 50961
CRR40-323 PS	TK 50874	TK 50961
CRR40-324	TK 50874	TK 50961
CRR40-325	TK 50874	TK 50961
CRR40-326	TK 50874	TK 50961
CRR40-327	TK 50874	TK 50961
CRR40-328	TK 50874	TK 50961
CRR40-329	TK 50874	TK 50961
CRR40-330	TK 50874	TK 50961
CRR40-331	TK 50874	TK 50961
CRR40-332	TK 50874	TK 50961
CRR40-333	TK 50874	TK 50961
CRR40-334	TK 50874	TK 50961

CSR Units

Container Model	Maintenance Manual #	Parts Manual #
CSR40-4	TK 41244	TK 50162
CSR40-42	TK 41244	TK 50192
CSR40-46	TK 41244	TK 50192
CSR40-57	TK 41244	TK 50219
CSR40-67	TK 41244	TK 50219
CSR40-792	TK 41244	TK 50192
CSR40-100	TK 41244	TK 50192
CSR40-101	TK 41244	TK 50028
CSR40-102	TK 41244	TK 50192
CSR40-103	TK 41244	TK 50192
CSR40-104	TK 41244	TK 50192
CSR40-109	TK 41244	TK 50192
CSR40-110	TK 41244	TK 50192
CSR40-111	TK 41244	TK 50192
CSR40-112	TK 41244	TK 50192
CSR40-113	TK 41244	TK 50192
CSR40-114	TK 41244	TK 50192
CSR40-115	TK 41244	TK 50192
CSR40-116	TK 50622	TK 50192
CSR40-117	TK 41244	TK 50192
CSR40-118	TK 50622	TK 50192
CSR40-121	TK 50622	TK 50192
CSR40-122	TK 50622	TK 50192
CSR40-123	TK 50622	TK 50192
CSR40-124	TK 50622	TK 50192
CSR40-125	TK 50622	TK 50192
CSR40-126	TK 50622	TK 50192
CSR40-127	TK 50622	TK 50192
CSR40-128	TK 50622	TK 50192
CSR40-129	TK 50622	TK 50192
CSR40-130	TK 50622	TK 50192
CSR40-131	TK 50622	TK 50192
CSR40-132	TK 41244	TK 50192
CSR40-133	TK 41244	TK 50192
CSR40-134	TK 50622	TK 50192
CSR40-135	TK 41244	TK 50192
CSR40-136	TK 50622	TK 50192
CSR40-139	TK 50622	TK 50192
CSR40-140	TK 50622	TK 50192
CSR40-SL 142	TK 50622	TK 50192
CSR40-140	TK 50622	TK 50192
CSR40SL-143	TK 50836	TK 50192
CSR40SL-168	TK 50836	TK 50192

CSR PS & PS+ Units

Container Model	Maintenance Manual #	Parts Manual #
CSR20SL-144 PS	TK 50824	TK 51176
CSR40-145 PS	TK 50824	TK 50762
CSR40SL-148 PS	TK 50825	TK 50896
CSR40-149 PS	TK 50892	TK 51176
CSR40-150 PS	TK 50892	TK 51176
CSR20SL-155 PS	TK 50824	TK 51176
CSR40-162 PS+	TK 50825	TK 51019
CSR40-164 PS	TK 50825	TK 51019
CSR40-165 PS	TK 50825	TK 51019
CSR40-166 PS	TK 50825	TK 51019
CSR40SL-167 PS	TK 50824	TK 51176
CSR40-169 PS	TK 50825	TK 51019
CSR40SL-170 PS	TK 50824	TK 51176
CSR40-171 PS+	TK 50825	TK 51176
CSR20SL/PS-173	TK 50825	TK 51176
CSR40SL-500 PS	TK 50825	TK 51176
CSR20SL-501 PS	TK 50825	TK 51176
CSR40SL-502 PS	TK 50825	TK 51176
CSR40-503 PS	TK 50825	TK 51176
CSR40SL-505 PS	TK 50825	TK 51176
CSR40SL-506 PS	TK 50825	TK 51176
CSR40SL-507 PS	TK 50825	TK 51176
CSR20SL-508 PS	TK 50825	TK 51176
CSR40-510 PS	TK 50825	TK 51176
CSR40SL-511 PS	TK 50825	TK 51176
CSR40SL-512 PS	TK 50825	TK 51176
CSR40-513 PS	TK 50825	TK 51176
CSR40-514 PS	TK 50825	TK 51176
CSR20SL-515 PS	TK 50825	TK 51176
CSR40SL-516 PS	TK 50825	TK 51176
CSR40SL-517 PS	TK 50825	TK 51176
CSR40SL-518 PS	TK 50825	TK 51176
CSR40-520	TK 50825	TK 51176
CSR40SL-521	TK 50825	TK 51176
CSR40SL-522	TK 50825	TK 51176
CSR40SL-523	TK 50825	TK 51176

MAGNUM Units

Container Model	Maintenance Manual #	Parts Manual #
MAGNUM-525	TK 51122	TK 51745
MAGNUM SL-526	TK 51122	TK 51745
MAGNUM-527	TK 51122	TK 51745
MAGNUM-528	TK 51122	TK 51745
MAGNUM-529	TK 51122	TK 51745
MAGNUM-922	TK 51122	TK 51745
MAGNUM SL-934	TK 51122	TK 51745

Gensets

Genset Model/System #	Maintenance Manual #	Parts Manual #
CGSM	TK 50819	TK 50766
SGSM	TK 50819	TK 50767
CGCM	TK 50819	TK 50764
SGCM	TK 50819	TK 50765
CGCO	TK 50819	TK 50768
SGCO	TK 50819	TK 50763
SGSM 2000	TK 50935	TK 51011
SGCM 2000	TK 50935	TK 51067
SGCO 2000	TK 50935	TK 50952
SGCO 2000-151	TK 51291	TK 51292

FAX NET

Thermo King Corporation
Minneapolis, Minnesota
Fax #: (952) 885-3458

ORDER FORM

Container Refrigeration

COMPANY : _____

CUSTOMER CODE : _____

ADDRESS : _____

P.O. # _____

NAME: _____

SHIP VIA : ☐ UPS Ground ☐ Federal Econ☐ Federal Standard ☐ Federal Priority

NUMBER OF PAGES SENT: _____

[illegible]