

YOUR CURRENT VEHICLE

2018 Chrysler Pacifica


Front

FRONT

REMOVAL

WARNING

To avoid serious or fatal injury during and following any seat belt or child restraint anchor service, carefully inspect all seat belts, buckles, mounting hardware, retractors, tether straps, and anchors for proper installation, operation, or damage. Replace any belt that is cut, frayed, or torn. Straighten any belt that is twisted. Tighten any loose fasteners. Replace any belt that has a damaged or ineffective buckle or retractor. Replace any belt that has a bent or damaged latch plate or anchor plate. Replace any child restraint anchor or the unit to which the anchor is integral that has been bent or damaged. Never attempt to repair a seat belt or child restraint component. Always replace damaged or ineffective seat belt and child restraint components with the correct, new and unused replacement parts listed in the Mopar® Parts Catalog. Failure to follow these instructions may result in possible serious or fatal injury.




1012082280

1. Disconnect and isolate the negative battery cable. If equipped with an Intelligent Battery Sensor (IBS), disconnect the IBS connector first before disconnecting the negative battery cable. Wait two minutes for the system capacitor to discharge before further service.
2. Remove the appropriate left or right front seat from the vehicle. ([Refer to Body/Seats/SEAT, Front/Removal and Installation](#))([Refer To List 1](#)).
3. Disconnect the seat belt buckle pigtail connector (1) from the seat wire harness connector.

NOTE

It is not necessary to completely remove the seat back cover to gain access to the inner side shield retaining screw.

4. Remove two screws (3) for the inner side shield (2). ([Refer to Body/Seats/COVER, Seat Back/Removal and Installation](#))([Refer To List 2](#))




5. Release the seat belt switch pigtail wire from the retainer (3) on the side of the front seat frame.
6. Remove the screw (2) that secures the buckle (1) lower anchor to the bracket on the inboard rear corner of the seat cushion frame.
7. Remove the seat belt buckle from the front seat.


INSTALLATION

WARNING

To avoid serious or fatal injury during and following any seat belt or child restraint anchor service, carefully inspect all seat belts, buckles, mounting hardware, retractors, tether straps, and anchors for proper installation, operation, or damage. Replace any belt that is cut, frayed, or torn. Straighten any belt that is twisted. Tighten any loose fasteners. Replace any belt that has a damaged or ineffective buckle or retractor. Replace any belt that has a bent or damaged latch plate or anchor plate. Replace any child restraint anchor or the unit to which the anchor is integral that has been bent or damaged. Never attempt to repair a seat belt or child restraint component. Always replace damaged or ineffective seat belt and child restraint components with the correct, new and unused replacement parts listed in the Mopar® Parts Catalog. Failure to follow these instructions may result in possible serious or fatal injury.



1. Position the seat belt buckle (1) lower anchor to the bracket on the inboard rear corner of the front seat.
2. Install the screw (2) that secures the buckle lower anchor to the seat bracket. Tighten the screw to the proper [Torque Specifications](#).
3. Engage the seat belt switch pigtail wire with the retainer (3) on the side of the front seat frame.



4. Position the inner side shield (2) and install the two screws (3) for the inner side shield (2). Tighten the screws securely. ([Refer to Body/Seats/COVER, Seat Back/Removal and Installation](#))([Refer To List 2](#))
5. Connect the seat belt buckle pigtail connector (1) to the seat wire harness connector.
6. Install the front seat into the vehicle. ([Refer to 23 - Body/Seats/SEAT, Front/Removal and Installation](#)) ([Refer To List 1](#)).
7. Do not connect the negative battery cable at this time. The Supplemental Restraint System (SRS) Verification Test procedure should be performed following service of any SRS component. ([Refer to 10 - Restraints - Standard Procedure](#)).

Refer To List:

List 1

- [23 - Body / Seats, First Row / SEAT, Front / Removal and Installation](#)
- [23 - Body / Seats, Second Row, Stow-n-Go / SEAT, Stow-n-Go / Removal and Installation](#)
- [23 - Body / Seats, Third Row, Stow-n-Go / SEAT / Removal and Installation](#)
- [23 - Body / Seats, Third Row, Power Folding / SEAT / Removal and Installation](#)

List 2

- [23 - Body / Seats, First Row / COVER, Seat Back, Front / Removal and Installation](#)
- [23 - Body / Seats, Second Row / COVER, Seat Back Second Row Center / Removal and Installation](#)
- [23 - Body / Seats, Second Row, Stow-n-Go / COVER, Seat Back, Stow-n-Go / Removal and Installation](#)
- [23 - Body / Seats, Third Row, Stow-n-Go / COVER, Seat Back / Removal and Installation](#)
- [23 - Body / Seats, Third Row, Power Folding / COVER, Seat Back, Third Row / Removal and Installation](#)