


YOUR CURRENT VEHICLE

2018 Chrysler Pacifica

Removal & Installation

REMOVAL AND INSTALLATION


REMOVAL

**FRONT**

1304054720

1. Remove the rear spring link ([Refer to Rear Suspension/LINK, Spring/Removal and Installation](#)).(Refer To [List 1](#))
2. As an installation reference, carefully mark location of isolator requiring removal on crossmember (around isolator can flange) using a marker or crayon.

Do not use a scratch awl to mark location.



1 - Adapters, Ball Joint Press C-4212-5

2 - Remover, Bushing Small 2026700170

3 - C-Support, Bushing Small, 2026800170-C

4 - Remover, Installer, Ball Joint 10140-3

5 - Press, Ball Joint C-4212F

NOTE

Prior to using special tools, lubricate Press, Ball Joint
Press, Ball Joint



(1) threads to provide ease of use and promote tool longevity.

3. Assemble tools over isolator crossmember assembly as shown:

1. Adapters, Ball Joint Press



2. Remover, Bushing Small



3. Support, Bushing Small



4. Remover, Installer, Ball Joint




5. Press, Ball Joint




4. Tighten Press (1) screw-drive, pressing bushing out of crossmember and remove all tools.

INSTALLATION



1304068729


1. Position isolator (2) on crossmember isolator bore (1).



FRONT

1304068729

2. Aligning isolator can flange with reference marks applied during removal.



1 - Adapters, Ball Joint Press C-4212-6

2 - Remover/Installer 8836-7

3 - Installer, Bushing Small 2026600170

4 - C-Support, Bushing Small, 2026800170-C

5 - Press, Ball Joint C-4212F

3. NOTE

Prior to using special tools, lubricate Press, Ball Joint
Press, Ball Joint



(1) threads to provide ease of use and promote tool longevity.

NOTE

A mixture of soap and water may be used to aid installation of the isolator.

4. Assemble tools over isolator crossmember assembly as shown:

1. Adapters, Ball Joint Press



2. Remover/Installer



3. Installer, Bushing Small



4. Support, Bushing Small



5. Press, Ball Joint



5. Tighten Press, Ball Joint

Press, Ball Joint



(1) screw-drive, pressing isolator into crossmember. Install isolator until isolator can flange contacts surface of crossmember.

6. Remove tools.

7. Install the rear crossmember ([Refer to 13 - Frame and Bumpers/Frame/CROSSMEMBER, Rear Suspension/Removal and Installation](#)).(Refer To List 2)

Refer To List:

List 1

- [17 - Rear Suspension / LINK, Camber / Removal and Installation](#)
- [17 - Rear Suspension / LINK, Comfort / Removal and Installation](#)
- [17 - Rear Suspension / LINK, Spring / Removal and Installation](#)
- [17 - Rear Suspension / LINK, Toe / Removal and Installation](#)

List 2

- [13 - Frame and Bumpers / Frame / CROSSMEMBER, Front Suspension / Removal and Installation](#)
- [13 - Frame and Bumpers / Frame / CROSSMEMBER, Rear Suspension / Removal and Installation](#)
- [13 - Frame and Bumpers / Frame / CROSSMEMBER, Steering Gear / Removal and Installation](#)