

Procedure to test TD Direct installation

- 1) Double-click TDD_Block.scdoc to open it in SpaceClaim.
- 2) Once the document is open, go to the Thermal Ribbon and click About. Look for “License is valid.” This will ensure you have a valid TD Direct license.
- 3) Double-click TDD_Test_Drawing.dwg to open it in Thermal Desktop.
- 4) Type **_TdUpdateSCImporters** and press Enter.
- 5) The red block should change to green. This ensures the meshing feature and link between Thermal Desktop and TD Direct are working correctly.

Contact support@crtech.com if you have any problems.