


SECTION 6 DISPLAY ON NC OPERATION PANEL

This section describes the contents of NC STATUS lamps on the NC operation panel, contents of the information displayed on the operation mode screen, and the information displayed on the special screen such as NC HOUR METER screen.

1. Status Indicating Lamps

On the NC operation panel, the following six NC status indicating lamps are arranged, and the current NC operating status can be confirmed from the lamp which is lit.



Lamp Name	Function
RUN	This lamp lights when NC is computing the axis position.
S.T.M	This lamp lights while the NC is executing the processing for the S (spindle function), T (tool function), and/or M (miscellaneous function) command.
SLIDE HOLD	This lamp lights when the SLIDE HOLD switch on the machine operation panel is pressed.
PROGRAM STOP	This lamp lights when the NC is in the program stop or the optional stop status. It flickers while the dwell command is being executed.
LIMIT	This lamp lights if the calculated axis position is on or beyond the soft-limit position.
ALARM	This lamp lights when an alarm comes on. This lamp does not light when a warning message comes from an operation mistake.

2. Actual Position Display

When function key [F2] (ACTUAL POSIT.) is pressed in the operation mode, the actual position data screen is displayed.

The actual position data is displayed in the following three absolute position data display modes and also in the relative position data display mode. The display screens can be changed by using the page keys.

2-1. Actual Position Display

For page [1] of actual position data display, two display modes are provided, double extension mode and four-fold extension mode. Which of the display mode should be used can be set using NC optional parameter (bit) No. 4, bit 6.

(1) Page [1] (Double Extension)




Fig. 6-1 Actual Position Display – Page [1] (Double Extension)

The following display data items are in common to the two actual position data display screens [1] (double extension and four-fold extension) and also to actual position display screen [2].

- X : X-axis actual position on active block
- Y : Y-axis actual position on active block
- Z : Z-axis actual position on active block
- CO : Work coordinate system number
- O : Currently active program name

- N** : Currently active sequence name
F : Actual feedrate (overridden programmed F value)
S : Actual spindle speed (overridden programmed S value)
H : Tool length offset number
D : Cutter radius compensation number

[Supplement] Actual position display of additional axes

In the double extension display mode:

1st additional axis data is displayed below "Z-axis".

2nd and 3rd additional axis data are displayed in the next page, which is accessible by pressing function key [F8] (EXTEND) and [F6] (AXIS CHANGE).

In the four-fold extension display mode:

1st to 3rd additional axis data are displayed in the next page, which is accessible by pressing function key [F8] (EXTEND) and [F6] (AXIS CHANGE).

(2) Page [1] (Four-fold Extension)




Fig. 6-2 Actual Position Display – Page [1] (Four-fold Extension)

(3) Page [2]




Fig. 6-3 Actual Position Display [2]

TOUCH SENSOR : Touch sensor status; Reverse display with touch sensor ON

TOUCH PROBE : Touch probe status; Reverse display with touch probe ON

LOAD DISPLAY : Loaded condition of the spindle and axes
(indicated by graph and percent values)

[Supplement] For the spindle overload monitor specification, the symbol "▽" (max. load value) and the message "LOAD MONITOR (***%)" are displayed on the screen. The message "TORQUE MONITOR (***%)" is displayed instead of "LOAD MONITOR (***%)" during torque monitoring for synchronized tapping operation.

(4) Page [3]




Fig. 6-4 Actual Position Display [3]

LOCAL COORDINATES	:	Distance referenced to the origin of the local coordinate system
WORK COORDS (APA)	:	Distance referenced to the origin of the work coordinate system
WORK COORDS	:	Distance referenced to the origin of the work coordinate system
MACHINE COORDS	:	Distance referenced to the machine origin
FEEDBACK COORDS	:	Output (numerical value) from the position encoder
TARGET VALUE	:	Target value
DISTANCE REMAINING	:	Distance remaining to the target point (commanded point)
MANUAL SHIFT ACTUL	:	Axis manual shift amount (current operation) in manual or pulse handle intervention operation
MANUAL SHIFT TOTAL	:	Axis manual shift amount (total) in manual or pulse handle intervention operation
PITCH ERROR COMP	:	Thread pitch error compensation amount

2-2. RELATIVE ACT POSIT Screen

The RELATIVE ACT POSIT screen looks like as follows.




Fig. 6-5 Relative Act Posit Screen

(a) Axis name

Indicates a basic axis name (X, Y, or Z) or an additional axis name (A, B, C, etc.).

An additional axis name is displayed only when an additional axis has been selected.

(b) Mirror image effective

When mirror image is effective, a minus sign “-” is placed preceding the axis name.

When mirror image is not effective, no sign is placed.

(c) Relative actual position data

Relative actual position data calculated using the following equation is displayed in the selected unit system.

$$\begin{aligned} \text{Relative actual position data} = & (\text{Coordinate value output from the encoder}^{*1}) \\ & - (\text{Reference position}^{*2}) - (\text{Tool length offset value}) \\ & - (\text{Machine zero point}) \end{aligned}$$

*1 Whether or not the manual shift amount is added can be set at NC optional parameter (bit) No. 5, bit 7.

*2 The reference position is the zero point (in the machine coordinate system) for the relative actual position. For the procedure to set the reference position, refer to (1) “Reference Position Setting”.

(d) Reference position

The reference position is the zero point in the machine coordinate system and is used to display the relative actual position, or, in their words, the zero point in the relative coordinate system. The reference position is calculated from the equation below and displayed for each axis in the selected unit system.

$$\text{Reference position} = (\text{output from position encoder } ^{*1}) - (\text{actual position value } ^{*2}) \\ - (\text{tool length offset value}) - (\text{machine zero point})$$

*1 Like the actual position display, it is possible to select whether or not the manual shift amount is included in the output from the position encoder by setting data at NC optional parameter (bit) No. 5, bit 7.


*2 Where the actual position is set in the coordinate system is input.
Refer to (1) "Reference Position Setting".

(1) Reference Position Setting

The reference position is the zero point (in the machine coordinate system) which is used to display the relative actual position, or, in other words, the zero point in the relative coordinate system. The reference position can be obtained by setting the coordinate value of the actual position.

The reference position can be set in two different manners: by setting the actual position at "0" and by setting the actual position at a desired position.

To set the reference position, press function key [F8] (EXTEND) in the automatic, MDI, or manual operation mode repeatedly until functions "RELATI. ZEROSET" and "RELATI. PRESET" are assigned to function keys [F2] and [F3], respectively.




(a) Setting the actual position at "0"

Follow the procedure below when setting the actual position at "0" in the relative coordinate system.

- 1) Press function key [F2] (RELATI. ZEROSET) in the automatic, MDI, or manual operation mode.

The prompt "= RPZS" will be displayed on the console line of the display screen.



- 2) Key in axis address(es) for which "0" is set through the keyboard. When no axis address has been keyed in, "0" is set for all axes.

Example: To set "0" for X and Z axes


= RPZS XZ



Key in axis addresses

A-Mtd							
=EX							
=EX							
=EX							
=RPZS XZ							
	RELATI. ZEROSSET	RELATI. PRESET					[EXTEND]
F1	F2	F3	F4	F5	F6	F7	F8

- 3) Press the WRITE key.



AUTO OPERATION		D3-CIR. MIN		0	N	2
				97/07/15 14:10:00		
RELATIVE ACT POSIT 1mm						
X	0.000	A	349.999			
Y	1540.189					
Z	0.000					
A-Mtd						
=EX						
=EX						
=RPZS XZ						
=						
	RELATI. ZEROSSET	RELATI. PRESET				[EXTEND]
F1	F2	F3	F4	F5	F6	F7
F8						


The reference position with which the actual position of the designated axis is "0" is obtained and relative actual position data of the designated axis will change to "0".

(b) Setting the actual position at a desired position

Follow the procedure below when setting the actual position at a desired position in the relative coordinate system.

- 1) Press function key [F3] (RELATI. PRESET) in the automatic, MDI, or manual operation mode.

The prompt "= RPPS" will be displayed on the console line of the display screen.



- 2) Key in axis address(es) and numerical value for which the actual position is set at a desired position through the keyboard. When no axis address has been keyed in, the actual position is set at a desired position for each axis.

Example 1: To set the actual position of X and Z axes at 200 and 300, respectively


= RPPS X200Z300

Key in axis addresses and numerical values.


Example 2: To set the actual position of all axes at 100

= RPPS 100

Key in a numerical value without specifying axis addresses.



- 3) Press the WRITE key.



AUTO OPERATION		D3-CIR.MIN		0	N	2
RELATIVE ACT POSIT				97/07/15 14:10:00		
				1mm		
X	200.000	A	349.999			
Y	1540.189					
Z	300.000					
A-Mtd						
=EX						
=EX						
=PPPS X200Z300						
=						
RELATI. ZEROSET		RELATI. PRESET				[EXTEND]

F1
F2
F3
F4
F5
F6
F7
F8

The reference position with which the actual position of the designated axis is a desired position is obtained and relative actual position data of the designated axis will change to a desired position.

[Supplement] Pressing the WRITE key without keying in address(es) and numerical value(s) does not set anything.

(c) Data setting range and restrictions

- 1) Data is input in the unit system (metric or inch) employed for machine operation and the decimal point position is fixed. For example, when "1" has been input while the 0.001 mm unit system is selected, it is recognized as 1 mm. The same rule also applies to the inch system.

- 2) Data can be set within the following range.

For linear axes: -99999.999 mm to +99999.999 mm

(When the inch system is selected, the entered value is converted into a metric value and checked if it is within the above range.)

For rotary axes: -99999.999° to +99999.999° (for the 0.001° unit system)

-9999.9999° to +9999.9999° (for the 0.0001° unit system)

(2) Precautions

- (a) Data is input in the unit system (metric or inch) employed for machine operation and the decimal point position is fixed. (For example, when "1" has been input while the 0.001 mm unit system is selected, it is recognized as 1 mm.)
- (b) When changing the reference position of all axes including rotary axes, the entered value is interpreted as length and degree.
- (c) The reference position cannot be set for an indexable axis. In this case, the actual position data is displayed on the RELATIVE ACT POSIT screen.

However, when axis designation was not made with reference position setting, "0" is set at the indexable axis, causing no error.

- (d) When the power is turned off, reference position data becomes "0" since it is not backed up by turning off of the power. (The machine zero point is employed as the reference position.)

However, when actual position data in the work coordinate system is rounded (parameter (bit) No. 2 bit 1 is ON) with the multi-turn rotary table specification, reference position data is calculated in reverse order. Therefore, when the work zero point is other than "0", a value other than "0" is set as reference position data.

- (e) Work coordinate values do not change when the reference position has been changed.

- (f) When the relative actual position value is smaller than -99999.999 mm (-9999.9999 inch for the inch system), "- OVERFLOW" will be displayed on the display screen.

When the relative actual position value is larger than +99999.999 mm (+9999.9999 inch for the inch system), "+ OVERFLOW" will be displayed on the display screen.

- (g) The display of the relative actual position of a rotary axis (rotary table) varies depending on the rotary axis specification.

- 1) Rotary table and indexable axis specification

The relative actual position is displayed within 0° and 360°. The reference position is also displayed within 0° and 360°.

- 2) Rotary axis with limits and multi-turn rotary table

The relative actual position obtained using the equation on page 23 is displayed as it is. With the multi-turn rotary table, whether or not relative actual position data is expressed within 0° and 360° when the NC is reset can be set at NC optional parameter No. 2, bit 1.

When the additional axis is removed with the removable axis specification, "- OVERFLOW" will be displayed as relative actual position data.

3. Program Display

In the operation mode, press function key [F3] (PART PROGRAM) and, the program information screens are accessed. There are three types of program information display screens such as schedule program, main program and MDI program. The display screen can be changed by pressing the PAGE key.

(1) Schedule Program

AUTO OPERATION		N13	16
		97/07/15	14:10:00
PROGRAM		* SCHEDULE *	
>>N001 VSET VC1=1		DIS X	0.000
N002 PSELECT GEAR. MIN, 0100 Q-10		Y	0.000
N003 PSELECT SHAFT. MIN		Z	0.000
N004 PSELECT WHEEL. MIN			
END			
		CO 33	
		O	F 0.0
		N	S 0
		H= 0	0.000
		D= 0	0.000
ACT POSIT (WORK)	X 39.500	Y 185.850	Z -1100.000
=EX			
=EX			
=PR			
=			
PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA
		SEARCH	CHECK DATA
			[EXTEND]

F1
F2
F3
F4
F5
F6
F7
F8

Fig. 6-6 Schedule Program Screen

The following display data items are in common to the CURRENT MAIN PROGRAM, READ MAIN PROGRAM, and MDI PROGRAM display screens.

DIS X: Remaining X-axis movement distance to the target position

DIS Y: Remaining Y-axis movement distance to the target position

DIS Z: Remaining Z-axis movement distance to the target position

Co : Work coordinate system number

O : Currently active program number

N : Currently active sequence number

F : Actual feedrate (overridden programmed F value)

S : Actual spindle speed (overridden programmed S value)

H : Tool length offset number and offset data

D : Cutter radius compensation number and compensation data

ACT POSIT (WORK) X : Actual X-axis position in the currently active block (work coordinate system)

ACT POSIT (WORK) Y : Actual Y-axis position in the currently active block (work coordinate system)

ACT POSIT (WORK) Z : Actual Z-axis position in the currently active block (work coordinate system)

[Supplement] The DIS data and ACT POSIT (WORK) data of additional axes are displayed in the following manner.

For the first additional axis, the data is displayed below the "Z-axis" data of DIS and right to the "Z-axis" data of (ACT POSIT) on the screen indicated above. For the second and third additional axes, the data is displayed on the page accessible by pressing function key [F8] (EXTEND) and [F6] (AXIS CHANGE).

(2) Current Main Program

AUTO OPERATION		A. MIN		0	N	1
				97/07/15 14:10:00		
PROGRAM		*CURRENT MAIN PROGRAM*		1mm		
>>G15H5		DIS	X	0.000		
G56X0Y0Z500H1			Y	0.000		
S1000M3			Z	0.000		
G0X100Y100			W	0.000		
CALL 0100		CO	0			
G0X200Y150		O		F	0.0	
CALL 0100		N		S	0	
M30		H=	0		0.000	
LOAD MAX		D=	0		0.000	
SPINDLE LOAD		LOAD MONITOR(110%)				
		0%				
ACT POSIT (WORK)	X	Y	Z	W		
	0.000	0.000	0.000	0.000		
	A-Mtd					
=PS A						
=						
PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	CHECK DATA	[EXTEND]

F1
F2
F3
F4
F5
F6
F7
F8

>> : Block just read into the buffer

↑ : Block being executed.

Fig. 6-7 Current Main Program Screen

[Supplement] For the spindle overload monitor specification, the symbol "▽" (max. load value) and the message "LOAD MONITOR (*** %)" are displayed on the screen. The message "TORQUE MONITOR (*** %)" is displayed instead of "LOAD MONITOR (*** %)" during torque monitoring for synchronized tapping operation.

(3) Read Main Program

AUTO OPERATION		A. MIN		O N 1	
				97/07/15 14:10:00	
PROGRAM		*READ MAIN PROGRAM*		1mm	
>>G15H5		DIS X		0.000	
G56X0Y0Z500H1		Y		0.000	
S1000M3		Z		0.000	
G0X100Y100		W		0.000	
CALL 0100		CO 0			
G0X200Y150		O		F 0.0	
CALL 0100		N		S 0	
M30		H= 0		0.000	
LOAD MAX		D= 0		0.000	
SPINDLE LOAD		LOAD MONITOR(110%)		0%	
ACT POSIT (WORK)		X 0.000		Y 0.000	
A-Mtd		Z 0.000		W 0.000	
=PS A					
=					
PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	CHECK DATA [EXTEND]

F1 F2 F3 F4 F5 F6 F7 F8

Fig. 6-8 Read Main Program Screen

(4) MDI Program

AUTO OPERATION		TST9. MIN		OTST9 N 1	
				97/07/15 14:10:00	
PROGRAM		*MDI PROGRAM*		1mm	
G90G0X0Y0Z0		*CURRENT*		DIS X 0.000	
RTMDI				Y 0.000	
				Z 0.000	
BUFFER				CO 1	
				O TST9 F 0.0	
				N S 0	
				H= 0 0.000	
				D= 0 0.000	
ACT POSIT (WORK)		X 0.000		Y 0.000	
A-Mtd		Z 100.000		-1	
=IN					
PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	CHECK DATA [EXTEND]

F1 F2 F3 F4 F5 F6 F7 F8

Fig. 6-9 MDI Program Screen

4. Block Display

In operation mode, function key [F4] (BLOCK DATA) accesses the block data screens.

Under the heading of BLOCK DATA, four screens of block data display are available: CURRENT, BUFFER, SECOND BUFFER, and THIRD BUFFER.

These display screens are selectable by pressing the PAGE key.

(1) Display of One Block Data Currently Executed

AUTO OPERATION		TST9. MIN		OTST9 N3		3	
BLOCK DATA		CURRENT		97/07/15 14:10:00		Tmm	
G00	M15	X	2000.000	S	0	Sr	0
G17	M115	Y	2000.000	Tc	0	So	0
G23	M131	Z	-1100.000	Tn	0		
G53	M135			M	0	Fm	0.000
G90	M137			H	0	Fr	0.000
G94	M139			D	0		
	M133	I	0.000			Pr	0
		J	0.000			Pe	0
		K	0.000	Np	0	Nr	0
		F	0.000			Ns	
		Fd	0.000	Hc		Cr	0
		Ft	0			Ce	0
		F1				BC	3
A-Mtd				EMPTY			
=BL =PR =BL =							
PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH		CHECK DATA	[EXTEND]
F1	F2	F3	F4	F5	F6	F7	F8

Fig. 6-10 Display of One Block Data Currently Executed

The following display data items are in common to the BUFFER, SECOND BUFFER, and THIRD BUFFER display screens.

- X : X-axis command value
- Y : Y-axis command value
- Z : Z-axis command value
- I : I command value
- J : J command value
- K : K command value
- F : Feedrate command value
- Fd : Feedrate command value (0.001 mm/6.4 ms)
- Ft : F command value for dwell
- F1 : Feedrate (F1-digit command)
- S : Spindle speed command value
- Sr : Actual spindle speed
- So : Actual spindle speed (overridden programmed S value)

Tc : Active tool number
 Tn : Next tool number
 M : M command value
 H : Tool length offset number
 D : Cutter radius compensation number
 Fm : Actual feedrate (mm/min)
 Fr : Actual feedrate (mm/rev)
 Pr : Main program repeat count by schedule operation
 Pe : Main program execution count by schedule operation
 Np : Hole number in coordinate calculation
 Nr : Hole number for restart
 Ns : Sequence specified by the sequence stop
 Hc : Work coordinate system number
 Cr : Number of subprogram to be repeated
 Ce : Number of subprogram actually repeated
 BC : Block counter
 EMPTY : No data in buffer
 (EXIST : Data existing in buffer)

[Supplement] For the additional axis specification, the data of the additional axes (first, second, third) is displayed below the "Z-axis" data.

(2) Display of One Block Data in Buffer (to be Executed Next)

AUTO OPERATION		TST9. MIN		OTST9 N3		3	
				97/07/15 14:10:00			
BLOCK DATA		BUFFER		1mm			
G00	M15	X	2000.000	S	0	Sr	0
G17	M115	Y	2000.000	Tc	0	So	0
G23	M131	Z	-1100.000	Tn	0		
G53	M135			M	0	Fm	0.000
G90	M137			H	0	Fr	0.000
G94	M139			D	0		
	M133	I	0.000			Pr	0
		J	0.000			Pe	0
		K	0.000	Np	0	Nr	0
		F	0.000			Ns	
		Fd	0.000	Hc		Cr	0
		Ft	0			Ce	0
		F1				BC	3
A-Mtd						EMPTY	
=BL							
=PR							
=BL							
=							
PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH		CHECK DATA	[EXTEND]
F1	F2	F3	F4	F5	F6	F7	F8

Fig. 6-11 Display of One Block Data in Buffer (to be Executed Next)

(3) Display of One Block Data in Second Buffer

AUTO OPERATION		TST9.MIN		OTST9 N3		3	
BLOCK DATA		SECOND BUFFER		97/07/15 14:10:00			
				1mm			
G00	M15	X	2000.000	S	0	Sr	0
G17	M115	Y	2000.000	Tc	0	So	0
G23	M131	Z	-1100.000	Tn	0		
G53	M135			M	0	Fm	0.000
G90	M137			H	0	Fr	0.000
G94	M139			D	0		
	M133	I	0.000			Pr	0
		J	0.000			Pe	0
		K	0.000	Np	0	Nr	0
		F	0.000			Ns	
		Fd	0.000	Hc		Cr	0
		Ft	0			Ce	0
		F1				BC	3
		A-Mtd		EMPTY			
=BL							
=PR							
=BL							
=							
PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH		CHECK DATA	[EXTEND]

F1 F2 F3 F4 F5 F6 F7 F8

Fig. 6-12 Display of One Block Data in Second Buffer

(4) Display of One Block Data in Third Buffer

AUTO OPERATION		A.MIN		0		N	
BLOCK DATA		THIRD BUFFER		97/07/15 14:10:00			
				1mm			
G00	M15	X	0.000	S	0	Sr	0
G17	M115	Y	0.000	Tc	0	So	0
G23	M131	Z	0.000	Tn	0		
G53	M135	W	0.000	M	0	Fm	0.000
G90	M137			H	0	Fr+OVERFLOW	
G94	M139			D	0		
	M133	I	0.000			Pr	0
	M326	J	0.000			Pe	0
		K	0.000	Np	0	Nr	0
		F				Ns	
		Fd	0.000	Hc	5	Cr	0
		Ft	0			Ce	0
		F1				BC	1
		A-Mtd		EMPTY			
=							
PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH		CHECK DATA	[EXTEND]

F1 F2 F3 F4 F5 F6 F7 F8

Fig. 6-13 Display of One Block Data in Third Buffer

5. ATC Tool Setting Data Display (Memory-Random ATC Specification)

Pressing function key [F8] (EXTEND) changes the key guidance display. Function key [F3] (TOOL DISPLAY) allows the ATC tool setting page to be accessed.

AUTO OPERATION				N 1	
				97/07/15 14:10:00	
* ATC TOOL SET (POT REF) *					
POT TOOL NO. NO.	POT TOOL NO. NO.	POT TOOL NO. NO.	POT TOOL NO. NO.		
1 001	11 011			:SPCY POT	NA
2 002	12 012			:ACT TOOL	020
3 003	13 013			:NXT TOOL	007
4 004	14 014				
5 005	15 015			:MAGAZINE	10
6 006	16 016				
7 007	17 017				
8 008	18 018				
9 009	19 019				
10 010	20 NA				
<div> <div>SET</div> <div></div> <div></div> <div>POT SEARCH</div> <div>TOOL SEARCH</div> <div></div> <div>QUIT</div> </div>					
<div> <div>F1</div> <div>F2</div> <div>F3</div> <div>F4</div> <div>F5</div> <div>F6</div> <div>F7</div> <div>F8</div> </div>					

Fig. 6-14 ATC Tool Set (Pot Reference) Screen

6. Message Display (Option)

In the operation mode, display the function guide and press function key [F7] (MESSAGE) and the messages in a program can be displayed.

While the display screen is in the message display mode, display page may be switched to the actual position display, program display, block display, and check display using a proper function key. The NMSG command in a program automatically returns the display mode from the message display mode to the original display mode. The message displayed on the display screen is the one specified in the program last.

Example:

```

N100      :
N101      :
N102 M00 MSG (CHECK TOOL!) ..... This automatically changes the display mode to
                                     the message mode and "CHECK TOOL!"
                                     appears on the display screen.
N103 NMSG ..... This restores the display mode to the original
                                     mode.
N104      :
N110 X100 Y100 (WORK FINISH) ..... Switching the display mode into the message by
                                     pressing function key allows the display screen to
                                     display the comment "WORK FINISH".
  
```




Fig. 6-15 Message Display Screen

7. Check Display

During operation in automatic, MDI, or manual mode, it is possible to check the NC axis data and the contents of the system variables by displaying them on the screen.

The following check items can be displayed.

Note that the actual display screens and check items will vary according the selected specifications.

1. NC specification codes
2. NC axis data
3. NC axis data enlarge display
4. Diagnostics
5. System variables – axis data
6. System variables – zero offset
7. System variables – tool offset
8. System variables – system parameter
9. System variables – home position
10. System variables – NC communication
11. System variables – other data

Select the data to be displayed by an NC optional parameter (bit) No. 5, bit 0 to bit 4.

Description of operating procedure:





Fig. 6-16 Displaying the CHECK DATA INDEX Page

(1) Press either MANUAL, MDI, or AUTO key.

(2) Press function key [F7] (CHECK DATA).

The screen displays a check data indications page.

(3) Press either the  or  page key to display the check data desired.

Pressing  once advances a page.

Pressing  once returns a page.

The SEARCH command displays the check data by one-touch operation, without repeatedly pressing the page key.

The explanation of operations (1) and (2) given above is omitted here as they both apply in this case.

(4) Press function key [F5] (SEARCH).

"= F" is displayed on the display screen console line.

(5) Enter the desired page number through the keyboard.


The input data is displayed following "= F □".

Example: = F □ 10

(6) Press the WRITE key.

This will display the desired check data.

When the WRITE key is pressed without inputting data following "= F □", the menu display shown below will be displayed.



The screenshot shows a screen titled "AUTO OPERATION" with a status bar at the top right displaying "N 1" and "97/07/15 14:10:00". Below the title is a "CHECK DATA INDEX" section. It contains two columns of items, each with a number and a description. The first column lists items 1 through 12, and the second column lists items 13 through 16. Below the list, there are two lines of text: "=F" followed by "Input a number of screen. !1" and another "=F" followed by "Input a number of screen. !". At the bottom of the screen is a row of eight buttons labeled F1 through F8. Below the buttons is a row of eight labels: PROGRAM SELECT, ACTUAL POSIT., PART PROGRAM, BLOCK DATA, SEARCH, ATC/APC, CHECK DATA, and [EXTEND].

NO.	ITEM	NO.	ITEM
* 1	NC SPEX TABLE	13	SYS. VAR. SYSTEM PARAMETER
2	NC AXIS DATA	14	SYS. VAR. HOME POSITION
3	NC AXIS DATA MAG. DISP.	15	SYS. VAR. NC COMMUNICATION
4	PLC AXIS DATA	16	SYS. VAR. VARIOUS DATA
5	PLC AXIS DATA MAG. DISP		
6	MEMORY DATA		
7	MCS DIAGNOSIS		
8	SYS. VAR. AXIS DATA		
9	SYS. VAR. ZERO OFFSET		
10	SYS. VAR. ZERO OFFSET MSB		
11	SYS. VAR. TOOL OFFSET		
12	SYS. VAR. TOOL OFFSET MSB		

=F
Input a number of screen. !1
=F
Input a number of screen. !

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1 F2 F3 F4 F5 F6 F7 F8

Fig. 6-17 Check Display Screen

Input the number for required item and press the WRITE key to display the first page of the required item screen.

7-1. Display Screen

7-1-1. NC Specification Codes

The NC SPEC TABLE screen has three pages and page selection is possible using the page keys.

AUTO OPERATION		N		1					
CHECK DATA		NC SPEC TABLE		97/07/15 14:10:00					
		PAGE1		1mm					
NO.	data	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
1	11111011=FB	SDRP	SBPR	ECAL	SYV	01DG	01MC	REVF	INML
2	10001010=8A	T100	T300	T200	Z050	Z020	3DCR	MOVOL	LSTR
3	00110000=30	BFUN	EPHD	PHD3	PHD2	PH1N	S6AX	S5AX	S4AX
4	11111111=FF	G50S	G62S	G61S	G43S	G92S	G31S	G60S	HELI
5	00000000=00	EPSN	OKUM	232C	F1PR	F1D4		F1DG	RAMC
6	01000100=44	MADS	FRPD		BLSM	EC-T	AX-T	EC-P	AX-P
7	10000000=80	GRTB	SYC5	RLT1	RLT0	SYC4	SYCZ	SYCY	SYCX
8	10100011=A3	EXP4	EXP2	GRP	PPC	IGF	FDF1	FDF0	COLR
9	00000000=00	AXCH	EXPB	EXPA	MIR6	MIR5	MIR4	BSP3	BSP2
10	00110111=37	E1GF	EPBK	MSG	G22S	G28S	MAP5	MAP4	MAP2
11	10101000=A8	SSTP	RET	AXSC	MEED	PHID	AXSL	JGNF	SFTH
12	00000000=00	E1ML	EGCA	DNC3	DNC2	DNC1	DNCB	DNCA	NPPC

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1	F2	F3	F4	F5	F6	F7	F8
----	----	----	----	----	----	----	----

Fig. 6-18 NC Specification Codes Screen

7-1-2. NC Axis Data

The NC axis data is displayed in decimal numbers on the display screen, as shown below.

AUTO OPERATION		N	
		97/07/15 14:10:00	
CHECK DATA	NC AXIS DATA	PAGE 4	1mm
	X	Y	Z
RDIF	0.001	0.001	0.001
ODIF	0.000	0.000	0.000
RCON	35999.999	35999.999	28799.999
RAPA	35999.998	35999.998	28799.998
RSAPA	0.000	0.000	0.000
RSVPVAR1	0.000	0.000	0.000
RSVPVAR2	0.000	0.000	0.000
RLEDATA	00000000	00000000	00000000
RFEDIDC	00000000	00000000	00000000
FIDFR(AK)	0000	0000	0000

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1	F2	F3	F4	F5	F6	F7	F8
----	----	----	----	----	----	----	----

Fig. 6-19 NC Axis Data Screen

- RDIF : Difference between calculated value and position encoder output
- ODIF : Difference between calculated value and position encoder output with acceleration/deceleration activated
- RCON : Calculated value
- RAPA : Position encoder output
- RSAPA : Position encoder output when contact with the touch setter is detected
- RSVPVAR1: Servo data (Designate the content of display with NC optional parameter (word) No. 10.)
- RSVPVAR2: Servo data (Designate the content of display with NC optional parameter (word) No. 10.)
- RLEDATA : Absolute scale data
- RFEDIDC : Position encoder data
- FIDFR(AK) : Indicates the inductosyn ON/OFF state.
- 0000 Inductosyn effective. For the axis for which inductosyn on/off is ineffective, "0000" is always displayed.
- 8080 Inductosyn ineffective.
- 8000 Inductosyn effective/ineffective status is changing from ineffective to effective.
- 0080 Inductosyn effective/ineffective status is changing from effective to ineffective.

SECTION 6 DISPLAY ON NC OPERATION PANEL

The NC axis data screens also include the following page where ODIF, RAPA, and LOAD values are displayed in enlarged characters. This page is displayed by pressing the page key from the screen indicated above.

AUTO OPERATION		N	
CHECK DATA	NC AXIS DATA	97/07/15 14:10:00	1mm
	ODIF	RAPA	LOAD %
X	0.000	35999.998	0
Y	0.000	35999.998	0
Z	0.000	28799.998	0

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
F1	F2	F3	F4	F5	F6	F7	F8

LOAD : Axis loaded status is displayed in %.

7-1-3. Diagnostics

Any memory content in the memory can be displayed in a designated format on the screen.

The diagnostics function is provided to be used by the machine tool manufacturer.








Fig. 6-20 Diagnostics Screen

- a) * : Displayed to the right of the diagnosis data: indicates the cursor key operation enabling position.

(Once a check address is set in the conventional manner, check address is increased or decreased in units of the data type being checked by pressing the cursor keys  ,  ,  ,  .)

- b) W : 2-byte indication of DCM data
L : 4-byte indication of DCM data

7-1-4. System Variables

The contents of the system variables are displayed on the screen.

Some of system variables (tool offset, etc.) cannot be displayed in one page. For such variables, the next page can be displayed by pressing the page key.

For details of the system variable names, refer to "System Variables" in the Programming Manual.

[Supplement] On the display screens where axis related system variables are displayed, those for the first additional axis are displayed to the right of the "Z-axis" data. For the second and third additional axes, the data is displayed on the page accessible by pressing function key [F8] (EXTEND) and [F6] (AXIS CHANGE).

(1) Axis Data

AUTO OPERATION		N 1	
		97/07/15 14:10:00	
CHECK DATA	SYSTEM VARIABLE	PAGE 10	1mm
	X	Y	Z
VRCO*	35999.999	35999.999	28799.999
VAPA*	35999.998	35999.998	28799.998
VSAP*	0.000	0.000	0.000
VDIN*	0.000	0.000	0.000
VALA*	0.000	0.000	0.000
VODM*	0.000	0.000	0.000
VDMP*	5243	5243	5243
VDDA*	256	256	256
VYDA*	3880	3880	3880
VDAM*	0	0	0

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1	F2	F3	F4	F5	F6	F7	F8
----	----	----	----	----	----	----	----

Fig. 6-21 System Variables Screen – Axis Data

(2) Zero Offset

AUTO OPERATION		N 1	
CHECK DATA		97/07/15 14:10:00	
SYSTEM VARIABLE		PAGE 11	1mm
VZOF*	[1]	X 0.000	Y 0.000 Z 0.000
	[2]	0.000	0.000 0.000
	[3]	-490.212	-108.797 -258.854
	[4]	-361.042	-108.797 -258.854
	[5]	59.645	41.201 -78.854
	[6]	-90.355	-108.799 -258.854
	[7]	-25.578	-389.835 -250.034
	[8]	-820.799	-389.835 -250.034
	[9]	-51.000	-108.800 -417.216
	[10]	-1.500	-388.800 -260.545

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1	F2	F3	F4	F5	F6	F7	F8
----	----	----	----	----	----	----	----

Fig. 6-22 System Variables Screen – Zero Offset

(3) Zero Offset (for system)

AUTO OPERATION		N 1	
CHECK DATA		97/07/15 14:10:00	
SYSTEM VARIABLE		PAGE 13	1mm
VSZO*	[1]	X 0.000	Y 0.000 Z 0.000
	[2]	0.000	0.000 0.000
	[3]	0.000	0.000 0.000
	[4]	0.000	0.000 0.000
	[5]	0.000	0.000 0.000
	[6]	0.000	0.000 0.000
	[7]	0.000	0.000 0.000
	[8]	0.000	0.000 0.000
	[9]	0.000	0.000 0.000
	[10]	0.000	0.000 0.000

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[拡張]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	------

F1	F2	F3	F4	F5	F6	F7	F8
----	----	----	----	----	----	----	----

Fig. 6-23 System Variables Screen – Zero Offset (for system)

(4) Tool Offset

AUTO OPERATION				N		1	
CHECK DATA				97/07/15 14:10:00			
SYSTEM VARIABLE				PAGE 18 1mm			
VTOFH[N]				VTOFD[N]			
NO.		NO.		NO.		NO.	
1	1.000	11	0.000	1	2.000	11	5.000
2	-65.974	12	-92.927	2	30.100	12	30.000
3	-65.629	13	-84.368	3	0.950	13	3.250
4	0.000	14	-85.932	4	0.000	14	3.990
5	0.000	15	-82.647	5	0.000	15	4.730
6	0.000	16	-76.238	6	0.000	16	5.500
7	0.000	17	-72.593	7	0.000	17	6.500
8	-92.110	18	-79.892	8	1.925	18	6.960
9	-71.620	19	-80.586	9	1.500	19	51.500
10	-68.702	20	-80.632	10	2.000	20	5.000

=

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1 F2 F3 F4 F5 F6 F7 F8

Fig. 6-24 System Variables Screen – Tool Offset

(5) Tool Offset (for system)

AUTO OPERATION				N		1	
CHECK DATA				97/07/15 14:10:00			
SYSTEM VARIABLE				PAGE 23 1mm			
VSTOH[N]				VSTOD[N]			
NO.		NO.		NO.		NO.	
1	0.000	11	0.000	1	0.000	11	0.000
2	0.000	12	0.000	2	0.000	12	0.000
3	0.000	13	0.000	3	0.000	13	0.000
4	0.000	14	0.000	4	0.000	14	0.000
5	0.000	15	0.000	5	0.000	15	0.000
6	0.000	16	0.000	6	0.000	16	0.000
7	0.000	17	0.000	7	0.000	17	0.000
8	0.000	18	0.000	8	0.000	18	0.000
9	0.000	19	0.000	9	0.000	19	0.000
10	0.000	20	0.000	10	0.000	20	0.000

=

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1 F2 F3 F4 F5 F6 F7 F8

Fig. 6-25 System Variables Screen – Tool Offset (for system)

(6) System Parameter

AUTO OPERATION		N	
		1	
		97/07/15 14:10:00	
CHECK DATA	SYSTEM VARIABLE	PAGE 26	1mm
	X	Y	Z
VPPL*	5000.000	5000.000	5000.000
VNPL*	-5000.000	-5000.000	-5000.000
VPSL*	5000.000	5000.000	5000.000
VNSL*	-5000.000	-5000.000	-5000.000
VINP*	0.100	0.100	0.100
VBLC*	0.000	0.000	0.000
VMOF*	36000.000	36000.000	28800.000
VHP *	0.020	0.020	0.020

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1	F2	F3	F4	F5	F6	F7	F8
----	----	----	----	----	----	----	----

Fig. 6-26 System Variables Screen – System Parameter

(7) Home Position

AUTO OPERATION		N	
		1	
		97/07/15 14:10:00	
CHECK DATA	SYSTEM VARIABLE	PAGE 27	1mm
	X	Y	Z
VHPP* [1]	200.000	200.000	200.000
[2]	200.000	200.000	200.000
[3]	300.000	300.000	300.000
[4]	40.000	0.000	0.000
[5]	0.000	0.000	0.000
[6]	0.000	0.000	0.000
[7]	0.000	0.000	0.000
[8]	0.000	0.000	0.000

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1	F2	F3	F4	F5	F6	F7	F8
----	----	----	----	----	----	----	----

Fig. 6-27 System Variables Screen – Home Position

(8) NC Communication Buffer

AUTO OPERATION				N 1	
CHECK DATA		SYSTEM VARIABLE		97/07/15 14:10:00	
				PAGE 31 1mm	
VNCOM[1]	00000000				
[2]	00000000				
[3]	00000000				
[4]	00000000				

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1
F2
F3
F4
F5
F6
F7
F8

Fig. 6-28 System Variables Screen – NC Communication Buffer

(9) Other Data

AUTO OPERATION				N 1	
CHECK DATA		SYSTEM VARIABLE		97/07/15 14:10:00	
				PAGE 32 1mm	
VPCNT	0	VFST	00000000=00		
VOK1	00000000=00	VINCH	01000010=42		
VOK2	00000000=00	VSPC0	10001010=8A		
VNLM	0	VSPSB	00010000=10		
VINTG	0	VMLOK	00000000=00		
VPRT	00000000=00	VACOD	0		
VMPC1	00000000=00	VFDMX	100000		
VMPC2	00000000=00	VFSOV	100		
VMPT	00000000=00	VTLNN	7		
VTLCN	7	VSTM	00000000=00		
VINS	01000010=42				
VINF	00000000=00				

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1
F2
F3
F4
F5
F6
F7
F8

Fig. 6-29 System Variables Screen – Other Data

7-1-5. PLC Axis Data

The PLC axis data is displayed in decimal numbers on the display screen, as shown below.

AUTO OPERATION		N 1	
CHECK DATA		97/07/15 14:10:00	
PLC AXIS DATA		PAGE 6 1mm	
	MA	TS	
RDIF	0.000	0.000	
ODIF	0.000	0.000	
RCON	0.000	359.999	
RAPA	0.000	359.998	
RCOM	0.000	359.999	
RCCON	0.000	359.999	
RCAPA	0.000	359.998	
RSVVAR1	0.000	0.000	
RSVVAR2	0.000	0.000	

PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH	ATC/APC	CHECK DATA	[EXTEND]
-------------------	------------------	-----------------	---------------	--------	---------	---------------	----------

F1	F2	F3	F4	F5	F6	F7	F8
----	----	----	----	----	----	----	----

Fig. 6-30 PLC Axis Data Screen

- RDIF : Difference between calculated value and position encoder output
- ODIF : Difference between calculated value and position encoder output with acceleration/deceleration activated
- RCON : Calculated value
- RAPA : Position encoder output
- RCOM : Command value
- RCCON : This is the RCON with the position encoder offset incorporated (applies to systems with axis switching specifications).
- RCAPA : This is the RAPA with the position encoder offset incorporated (applies to systems with axis switching specifications).
- RAVVAR1 : Servo data (Designate the content of display with NC optional parameter (word) No. 10.)
- RAVVAR2 : Servo data (Designate the content of display with NC optional parameter (word) No. 10.)
- WA : Crossrail
- MA : Magazine
- TS : Varies depending on the machine being used. Refer to the Maintenance Manual for the machine in question.
- TI : Varies depending on the machine being used. Refer to the Maintenance Manual for the machine in question.

Additionally, the machine axis data enlarge display screen displaying ODIF, RAPA and load data in enlarged characters is provided.

AUTO OPERATION		N		1
CHECK DATA		97/07/15 14:10:00 1mm		
PLC AXIS DATA				
	ODIF	RAPA	LOAD	%
MA	0.000	0.000	0	
TS	0.000	359.998	0	
=				
PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH
ATC/APC		CHECK DATA	[EXTEND]	
F1	F2	F3	F4	F5
F6	F7	F8		

7-1-6. MCS Diagnostics

AUTO OPERATION		N		1
CHECK DATA		97/07/15 14:10:00 PAGE 9 1mm		
MCS DIAGNOSIS				
MACHINE COORDS		X -0.001	Y -0.001	Z -0.001
	AXIS	COM.CODE	DATA ID	DATA
* CH 1	****	**	****	*****
CH 2	****	**	****	*****
CH 3	****	**	****	*****
CH 4	****	**	****	*****
=				
PROGRAM SELECT	ACTUAL POSIT.	PART PROGRAM	BLOCK DATA	SEARCH
ATC/APC		CHECK DATA	[EXTEND]	
F1	F2	F3	F4	F5
F6	F7	F8		

Fig. 6-31 MCS Diagnostics Screen

8. Run Guide Display

After selecting the EDIT AUX mode, press function key [F7] (RUN GUIDE), and the RUN GUIDE screen is displayed.

(1) RUNNING FILE

The operation status of the file currently selected is displayed at the left half area on the screen.




Fig. 6-32 Running File Display

(a) File selection method

This field indicates how the file has been selected and is being operated.

Display	Contents
EXTERNAL SELECT MODE	Operation by external program selection command
SCHEDULE MODE	Scheduled program operation
MANUAL SELECT MODE	Operation by manual program selection

(b) MAIN FILE NAME

This field indicates the main file name currently selected.

(c) MAIN PROGRAM NAME

This field indicates the main file program name currently selected.

(d) RUNNING METHOD

This field indicates the operation method of the program currently selected.

Display	Contents
A-Mtd	Normal operation
B-Mtd	Large volume operation
S-Mtd	Operation without branching and subprogram

(e) Operation status

This field indicates the current operation status of the program selected.

Display	Contents
SELECTED	Program selection complete, but it is not run.
RUNNING	Program is being executed.
END	Program execution has been completed; this display is given until the next program is selected or the next cycle is started.

(2) SELECT ERROR FILE

If an error occurred during automatic program selection, file is displayed at the right half of the screen.

PROGRAM OPERATION RUN GUIDE

2203 ALARM B Schedule program: main program load 10000002

RUNNING FILE SELECT ERROR FILE

SCHEDULE MODE
SCHEDULE PROGRAM FILE
TST9.MIN END
MAIN PROGRAM NAME
OTST9

MAIN FILE NAME
GEAR.MIN (f)
MAIN PROGRAM NAME
0100 (g)
SUB FILE NAME
EMPTY (h)
SELECT RUNNING METHOD
A-Mtd (i)

RUNNING METHOD
A-Mtd

=EX
=GO
=

TIME INIT DELETE RENAME RUN GUIDE [EXTEND]

F1 F2 F3 F4 F5 F6 F7 F8

Fig. 6-33 Select Error File Display

(f) MAIN FILE NAME

This field indicates the main file name selected if a program selection error has occurred.

(g) MAIN PROGRAM NAME

This field indicates the main file program name selected if a program selection error has occurred.

(h) SUB FILE NAME

This field indicates the sub file name selected if a program selection error has occurred.

(i) SELECTED RUNNING METHOD

This field indicates the operation method selected when a program selection error has occurred. The operation method is explained in detail in d) in (1), "RUNNING FILE".