



Software Manual

AS560X

Demo Software

Table of Contents

1	Introduction	3
2	Getting Started	3
3	Detailed Description	4
3.1	Start Screen	4
3.2	General AS560X description	5
3.2.1	IC settings	5
3.2.1.1	Power Mode	5
3.2.1.2	Watchdog	5
3.2.1.3	Fast filter threshold	5
3.2.1.4	Slow filter step response	6
3.2.1.5	Permanently programming	6
3.3	AS5600 specific description	7
3.3.1	Visualization	7
3.3.2	Output Options	8
3.3.3	Setting Zero Position and Maximum Angle	9
3.3.4	Setting an Angular Range	10
3.4	AS5601 specific description	10
3.4.1	Visualization	10
3.4.2	Setting the resolution	11
3.4.3	Setting the grid offset	11
3.4.4	Setting the push threshold	12
4	Firmware Update	13
4.1	Firmware Update	13
4.2	Firmware update in bootloader mode	13
5	Contact Information	14
6	Copyrights & Disclaimer	15
7	Revision Information	16

1 Introduction

The Demo Board Software was designed to show the features and benefits of AS6500 IC. It also provides an easy use to evaluation and lab programming interface.

The Software supports different hardware applications:

- DemoBoard: AS560X-DK_ST
- USB I&P Box Programmer
(The AS560X demo software is integrated in the USB I&P Box software)

Note: The software is not intended for use in production and must not be used for this purpose.

2 Getting Started

The AS560X demo software is ideal for demonstrating the AS560X product features. This first step describes how to connect and use an AS560X demo kit together with the AS560X Demo Software and the adapter board.

1st Install the AS560X Demo Software

The Software is located on the USB drive that comes with a Demo Kit or it can be downloaded from our webpage. After installation run the software.

2nd Check the Hardware Setup

Set-up the hardware correctly. For details refer to the specific hardware manual. Of the USB I&P Box or of the AS560X-DK_ST.


Note: It might be necessary to perform a firmware update on the Demo Kit if a wrong firmware was detected. In this case, the user will be prompted to allow an automatic firmware upgrade.

3rd Start using the software

Following parts of the software are used to perform a configuration and to read-out the AS5600. Refer to Figure 1 for reference.

- A. Perform the desired configuration
- B. Perform the required angle programming. Use the wizard function for reference.
- C. Verify the results

Figure 1:
General Software Instructions (Example: AS5600)




3 Detailed Description

Find the detailed description of the demo software below.

3.1 Start Screen

Figure 2:
Demo software start screen




Note: Please connect a hardware if the status line at the bottom of the window shows a red box with the message: "Not Identified"

3.2 General AS560X description

3.2.1 IC settings

Figure 3:
AS560X Settings



Note: For details refer to the product datasheet.

3.2.1.1 Power Mode

Three low power modes are available.

Figure 4:
AS560X Power Modes

Power Mode	Polling Time (ms)
NOM	Always on
LPM1	5
LPM2	20
LPM3	100


3.2.1.2 Watchdog

If the angle doesn't change, the AS5600 automatically enters LPM3 after one minute.

3.2.1.3 Fast filter threshold

The fast filter improves noise suppression during fast angle changes.

Figure 5:
AS560X Fast Filter Threshold




Example: The fast filter threshold is set on “Slow to fast>6LSB, Fast to slow<=1LSB”. This means when the angle changes with minimum 6 LSB the fast filter is activated. When the angle changes with maximum 1 LSB the slow filter is activated.

3.2.1.4 Slow filter step response

The fast filter improves noise suppression during slow angle changes. The slow filter response time can be set under Slow Filter. The response time of the slow filter is depending on the sampling time.

Figure 6:
AS560X Slow Filter Settings




Example: Slow Filter is set on 2x. This means that the step response is twice larger as the sampling time.

3.2.1.5 Permanently programming

The AS560X comes with an internal OTP block which allows the user to permanently program an output range as well as a configuration. There are two command available which will affect different registers. The Burn Settings command is used to burn a configuration and angular range. A Start and Stop position is programmed using the Burn Angle command. For details refer to the datasheet.

Figure 7:
AS5600 Setting an Angular Range



Power mode: **NOM**

☐ Watch dog

Hysteresis: **off**

Output: **0 - VDD**

Fast Filter threshold:
slow filter only

Slow Filter: **16x (forced for LPM)**

Burn settings **Burn Settings**

* Magnetic angle: **62.2°**

Max. Position: **90.0°**

Zero position: **30**

Angular excursion: **60**

Burn positions **Burn Positions** **3 burns remaining**

3.3 AS5600 specific description

The GUI Elements of the AS5600 are described below in detail.

3.3.1 Visualization

Figure 8:
Visualization of the user defined range

Example settings: Zero Position= 30°
 Maximum Position= 90°





Figure 9:
Output Graph




3.3.2 Output Options

Three output signal types are closeable:


- Analog output signal: 0-VDD
- Analog output signal: 10%- 90%VDD
- PWM output

Figure 10:
AS560X Analog output 0-VDD




Minimum possible limit is 0V and maximum possible limit is VDD voltage.

Figure 11:
AS560X Analog output 10%-90%VDD



Minimum possible limit is 10% from VDD voltage and maximum possible limit is 90% from VDD voltage.

Figure 12:
AS560X PWM output




Four different PWM frequencies can be chosen.

3.3.3 Setting Zero Position and Maximum Angle

For detail description how to set zero position and maximum position see “Zero & Maximum Position Wizard”. When a position is set the actual output values and the visualization graph are adapt to the new setting.

Figure 13:
AS5600 Main screen with Zero Position and Maximum Angel setting



3.3.4 Setting an Angular Range

For detail description how to set zero position and angel excursion see “Zero Position & Angle Offset Wizard”. When a position or excursion is set the actual output values and the visualization graph are adapt to the new setting.

3.4 AS5601 specific description

The GUI Elements of the AS5600 are described below in detail.


3.4.1 Visualization

The output of the AS5601 is shown in the GUI on the left side and shows a menu to set the resolution at the top. Below that, a round knob display is indicating the electrical and mechanical positions as well as the push output.

Under the knob display, there is a graph showing the AB signal. This may be deactivated for some software versions of the USB I&P Box software.

At the bottom, the AGC value as well as the magnitude level is indicated.


Figure 14:
AS5601 Visualization



3.4.2 Setting the resolution

The first step is to set up the correct number of output cycles for the incremental interface. This is done by setting the resolution. For example for a grid with 16 positions we set up a resolution of 4bit to get four output cycles over a full turn. The change of the incremental signal would change one count per position.


Figure 15:
AS5601 Resolution setup



3.4.3 Setting the grid offset

To move the electrical switch position exactly between two mechanical positions please follow the Grid Offset Wizard Instructions.

Figure 16:
AS5601 Grid offset configuration

3.4.4 Setting the push threshold

To configure the push threshold, calculate the correct value and enter it into the textbox as shown below.

Figure 17:
AS5601 Push threshold configuration



Figure 18:
AS5601 Push threshold calculation

$$PUSHTHR = \frac{AGC_{NOPUSH} - ACGPUSH}{2}$$

$$(Example = \frac{90-56}{2} = 17)$$

4 Firmware Update


Depending on the current version of the hardware it might be necessary to perform a firmware update. The firmware update can be performed using the software if an old version of the firmware was detected by the software. If the hardware doesn't detect a compatible device, the firmware must be uploaded in bootloader mode.

4.1 Firmware Update

These steps are required to update the firmware.

- 1) click on Help -> Firmware Update
- 2) Open bin file

Figure 19:
Firmware update menu



4.2 Firmware update in bootloader mode

Perform following steps to reinitialize the firmware.

- 1) Open USB I&P Box Programmer
- 2) Short pin3 and 4 (see picture) to enable the bootloader mode
- 3) Start Demo Board Software
- 4) Click on Help -> Firmware Update
- 5) Open bin file for bootloader

Figure 20:
Firmware update – enable bootloader mode



Figure 21:
Start screen - bootloader detected

**ams USB Bootloader detected.
Please start Firmware Upgrade in Help Menu.**

5 Contact Information

Buy our products or get free samples online at:

www.ams.com/ICdirect

Technical Support is available at:

www.ams.com/Technical-Support

Provide feedback about this document at:

www.ams.com/Document-Feedback

For further information and requests, e-mail us at:

ams_sales@ams.com

For sales offices, distributors and representatives, please visit:

www.ams.com/contact

Headquarters

ams AG

Tobelbaderstrasse 30

8141 Unterpremstaetten

Austria, Europe

Tel: +43 (0) 3136 500 0

Website: www.ams.com

6 Copyrights & Disclaimer

Copyright ams AG, Tobelbader Strasse 30, 8141 Unterpremstaetten, Austria-Europe. Trademarks Registered. All rights reserved. The material herein may not be reproduced, adapted, merged, translated, stored, or used without the prior written consent of the copyright owner.

Demo Kits, Evaluation Kits and Reference Designs are provided to recipient on an “as is” basis for demonstration and evaluation purposes only and are not considered to be finished end-products intended and fit for general consumer use, commercial applications and applications with special requirements such as but not limited to medical equipment or automotive applications. Demo Kits, Evaluation Kits and Reference Designs have not been tested for compliance with electromagnetic compatibility (EMC) standards and directives, unless otherwise specified. Demo Kits, Evaluation Kits and Reference Designs shall be used by qualified personnel only.

ams AG reserves the right to change functionality and price of Demo Kits, Evaluation Kits and Reference Designs at any time and without notice.

Any express or implied warranties, including, but not limited to the implied warranties of merchantability and fitness for a particular purpose are disclaimed. Any claims and demands and any direct, indirect, incidental, special, exemplary or consequential damages arising from the inadequacy of the provided Demo Kits, Evaluation Kits and Reference Designs or incurred losses of any kind (e.g. loss of use, data or profits or business interruption however caused) as a consequence of their use are excluded.

ams AG shall not be liable to recipient or any third party for any damages, including but not limited to personal injury, property damage, loss of profits, loss of use, interruption of business or indirect, special, incidental or consequential damages, of any kind, in connection with or arising out of the furnishing, performance or use of the technical data herein. No obligation or liability to recipient or any third party shall arise or flow out of ams AG rendering of technical or other services.



7 Revision Information

Version 1-01

Changes from 1-00 (2014-Jul-2) to current revision 1-01 (2014-Jul-2)	Page
Added AS5601 software description.	

Note: Page numbers for the previous version may differ from page numbers in the current revision.