

Last LPF and Cap Pinout

Configuration and placing: With 1-8 left to right, Large Cap in top left:

1=In (from last stage OUT)

3,4,5=GND (0V)

6,7=Out (to spkr)

8=In (from last stage OUT)

—