

DFR0534

1.0.4

Generated by Doxygen 1.12.0



<b>1 DFR0534</b>	<b>1</b>
1.1 SoftwareSerial for Arduino Uno/Nano/ATmega328p	1
1.2 HardwareSerial for ESP32	1
1.3 License and copyright	2
1.4 Appendix	3
1.4.1 DFR0534 pinout	3
<b>2 Class Index</b>	<b>5</b>
2.1 Class List	5
<b>3 File Index</b>	<b>7</b>
3.1 File List	7
<b>4 Class Documentation</b>	<b>9</b>
4.1 DFR0534 Class Reference	9
4.1.1 Detailed Description	11
4.1.2 Member Enumeration Documentation	11
4.1.2.1 DFR0534CHANNELS	11
4.1.2.2 DFR0534DRIVE	11
4.1.2.3 DFR0534EQ	12
4.1.2.4 DFR0534LOOPMODE	12
4.1.2.5 DFR0534STATUS	13
4.1.3 Constructor & Destructor Documentation	13
4.1.3.1 DFR0534()	13
4.1.4 Member Function Documentation	14
4.1.4.1 decreaseVolume()	14
4.1.4.2 fastBackwardDuration()	14
4.1.4.3 fastForwardDuration()	14
4.1.4.4 getDrive()	14
4.1.4.5 getDrivesStates()	15
4.1.4.6 getDuration()	17
4.1.4.7 getFileName()	18
4.1.4.8 getFileNumber()	19
4.1.4.9 getFirstFileNumberInCurrentDirectory()	20
4.1.4.10 getRuntime()	21
4.1.4.11 getStatus()	22
4.1.4.12 getTotalFiles()	23
4.1.4.13 getTotalFilesInCurrentDirectory()	24
4.1.4.14 increaseVolume()	25
4.1.4.15 insertFileByNumber()	26
4.1.4.16 pause()	26
4.1.4.17 play()	26
4.1.4.18 playCombined()	26

4.1.4.19 playFileByName()	27
4.1.4.20 playFileByNumber()	28
4.1.4.21 playLastInDirectory()	28
4.1.4.22 playNext()	29
4.1.4.23 playNextDirectory()	29
4.1.4.24 playPrevious()	29
4.1.4.25 prepareFileByNumber()	29
4.1.4.26 repeatPart()	30
4.1.4.27 setChannel()	30
4.1.4.28 setDirectory()	30
4.1.4.29 setDrive()	31
4.1.4.30 setEqualizer()	31
4.1.4.31 setLoopMode()	32
4.1.4.32 setRepeatLoops()	32
4.1.4.33 setVolume()	32
4.1.4.34 startSendingRuntime()	33
4.1.4.35 stop()	33
4.1.4.36 stopCombined()	33
4.1.4.37 stopInsertedFile()	34
4.1.4.38 stopRepeatPart()	34
4.1.4.39 stopSendingRuntime()	34
<b>5 File Documentation</b>	<b>35</b>
5.1 playCombined.ino	35
5.2 playFileByName.ino	36
5.3 playFileByNumber.ino	37
5.4 DFR0534.cpp File Reference	38
5.4.1 Detailed Description	38
5.5 DFR0534.cpp	40
5.6 DFR0534.h File Reference	51
5.6.1 Detailed Description	51
5.6.2 Macro Definition Documentation	52
5.6.2.1 DFR0534_VERSION	52
5.7 DFR0534.h	52
<b>Index</b>	<b>55</b>

# Chapter 1

## DFR0534

An Arduino Uno/Nano/ATmega328p, ESP32 library for a [DFR0534](#) audio module. The library works with SoftwareSerial/HardwareSerial and is very similar to [https://github.com/sleemanj/JQ8400\\_↵](https://github.com/sleemanj/JQ8400_↵) [Serial](#), but is no fork.

Examples, how to use the library

- [examples/playFileName/playFileName.ino](#)
- [examples/playFileByNumber/playFileByNumber.ino](#)
- [examples/playCombined/playCombined.ino](#)

### 1.1 SoftwareSerial for Arduino Uno/Nano/ATmega328p

To create a [DFR0534](#) object pass the SoftwareSerial object as a parameter to the [DFR0534](#) constructor, for example

```
#include <SoftwareSerial.h>
#include <DFR0534.h>

#define TX_PIN A0
#define RX_PIN A1
SoftwareSerial g_serial(RX_PIN, TX_PIN);
DFR0534 g_audio(g_serial);
...
```

### 1.2 HardwareSerial for ESP32

To create a [DFR0534](#) object pass the HardwareSerial object as a parameter to the [DFR0534](#) constructor, for example

```
#include <DFR0534.h>

#define TX_PIN 19
#define RX_PIN 23
HardwareSerial g_serial(1);

DFR0534 g_audio(g_serial);

void setup() {
  g_serial.begin(9600, SERIAL_8N1, RX_PIN, TX_PIN);
  ...
}
```

## 1.3 License and copyright

This library is licensed under the terms of

BSD 2-Clause License

Copyright (c) 2024, codingABI All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

## 1.4 Appendix

### 1.4.1 DFR0534 pinout




Figure 1.1 DFR0534 frontside




Figure 1.2 DFR0534 backside

Minimal schematic to use this library

Pin	Connected to
TX	SoftwareSerial/HardwareSerial RX
RX	SoftwareSerial/HardwareSerial TX*
GND	Ground
VCC	3.3-5V
SP+	Speaker + connector
SP-	Speaker - connector

\*If your microcontroller runs at 5V, use a 1k resistor between RX and SoftwareSerial/HardwareSerial TX.



## Chapter 2

# Class Index

### 2.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

<a href="#">DFR0534</a>	
Class for a <a href="#">DFR0534</a> audio module	9



## Chapter 3

# File Index

### 3.1 File List

Here is a list of all documented files with brief descriptions:

<a href="#">playCombined.ino</a>	35
<a href="#">playFileByName.ino</a>	36
<a href="#">playFileByNumber.ino</a>	37
<a href="#">DFR0534.cpp</a>	38
<a href="#">DFR0534.h</a>	51



# Chapter 4

## Class Documentation

### 4.1 DFR0534 Class Reference

Class for a [DFR0534](#) audio module.

```
#include <DFR0534.h>
```

#### Public Types

- enum [DFR0534CHANNELS](#) { [CHANNELMP3](#) , [CHANNELAUX](#) , [CHANNELMP3AUX](#) , [CHANNELUNKNOWN](#) }
- enum [DFR0534DRIVE](#) { [DRIVEUSB](#) , [DRIVESD](#) , [DRIVEFLASH](#) , [DRIVEUNKNOWN](#) , [DRIVENO](#) = 0xff }
- enum [DFR0534LOOPMODE](#) { [LOOPBACKALL](#) , [SINGLEAUDIOLOOP](#) , [SINGLEAUDIOSTOP](#) , [PLAYRANDOM](#) , [DIRECTORYLOOP](#) , [RANDOMINDIRECTORY](#) , [SEQUENTIALINDIRECTORY](#) , [SEQUENTIAL](#) , [PLAYMODEUNKNOWN](#) }
- enum [DFR0534EQ](#) { [NORMAL](#) , [POP](#) , [ROCK](#) , [JAZZ](#) , [CLASSIC](#) , [EQUNKNOWN](#) }
- enum [DFR0534STATUS](#) { [STOPPED](#) , [PLAYING](#) , [PAUSED](#) , [STATUSUNKNOWN](#) }

#### Public Member Functions

- [DFR0534](#) (Stream &stream)  
*Constructor of a the [DFR0534](#) audio module.*
- void [decreaseVolume](#) ()  
*Decrease volume by one step.*
- void [fastBackwardDuration](#) (word seconds)  
*Fast backward in seconds.*
- void [fastForwardDuration](#) (word seconds)  
*Fast forward in seconds.*
- byte [getDrive](#) ()  
*Get current drive.*
- byte [getDrivesStates](#) ()

- Checks which drives are ready/online.*

  - bool [getDuration](#) (byte &hour, byte &minute, byte &second)

*Get duration/length of current file.*
- bool [getFileName](#) (char \*name)

*Get name for current file.*
- word [getFileNumber](#) ()

*Get file number of current file.*
- int [getFirstFileNumberInCurrentDirectory](#) ()

*Get number of first file in current directory.*
- bool [getRuntime](#) (byte &hour, byte &minute, byte &second)

*Get elapsed runtime/duration of the current file.*
- byte [getStatus](#) ()

*Get module status.*
- int [getTotalFiles](#) ()

*Get total number of supported audio files on current drive.*
- int [getTotalFilesInCurrentDirectory](#) ()

*Count all audio files for the current directory.*
- void [increaseVolume](#) ()

*Increase volume by one step.*
- void [insertFileByNumber](#) (word track, byte drive=[DRIVEFLASH](#))

*Pause current file and play another file by number.*
- void [pause](#) ()

*Pause the current file.*
- void [play](#) ()

*Play the current selected file.*
- void [playCombined](#) (char \*list)

*Combined/concatenated play of files.*
- void [playFileByName](#) (char \*path, byte drive=[DRIVEFLASH](#))

*Play audio file by file name/path.*
- void [playFileByNumber](#) (word track)

*Play audio file by number.*
- void [playLastInDirectory](#) ()

*Play last file in directory (in "file copy order")*
- void [playNext](#) ()

*Play next file (in "file copy order")*
- void [playNextDirectory](#) ()

*Play first file in next directory (in "file copy order")*
- void [playPrevious](#) ()

*Play previous file (in "file copy order")*
- void [prepareFileByNumber](#) (word track)

*Select file by number, but not start playing.*
- void [repeatPart](#) (byte startMinute, byte startSecond, byte stopMinute, byte stopSecond)

*Repeat part of the current file.*
- void [setChannel](#) (byte channel)

*Set output for DAC to channel MP3, AUX or both.*
- void [setDirectory](#) (char \*path, byte drive=[DRIVEFLASH](#))

*Should set directory, but does not work for me.*
- void [setDrive](#) (byte drive)

*Switch to drive.*
- void [setEqualizer](#) (byte mode)

*Set equalizer to NORMAL, POP, ROCK, JAZZ or CLASSIC.*

- void [setLoopMode](#) (byte mode)  
*Set loop mode.*
- void [setRepeatLoops](#) (word loops)  
*Set repeat loops.*
- void [setVolume](#) (byte volume)  
*Set volume.*
- void [stop](#) ()  
*Stop the current file.*
- void [stopInsertedFile](#) ()  
*Stop inserted file.*
- void [startSendingRuntime](#) ()  
*Start sending elapsed runtime every 1 second.*
- void [stopCombined](#) ()  
*Stop combined play (playlist)*
- void [stopRepeatPart](#) ()  
*Stop repeating part of the current file.*
- void [stopSendingRuntime](#) ()  
*Stop sending runtime.*

### 4.1.1 Detailed Description

Class for a [DFR0534](#) audio module.

Definition at line 32 of file [DFR0534.h](#).

### 4.1.2 Member Enumeration Documentation

#### 4.1.2.1 DFR0534CHANNELS

enum [DFR0534::DFR0534CHANNELS](#)

Supported input channels

Enumerator

CHANNELMP3	Use MP3 input channel for DAC output (=default after device startup)
CHANNELAUX	Use AUX input (P26 and P27) for DAC output
CHANNELMP3AUX	Combines MP3 and AUX audio from P26 and P27 for DAC output
CHANNELUNKNOWN	Unknown

Definition at line 35 of file [DFR0534.h](#).

```
00036 {
00037     CHANNELMP3,
00038     CHANNELAUX,
00039     CHANNELMP3AUX,
00040     CHANNELUNKNOWN
00041 };
```

#### 4.1.2.2 DFR0534DRIVE

enum [DFR0534::DFR0534DRIVE](#)

Supported drives

## Enumerator

DRIVEUSB	USB drive
DRIVESD	SD card
DRIVEFLASH	Flash memory chip
DRIVEUNKNOWN	Unknown
DRIVENO	No drive

Definition at line 43 of file [DFR0534.h](#).

```
00044 {
00045     DRIVEUSB,
00046     DRIVESD,
00047     DRIVEFLASH,
00048     DRIVEUNKNOWN,
00049     DRIVENO = 0xff
00050 };
```

## 4.1.2.3 DFR0534EQ

```
enum DFR0534::DFR0534EQ
```

## EQ modes

## Enumerator

NORMAL	(=default after device startup)
--------	---------------------------------

Definition at line 65 of file [DFR0534.h](#).

```
00066 {
00067     NORMAL,
00068     POP,
00069     ROCK,
00070     JAZZ ,
00071     CLASSIC,
00072     EQUNKNOWN
00073 };
```

## 4.1.2.4 DFR0534LOOPMODE

```
enum DFR0534::DFR0534LOOPMODE
```

## Loop modes

## Enumerator

LOOPBACKALL	Every file on drive in "file copy order" and loop afterwards
SINGLEAUDIOLOOP	Repeat current file
SINGLEAUDIOSTOP	Stops after single file (=default after device startup)
PLAYRANDOM	Random play order
DIRECTORYLOOP	Every file in current director in "file copy order" and loop afterwards
RANDOMINDIRECTORY	Random play order in current directory
SEQUENTIALINDIRECTORY	Every file in current directory in "file copy order" without loop
SEQUENTIAL	Every file on drive in "file copy order" without loop
PLAYMODEUNKNOWN	Unknown



Definition at line 52 of file [DFR0534.h](#).

```
00053     {
00054         LOOPBACKALL,
00055         SINGLEAUDIOLOOP,
00056         SINGLEAUDIOSTOP,
00057         PLAYRANDOM,
00058         DIRECTORYLOOP,
00059         RANDOMINDIRECTORY,
00060         SEQUENTIALINDIRECTORY,
00061         SEQUENTIAL,
00062         PLAYMODEUNKNOWN
00063     };
```

#### 4.1.2.5 DFR0534STATUS

enum [DFR0534::DFR0534STATUS](#)

Modul states

Enumerator

STOPPED	Audio module is idle
PLAYING	Audio module is playing a file
PAUSED	Audio module is paused
STATUSUNKNOWN	Unkown

Definition at line 75 of file [DFR0534.h](#).

```
00076     {
00077         STOPPED,
00078         PLAYING,
00079         PAUSED,
00080         STATUSUNKNOWN
00081     };
```

### 4.1.3 Constructor & Destructor Documentation

#### 4.1.3.1 DFR0534()

```
DFR0534::DFR0534 (
    Stream & stream) [inline]
```

Constructor of a the [DFR0534](#) audio module.

Parameters

in	<i>stream</i>	Serial connection object, like SoftwareSerial or HardwareSerial
----	---------------	---

Definition at line 87 of file [DFR0534.h](#).

```
00088     {
00089         m_ptrStream = &stream;
00090     }
```

## 4.1.4 Member Function Documentation

### 4.1.4.1 decreaseVolume()

```
void DFR0534::decreaseVolume ()
```

Decrease volume by one step.

Definition at line 747 of file [DFR0534.cpp](#).

```
00748 {
00749     if (m_ptrStream == NULL) return; // Should not happen
00750     sendStartingCode();
00751     sendDataByte(0x15);
00752     sendDataByte(0x00);
00753     sendChecksum();
00754 }
```

### 4.1.4.2 fastBackwardDuration()

```
void DFR0534::fastBackwardDuration (
    word seconds)
```

Fast backward in seconds.

Parameters

in	<i>seconds</i>	Seconds to go backward
----	----------------	------------------------

Definition at line 1023 of file [DFR0534.cpp](#).

```
01024 {
01025     if (m_ptrStream == NULL) return; // Should not happen
01026     sendStartingCode();
01027     sendDataByte(0x22);
01028     sendDataByte(0x02);
01029     sendDataByte((seconds » 8) & 0xff);
01030     sendDataByte(seconds & 0xff);
01031     sendChecksum();
01032 }
```

### 4.1.4.3 fastForwardDuration()

```
void DFR0534::fastForwardDuration (
    word seconds)
```

Fast forward in seconds.

Parameters

in	<i>seconds</i>	Seconds to go forward
----	----------------	-----------------------

Definition at line 1040 of file [DFR0534.cpp](#).

```
01041 {
01042     if (m_ptrStream == NULL) return; // Should not happen
01043     sendStartingCode();
01044     sendDataByte(0x23);
01045     sendDataByte(0x02);
01046     sendDataByte((seconds » 8) & 0xff);
01047     sendDataByte(seconds & 0xff);
01048     sendChecksum();
01049 }
```

### 4.1.4.4 getDrive()

```
byte DFR0534::getDrive ()
```

Get current drive.

## Return values

<a href="#"><i>DFR0534::DRIVEUSB</i></a>	USB drive
<a href="#"><i>DFR0534::DRIVESD</i></a>	SD card
<a href="#"><i>DFR0534::DRIVEFLASH</i></a>	Flash memory chip
<a href="#"><i>DFR0534::DRIVENO</i></a>	No drive found
<a href="#"><i>DFR0534::DRIVEUNKNOWN</i></a>	Error (for example request timeout)

Definition at line 344 of file [DFR0534.cpp](#).

```

00345 {
00346     #define COMMAND 0x0A
00347     #define RECEIVEBYTETIMEOUTMS 100
00348     #define RECEIVEGLOBALTIMEOUTMS 500
00349     #define RECEIVEFAILED DRIVEUNKNOWN
00350     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00351
00352     if (m_ptrStream == NULL) return RECEIVEFAILED; // Should not happen
00353     sendStartingCode();
00354     sendDataByte(COMMAND);
00355     sendDataByte(0x00);
00356     sendChecksum();
00357
00358     // Receive
00359     int i=0;
00360     byte data, firstByte = 0, sum, length=0xff, result = 0;
00361     unsigned long receiveStartMS = millis();
00362     do {
00363         byte dataReady = 0;
00364         unsigned long lastMS = millis();
00365         // Wait for response or timeout
00366         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00367
00368         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00369         data = m_ptrStream->read();
00370
00371         if (i==0) { // Begin of transmission
00372             firstByte=data;
00373             sum = 0;
00374         }
00375         if ((i == 1) && (data != COMMAND)) {
00376             // Invalid signal => reset receive
00377             i=0;
00378             firstByte = 0;
00379         }
00380         if (i == RECEIVEHEADERLENGTH) {
00381             length = data; // Length of receiving data
00382             if (length != 1) {
00383                 // Invalid length => reset receive
00384                 i=0;
00385                 firstByte = 0;
00386             }
00387         }
00388         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00389             result = data;
00390         }
00391         if (firstByte == STARTINGCODE) {
00392             if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00393             i++;
00394         }
00395         if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00396     } while (i<length+RECEIVEHEADERLENGTH+2);
00397
00398     if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00399     return result;
00400 }
```

#### 4.1.4.5 getDrivesStates()

```
byte DFR0534::getDrivesStates ()
```

Checks which drives are ready/online.

Returned value is a bit pattern that shows which drives are ready/online (1=online,0=offline):

- Bit 0 = [DFR0534::DRIVEUSB](#)
- Bit 1 = [DFR0534::DRIVESD](#)
- Bit 2 = [DFR0534::DRIVEFLASH](#)

## Returns

Bit pattern for drives

## Return values

<a href="#">DFR0534::DRIVEUNKNOWN</a>	Error (for example request timeout)
---------------------------------------	-------------------------------------

Definition at line 277 of file [DFR0534.cpp](#).

```

00278 {
00279     #define COMMAND 0x09
00280     #define RECEIVEBYTETIMEOUTMS 100
00281     #define RECEIVEGLOBALTIMEOUTMS 500
00282     #define RECEIVEFAILED DRIVEUNKNOWN
00283     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00284
00285     if (m_ptrStream == NULL) return RECEIVEFAILED; // Should not happen
00286     sendStartingCode();
00287     sendDataByte(COMMAND);
00288     sendDataByte(0x00);
00289     sendChecksum();
00290
00291     // Receive
00292     int i=0;
00293     byte data, firstByte = 0, sum, length=0xff, result = 0;
00294     unsigned long receiveStartMS = millis();
00295     do {
00296         byte dataReady = 0;
00297         unsigned long lastMS = millis();
00298         // Wait for response or timeout
00299         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00300
00301         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00302         data = m_ptrStream->read();
00303
00304         if (i==0) { // Begin of transmission
00305             firstByte=data;
00306             sum = 0;
00307         }
00308         if ((i == 1) && (data != COMMAND)) {
00309             // Invalid signal => reset receive
00310             i=0;
00311             firstByte = 0;
00312         }
00313         if (i == RECEIVEHEADERLENGTH) {
00314             length = data; // Length of receiving data
00315             if (length != 1) {
00316                 // Invalid length => reset receive
00317                 i=0;
00318                 firstByte = 0;
00319             }
00320         }
00321         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00322             result = data;
00323         }
00324         if (firstByte == STARTINGCODE) {
00325             if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00326             i++;
00327         }
00328         if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00329     } while (i<length+RECEIVEHEADERLENGTH+2);
00330
00331     if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00332     return result;
00333 }
```

## 4.1.4.6 getDuration()

```
bool DFR0534::getDuration (
    byte & hour,
    byte & minute,
    byte & second)
```

Get duration/length of current file.

Get duration/length of current file in hours:minutes:seconds

## Parameters

out	<i>hour</i>	Hours
out	<i>minute</i>	Minutes
out	<i>second</i>	Seconds

## Return values

<i>true</i>	Request was successful
<i>false</i>	Request failed

Definition at line 1063 of file DFR0534.cpp.

```
01064 {
01065     #define COMMAND 0x24
01066     #define RECEIVEFAILED false
01067     #define RECEIVEBYTETIMEOUTMS 100
01068     #define RECEIVEGLOBALTIMEOUTMS 500
01069     #define RECEIVEHEADERLENGTH 2 // startingcode+command
01070
01071     if (m_ptrStream == NULL) return false; // Should not happen
01072     sendStartingCode();
01073     sendDataByte(COMMAND);
01074     sendDataByte(0x00);
01075     sendChecksum();
01076
01077     // Receive
01078     int i=0;
01079     byte data, firstByte = 0, sum, length=0xff;
01080     word result = 0;
01081     unsigned long receiveStartMS = millis();
01082     do {
01083         byte dataReady = 0;
01084         unsigned long lastMS = millis();
01085         // Wait for response or timeout
01086         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
01087
01088         if (dataReady == 0) return RECEIVEFAILED; // Timeout
01089         data = m_ptrStream->read();
01090
01091         if (i==0) { // Begin of transmission
01092             firstByte=data;
01093             sum = 0;
01094         }
01095         if ((i == 1) && (data != COMMAND)) {
01096             // Invalid signal => reset receive
01097             i=0;
01098             firstByte = 0;
01099         }
01100         if (i == RECEIVEHEADERLENGTH) {
01101             length = data; // Length of receiving data
01102             if (length != 3) {
01103                 // Invalid length => reset receive
01104                 i=0;
01105                 firstByte = 0;
01106             }
01107         }
01108         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
01109             switch (i-RECEIVEHEADERLENGTH-1) {
01110                 case 0:
```

```

01111         hour=data;
01112         break;
01113     case 1:
01114         minute=data;
01115         break;
01116     case 2:
01117         second=data;
01118         break;
01119     }
01120 }
01121 if (firstByte == STARTINGCODE) {
01122     if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
01123     i++;
01124 }
01125 if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
01126 } while (i<length+RECEIVEHEADERLENGTH+2);
01127
01128 return (data == sum); // Does checksum matches?
01129 }

```

#### 4.1.4.7 getFileName()

```

bool DFR0534::getFileName (
    char * name)

```

Get name for current file.

File name is in 8+3 format in upper case, with spaces without the dot "." between name and extension, e.g. "TEST WAV" for the file test.wav

##### Parameters

out	name	Filename. You have to allocate at least 12 chars memory for this variable.
-----	------	--

Definition at line 912 of file [DFR0534.cpp](#).

```

00913 {
00914     #define COMMAND 0x1E
00915     #define RECEIVEBYTETIMEOUTMS 100
00916     #define RECEIVEGLOBALTIMEOUTMS 500
00917     #define RECEIVEFAILED false
00918     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00919
00920     if (m_ptrStream == NULL) return false; // Should not happen
00921     if (name == NULL) return false;
00922     name[0] = '\0';
00923
00924     sendStartingCode();
00925     sendDataByte(COMMAND);
00926     sendDataByte(0x00);
00927     sendChecksum();
00928
00929     // Receive
00930     int i=0;
00931     byte data, firstByte = 0, sum, length=0xff;
00932     unsigned long receiveStartMS = millis();
00933     do {
00934         byte dataReady = 0;
00935         unsigned long lastMS = millis();
00936         // Wait for response or timeout
00937         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00938
00939         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00940         data = m_ptrStream->read();
00941         if (i==0) { // Begin of transmission
00942             firstByte=data;
00943             sum = 0;
00944         }
00945         if ((i == 1) && (data != COMMAND)) {
00946             // Invalid signal => reset receive
00947             i=0;
00948             firstByte = 0;
00949         }
00950         if (i == RECEIVEHEADERLENGTH) length = data; // Length of receiving string
00951         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {

```

```

00952         if ((i-RECEIVEHEADERLENGTH) < 12) { // I expect no longer file names than 8+3 chars plus '\0'
00953             name[i-RECEIVEHEADERLENGTH-1] = data;
00954             name[i-RECEIVEHEADERLENGTH] = '\0';
00955         }
00956     }
00957     if (firstByte == STARTINGCODE) {
00958         if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00959         i++;
00960     }
00961     if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00962 } while (i<length+RECEIVEHEADERLENGTH+2);
00963 return (data == sum); // Does checksum matches?
00964 }

```

#### 4.1.4.8 getFileNumber()

word DFR0534::getFileNumber ()

Get file number of current file.

File number is in "file copy order". First audio file copied to the drive get number 1...

##### Returns

File number

##### Return values

0	Error (for example request timeout)
---	-------------------------------------

Definition at line 426 of file DFR0534.cpp.

```

00427 {
00428     #define COMMAND 0x0D
00429     #define RECEIVEFAILED 0
00430     #define RECEIVEBYTETIMEOUTMS 100
00431     #define RECEIVEGLOBALTIMEOUTMS 500
00432     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00433
00434     if (m_ptrStream == NULL) return RECEIVEFAILED; // Should not happen
00435     sendStartingCode();
00436     sendDataByte(COMMAND);
00437     sendDataByte(0x00);
00438     sendChecksum();
00439
00440     // Receive
00441     int i=0;
00442     byte data, firstByte = 0, sum, length=0xff;
00443     word result = 0;
00444     unsigned long receiveStartMS = millis();
00445     do {
00446         byte dataReady = 0;
00447         unsigned long lastMS = millis();
00448         // Wait for response or timeout
00449         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00450
00451         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00452         data = m_ptrStream->read();
00453
00454         if (i==0) { // Begin of transmission
00455             firstByte=data;
00456             sum = 0;
00457         }
00458         if ((i == 1) && (data != COMMAND)) {
00459             // Invalid signal => reset receive
00460             i=0;
00461             firstByte = 0;
00462         }
00463         if (i == RECEIVEHEADERLENGTH) {
00464             length = data; // Length of receiving data
00465             if (length != 2) {
00466                 // Invalid length => reset receive
00467                 i=0;

```

```

00468         firstByte = 0;
00469     }
00470 }
00471 if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00472     switch (i-RECEIVEHEADERLENGTH-1) {
00473         case 0:
00474             result=data<<8;
00475             break;
00476         case 1:
00477             result+=data;
00478             break;
00479     }
00480 }
00481 if (firstByte == STARTINGCODE) {
00482     if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00483     i++;
00484 }
00485 if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00486 } while (i<length+RECEIVEHEADERLENGTH+2);
00487
00488 if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00489 return result;
00490 }

```

#### 4.1.4.9 getFirstFileNumberInCurrentDirectory()

```
int DFR0534::getFirstFileNumberInCurrentDirectory ()
```

Get number of first file in current directory.

#### Returns

File number

#### Return values

-1	Error (for example request timeout)
----	-------------------------------------

Definition at line 594 of file [DFR0534.cpp](#).

```

00595 {
00596     #define COMMAND 0x11
00597     #define RECEIVEFAILED -1
00598     #define RECEIVEBYTETIMEOUTMS 100
00599     #define RECEIVEGLOBALTIMEOUTMS 500
00600     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00601
00602     if (m_ptrStream == NULL) RECEIVEFAILED; // Should not happen
00603     sendStartingCode();
00604     sendDataByte(COMMAND);
00605     sendDataByte(0x00);
00606     sendChecksum();
00607
00608     // Receive
00609     int i=0;
00610     byte data, firstByte = 0, sum, length=0xff;
00611     word result = 0;
00612     unsigned long receiveStartMS = millis();
00613     do {
00614         byte dataReady = 0;
00615         unsigned long lastMS = millis();
00616         // Wait for response or timeout
00617         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00618
00619         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00620         data = m_ptrStream->read();
00621
00622         if (i==0) { // Begin of transmission
00623             firstByte=data;
00624             sum = 0;
00625         }
00626         if ((i == 1) && (data != COMMAND)) {
00627             // Invalid signal => reset receive
00628             i=0;

```



```

00629     firstByte = 0;
00630 }
00631 if (i == RECEIVEHEADERLENGTH) {
00632     length = data; // Length of receiving data
00633     if (length != 2) {
00634         // Invalid length => reset receive
00635         i=0;
00636         firstByte = 0;
00637     }
00638 }
00639 if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00640     switch (i-RECEIVEHEADERLENGTH-1) {
00641         case 0:
00642             result=data<<8;
00643             break;
00644         case 1:
00645             result+=data;
00646             break;
00647     }
00648 }
00649 if (firstByte == STARTINGCODE) {
00650     if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00651     i++;
00652 }
00653 if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00654 } while (i<length+RECEIVEHEADERLENGTH+2);
00655
00656 if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00657 return result;
00658 }

```

#### 4.1.4.10 getRuntime()

```

bool DFR0534::getRuntime (
    byte & hour,
    byte & minute,
    byte & second)

```

Get elapsed runtime/duration of the current file.

Runtime is in hours:minutes:seconds. You have to call [startSendingRuntime\(\)](#) before runtimes can be received.

##### Parameters

out	<i>hour</i>	Hours
out	<i>minute</i>	Minutes
out	<i>second</i>	Seconds

##### Return values

<i>true</i>	Request was successful
<i>false</i>	Request failed

Definition at line 1156 of file [DFR0534.cpp](#).

```

01157 {
01158     #define COMMAND 0x25
01159     #define RECEIVEFAILED false
01160     #define RECEIVEBYTETIMEOUTMS 100
01161     #define RECEIVEGLOBALTIMEOUTMS 500
01162     #define RECEIVEHEADERLENGTH 2 // startingcode+command
01163
01164     if (m_ptrStream == NULL) return false; // Should not happen
01165
01166     // Receive
01167     int i=0;
01168     byte data, firstByte = 0, sum, length=0xff;
01169     word result = 0;
01170     unsigned long receiveStartMS = millis();
01171     do {

```

```

01172     byte dataReady = 0;
01173     unsigned long lastMS = millis();
01174     // Wait for response or timeout
01175     while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
01176
01177     if (dataReady == 0) return RECEIVEFAILED; // Timeout
01178     data = m_ptrStream->read();
01179
01180     if (i==0) { // Begin of transmission
01181         firstByte=data;
01182         sum = 0;
01183     }
01184     if ((i == 1) && (data != COMMAND)) {
01185         // Invalid signal => reset receive
01186         i=0;
01187         firstByte = 0;
01188     }
01189     if (i == RECEIVEHEADERLENGTH) {
01190         length = data; // Length of receiving data
01191         if (length != 3) {
01192             // Invalid length => reset receive
01193             i=0;
01194             firstByte = 0;
01195         }
01196     }
01197     if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
01198         switch (i-RECEIVEHEADERLENGTH-1) {
01199             case 0:
01200                 hour=data;
01201                 break;
01202             case 1:
01203                 minute=data;
01204                 break;
01205             case 2:
01206                 second=data;
01207                 break;
01208         }
01209     }
01210     if (firstByte == STARTINGCODE) {
01211         if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
01212         i++;
01213     }
01214     if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
01215 } while (i<length+RECEIVEHEADERLENGTH+2);
01216
01217 return (data == sum); // Does checksum matches?
01218 }

```

#### 4.1.4.11 getStatus()

```
byte DFR0534::getStatus ()
```

Get module status.

##### Return values

<a href="#"><i>DFR0534::STOPPED</i></a>	Audio module is idle
<a href="#"><i>DFR0534::PLAYING</i></a>	Audio module is playing a file
<a href="#"><i>DFR0534::PAUSED</i></a>	Audio module is paused
<a href="#"><i>DFR0534::STATUSUNKNOWN</i></a>	Error (for example request timeout)

Definition at line 53 of file [DFR0534.cpp](#).

```

00054 {
00055     #define COMMAND 0x01
00056     #define RECEIVEBYTETIMEOUTMS 100
00057     #define RECEIVEGLOBALTIMEOUTMS 500
00058     #define RECEIVEFAILED STATUSUNKNOWN
00059     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00060
00061     if (m_ptrStream == NULL) return RECEIVEFAILED; // Should not happen
00062     sendStartingCode();
00063     sendDataByte(COMMAND);;
00064     sendDataByte(0x00);;
00065     sendChecksum();

```

```

00066
00067 // Receive
00068 int i=0;
00069 byte data, firstByte = 0, sum, length=0xff, result = 0;
00070 unsigned long receiveStartMS = millis();
00071 do {
00072     byte dataReady = 0;
00073     unsigned long lastMS = millis();
00074     // Wait for response or timeout
00075     while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00076
00077     if (dataReady == 0) return RECEIVEFAILED; // Timeout
00078     data = m_ptrStream->read();
00079
00080     if (i==0) { // Begin of transmission
00081         firstByte=data;
00082         sum = 0;
00083     }
00084     if ((i == 1) && (data != COMMAND)) {
00085         // Invalid signal => reset receive
00086         i=0;
00087         firstByte = 0;
00088     }
00089     if (i == RECEIVEHEADERLENGTH) {
00090         length = data; // Length of receiving data
00091         if (length != 1) {
00092             // Invalid length => reset receive
00093             i=0;
00094             firstByte = 0;
00095         }
00096     }
00097     if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00098         result = data;
00099     }
00100     if (firstByte == STARTINGCODE) {
00101         if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00102         i++;
00103     }
00104     if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00105 } while (i<length+RECEIVEHEADERLENGTH+2);
00106
00107 if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00108 return result;
00109 }

```

#### 4.1.4.12 getTotalFiles()

```
int DFR0534::getTotalFiles ()
```

Get total number of supported audio files on current drive.

##### Returns

Number of files

##### Return values

-1	Error (for example request timeout)
----	-------------------------------------

Definition at line 498 of file [DFR0534.cpp](#).

```

00499 {
00500     #define COMMAND 0x0C
00501     #define RECEIVEFAILED -1
00502     #define RECEIVEBYTETIMEOUTMS 100
00503     #define RECEIVEGLOBALTIMEOUTMS 500
00504     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00505
00506     if (m_ptrStream == NULL) return RECEIVEFAILED; // Should not happen
00507     sendStartingCode();
00508     sendDataByte(COMMAND);
00509     sendDataByte(0x00);
00510     sendChecksum();
00511 }

```

```

00512 // Receive
00513 int i=0;
00514 byte data, firstByte = 0, sum, length=0xff;
00515 word result = 0;
00516 unsigned long receiveStartMS = millis();
00517 do {
00518     byte dataReady = 0;
00519     unsigned long lastMS = millis();
00520     // Wait for response or timeout
00521     while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00522
00523     if (dataReady == 0) return RECEIVEFAILED; // Timeout
00524     data = m_ptrStream->read();
00525
00526     if (i==0) { // Begin of transmission
00527         firstByte=data;
00528         sum = 0;
00529     }
00530     if ((i == 1) && (data != COMMAND)) {
00531         // Invalid signal => reset receive
00532         i=0;
00533         firstByte = 0;
00534     }
00535     if (i == RECEIVEHEADERLENGTH) {
00536         length = data; // Length of receiving data
00537         if (length != 2) {
00538             // Invalid length => reset receive
00539             i=0;
00540             firstByte = 0;
00541         }
00542     }
00543     if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00544         switch (i-RECEIVEHEADERLENGTH-1) {
00545             case 0:
00546                 result=data<<8;
00547                 break;
00548             case 1:
00549                 result+=data;
00550                 break;
00551         }
00552     }
00553     if (firstByte == STARTINGCODE) {
00554         if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00555         i++;
00556     }
00557     if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00558 } while (i<length+RECEIVEHEADERLENGTH+2);
00559
00560 if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00561 return result;
00562 }

```

#### 4.1.4.13 getTotalFilesInCurrentDirectory()

```
int DFR0534::getTotalFilesInCurrentDirectory ()
```

Count all audio files for the current directory.

##### Returns

File count

##### Return values

-1	Error (for example request timeout)
----	-------------------------------------

Definition at line 666 of file [DFR0534.cpp](#).

```

00667 {
00668     #define COMMAND 0x12
00669     #define RECEIVEFAILED -1
00670     #define RECEIVEBYTETIMEOUTMS 100
00671     #define RECEIVEGLOBALTIMEOUTMS 500
00672     #define RECEIVEHEADERLENGTH 2 // startingcode+command

```

```

00673
00674     if (m_ptrStream == NULL) RECEIVEFAILED; // Should not happen
00675     sendStartingCode();
00676     sendDataByte(COMMAND);
00677     sendDataByte(0x00);
00678     sendChecksum();
00679
00680     // Receive
00681     int i=0;
00682     byte data, firstByte = 0, sum, length=0xff;
00683     word result = 0;
00684     unsigned long receiveStartMS = millis();
00685     do {
00686         byte dataReady = 0;
00687         unsigned long lastMS = millis();
00688         // Wait for response or timeout
00689         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00690
00691         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00692         data = m_ptrStream->read();
00693
00694         if (i==0) { // Begin of transmission
00695             firstByte=data;
00696             sum = 0;
00697         }
00698         if ((i == 1) && (data != COMMAND)) {
00699             // Invalid signal => reset receive
00700             i=0;
00701             firstByte = 0;
00702         }
00703         if (i == RECEIVEHEADERLENGTH) {
00704             length = data; // Length of receiving data
00705             if (length != 2) {
00706                 // Invalid length => reset receive
00707                 i=0;
00708                 firstByte = 0;
00709             }
00710         }
00711         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00712             switch (i-RECEIVEHEADERLENGTH-1) {
00713                 case 0:
00714                     result=data<<8;
00715                     break;
00716                 case 1:
00717                     result+=data;
00718                     break;
00719             }
00720         }
00721         if (firstByte == STARTINGCODE) {
00722             if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00723             i++;
00724         }
00725         if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00726     } while (i<length+RECEIVEHEADERLENGTH+2);
00727
00728     if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00729     return result;
00730 }

```

#### 4.1.4.14 increaseVolume()

```
void DFR0534::increaseVolume ()
```

Increase volume by one step.

Definition at line 735 of file [DFR0534.cpp](#).

```

00736 {
00737     if (m_ptrStream == NULL) return; // Should not happen
00738     sendStartingCode();
00739     sendDataByte(0x14);
00740     sendDataByte(0x00);
00741     sendChecksum();
00742 }

```

#### 4.1.4.15 insertFileByNumber()

```
void DFR0534::insertFileByNumber (
    word track,
    byte drive = DRIVEFLASH)
```

Pause current file and play another file by number.

File number order is "file copy order". Continue original file when this file stops

##### Parameters

in	<i>track</i>	File number of the audio file
in	<i>drive</i>	Drive, where file is stored: Drive <a href="#">DFR0534::DRIVEUSB</a> , <a href="#">DFR0534::DRIVESD</a> or <a href="#">DFR0534::DRIVEFLASH</a> (=default)

Definition at line 764 of file [DFR0534.cpp](#).

```
00765 {
00766     if (m_ptrStream == NULL) return; // Should not happen
00767     if (drive >= DRIVEUNKNOWN) return;
00768     sendStartingCode();
00769     sendDataByte(0x16);
00770     sendDataByte(0x03);
00771     sendDataByte(drive);
00772     sendDataByte((track >> 8) & 0xff);
00773     sendDataByte(track & 0xff);
00774     sendChecksum();
00775 }
```

#### 4.1.4.16 pause()

```
void DFR0534::pause ()
```

Pause the current file.

Definition at line 180 of file [DFR0534.cpp](#).

```
00181 {
00182     if (m_ptrStream == NULL) return; // Should not happen
00183     sendStartingCode();
00184     sendDataByte(0x03);
00185     sendDataByte(0x00);
00186     sendChecksum();
00187 }
```

#### 4.1.4.17 play()

```
void DFR0534::play ()
```

Play the current selected file.

Definition at line 168 of file [DFR0534.cpp](#).

```
00169 {
00170     if (m_ptrStream == NULL) return; // Should not happen
00171     sendStartingCode();
00172     sendDataByte(0x02);
00173     sendDataByte(0x00);
00174     sendChecksum();
00175 }
```

#### 4.1.4.18 playCombined()

```
void DFR0534::playCombined (
    char * list)
```

Combined/concatenated play of files.

Combined is like a playlist, for example `playCombined("0103")` for the two files 01 and 03. The Filenames must be two chars long and the files must be in a directory called /ZH Combined playback ignores loop mode and stops after last file.

## Parameters

in	<i>list</i>	Concatenated list of all files to play
----	-------------	--

Definition at line 857 of file DFR0534.cpp.

```

00858 {
00859     if (m_ptrStream == NULL) return; // Should not happen
00860     if (list == NULL) return;
00861     if ((strlen(list) % 2) != 0) return;
00862
00863     sendStartingCode();
00864     sendDataByte(0x1B);
00865     sendDataByte(strlen(list));
00866     for (int i=0; i<strlen(list); i++) {
00867         sendDataByte(list[i]);
00868     }
00869     sendChecksum();
00870 }
```

#### 4.1.4.19 playFileByName()

```

void DFR0534::playFileByName (
    char * path,
    byte drive = DRIVEFLASH)
```

Play audio file by file name/path.

The file name/path is the full path of the audio file to be played in format which looks like a special unix 8+3 format:

- Without a dot between file name and file extension
- All characters in upper case
- Maximal 8 characters for file name
- Every file and folder whose name length is shorter then 8 chars must be filled up to the 8 chars length by space chars
- Must end with WAV or MP3
- Only WAV and MP3 files are supported
- Wildcards \* (=multiple arbitrary characters) and ? (=one single arbitrary character) are allowed and can be used to reduce the filling space chars

Valid examples (first means first in "file copy order"):

- "/01 WAV" for a file '/01.wav'
- "/99-AFR~1MP3" for a file '/99-Africa.mp3'
- "/SUN\*MP3" for first file matching '/sun\*.mp3', for example '/sun.mp3'
- "/99-AFR\*MP3" for first file matching '/99-Afr\*.mp3'
- "/10\*" for first audio file matching '/10\*.\*'
- "/10 /20 WAV" for the file '/10/20.wav'

## Parameters

in	<i>path</i>	Full path of the audio file
in	<i>drive</i>	Drive, where file is stored: Drive <a href="#">DFR0534::DRIVEUSB</a> , <a href="#">DFR0534::DRIVESD</a> or <a href="#">DFR0534::DRIVEFLASH</a> (=default)

Definition at line 251 of file [DFR0534.cpp](#).

```
00252 {
00253     if (m_ptrStream == NULL) return; // Should not happen
00254     if (path == NULL) return;
00255     if (drive >= DRIVEUNKNOWN) return;
00256     sendStartingCode();
00257     sendDataByte(0x08);
00258     sendDataByte(strlen(path)+1);
00259     sendDataByte(drive);
00260     for (int i=0;i<strlen(path);i++) {
00261         sendDataByte(path[i]);
00262     }
00263     sendChecksum();
00264 }
```

#### 4.1.4.20 playFileByNumber()

```
void DFR0534::playFileByNumber (
    word track)
```

Play audio file by number.

File number order is "file copy order": First audio file copied to the drive gets number 1, second audio file copied gets number 2... )

## Parameters

in	<i>track</i>	File number
----	--------------	-------------

Definition at line 135 of file [DFR0534.cpp](#).

```
00136 {
00137     if (m_ptrStream == NULL) return; // Should not happen
00138     if (track <=0) return;
00139     sendStartingCode();
00140     sendDataByte(0x07);
00141     sendDataByte(0x02);
00142     sendDataByte((track >> 8) & 0xff);
00143     sendDataByte(track & 0xff);
00144     sendChecksum();
00145 }
```

#### 4.1.4.21 playLastInDirectory()

```
void DFR0534::playLastInDirectory ()
```

Play last file in directory (in "file copy order")

Definition at line 567 of file [DFR0534.cpp](#).

```
00568 {
00569     if (m_ptrStream == NULL) return; // Should not happen
00570     sendStartingCode();
00571     sendDataByte(0x0E);
00572     sendDataByte(0x00);
00573     sendChecksum();
00574 }
```



#### 4.1.4.22 playNext()

```
void DFR0534::playNext ()
```

Play next file (in "file copy order")

Definition at line 216 of file [DFR0534.cpp](#).

```
00217 {
00218     if (m_ptrStream == NULL) return; // Should not happen
00219     sendStartingCode();
00220     sendDataByte(0x06);
00221     sendDataByte(0x00);
00222     sendChecksum();
00223 }
```

#### 4.1.4.23 playNextDirectory()

```
void DFR0534::playNextDirectory ()
```

Play first file in next directory (in "file copy order")

Definition at line 579 of file [DFR0534.cpp](#).

```
00580 {
00581     if (m_ptrStream == NULL) return; // Should not happen
00582     sendStartingCode();
00583     sendDataByte(0x0F);
00584     sendDataByte(0x00);
00585     sendChecksum();
00586 }
```

#### 4.1.4.24 playPrevious()

```
void DFR0534::playPrevious ()
```

Play previous file (in "file copy order")

Definition at line 204 of file [DFR0534.cpp](#).

```
00205 {
00206     if (m_ptrStream == NULL) return; // Should not happen
00207     sendStartingCode();
00208     sendDataByte(0x05);
00209     sendDataByte(0x00);
00210     sendChecksum();
00211 }
```

#### 4.1.4.25 prepareFileByNumber()

```
void DFR0534::prepareFileByNumber (
    word track)
```

Select file by number, but not start playing.

##### Parameters

in	<i>track</i>	Number for file
----	--------------	-----------------

Definition at line 971 of file [DFR0534.cpp](#).

```
00972 {
00973     if (m_ptrStream == NULL) return; // Should not happen
00974     sendStartingCode();
00975     sendDataByte(0x1F);
00976     sendDataByte(0x02);
00977     sendDataByte((track >> 8) & 0xff);
00978     sendDataByte(track & 0xff);
00979     sendChecksum();
00980 }
```

#### 4.1.4.26 repeatPart()

```
void DFR0534::repeatPart (
    byte startMinute,
    byte startSecond,
    byte stopMinute,
    byte stopSecond)
```

Repeat part of the current file.

Repeat between time start and stop position

##### Parameters

in	<i>startMinute</i>	Minute for start position
in	<i>startSecond</i>	Second for start position
in	<i>stopMinute</i>	Minute for stop position
in	<i>stopSecond</i>	Seconde for stop position

Definition at line 992 of file [DFR0534.cpp](#).

```
00993 {
00994     if (m_ptrStream == NULL) return; // Should not happen
00995     sendStartingCode();
00996     sendDataByte(0x20);
00997     sendDataByte(0x04);
00998     sendDataByte(startMinute);
00999     sendDataByte(startSecond);
01000     sendDataByte(stopMinute);
01001     sendDataByte(stopSecond);
01002     sendChecksum();
01003 }
```

#### 4.1.4.27 setChannel()

```
void DFR0534::setChannel (
    byte channel)
```

Set output for DAC to channel MP3, AUX or both.

I found not P26/P27 for AUX on my [DFR0534](#) => Only [DFR0534::CHANNELMP3](#) makes sense (and is already set by default) Perhaps this function works on other audio modules with the same chip.

##### Parameters

in	<i>channel</i>	Output channel: <a href="#">DFR0534::CHANNELMP3</a> , <a href="#">DFR0534::CHANNELAUX</a> or <a href="#">DFR0534::CHANNELMP3AUX</a>
----	----------------	---

Definition at line 892 of file [DFR0534.cpp](#).

```
00893 {
00894     if (m_ptrStream == NULL) return; // Should not happen
00895     if (channel >= CHANNELUNKNOWN) return;
00896     sendStartingCode();
00897     sendDataByte(0x1D);
00898     sendDataByte(0x01);
00899     sendDataByte(channel);
00900     sendChecksum();
00901 }
```

#### 4.1.4.28 setDirectory()

```
void DFR0534::setDirectory (
    char * path,
    byte drive = DRIVEFLASH)
```

Should set directory, but does not work for me.

## Parameters

in	<i>path</i>	Directory
in	<i>drive</i>	Drive, where directory is stored: Drive <a href="#">DFR0534::DRIVEUSB</a> , <a href="#">DFR0534::DRIVESD</a> or <a href="#">DFR0534::DRIVEFLASH</a> (=default)

Definition at line 797 of file [DFR0534.cpp](#).

```
00798 {
00799     if (m_ptrStream == NULL) return; // Should not happen
00800     if (path == NULL) return;
00801     if (drive >= DRIVEUNKNOWN) return;
00802     sendStartingCode();
00803     sendDataByte(0x17);
00804     sendDataByte(strlen(path)+1);
00805     sendDataByte(drive);
00806     for (int i=0;i<strlen(path);i++) {
00807         sendDataByte(path[i]);
00808     }
00809     sendChecksum();
00810 }
```

#### 4.1.4.29 setDrive()

```
void DFR0534::setDrive (
    byte drive)
```

Switch to drive.

## Parameters

in	<i>drive</i>	Drive <a href="#">DFR0534::DRIVEUSB</a> , <a href="#">DFR0534::DRIVESD</a> or <a href="#">DFR0534::DRIVEFLASH</a>
----	--------------	---

Definition at line 407 of file [DFR0534.cpp](#).

```
00408 {
00409     if (m_ptrStream == NULL) return; // Should not happen
00410     if (drive >= DRIVEUNKNOWN) return;
00411     sendStartingCode();
00412     sendDataByte(0x0B);
00413     sendDataByte(0x01);
00414     sendDataByte(drive);
00415     sendChecksum();
00416 }
```

#### 4.1.4.30 setEqualizer()

```
void DFR0534::setEqualizer (
    byte mode)
```

Set equalizer to NORMAL, POP, ROCK, JAZZ or CLASSIC.

## Parameters

in	<i>mode</i>	EQ mode: <a href="#">DFR0534::NORMAL</a> , <a href="#">DFR0534::POP</a> , <a href="#">DFR0534::ROCK</a> , <a href="#">DFR0534::JAZZ</a> or <a href="#">DFR0534::CLASSIC</a>
----	-------------	---

Definition at line 116 of file [DFR0534.cpp](#).

```
00117 {
00118     if (m_ptrStream == NULL) return; // Should not happen
00119     if (mode >= EQUNKNOWN) return;
00120     sendStartingCode();
00121     sendDataByte(0x1A);
00122     sendDataByte(0x01);
00123     sendDataByte(mode);
00124     sendChecksum();
00125 }
```

#### 4.1.4.31 setLoopMode()

```
void DFR0534::setLoopMode (
    byte mode)
```

Set loop mode.

##### Parameters

in	mode	Loop mode: <a href="#">DFR0534::LOOPBACKALL</a> , <a href="#">DFR0534::SINGLEAUDIOLOOP</a> , <a href="#">DFR0534::SINGLEAUDIOSTOP</a> , <a href="#">DFR0534::PLAYRANDOM</a> , <a href="#">DFR0534::DIRECTORYLOOP</a> , <a href="#">DFR0534::RANDOMINDIRECTORY</a> , <a href="#">DFR0534::SEQUENTIALINDIRECTORY</a> or <a href="#">DFR0534::SEQUENTIAL</a>
----	------	---

Definition at line 817 of file [DFR0534.cpp](#).

```
00818 {
00819     if (m_ptrStream == NULL) return; // Should not happen
00820     if (mode >= PLAYMODEUNKNOWN) return;
00821     sendStartingCode();
00822     sendDataByte(0x18);
00823     sendDataByte(0x01);
00824     sendDataByte(mode);
00825     sendChecksum();
00826 }
```

#### 4.1.4.32 setRepeatLoops()

```
void DFR0534::setRepeatLoops (
    word loops)
```

Set repeat loops.

Only valid for loop modes [DFR0534::LOOPBACKALL](#), [DFR0534::SINGLEAUDIOLOOP](#) or [DFR0534::DIRECTORYLOOP](#)

##### Parameters

in	loops	Number of loops
----	-------	-----------------

Definition at line 835 of file [DFR0534.cpp](#).

```
00836 {
00837     if (m_ptrStream == NULL) return; // Should not happen
00838     sendStartingCode();
00839     sendDataByte(0x19);
00840     sendDataByte(0x02);
00841     sendDataByte((loops >> 8) & 0xff);
00842     sendDataByte(loops & 0xff);
00843     sendChecksum();
00844 }
```

#### 4.1.4.33 setVolume()

```
void DFR0534::setVolume (
    byte volume)
```

Set volume.

Volumen levels 0-30 are allowed. Audio module starts always with level 20.

## Parameters

in	<i>volume</i>	Volume level
----	---------------	--------------

Definition at line 154 of file [DFR0534.cpp](#).

```
00155 {
00156     if (m_ptrStream == NULL) return; // Should not happen
00157     if (volume > 30) volume = 30;
00158     sendStartingCode();
00159     sendDataByte(0x13);
00160     sendDataByte(0x01);
00161     sendDataByte(volume);
00162     sendChecksum();
00163 }
```

#### 4.1.4.34 startSendingRuntime()

```
void DFR0534::startSendingRuntime ()
```

Start sending elapsed runtime every 1 second.

Definition at line 1134 of file [DFR0534.cpp](#).

```
01135 {
01136     if (m_ptrStream == NULL) return; // Should not happen
01137     sendStartingCode();
01138     sendDataByte(0x25);
01139     sendDataByte(0x00);
01140     sendChecksum();
01141 }
```

#### 4.1.4.35 stop()

```
void DFR0534::stop ()
```

Stop the current file.

Definition at line 192 of file [DFR0534.cpp](#).

```
00193 {
00194     if (m_ptrStream == NULL) return; // Should not happen
00195     sendStartingCode();
00196     sendDataByte(0x04);
00197     sendDataByte(0x00);
00198     sendChecksum();
00199 }
```

#### 4.1.4.36 stopCombined()

```
void DFR0534::stopCombined ()
```

Stop combined play (playlist)

Definition at line 875 of file [DFR0534.cpp](#).

```
00876 {
00877     if (m_ptrStream == NULL) return; // Should not happen
00878     sendStartingCode();
00879     sendDataByte(0x1C);
00880     sendDataByte(0x00);
00881     sendChecksum();
00882 }
```

#### 4.1.4.37 stopInsertedFile()

```
void DFR0534::stopInsertedFile ()
```

Stop inserted file.

Continue original file

Definition at line 782 of file [DFR0534.cpp](#).

```
00783 {  
00784     if (m_ptrStream == NULL) return; // Should not happen  
00785     sendStartingCode();  
00786     sendDataByte(0x10);  
00787     sendDataByte(0x00);  
00788     sendChecksum();  
00789 }
```

#### 4.1.4.38 stopRepeatPart()

```
void DFR0534::stopRepeatPart ()
```

Stop repeating part of the current file.

Definition at line 1008 of file [DFR0534.cpp](#).

```
01009 {  
01010     if (m_ptrStream == NULL) return; // Should not happen  
01011     sendStartingCode();  
01012     sendDataByte(0x21);  
01013     sendDataByte(0x00);  
01014     sendChecksum();  
01015 }
```

#### 4.1.4.39 stopSendingRuntime()

```
void DFR0534::stopSendingRuntime ()
```

Stop sending runtime.

Definition at line 1223 of file [DFR0534.cpp](#).

```
01224 {  
01225     if (m_ptrStream == NULL) return; // Should not happen  
01226     sendStartingCode();  
01227     sendDataByte(0x26);  
01228     sendDataByte(0x00);  
01229     sendChecksum();  
01230 }
```

The documentation for this class was generated from the following files:

- [DFR0534.h](#)
- [DFR0534.cpp](#)

## Chapter 5

# File Documentation

### 5.1 playCombined.ino

```
00001 /*
00002  * Example for using the DFR0534 for playing combined audio files like a playlist
00003  *
00004  * This example code was made for Arduino Uno/Nano/ATmega328p. For ESP32 you have to change the code
00005  * to use HardwareSerial (see https://github.com/codingABI/DFR0534#hardwareserial-for-esp32)
00006  */
00007
00008 #include <SoftwareSerial.h>
00009 #include <DFR0534.h>
00010
00011 #define TX_PIN A0
00012 #define RX_PIN A1
00013 SoftwareSerial g_serial(RX_PIN, TX_PIN);
00014 DFR0534 g_audio(g_serial);
00015
00016 void setup() {
00017     // Serial for console output
00018     Serial.begin(9600);
00019     // Software serial for communication to DFR0534 module
00020     g_serial.begin(9600);
00021
00022     // Set volume
00023     g_audio.setVolume(18);
00024
00025     /* The parameter string for the playCombined function is just
00026      * a concatenation of all files in the desired order without
00027      * path and without extension.
00028      * All files have to be in the folder /ZH and the each
00029      * file has to have a length (without extension) of two chars.
00030      *
00031      * You can get example files from
00032      * https://github.com/codingABI/DFR0534/tree/main/assets/exampleContent
00033      */
00034     /* Plays files the custom order, like a playlist and stops after the last file:
00035      * /ZH/05.wav
00036      * /ZH/04.wav
00037      * /ZH/03.wav
00038      * /ZH/02.wav
00039      * /ZH/01.wav
00040      * /ZH/0A.wav
00041      */
00042     g_audio.playCombined("05040302010A");
00043 }
00044
00045 void loop() {
00046     static unsigned long lastDisplayMS = millis();
00047     char name[12];
00048
00049     // Show information about current track every 500ms
00050     if (millis() - lastDisplayMS > 500) {
00051         Serial.print("number: ");
00052         word fileNumber = g_audio.getFileNumber();
00053         if (fileNumber > 0) Serial.print(fileNumber); else Serial.print("--");
00054
00055         Serial.print(" name: ");
00056         if (g_audio.getFileName(name)) Serial.print(name);
```

```

00057
00058     Serial.print(" status: ");
00059     switch (g_audio.getStatus()) {
00060     case DFR0534::STOPPED:
00061         Serial.println("Stopped");
00062         break;
00063     case DFR0534::PAUSED:
00064         Serial.println("Paused");
00065         break;
00066     case DFR0534::PLAYING:
00067         Serial.println("Playing");
00068         break;
00069     case DFR0534::STATUSUNKNOWN:
00070         Serial.println("Unknown");
00071         break;
00072     }
00073     lastDisplayMS = millis();
00074 }
00075 }

```

## 5.2 playFileByName.ino

```

00001 /*
00002  * Example for using the DFR0534 for playing audio files by file name
00003  *
00004  * This example code was made for Arduino Uno/Nano/ATmega328p. For ESP32 you have the change the code
00005  * to use HardwareSerial
00006  * instead of SoftwareSerial (see https://github.com/codingABI/DFR0534#hardwareserial-for-esp32)
00007  */
00008 #include <SoftwareSerial.h>
00009 #include <DFR0534.h>
00010
00011 #define TX_PIN A0
00012 #define RX_PIN A1
00013 SoftwareSerial g_serial(RX_PIN, TX_PIN);
00014 DFR0534 g_audio(g_serial);
00015
00016 void setup() {
00017     // Serial for console output
00018     Serial.begin(9600);
00019     // Software serial for communication to DFR0534 module
00020     g_serial.begin(9600);
00021
00022     // Set volume
00023     g_audio.setVolume(18);
00024
00025     /* The file name/path for the function playFileByName() is the
00026      * full path of the audio file to be played in format which looks like
00027      * a special unix 8+3 format:
00028      * - Without a dot between file name and file extension
00029      * - All characters in upper case
00030      * - Maximal 8 characters for file name
00031      * - Every file and folder whose name length is shorter then 8 chars
00032      * - must be filled up to the 8 chars length by space chars
00033      * - Must end with WAV or MP3
00034      * - Only WAV and MP3 files are supported
00035      * - Wildcards * (=multiple arbitrary characters) and ? (=one single arbitrary character)
00036      * - are allowed and can be used to reduce the filling space chars
00037      *
00038      * Valid examples (first means first in "file copy order"):
00039      * - "/01 WAV" for a file '/01.wav'
00040      * - "/99-AFR~1MP3" for a file '/99-Africa.mp3'
00041      * - "/SUN*MP3" for first file matching '/sun*.mp3', for example '/sun.mp3'
00042      * - "/99-AFR*MP3" for first file matching '/99-Afr*.mp3'
00043      * - "/10*" for first audio file matching '/10*.*'
00044      * - "/10 /20 WAV" for the file '/10/20.wav'
00045      *
00046      * You can get example files from
00047      * https://github.com/codingABI/DFR0534/tree/main/assets/exampleContent
00048      */
00049
00050     // Play the file "test.wav"
00051     g_audio.playFileByName("/TEST WAV");
00052 }
00053
00054 void loop() {
00055     static unsigned long lastDisplayMS = millis()-500;
00056     char name[12];
00057
00058     // Show information about current track once per second
00059     if (millis()-lastDisplayMS > 1000) {
00060         Serial.print("number: ");

```



```

00061     word fileName = g_audio.getFileNumber();
00062     if (fileName > 0) Serial.print(fileName); else Serial.print("--");
00063
00064     Serial.print(" name: ");
00065     if (g_audio.getFileName(name)) Serial.print(name);
00066
00067     Serial.print(" status: ");
00068     switch (g_audio.getStatus()) {
00069         case DFR0534::STOPPED:
00070             Serial.println("Stopped");
00071             break;
00072         case DFR0534::PAUSED:
00073             Serial.println("Paused");
00074             break;
00075         case DFR0534::PLAYING:
00076             Serial.println("Playing");
00077             break;
00078         case DFR0534::STATUSUNKNOWN:
00079             Serial.println("Unknown");
00080             break;
00081     }
00082     lastDisplayMS = millis();
00083 }
00084 }

```

## 5.3 playFileByNumber.ino

```

00001 /*
00002  * Example for using the DFR0534 for playing audio files by file number
00003  *
00004  * This example code was made for Arduino Uno/Nano/ATmega328p. For ESP32 you have to change the code
00005  * to use HardwareSerial (see https://github.com/codingABI/DFR0534#hardwareserial-for-esp32)
00006  */
00007
00008 #include <SoftwareSerial.h>
00009 #include <DFR0534.h>
00010
00011 #define TX_PIN A0
00012 #define RX_PIN A1
00013 SoftwareSerial g_serial(RX_PIN, TX_PIN);
00014 DFR0534 g_audio(g_serial);
00015
00016 void setup() {
00017     // Serial for console output
00018     Serial.begin(9600);
00019     // Software serial for communication to DFR0534 module
00020     g_serial.begin(9600);
00021
00022     // Set volume
00023     g_audio.setVolume(18);
00024
00025     // Show some device infos
00026     Serial.print("Ready drives: ");
00027     byte drive = g_audio.getDrivesStates();
00028     if ((drive >> DFR0534::DRIVEUSB) & 1) == 1) Serial.print("USB ");
00029     if ((drive >> DFR0534::DRIVESD) & 1) == 1) Serial.print("SD ");
00030     if ((drive >> DFR0534::DRIVEFLASH) & 1) == 1) Serial.print("FLASH ");
00031     Serial.println();
00032
00033     Serial.print("Current playing drive: ");
00034     switch(g_audio.getCurrentDrive()) {
00035         case DFR0534::DRIVEUSB:
00036             Serial.println("USB");
00037             break;
00038         case DFR0534::DRIVESD:
00039             Serial.println("SD");
00040             break;
00041         case DFR0534::DRIVEFLASH:
00042             Serial.println("FLASH");
00043             break;
00044         case DFR0534::DRIVENO:
00045             Serial.println("No drive");
00046             break;
00047         default:
00048             Serial.println("Unknown");
00049             break;
00050     }
00051
00052     Serial.print("Total files: ");
00053     Serial.println(g_audio.getTotalFiles());
00054     Serial.print("Total files in directory: ");
00055     Serial.println(g_audio.getTotalFilesInCurrentDirectory());

```

```


00056
00057 Serial.print("First file: ");
00058 Serial.println(g_audio.getFirstFileNumberInCurrentDirectory());
00059
00060 // Play the first audio file copied to the DFR0534
00061 // (Second file copied to the DFR0534 would be number 2...)
00062 g_audio.playFileByNumber(1);
00063 }
00064
00065 void loop() {
00066     static unsigned long lastDisplayMS = millis()-500;
00067     char name[12];
00068
00069     // Show information about current track once per second
00070     if (millis()-lastDisplayMS > 1000) {
00071         Serial.print("number: ");
00072         word fileNumber = g_audio.getFileNumber();
00073         if (fileNumber > 0) Serial.print(fileNumber); else Serial.print("--");
00074
00075         Serial.print(" name: ");
00076         if (g_audio.getFileName(name)) Serial.print(name);
00077
00078         Serial.print(" status: ");
00079         switch (g_audio.getStatus()) {
00080             case DFR0534::STOPPED:
00081                 Serial.println("Stopped");
00082                 break;
00083             case DFR0534::PAUSED:
00084                 Serial.println("Paused");
00085                 break;
00086             case DFR0534::PLAYING:
00087                 Serial.println("Playing");
00088                 break;
00089             case DFR0534::STATUSUNKNOWN:
00090                 Serial.println("Unknown");
00091                 break;
00092         }
00093         lastDisplayMS = millis();
00094     }
00095 }

```

## 5.4 DFR0534.cpp File Reference

#include "DFR0534.h"

Include dependency graph for DFR0534.cpp:



### 5.4.1 Detailed Description

Class: [DFR0534](#)

Description: Class for controlling a [DFR0534](#) audio module ( [https://wiki.dfrobot.com/Voice\\_Module\\_SKU\\_\\_DFR0534](https://wiki.dfrobot.com/Voice_Module_SKU__DFR0534)) by SoftwareSerial or HardwareSerial

License: 2-Clause BSD License Copyright (c) 2024 codingABI For details see: LICENSE.txt

Notes for [DFR0534](#) audio module:

- Consumes about 20mA when idle (Vcc = 5V)
- Creates a short "click" noise, when Vcc is powered on
- Should be used with a 1k resistor on TX when your MCU runs on 5V, because the [DFR0534](#) uses 3.3V logic (and 5V on TX causes clicks/noise)
- Can be controlled by a RX/TX serial connection (9600 baud) or one-wire protocol
- Can play WAV and MP3 audiofiles
- Can "insert" audiofiles while another audiofile is running. In this case to original audiofile is paused and will be resumed after the "inserted" audiofile
- Can play files in a playlist like mode called "combined" for files stored in a directory /ZH
- Can select the file to play by a file number\* or file name\*\* \*File number is independent from file name. The first WAV or MP3 copied to the [DFR0534](#) gets file number 1 and so on. To play a file by number use `playFileByNumber()` \*\*File name is a little bit like a 8+3 file path and can be used with `playFileByName()`, but have special rules (see `playFileByName()` for details)
- Can send automatically the file runtime every second (when enabled)
- Has a NS8002 amplifier, JQ8400 Audio chip, W25Q64JVS1Q flash memory
- Has a Sleep mode 0x1B and this mode only works with one-wire protocol ( [https://github.com/arduino12/mp3\\_player\\_module\\_wire](https://github.com/arduino12/mp3_player_module_wire)) and does not work for me without additional electric modifications (e.g. disconnecting speakers) => Switching off [DFR0534](#) with a FET is a better solution

Home: <https://github.com/codingABI/DFR0534>

#### Author

codingABI <https://github.com/codingABI/>

#### Copyright

2-Clause BSD License

#### Version

1.0.4

Definition in file [DFR0534.cpp](#).

## 5.5 DFR0534.cpp

[Go to the documentation of this file.](#)

```

00001
00043 #include "DFR0534.h"
00044
00053 byte DFR0534::getStatus()
00054 {
00055     #define COMMAND 0x01
00056     #define RECEIVEBYTETIMEOUTMS 100
00057     #define RECEIVEGLOBALTIMEOUTMS 500
00058     #define RECEIVEFAILED STATUSUNKNOWN
00059     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00060
00061     if (m_ptrStream == NULL) return RECEIVEFAILED; // Should not happen
00062     sendStartingCode();
00063     sendDataByte(COMMAND);
00064     sendDataByte(0x00);
00065     sendChecksum();
00066
00067     // Receive
00068     int i=0;
00069     byte data, firstByte = 0, sum, length=0xff, result = 0;
00070     unsigned long receiveStartMS = millis();
00071     do {
00072         byte dataReady = 0;
00073         unsigned long lastMS = millis();
00074         // Wait for response or timeout
00075         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00076
00077         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00078         data = m_ptrStream->read();
00079
00080         if (i==0) { // Begin of transmission
00081             firstByte=data;
00082             sum = 0;
00083         }
00084         if ((i == 1) && (data != COMMAND)) {
00085             // Invalid signal => reset receive
00086             i=0;
00087             firstByte = 0;
00088         }
00089         if (i == RECEIVEHEADERLENGTH) {
00090             length = data; // Length of receiving data
00091             if (length != 1) {
00092                 // Invalid length => reset receive
00093                 i=0;
00094                 firstByte = 0;
00095             }
00096         }
00097         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00098             result = data;
00099         }
00100         if (firstByte == STARTINGCODE) {
00101             if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00102             i++;
00103         }
00104         if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00105     } while (i<length+RECEIVEHEADERLENGTH+2);
00106
00107     if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00108     return result;
00109 }
00110
00116 void DFR0534::setEqualizer(byte mode)
00117 {
00118     if (m_ptrStream == NULL) return; // Should not happen
00119     if (mode >= EQUNKNOWN) return;
00120     sendStartingCode();
00121     sendDataByte(0x1A);
00122     sendDataByte(0x01);
00123     sendDataByte(mode);
00124     sendChecksum();
00125 }
00126
00135 void DFR0534::playFileByNumber(word track)
00136 {
00137     if (m_ptrStream == NULL) return; // Should not happen
00138     if (track <=0) return;
00139     sendStartingCode();
00140     sendDataByte(0x07);
00141     sendDataByte(0x02);
00142     sendDataByte((track » 8) & 0xff);
00143     sendDataByte(track & 0xff);

```

```

00144     sendChecksum();
00145 }
00146
00154 void DFR0534::setVolume(byte volume)
00155 {
00156     if (m_ptrStream == NULL) return; // Should not happen
00157     if (volume > 30) volume = 30;
00158     sendStartingCode();
00159     sendDataByte(0x13);
00160     sendDataByte(0x01);
00161     sendDataByte(volume);
00162     sendChecksum();
00163 }
00164
00168 void DFR0534::play()
00169 {
00170     if (m_ptrStream == NULL) return; // Should not happen
00171     sendStartingCode();
00172     sendDataByte(0x02);
00173     sendDataByte(0x00);
00174     sendChecksum();
00175 }
00176
00180 void DFR0534::pause()
00181 {
00182     if (m_ptrStream == NULL) return; // Should not happen
00183     sendStartingCode();
00184     sendDataByte(0x03);
00185     sendDataByte(0x00);
00186     sendChecksum();
00187 }
00188
00192 void DFR0534::stop()
00193 {
00194     if (m_ptrStream == NULL) return; // Should not happen
00195     sendStartingCode();
00196     sendDataByte(0x04);
00197     sendDataByte(0x00);
00198     sendChecksum();
00199 }
00200
00204 void DFR0534::playPrevious()
00205 {
00206     if (m_ptrStream == NULL) return; // Should not happen
00207     sendStartingCode();
00208     sendDataByte(0x05);
00209     sendDataByte(0x00);
00210     sendChecksum();
00211 }
00212
00216 void DFR0534::playNext()
00217 {
00218     if (m_ptrStream == NULL) return; // Should not happen
00219     sendStartingCode();
00220     sendDataByte(0x06);
00221     sendDataByte(0x00);
00222     sendChecksum();
00223 }
00224
00251 void DFR0534::playFileByName(char *path, byte drive)
00252 {
00253     if (m_ptrStream == NULL) return; // Should not happen
00254     if (path == NULL) return;
00255     if (drive >= DRIVEUNKNOWN) return;
00256     sendStartingCode();
00257     sendDataByte(0x08);
00258     sendDataByte(strlen(path)+1);
00259     sendDataByte(drive);
00260     for (int i=0; i<strlen(path); i++) {
00261         sendDataByte(path[i]);
00262     }
00263     sendChecksum();
00264 }
00265
00277 byte DFR0534::getDrivesStates()
00278 {
00279     #define COMMAND 0x09
00280     #define RECEIVEBYTETIMEOUTMS 100
00281     #define RECEIVEGLOBALTIMEOUTMS 500
00282     #define RECEIVEFAILED DRIVEUNKNOWN
00283     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00284
00285     if (m_ptrStream == NULL) return RECEIVEFAILED; // Should not happen
00286     sendStartingCode();
00287     sendDataByte(COMMAND);
00288     sendDataByte(0x00);
00289     sendChecksum();

```

```

00290
00291 // Receive
00292 int i=0;
00293 byte data, firstByte = 0, sum, length=0xff, result = 0;
00294 unsigned long receiveStartMS = millis();
00295 do {
00296     byte dataReady = 0;
00297     unsigned long lastMS = millis();
00298     // Wait for response or timeout
00299     while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00300
00301     if (dataReady == 0) return RECEIVEFAILED; // Timeout
00302     data = m_ptrStream->read();
00303
00304     if (i==0) { // Begin of transmission
00305         firstByte=data;
00306         sum = 0;
00307     }
00308     if ((i == 1) && (data != COMMAND)) {
00309         // Invalid signal => reset receive
00310         i=0;
00311         firstByte = 0;
00312     }
00313     if (i == RECEIVEHEADERLENGTH) {
00314         length = data; // Length of receiving data
00315         if (length != 1) {
00316             // Invalid length => reset receive
00317             i=0;
00318             firstByte = 0;
00319         }
00320     }
00321     if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00322         result = data;
00323     }
00324     if (firstByte == STARTINGCODE) {
00325         if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00326         i++;
00327     }
00328     if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00329 } while (i<length+RECEIVEHEADERLENGTH+2);
00330
00331 if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00332 return result;
00333 }
00334
00344 byte DFR0534::getDrive()
00345 {
00346     #define COMMAND 0x0A
00347     #define RECEIVEBYTETIMEOUTMS 100
00348     #define RECEIVEGLOBALTIMEOUTMS 500
00349     #define RECEIVEFAILED DRIVEUNKNOWN
00350     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00351
00352     if (m_ptrStream == NULL) return RECEIVEFAILED; // Should not happen
00353     sendStartingCode();
00354     sendDataByte(COMMAND);
00355     sendDataByte(0x00);
00356     sendChecksum();
00357
00358     // Receive
00359     int i=0;
00360     byte data, firstByte = 0, sum, length=0xff, result = 0;
00361     unsigned long receiveStartMS = millis();
00362     do {
00363         byte dataReady = 0;
00364         unsigned long lastMS = millis();
00365         // Wait for response or timeout
00366         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00367
00368         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00369         data = m_ptrStream->read();
00370
00371         if (i==0) { // Begin of transmission
00372             firstByte=data;
00373             sum = 0;
00374         }
00375         if ((i == 1) && (data != COMMAND)) {
00376             // Invalid signal => reset receive
00377             i=0;
00378             firstByte = 0;
00379         }
00380         if (i == RECEIVEHEADERLENGTH) {
00381             length = data; // Length of receiving data
00382             if (length != 1) {
00383                 // Invalid length => reset receive

```

```

00384         i=0;
00385         firstByte = 0;
00386     }
00387 }
00388 if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00389     result = data;
00390 }
00391 if (firstByte == STARTINGCODE) {
00392     if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00393     i++;
00394 }
00395 if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00396 } while (i<length+RECEIVEHEADERLENGTH+2);
00397
00398 if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00399 return result;
00400 }
00401
00402 void DFR0534::setDrive(byte drive)
00403 {
00404     if (m_ptrStream == NULL) return; // Should not happen
00405     if (drive >= DRIVEUNKNOWN) return;
00406     sendStartingCode();
00407     sendDataByte(0x0B);
00408     sendDataByte(0x01);
00409     sendDataByte(drive);
00410     sendChecksum();
00411 }
00412
00413 word DFR0534::getFileNumber()
00414 {
00415     #define COMMAND 0x0D
00416     #define RECEIVEFAILED 0
00417     #define RECEIVEBYTETIMEOUTMS 100
00418     #define RECEIVEGLOBALTIMEOUTMS 500
00419     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00420
00421     if (m_ptrStream == NULL) return RECEIVEFAILED; // Should not happen
00422     sendStartingCode();
00423     sendDataByte(COMMAND);
00424     sendDataByte(0x00);
00425     sendChecksum();
00426
00427     // Receive
00428     int i=0;
00429     byte data, firstByte = 0, sum, length=0xff;
00430     word result = 0;
00431     unsigned long receiveStartMS = millis();
00432     do {
00433         byte dataReady = 0;
00434         unsigned long lastMS = millis();
00435         // Wait for response or timeout
00436         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00437
00438         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00439         data = m_ptrStream->read();
00440
00441         if (i==0) { // Begin of transmission
00442             firstByte=data;
00443             sum = 0;
00444         }
00445         if ((i == 1) && (data != COMMAND)) {
00446             // Invalid signal => reset receive
00447             i=0;
00448             firstByte = 0;
00449         }
00450         if (i == RECEIVEHEADERLENGTH) {
00451             length = data; // Length of receiving data
00452             if (length != 2) {
00453                 // Invalid length => reset receive
00454                 i=0;
00455                 firstByte = 0;
00456             }
00457         }
00458         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00459             switch (i-RECEIVEHEADERLENGTH-1) {
00460                 case 0:
00461                     result=data<<8;
00462                     break;
00463                 case 1:
00464                     result+=data;
00465                     break;
00466             }
00467         }
00468         if (firstByte == STARTINGCODE) {
00469             if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum

```

```

00483         i++;
00484     }
00485     if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00486 } while (i<length+RECEIVEHEADERLENGTH+2);
00487
00488 if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00489 return result;
00490 }
00491
00492 int DFR0534::getTotalFiles()
00493 {
00494     #define COMMAND 0x0C
00495     #define RECEIVEFAILED -1
00496     #define RECEIVEBYTETIMEOUTMS 100
00497     #define RECEIVEGLOBALTIMEOUTMS 500
00498     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00499
00500     if (m_ptrStream == NULL) return RECEIVEFAILED; // Should not happen
00501     sendStartingCode();
00502     sendDataByte(COMMAND);
00503     sendDataByte(0x00);
00504     sendChecksum();
00505
00506     // Receive
00507     int i=0;
00508     byte data, firstByte = 0, sum, length=0xff;
00509     word result = 0;
00510     unsigned long receiveStartMS = millis();
00511     do {
00512         byte dataReady = 0;
00513         unsigned long lastMS = millis();
00514         // Wait for response or timeout
00515         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
00516             m_ptrStream->available();
00517
00518         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00519         data = m_ptrStream->read();
00520
00521         if (i==0) { // Begin of transmission
00522             firstByte=data;
00523             sum = 0;
00524         }
00525         if ((i == 1) && (data != COMMAND)) {
00526             // Invalid signal => reset receive
00527             i=0;
00528             firstByte = 0;
00529         }
00530         if (i == RECEIVEHEADERLENGTH) {
00531             length = data; // Length of receiving data
00532             if (length != 2) {
00533                 // Invalid length => reset receive
00534                 i=0;
00535                 firstByte = 0;
00536             }
00537         }
00538         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00539             switch (i-RECEIVEHEADERLENGTH-1) {
00540                 case 0:
00541                     result=data<<8;
00542                     break;
00543                 case 1:
00544                     result+=data;
00545                     break;
00546             }
00547         }
00548         if (firstByte == STARTINGCODE) {
00549             if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00550             i++;
00551         }
00552         if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00553     } while (i<length+RECEIVEHEADERLENGTH+2);
00554
00555     if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00556     return result;
00557 }
00558
00559 void DFR0534::playLastInDirectory()
00560 {
00561     if (m_ptrStream == NULL) return; // Should not happen
00562     sendStartingCode();
00563     sendDataByte(0x0E);
00564     sendDataByte(0x00);
00565     sendChecksum();
00566 }
00567
00568 void DFR0534::playNextDirectory()
00569 {

```



```

00581     if (m_ptrStream == NULL) return; // Should not happen
00582     sendStartingCode();
00583     sendDataByte(0x0F);
00584     sendDataByte(0x00);
00585     sendChecksum();
00586 }
00587
00594 int DFR0534::getFirstFileNumberInCurrentDirectory()
00595 {
00596     #define COMMAND 0x11
00597     #define RECEIVEFAILED -1
00598     #define RECEIVEBYTETIMEOUTMS 100
00599     #define RECEIVEGLOBALTIMEOUTMS 500
00600     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00601
00602     if (m_ptrStream == NULL) RECEIVEFAILED; // Should not happen
00603     sendStartingCode();
00604     sendDataByte(COMMAND);
00605     sendDataByte(0x00);
00606     sendChecksum();
00607
00608     // Receive
00609     int i=0;
00610     byte data, firstByte = 0, sum, length=0xff;
00611     word result = 0;
00612     unsigned long receiveStartMS = millis();
00613     do {
00614         byte dataReady = 0;
00615         unsigned long lastMS = millis();
00616         // Wait for response or timeout
00617         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00618
00619         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00620         data = m_ptrStream->read();
00621
00622         if (i==0) { // Begin of transmission
00623             firstByte=data;
00624             sum = 0;
00625         }
00626         if ((i == 1) && (data != COMMAND)) {
00627             // Invalid signal => reset receive
00628             i=0;
00629             firstByte = 0;
00630         }
00631         if (i == RECEIVEHEADERLENGTH) {
00632             length = data; // Length of receiving data
00633             if (length != 2) {
00634                 // Invalid length => reset receive
00635                 i=0;
00636                 firstByte = 0;
00637             }
00638         }
00639         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00640             switch (i-RECEIVEHEADERLENGTH-1) {
00641                 case 0:
00642                     result=data<<8;
00643                     break;
00644                 case 1:
00645                     result+=data;
00646                     break;
00647             }
00648         }
00649         if (firstByte == STARTINGCODE) {
00650             if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00651             i++;
00652         }
00653         if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00654     } while (i<length+RECEIVEHEADERLENGTH+2);
00655
00656     if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00657     return result;
00658 }
00659
00666 int DFR0534::getTotalFilesInCurrentDirectory()
00667 {
00668     #define COMMAND 0x12
00669     #define RECEIVEFAILED -1
00670     #define RECEIVEBYTETIMEOUTMS 100
00671     #define RECEIVEGLOBALTIMEOUTMS 500
00672     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00673
00674     if (m_ptrStream == NULL) RECEIVEFAILED; // Should not happen
00675     sendStartingCode();
00676     sendDataByte(COMMAND);
00677     sendDataByte(0x00);
00678     sendChecksum();

```

```

00679
00680 // Receive
00681 int i=0;
00682 byte data, firstByte = 0, sum, length=0xff;
00683 word result = 0;
00684 unsigned long receiveStartMS = millis();
00685 do {
00686     byte dataReady = 0;
00687     unsigned long lastMS = millis();
00688     // Wait for response or timeout
00689     while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00690
00691     if (dataReady == 0) return RECEIVEFAILED; // Timeout
00692     data = m_ptrStream->read();
00693
00694     if (i==0) { // Begin of transmission
00695         firstByte=data;
00696         sum = 0;
00697     }
00698     if ((i == 1) && (data != COMMAND)) {
00699         // Invalid signal => reset receive
00700         i=0;
00701         firstByte = 0;
00702     }
00703     if (i == RECEIVEHEADERLENGTH) {
00704         length = data; // Length of receiving data
00705         if (length != 2) {
00706             // Invalid length => reset receive
00707             i=0;
00708             firstByte = 0;
00709         }
00710     }
00711     if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00712         switch (i-RECEIVEHEADERLENGTH-1) {
00713             case 0:
00714                 result=data<<8;
00715                 break;
00716             case 1:
00717                 result+=data;
00718                 break;
00719         }
00720     }
00721     if (firstByte == STARTINGCODE) {
00722         if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00723         i++;
00724     }
00725     if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00726 } while (i<length+RECEIVEHEADERLENGTH+2);
00727
00728 if (data != sum) return RECEIVEFAILED; // Does checksum matches?
00729 return result;
00730 }
00731
00735 void DFR0534::increaseVolume()
00736 {
00737     if (m_ptrStream == NULL) return; // Should not happen
00738     sendStartingCode();
00739     sendDataByte(0x14);
00740     sendDataByte(0x00);
00741     sendChecksum();
00742 }
00743
00747 void DFR0534::decreaseVolume()
00748 {
00749     if (m_ptrStream == NULL) return; // Should not happen
00750     sendStartingCode();
00751     sendDataByte(0x15);
00752     sendDataByte(0x00);
00753     sendChecksum();
00754 }
00755
00764 void DFR0534::insertFileByNumber(word track, byte drive)
00765 {
00766     if (m_ptrStream == NULL) return; // Should not happen
00767     if (drive >= DRIVEUNKNOWN) return;
00768     sendStartingCode();
00769     sendDataByte(0x16);
00770     sendDataByte(0x03);
00771     sendDataByte(drive);
00772     sendDataByte((track >> 8) & 0xff);
00773     sendDataByte(track & 0xff);
00774     sendChecksum();
00775 }
00776
00782 void DFR0534::stopInsertedFile()
00783 {

```

```

00784     if (m_ptrStream == NULL) return; // Should not happen
00785     sendStartingCode();
00786     sendDataByte(0x10);
00787     sendDataByte(0x00);
00788     sendChecksum();
00789 }
00790
00797 void DFR0534::setDirectory(char *path, byte drive)
00798 {
00799     if (m_ptrStream == NULL) return; // Should not happen
00800     if (path == NULL) return;
00801     if (drive >= DRIVEUNKNOWN) return;
00802     sendStartingCode();
00803     sendDataByte(0x17);
00804     sendDataByte(strlen(path)+1);
00805     sendDataByte(drive);
00806     for (int i=0;i<strlen(path);i++) {
00807         sendDataByte(path[i]);
00808     }
00809     sendChecksum();
00810 }
00811
00817 void DFR0534::setLoopMode(byte mode)
00818 {
00819     if (m_ptrStream == NULL) return; // Should not happen
00820     if (mode >= PLAYMODEUNKNOWN) return;
00821     sendStartingCode();
00822     sendDataByte(0x18);
00823     sendDataByte(0x01);
00824     sendDataByte(mode);
00825     sendChecksum();
00826 }
00827
00835 void DFR0534::setRepeatLoops(word loops)
00836 {
00837     if (m_ptrStream == NULL) return; // Should not happen
00838     sendStartingCode();
00839     sendDataByte(0x19);
00840     sendDataByte(0x02);
00841     sendDataByte((loops >> 8) & 0xff);
00842     sendDataByte(loops & 0xff);
00843     sendChecksum();
00844 }
00845
00857 void DFR0534::playCombined(char* list)
00858 {
00859     if (m_ptrStream == NULL) return; // Should not happen
00860     if (list == NULL) return;
00861     if ((strlen(list) % 2) != 0) return;
00862     sendStartingCode();
00863     sendDataByte(0x1B);
00864     sendDataByte(strlen(list));
00865     for (int i=0;i<strlen(list);i++) {
00866         sendDataByte(list[i]);
00867     }
00868     sendChecksum();
00869 }
00870
00871
00875 void DFR0534::stopCombined()
00876 {
00877     if (m_ptrStream == NULL) return; // Should not happen
00878     sendStartingCode();
00879     sendDataByte(0x1C);
00880     sendDataByte(0x00);
00881     sendChecksum();
00882 }
00883
00892 void DFR0534::setChannel(byte channel)
00893 {
00894     if (m_ptrStream == NULL) return; // Should not happen
00895     if (channel >= CHANNELUNKNOWN) return;
00896     sendStartingCode();
00897     sendDataByte(0x1D);
00898     sendDataByte(0x01);
00899     sendDataByte(channel);
00900     sendChecksum();
00901 }
00902
00912 bool DFR0534::getFileName(char *name)
00913 {
00914     #define COMMAND 0x1E
00915     #define RECEIVEBYTETIMEOUTMS 100
00916     #define RECEIVEGLOBALTIMEOUTMS 500
00917     #define RECEIVEFAILED false
00918     #define RECEIVEHEADERLENGTH 2 // startingcode+command
00919

```

```

00920     if (m_ptrStream == NULL) return false; // Should not happen
00921     if (name == NULL) return false;
00922     name[0] = '\0';
00923
00924     sendStartingCode();
00925     sendDataByte(COMMAND);
00926     sendDataByte(0x00);
00927     sendChecksum();
00928
00929     // Receive
00930     int i=0;
00931     byte data, firstByte = 0, sum, length=0xff;
00932     unsigned long receiveStartMS = millis();
00933     do {
00934         byte dataReady = 0;
00935         unsigned long lastMS = millis();
00936         // Wait for response or timeout
00937         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
00938
00939         if (dataReady == 0) return RECEIVEFAILED; // Timeout
00940         data = m_ptrStream->read();
00941         if (i==0) { // Begin of transmission
00942             firstByte=data;
00943             sum = 0;
00944         }
00945         if ((i == 1) && (data != COMMAND)) {
00946             // Invalid signal => reset receive
00947             i=0;
00948             firstByte = 0;
00949         }
00950         if (i == RECEIVEHEADERLENGTH) length = data; // Length of receiving string
00951         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
00952             if ((i-RECEIVEHEADERLENGTH) < 12) { // I expect no longer file names than 8+3 chars plus '\0'
00953                 name[i-RECEIVEHEADERLENGTH-1] = data;
00954                 name[i-RECEIVEHEADERLENGTH] = '\0';
00955             }
00956         }
00957         if (firstByte == STARTINGCODE) {
00958             if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
00959             i++;
00960         }
00961         if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
00962     } while (i<length+RECEIVEHEADERLENGTH+2);
00963     return (data == sum); // Does checksum matches?
00964 }
00965
00971 void DFR0534::prepareFileByNumber(word track)
00972 {
00973     if (m_ptrStream == NULL) return; // Should not happen
00974     sendStartingCode();
00975     sendDataByte(0x1F);
00976     sendDataByte(0x02);
00977     sendDataByte((track » 8) & 0xff);
00978     sendDataByte(track & 0xff);
00979     sendChecksum();
00980 }
00981
00992 void DFR0534::repeatPart(byte startMinute, byte startSecond, byte stopMinute, byte stopSecond )
00993 {
00994     if (m_ptrStream == NULL) return; // Should not happen
00995     sendStartingCode();
00996     sendDataByte(0x20);
00997     sendDataByte(0x04);
00998     sendDataByte(startMinute);
00999     sendDataByte(startSecond);
01000     sendDataByte(stopMinute);
01001     sendDataByte(stopSecond);
01002     sendChecksum();
01003 }
01004
01008 void DFR0534::stopRepeatPart()
01009 {
01010     if (m_ptrStream == NULL) return; // Should not happen
01011     sendStartingCode();
01012     sendDataByte(0x21);
01013     sendDataByte(0x00);
01014     sendChecksum();
01015 }
01016
01023 void DFR0534::fastBackwardDuration(word seconds)
01024 {
01025     if (m_ptrStream == NULL) return; // Should not happen
01026     sendStartingCode();
01027     sendDataByte(0x22);
01028     sendDataByte(0x02);
01029     sendDataByte((seconds » 8) & 0xff);

```

```

01030     sendDataByte(seconds & 0xff);
01031     sendChecksum();
01032 }
01033
01040 void DFR0534::fastForwardDuration(word seconds)
01041 {
01042     if (m_ptrStream == NULL) return; // Should not happen
01043     sendStartingCode();
01044     sendDataByte(0x23);
01045     sendDataByte(0x02);
01046     sendDataByte((seconds » 8) & 0xff);
01047     sendDataByte(seconds & 0xff);
01048     sendChecksum();
01049 }
01050
01063 bool DFR0534::getDuration(byte &hour, byte &minute, byte &second)
01064 {
01065     #define COMMAND 0x24
01066     #define RECEIVEFAILED false
01067     #define RECEIVEBYTETIMEOUTMS 100
01068     #define RECEIVEGLOBALTIMEOUTMS 500
01069     #define RECEIVEHEADERLENGTH 2 // startingcode+command
01070
01071     if (m_ptrStream == NULL) return false; // Should not happen
01072     sendStartingCode();
01073     sendDataByte(COMMAND);
01074     sendDataByte(0x00);
01075     sendChecksum();
01076
01077     // Receive
01078     int i=0;
01079     byte data, firstByte = 0, sum, length=0xff;
01080     word result = 0;
01081     unsigned long receiveStartMS = millis();
01082     do {
01083         byte dataReady = 0;
01084         unsigned long lastMS = millis();
01085         // Wait for response or timeout
01086         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
01087
01088         if (dataReady == 0) return RECEIVEFAILED; // Timeout
01089         data = m_ptrStream->read();
01090
01091         if (i==0) { // Begin of transmission
01092             firstByte=data;
01093             sum = 0;
01094         }
01095         if ((i == 1) && (data != COMMAND)) {
01096             // Invalid signal => reset receive
01097             i=0;
01098             firstByte = 0;
01099         }
01100         if (i == RECEIVEHEADERLENGTH) {
01101             length = data; // Length of receiving data
01102             if (length != 3) {
01103                 // Invalid length => reset receive
01104                 i=0;
01105                 firstByte = 0;
01106             }
01107         }
01108         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
01109             switch (i-RECEIVEHEADERLENGTH-1) {
01110                 case 0:
01111                     hour=data;
01112                     break;
01113                 case 1:
01114                     minute=data;
01115                     break;
01116                 case 2:
01117                     second=data;
01118                     break;
01119             }
01120         }
01121         if (firstByte == STARTINGCODE) {
01122             if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
01123             i++;
01124         }
01125         if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
01126     } while (i<length+RECEIVEHEADERLENGTH+2);
01127
01128     return (data == sum); // Does checksum matches?
01129 }
01130
01134 void DFR0534::startSendingRuntime()
01135 {
01136     if (m_ptrStream == NULL) return; // Should not happen

```

```

01137     sendStartingCode();
01138     sendDataByte(0x25);
01139     sendDataByte(0x00);
01140     sendChecksum();
01141 }
01142
01156 bool DFR0534::getRuntime(byte &hour, byte &minute, byte &second)
01157 {
01158     #define COMMAND 0x25
01159     #define RECEIVEFAILED false
01160     #define RECEIVEBYTETIMEOUTMS 100
01161     #define RECEIVEGLOBALTIMEOUTMS 500
01162     #define RECEIVEHEADERLENGTH 2 // startingcode+command
01163
01164     if (m_ptrStream == NULL) return false; // Should not happen
01165
01166     // Receive
01167     int i=0;
01168     byte data, firstByte = 0, sum, length=0xff;
01169     word result = 0;
01170     unsigned long receiveStartMS = millis();
01171     do {
01172         byte dataReady = 0;
01173         unsigned long lastMS = millis();
01174         // Wait for response or timeout
01175         while ((millis()-lastMS < RECEIVEBYTETIMEOUTMS) && (dataReady==0)) dataReady =
m_ptrStream->available();
01176
01177         if (dataReady == 0) return RECEIVEFAILED; // Timeout
01178         data = m_ptrStream->read();
01179
01180         if (i==0) { // Begin of transmission
01181             firstByte=data;
01182             sum = 0;
01183         }
01184         if ((i == 1) && (data != COMMAND)) {
01185             // Invalid signal => reset receive
01186             i=0;
01187             firstByte = 0;
01188         }
01189         if (i == RECEIVEHEADERLENGTH) {
01190             length = data; // Length of receiving data
01191             if (length != 3) {
01192                 // Invalid length => reset receive
01193                 i=0;
01194                 firstByte = 0;
01195             }
01196         }
01197         if ((i > RECEIVEHEADERLENGTH) && (i-RECEIVEHEADERLENGTH-1<length)) {
01198             switch (i-RECEIVEHEADERLENGTH-1) {
01199                 case 0:
01200                     hour=data;
01201                     break;
01202                 case 1:
01203                     minute=data;
01204                     break;
01205                 case 2:
01206                     second=data;
01207                     break;
01208             }
01209         }
01210         if (firstByte == STARTINGCODE) {
01211             if (i-RECEIVEHEADERLENGTH<=length) sum+=data; // Update checksum
01212             i++;
01213         }
01214         if (millis()-receiveStartMS > RECEIVEGLOBALTIMEOUTMS) return RECEIVEFAILED; // Timeout
01215     } while (i<length+RECEIVEHEADERLENGTH+2);
01216
01217     return (data == sum); // Does checksum matches?
01218 }
01219
01223 void DFR0534::stopSendingRuntime()
01224 {
01225     if (m_ptrStream == NULL) return; // Should not happen
01226     sendStartingCode();
01227     sendDataByte(0x26);
01228     sendDataByte(0x00);
01229     sendChecksum();
01230 }


```

## 5.6 DFR0534.h File Reference


```
#include <Arduino.h>
```

```
#include <Stream.h>
```

Include dependency graph for DFR0534.h:



This graph shows which files directly or indirectly include this file:



### Classes

- class [DFR0534](#)  
*Class for a [DFR0534](#) audio module.*

### Macros

- `#define DFR0534\_VERSION "1.0.4"`

### 5.6.1 Detailed Description

Class: [DFR0534](#)

Description: Class for controlling a [DFR0534](#) audio module ( [https://wiki.dfrobot.com/Voice\\_Module\\_SKU\\_\\_DFR0534](https://wiki.dfrobot.com/Voice_Module_SKU__DFR0534)) by SoftwareSerial or HardwareSerial

License: 2-Clause BSD License Copyright (c) 2024 codingABI For details see: LICENSE.txt

Home: <https://github.com/codingABI/DFR0534>

**Author**

codingABI <https://github.com/codingABI/>

**Copyright**

2-Clause BSD License

**Version**

1.0.4

Definition in file [DFR0534.h](#).

## 5.6.2 Macro Definition Documentation

### 5.6.2.1 DFR0534\_VERSION

```
#define DFR0534_VERSION "1.0.4"
```

Library version

Definition at line 22 of file [DFR0534.h](#).

## 5.7 DFR0534.h

[Go to the documentation of this file.](#)

```
00001
00019 #pragma once
00020
00022 #define DFR0534_VERSION "1.0.4"
00023
00024 #include <Arduino.h>
00025 #include <Stream.h>
00026
00027 #define STARTINGCODE 0xAA
00028
00032 class DFR0534 {
00033 public:
00035     enum DFR0534CHANNELS
00036     {
00037         CHANNELMP3,
00038         CHANNELAUX,
00039         CHANNELMP3AUX,
00040         CHANNELUNKNOWN
00041     };
00043     enum DFR0534DRIVE
00044     {
00045         DRIVEUSB,
00046         DRIVESD,
00047         DRIVEFLASH,
00048         DRIVEUNKNOWN,
00049         DRIVENO = 0xFF
00050     };
00052     enum DFR0534LOOPMODE
00053     {
00054         LOOPBACKALL,
00055         SINGLEAUDIOLOOP,
00056         SINGLEAUDIOSTOP,
00057         PLAYRANDOM,
00058         DIRECTORYLOOP,
00059         RANDOMINDIRECTORY,
00060         SEQUENTIALINDIRECTORY,
00061         SEQUENTIAL,
```



```

00062     PLAYMODEUNKNOWN
00063 };
00065 enum DFR0534EQ
00066 {
00067     NORMAL,
00068     POP,
00069     ROCK,
00070     JAZZ ,
00071     CLASSIC,
00072     EQUNKNOWN
00073 };
00075 enum DFR0534STATUS
00076 {
00077     STOPPED,
00078     PLAYING,
00079     PAUSED,
00080     STATUSUNKNOWN
00081 };
00087 DFR0534(Stream &stream)
00088 {
00089     m_ptrStream = &stream;
00090 }
00091 void decreaseVolume();
00092 void fastBackwardDuration(word seconds);
00093 void fastForwardDuration(word seconds);
00094 byte getDrive();
00095 byte getDrivesStates();
00096 bool getDuration(byte &hour, byte &minute, byte &second);
00097 bool getFileName(char *name);
00098 word getFileNameNumber();
00099 int getFirstFileNameNumberInCurrentDirectory();
00100 bool getRuntime(byte &hour, byte &minute, byte &second);
00101 byte getStatus();
00102 int getTotalFiles();
00103 int getTotalFilesInCurrentDirectory();
00104 void increaseVolume();
00105 void insertFileByNumber(word track, byte drive=DRIVEFLASH);
00106 void pause();
00107 void play();
00108 void playCombined(char* list);
00109 void playFileByName(char *path, byte drive=DRIVEFLASH);
00110 void playFileByNumber(word track);
00111 void playLastInDirectory();
00112 void playNext();
00113 void playNextDirectory();
00114 void playPrevious();
00115 void prepareFileByNumber(word track);
00116 void repeatPart(byte startMinute, byte startSecond, byte stopMinute, byte stopSecond);
00117 void setChannel(byte channel);
00118 void setDirectory(char *path, byte drive=DRIVEFLASH);
00119 void setDrive(byte drive);
00120 void setEqualizer(byte mode);
00121 void setLoopMode(byte mode);
00122 void setRepeatLoops(word loops);
00123 void setVolume(byte volume);
00124 void stop();
00125 void stopInsertedFile();
00126 void startSendingRuntime();
00127 void stopCombined();
00128 void stopRepeatPart();
00129 void stopSendingRuntime();
00130 private:
00131 void sendStartingCode() {
00132     m_checksum=STARTINGCODE;
00133     m_ptrStream->write((byte) STARTINGCODE);
00134 }
00135 void sendDataByte(byte data) {
00136     m_checksum +=data;
00137     m_ptrStream->write((byte) data);
00138 }
00139 void sendCheckSum() {
00140     m_ptrStream->write((byte)m_checksum);
00141 }
00142 byte m_checksum;
00143 Stream *m_ptrStream = NULL;
00144 };

```



# Index

CHANNELAUX  
    DFR0534, [11](#)  
CHANNELMP3  
    DFR0534, [11](#)  
CHANNELMP3AUX  
    DFR0534, [11](#)  
CHANNELUNKNOWN  
    DFR0534, [11](#)  
  
decreaseVolume  
    DFR0534, [14](#)  
DFR0534, [1](#), [9](#)  
    CHANNELAUX, [11](#)  
    CHANNELMP3, [11](#)  
    CHANNELMP3AUX, [11](#)  
    CHANNELUNKNOWN, [11](#)  
    decreaseVolume, [14](#)  
    DFR0534, [13](#)  
    DFR0534CHANNELS, [11](#)  
    DFR0534DRIVE, [11](#)  
    DFR0534EQ, [12](#)  
    DFR0534LOOPMODE, [12](#)  
    DFR0534STATUS, [13](#)  
    DIRECTORYLOOP, [12](#)  
    DRIVEFLASH, [12](#)  
    DRIVENO, [12](#)  
    DRIVESD, [12](#)  
    DRIVEUNKNOWN, [12](#)  
    DRIVEUSB, [12](#)  
    fastBackwardDuration, [14](#)  
    fastForwardDuration, [14](#)  
    getDrive, [14](#)  
    getDrivesStates, [15](#)  
    getDuration, [16](#)  
    getFileName, [18](#)  
    getFileName, [19](#)  
    getFirstFileNameInCurrentDirectory, [20](#)  
    getRuntime, [21](#)  
    getStatus, [22](#)  
    getTotalFiles, [23](#)  
    getTotalFilesInCurrentDirectory, [24](#)  
    increaseVolume, [25](#)  
    insertFileByNumber, [25](#)  
    LOOPBACKALL, [12](#)  
    NORMAL, [12](#)  
    pause, [26](#)  
    PAUSED, [13](#)  
    play, [26](#)  
    playCombined, [26](#)  
    playFileByName, [27](#)  
    playFileByNumber, [28](#)  
    PLAYING, [13](#)  
    playLastInDirectory, [28](#)  
    PLAYMODEUNKNOWN, [12](#)  
    playNext, [28](#)  
    playNextDirectory, [29](#)  
    playPrevious, [29](#)  
    PLAYRANDOM, [12](#)  
    prepareFileByNumber, [29](#)  
    RANDOMINDIRECTORY, [12](#)  
    repeatPart, [29](#)  
    SEQUENTIAL, [12](#)  
    SEQUENTIALINDIRECTORY, [12](#)  
    setChannel, [30](#)  
    setDirectory, [30](#)  
    setDrive, [31](#)  
    setEqualizer, [31](#)  
    setLoopMode, [31](#)  
    setRepeatLoops, [32](#)  
    setVolume, [32](#)  
    SINGLEAUDIOLOOP, [12](#)  
    SINGLEAUDIOSTOP, [12](#)  
    startSendingRuntime, [33](#)  
    STATUSUNKNOWN, [13](#)  
    stop, [33](#)  
    stopCombined, [33](#)  
    stopInsertedFile, [33](#)  
    STOPPED, [13](#)  
    stopRepeatPart, [34](#)  
    stopSendingRuntime, [34](#)  
DFR0534.cpp, [38](#), [40](#)  
DFR0534.h, [51](#), [52](#)  
    DFR0534\_VERSION, [52](#)  
DFR0534\_VERSION  
    DFR0534.h, [52](#)  
DFR0534CHANNELS  
    DFR0534, [11](#)  
DFR0534DRIVE  
    DFR0534, [11](#)  
DFR0534EQ  
    DFR0534, [12](#)  
DFR0534LOOPMODE  
    DFR0534, [12](#)  
DFR0534STATUS  
    DFR0534, [13](#)  
DIRECTORYLOOP  
    DFR0534, [12](#)  
DRIVEFLASH  
    DFR0534, [12](#)

DRIVENO  
     DFR0534, [12](#)  
 DRIVESD  
     DFR0534, [12](#)  
 DRIVEUNKNOWN  
     DFR0534, [12](#)  
 DRIVEUSB  
     DFR0534, [12](#)  
  
 fastBackwardDuration  
     DFR0534, [14](#)  
 fastForwardDuration  
     DFR0534, [14](#)  
  
 getDrive  
     DFR0534, [14](#)  
 getDrivesStates  
     DFR0534, [15](#)  
 getDuration  
     DFR0534, [16](#)  
 getFileName  
     DFR0534, [18](#)  
 getFileNumber  
     DFR0534, [19](#)  
 getFirstFileNumberInCurrentDirectory  
     DFR0534, [20](#)  
 getRuntime  
     DFR0534, [21](#)  
 getStatus  
     DFR0534, [22](#)  
 getTotalFiles  
     DFR0534, [23](#)  
 getTotalFilesInCurrentDirectory  
     DFR0534, [24](#)  
  
 increaseVolume  
     DFR0534, [25](#)  
 insertFileByNumber  
     DFR0534, [25](#)  
  
 LOOPBACKALL  
     DFR0534, [12](#)  
  
 NORMAL  
     DFR0534, [12](#)  
  
 pause  
     DFR0534, [26](#)  
 PAUSED  
     DFR0534, [13](#)  
 play  
     DFR0534, [26](#)  
 playCombined  
     DFR0534, [26](#)  
 playCombined.ino, [35](#)  
 playFileByName  
     DFR0534, [27](#)  
 playFileByName.ino, [36](#)  
 playFileByNumber  
     DFR0534, [28](#)  
  
 playFileByNumber.ino, [37](#)  
 PLAYING  
     DFR0534, [13](#)  
 playLastInDirectory  
     DFR0534, [28](#)  
 PLAYMODEUNKNOWN  
     DFR0534, [12](#)  
 playNext  
     DFR0534, [28](#)  
 playNextDirectory  
     DFR0534, [29](#)  
 playPrevious  
     DFR0534, [29](#)  
 PLAYRANDOM  
     DFR0534, [12](#)  
 prepareFileByNumber  
     DFR0534, [29](#)  
  
 RANDOMINDIRECTORY  
     DFR0534, [12](#)  
 repeatPart  
     DFR0534, [29](#)  
  
 SEQUENTIAL  
     DFR0534, [12](#)  
 SEQUENTIALINDIRECTORY  
     DFR0534, [12](#)  
 setChannel  
     DFR0534, [30](#)  
 setDirectory  
     DFR0534, [30](#)  
 setDrive  
     DFR0534, [31](#)  
 setEqualizer  
     DFR0534, [31](#)  
 setLoopMode  
     DFR0534, [31](#)  
 setRepeatLoops  
     DFR0534, [32](#)  
 setVolume  
     DFR0534, [32](#)  
 SINGLEAUDIOLOOP  
     DFR0534, [12](#)  
 SINGLEAUDIOSTOP  
     DFR0534, [12](#)  
 startSendingRuntime  
     DFR0534, [33](#)  
 STATUSUNKNOWN  
     DFR0534, [13](#)  
 stop  
     DFR0534, [33](#)  
 stopCombined  
     DFR0534, [33](#)  
 stopInsertedFile  
     DFR0534, [33](#)  
 STOPPED  
     DFR0534, [13](#)  
 stopRepeatPart  
     DFR0534, [34](#)

stopSendingRuntime  
DFR0534, [34](#)